# DCR-TRV230E/TRV235E/TRV325E/ TRV330E/TRV430E/TRV530E

# SERVICE MANUAL



Ver 1.1 2001.09

# Digital 8

Digital Handycam











Photo: DCR-TRV325E RMT-814

## AEP Model

DCR-TRV230E/TRV235E/TRV325E/ TRV330E/TRV430E/TRV530E

UK Model

DCR-TRV230E/TRV325E/TRV330E

E Model Hong Kong Model Australian Model

DCR-TRV230F/TRV330F/TRV530F

Chinese Model Tourist Model

DCR-TRV330E/TRV530E

M2000 MECHANISM

For MECHANISM ADJUSTMENT, refer to the "8mm Video MECHANICAL ADJUSTMENT MANUAL IX M2000 MECHANISM " (9-929-861-11).

#### **SPECIFICATIONS**

## Video camera recorder

#### System

Video recording system 2 rotary heads Helical scaning system Audio recording system Rotary heads, PCM system Quantization: 12 bits (Fs 32 kHz, stereo 1, stereo 2), 16 bits (Fs 48 kHz, stereo) Video signal PAL colour, CCIR standards Recommended cassette Hi8/Digital8 video cassette Recording/playback time (using 90 min. Hi8 video cassette) SP mode: 1 hour LP mode: 1 hour and 30 minuites Fastforward/rewind time (using 90 min. Hi8 video cassette) Approx. 5 min. Viewfinder Electric Viewfinder, Monochrome Image device 3 mm (1/6 type CCD) (Charge Coupled Device) Approx. 800 000 pixels (Effective: Approx. 400 000 pixels) Combined power zoom lens Filter diameter 37 mm (1 1/2 in.)

25× (Optical), 700×\* (Digital) \*800× (DCR-TRV235E/TRV430E)

2.4 - 60 mm (1/8 - 2 3/8 in.) When converted to a 35 mm still 46 - 1 150 mm (1 13/16 - 45 3/8 in.) Colour temperature Auto

Minimum illumination 6 lx (lux) (F 1.6)

0 lx (lux) (in the NightShot mode)\* \* Objects unable to be seen due to the dark can be shot with infrared lighting.

# Input/output

connectors S video input/output 4-pin mini DIN Luminance signal: 1 Vp-p, 75  $\Omega$  (ohms), unbalanced Chrominance signal: 0.3 Vp-p, 75  $\Omega$ (ohms), unbalanced Audio/Video input/output AV MINIJACK, 1 Vp-p, 75  $\Omega$ (ohms), unbalanced, sync negative 327 mV, (at output impedance more than 47 kΩ (kilohms)) Output impedance with less than 2.2 kΩ (kilohms)/Stereo minijack (ø 3.5 mm) Input impedance more than 47 k $\Omega$ (kilohms)

#### Headphone jack Stereo minijack (ø 3.5 mm)

USB jack (DCR-TRV325E/TRV330E/ TRV430E/TRV530E)

mini-B

### LANC C jack

Stereo mini-minijack (ø 2.5 mm) MIC jack

Stereo minijack (ø 3.5 mm) DV input/output

4-pin connector

#### LCD screen

Picture DCR-TRV230E/TRV235E/ TRV325E/TRV330E: 6.2 cm (2.5 type)  $50.3 \times 37.4 \text{ mm} (2 \times 1.1/2 \text{ in.})$ DCR-TRV430E: 7.5 cm (3 type)  $61.0 \times 43.8 \text{ mm} (2 1/2 \times 1 3/4 \text{ in.})$ DCR-TRV530E: 8.8 cm (3.5 type)  $72.2\times50.4$  mm (2  $7/8\times2$  in.) Total dot number DCR-TRV230E: E, HK, AUS/ TRV330E: E, HK, AUS, JE, CN: 61 600 (280  $\times$  220) DCR-TRV230E: AEP, UK/TRV235E/ TRV325E/TRV330E: AEP, UK/ TRV430E/TRV530E: 123 200 (560 × 220)

#### General

Power requirements 7.2 V (battery pack) 8.4 V (AC power adaptor) Average power consumption (when using the battery pack) During camera recording using LCD DCR-TRV230E/TRV235E/ TRV325E/TRV330E: 3.9 W DCR-TRV430E/TRV530E: 4.2 W Viewfinder 30 W Operating temperature  $0~^{\circ}\text{C}$  to  $40~^{\circ}\text{C}$  (32  $^{\circ}\text{F}$  to 104  $^{\circ}\text{F})$ Recommended charging temperature 10 °C to 30 °C (50 °F to 86 °F) Storage temperature -20 °C to +60 °C (-4 °F to +140 °F) Dimensions (Approx.)  $85 \times 102 \times 205.5 \text{ mm}$  $(3\ 3/8 \times 4\ 1/8 \times 8\ 1/8\ in.)\ (w/h/d)$ Mass (approx.) DCR-TRV230E/TRV235E: 880 g (1 lb 15 oz) DCR-TRV325E/TRV330E:

excluding the battery pack, cassette and shoulder strap

— Continued on next page —





900 g (1 lb 15 oz)

930 g (2 lb 0 oz)

DCR-TRV430E/TRV530E:

DCR-TRV230E:
1 020 g (2 lb 3 oz)
DCR-TRV235E/TRV325E/
TRV330E:
1 040 g (2 lb 4 oz)
DCR-TRV430E:
1 090 g (2 lb 6 oz)
DCR-TRV530E:
1 070 g (2 lb 5 oz)
including the supplied battery pack
(NP-FM30 or NP-FM50), 90min. Hi8
cassette, and shoulder strap
Supplied accessories
See page 2.

## **AC** power adaptor

Power requirements 100 - 240 V AC, 50/60 Hz Power consumption 23 W Output voltage DC OUT: 8.4 V, 1.5 A in the operating mode Operating temperature 0 °C to 40 °C (32 °F to 104 °F) Storage temperature -20 °C to +60 °C (-4 °F to +140 °F) Dimensions (approx.)  $125 \times 39 \times 62 \text{ mm}$  $(5 \times 1.9/16 \times 2.1/2 \text{ in.}) (w/h/d)$ excluding projecting parts Mass (approx.) 280 g (9.8 oz) excluding the mains lead

## **Battery pack**

Maximun output voltage DC 8.4 V Mean output voltage DC 7.2 V Capacity NP-FM30: 5.0 Wh (700 mAh) NP-FM50: 8.5 Wh (1 180 mAh) Operating temperatur 0 °C to 40 °C (32 °F to 104 °F) Dimensions (approx.)  $38.2\times20.5\times55.6~mm$  $(1.9/16 \times 13/16 \times 2.1/4 \text{ in.})$ (w/h/d) Mass (approx.) NP-FM30: 65 g (2.3 oz) NP-FM50: 76 g (2.7 oz) Type Lithium ion

## "Memory Stick"


# (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

Memory Flash memory 4MB: MSA-4A Operating voltage 2.7 - 3.6 V Power consumption Approx. 45 mA in the operating mode Approx.  $130 \text{ }\mu\text{A}$  in the standby mode Dimensions (approx.)  $50 \times 2.8 \times 21.5 \text{ }mm$  ( $2 \times 1/8 \times 7/8 \text{ }in.$ ) (w/h/d) Mass (approx.) 4 g (0.14 oz)

Design and specifications are subject to change without notice.

## • SUPPLIED ACCESSORIES

Make sure that the following accessories are supplied with your camcorder.



- 1 Wireless Remote Commander (1)
- 2 AC-L10A/L10B/L10C AC power adaptor (1), Mains lead (1)
- 3 NP-FM30 battery pack (1) DCR-TRV230E/TRV325E/TRV330E/TRV530E NP-FM50 battery pack (1) DCR-TRV235E/TRV430E
- 4 R6 (size AA) battery for Remote Commander (2)
- 5 A/V connecting cable (1)
- 6 Shoulder strap (1)
- 7 Lens cap (1)
- 8 USB cable (1)
  DCR-TRV325E/TRV330E/TRV430E/TRV530E
  only
- 9 "Memory Stick" (1) DCR-TRV325E/TRV330E/TRV430E/TRV530E only
- 10 CD-ROM (SPVD-004 USB Driver) (1) DCR-TRV325E/TRV330E/TRV430E/TRV530E only
- 11 21-pin adaptor (1) DCR-TRV230E: AEP, UK/TRV235E/TRV325E/ TRV330E: AEP, UK/TRV430E/ TRV530E: AEP, UK only
- 12 2-pin conversion adaptor (1) DCR-TRV330E: JE/TRV530E: JE only
- 13 2-pin conversion adaptor (1) DCR-TRV230E: E,HK/TRV330E: E, HK/ TRV530E: E, HK only

• Abbreviation

HK : Hong Kong model
AUS : Australian model
CN : Chinese model
JE : Tourist model

## SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK  $\triangle$  OR DOTTED LINE WITH MARK  $\triangle$  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer.

- Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
- 2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
- Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
- 4. Look for parts which, through functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
- 5. Check the B+ voltage to see it is at the values specified.
- 6. Flexible Circuit Board Repairing
  - Keep the temperature of the soldering iron around 270°C during repairing.
  - Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
  - Be careful not to apply force on the conductor when soldering or unsoldering.

Table for difference of function

DCR-		TRV	TRV230E	TRV235E	TRV325E	TRV	TRV330E	TRV430E	TRV530E	
Destination	uc	AEP,UK	E,HK,AUS	AEP	AEP,UK	AEP,UK	E,HK,AUS, AEP JE,CN		AEP E,HK,AUS, JE,CN	S, Remark
I one	Optical					25×				
rems	Digital	×00 <i>L</i>	×0	×008		X00X		×008	X00X	
	Type			Type SO	SO			Type SH	Type SO	
CCD	Size			2.5 inch	inch			3 inch	3.5 inch	
	Pixel	123K	61K		123K		61K		123K	
Memory stick	stick		×				0			O: with PC-082 board
VTR Rec		×	0	×	<b>\</b>		0	×	0	O: with REC button
DV IN/OUT	UT		×				0		×	O: with DV IN/OUT X: with DV OUT
Intelligen	Intelligent accessory shoe		0				O (P)	P)		O (P): Supports printer
DIGITAL	DIGITAL IN/OUT (USB)		×				0			O: with PC-082 board
Self-time	Self-timer recording		×				0			O: Select of menu
	CD-			CD-	CD-294				CD-317	CD-294: 2.5 inch LCD CD-317: 3/3.5 inch LCD
	CF-			CF-	CF-079				CF-080	CF-079: 2.5 inch LCD CF-080: 3/3.5 inch LCD
Roard	LB-			LB-	LB-068				LB-070	LB-068: 2.5 inch LCD LB-070: 3/3.5 inch LCD
	-IS			)-IS	SI-028				SI-029	SI-028: 2.5 inch LCD SI-029: 3/3.5 inch LCD
	FU-			FU-150	150				FU-154	FU-150: 2.5 inch LCD FU-154: 3/3.5 inch LCD
	PC-		××				PC-082	182		With Memory stick slot & USB connector
	PD-			PD-139	139			PD-138	PD-139	PD-138: Type SH LCD PD-139: Type SO LCD

• Abbreviation
HK : Hong Kong model
AUS : Australian model
CN : Chinese model
JE : Tourist model

## **TABLE OF CONTENTS**

SERVICE NOTE	"Memory Stick" operations
1. POWER SUPPLY DURING REPAIRS 8	(DCR-TRV325E/TRV330E/TRV430E/TRV530E only)
2. TO TAKE OUT A CASSETTE WHEN NOT EJECT	Using "Memory Stick"-introduction 1-28
(FORCE EJECT)8	Recording still images on "Memory Stick"
	- Memory Photo recording ······ 1-29
SELF-DIAGNOSIS FUNCTION	Superimposing a still image in the "Memory Stick" on an
1. Self-diagnosis Function ————9	image – MEMORY MIX ······1-30
2. Self-diagnosis Display9	Recording an image from a tape as a still image1-32
3. Service Mode Display	Copying still images from a tape – Photo save ······ 1-33
3-1. Display Method	Viewing a still image – Memory Photo playback ····· 1-33
3-2. Switching of Backup No9	Viewing images using your computer1-34
3-3. End of Display9	Copying the image recorded on "Memory Stick" to tapes
	(DCR-TRV330E only)1-35
4. Self-diagnosis Code Table ······ 10	Enlarging still images recorded on "Memory Stick"s
4 CENEDAL	- Memory PB ZOOM1-36
1. GENERAL	Playing back images in a continuous loop – SLIDE SHOW ·· 1-36
Checking supplied accessories1-1	Preventing accidental erasure – Image protection ···············1-37
Main Features1-1	Deleting images
Quick Start Guide1-1	Writing a print mark – PRINT MARK ·······1-38
Getting started	Using the printer (optional)1-39
Using this manual1-2	Troubleshooting
Step 1 Preparing the power supply1-2	Types of trouble and their solutions1-39
Installing the battery pack1-2	Self-diagnosis display ··········1-40
Charging the battery pack1-3	
Connecting to a wall socket1-4	Warning indicators and messages ······1-40
Step 2 Setting the date and time1-4	Additional Information
Step 3 Inserting a cassette1-5	Digital8 ( ) system, recording and playback ······ 1-41
Recording – Basics	About the "InfoLITHIUM" battery pack1-42
Recording a picture1-5	About i.LINK 1-42
Shooting backlit subjects – BACK LIGHT ······1-7	Using your camcorder abroad1-43
Shooting in the dark – NightShot/Super NightShot ······1-7	Maintenance information and precautions 1-43
Self-timer recording	Quick Reference
(DCR-TRV325E/TRV330E/TRV430E/TRV530E only) 1-7	Identifying the parts and controls1-44
Checking the recording – END SEARCH/EDITSEARCH/	, , ,
Rec Review1-8	2. DISASSEMBLY
	2-1. LCD UNIT, PD-139 BOARD (2.5 INCH LCD MODEL)
Playback – Basics	(TRV230E/TRV235E/TRV325E/TRV330E)2-2
Playing back a tape	2-2. LCD UNIT, PD-138/139 BOARD
Viewing the recording on TV1-10	(3/3.5 INCH LCD MODEL)(TRV430E/TRV530E)2-3
Advanced Recording Operations	
Recording a still image on a tape – Tape Photo recording ·· 1-11	2-3. FRONT PANEL SECTION, SI-028/029 BOARD2-4
Using the wide mode ·····1-12	2-4. CABINET (R) SECTION2-5
Using the fader function1-12	2-5. CF-079 BOARD (2.5 INCH LCD MODEL)
Using special effects – Picture effect ······ 1-13	(TRV230E/TRV235E/TRV325E/TRV330E)2-5
Using special effects – Digital effect ······ 1-13	2-6. CF-080 BOARD (3/3.5 INCH LCD MODEL)
Using the PROGRAM AE function1-14	(TRV430E/TRV530E)2-6
Adjusting the exposure manually1-15	2-7. EVF SECTION, LB-068/070 BOARD2-7
Focusing manually1-15	2-8. LENS SECTION, CD-294/317 BOARD2-8
Superimposing a title1-15	2-9. PC-082 BOARD (MEMORY STICK MODEL)
Making your own titles ······1-16	(TRV325E/TRV330E/TRV430E/TRV530E)2-9
Inserting a scene	2-10. BATTERY PANEL SECTION,
Advanced Playback Operations	BATTERY TERMINAL BOARD2-10
Playing back a tape with picture effects1-17	2-11. CONTROL SWITCH BLOCK (SS-1380),
Playing back a tape with digital effects1-17	FU-150/154 BOARD2-10
	2-12. CABINET (L) SECTION, MECHANISM DECK-1 ···· 2-11
Enlarging recorded images – Tape PB ZOOM ······ 1-17	2-13. VC-254 BOARD2-12
Quickly locating a scene using the zero set memory function · 1-18	2-13. VC-234 BOARD
Searching a recording by date – Date search ······ 1-18	2-14. MECHANISM DECK-2, MD TRAME2-12 2-15. HINGE SECTION2-14
Searching for a photo – Photo search/Photo scan ······ 1-19	2-13. FINUE SECTION 2-14
Editing	2-16. CIRCUIT BOARDS LOCATION2-15
Dubbing a tape ·····1-19	2-17. FLEXIBLE BOARDS LOCATION2-16
Dubbing only desired scenes – Digital program editing ····· 1-20	0 DI 001/ DIACE ****
Using with analog video unit and your computer	3. BLOCK DIAGRAMS
- Signal convert function (DCR-TRV330E only)1-23	3-1. OVERALL BLOCK DIAGRAM (1/5)3-1
Recording video or TV programmes (DCR-TRV330E only) ·· 1-24	3-2. OVERALL BLOCK DIAGRAM (2/5)3-3
Inserting a scene from a VCR	3-3. OVERALL BLOCK DIAGRAM (3/5)3-5
- Insert Editing (DCR-TRV330E only) ······1-25	2.4 OVERALL DLOCK DIACRAM (4/5)
	3-4. OVERALL BLOCK DIAGRAM (4/5)3-7
Customizing Your Camcorder	3-4. OVERALL BLOCK DIAGRAM (4/5)

3-7. 3-8.	POWER BLOCK DIAGRAM (2/3)	• LS-057 (S/T REEL SENSOR), FP-228 (DEW SENSOR) FP-299 (MODE SWITCH), FP-300 (TAPE TOP), FP-302 (TAPE END), FP-301 (TAPE LED)
4.	PRINTED WIRING BOARDS AND	FLEXIBLE BOARDS4-5
4.	SCHEMATIC DIAGRAMS	• FP-270 (S VIDEO, AUDIO/VIDEO),
4 1		FP-272 (LANC, DV IN/OUT)
4-1.	FRAME SCHEMATIC DIAGRAM (1/3)4-1 FRAME SCHEMATIC DIAGRAM (2/3)4-3	FLEXIBLE BOARDS4-5:
	FRAME SCHEMATIC DIAGRAM (2/3)4-5 FRAME SCHEMATIC DIAGRAM (3/3)4-5	• PC-082 (DIGITAL STILL CONTROL,
4-2.		DS STILL PROCESS)
4-2.	SCHEMATIC DIAGRAMS4-8	PRINTED WIRING BOARD4-5:
	• CD-294 (CCD IMAGER)	• PC-082 (DIGITAL STILL CONTROL 1)(1/3)
	PRINTED WIRING BOARD	SCHEMATIC DIAGRAM ······4-59
	(DCR-TRV230E/TRV235E/TRV330E) · 4-9	• PC-082 (DIGITAL STILL CONTROL 2)(2/3)
	• CD-317 (CCD IMAGER)	SCHEMATIC DIAGRAM ······4-6
	PRINTED WIRING BOARD	• FP-271 (USB)
	(DCR-TRV430E/TRV530E)4-9	SCHEMATIC DIAGRAM ······4-69
	• CD-294/317 (CCD IMAGER)	• PC-082 (DS STILL PROCESS)(3/3)
	SCHEMATIC DIAGRAM ······4-10	SCHEMATIC DIAGRAM ······4-6
	<ul> <li>VC-254 (CAMERA/STD8/Hi8/PB PROCESS,</li> </ul>	• FP-271 (USB), FP-282 (FOCUS), FP-275 (SWITCH)
	DV SIGNAL, PB RF AMP, VIDEO IN/OUT,	FLEXIBLE BOARDS4-69
	AD CONVERTER, MODE/CAMERA/MECHA	CF-079 (USER FUNCTION, EVF DRIVE)      DRIVED WHILE BOARD.
	CONTROL, LASER LINK, DRUM CAPSTAN DRIVE,	PRINTED WIRING BOARD
	AUDIO PROCESS, MIC, DC/DC CONVERTER)	(DCR-TRV230/TRV330)4-6'
	PRINTED WIRING BOARD4-11	• CF-080 (USER FUNCTION, EVF DRIVE) PRINTED WIRING BOARD (DCR-TRV530) · 4-7
	• VC-254 (CAMERA PROCESS)(1/18)	• CF-079/080 (USER FUNCTION)(1/2)
	SCHEMATIC DIAGRAM4-15	SCHEMATIC DIAGRAM ·······4-7:
	• VC-254 (CAMERA PROCESS, Hi8/STD8/PB	• FP-282 (FOCUS), FP-275 (SWITCH)
	PROCESS)(2/18)	SCHEMATIC DIAGRAM4-70
	SCHEMATIC DIAGRAM4-17	• CF-079/080 (EVF DRIVE)(2/2)
	VC-254 (IRIS/FOCUS/ZOOM DRIVE)(3/18)     SCHEMATIC DIAGRAM4-19	SCHEMATIC DIAGRAM ·······4-7′
	• VC-254 (DV SIGNAL PROCESS-1)(4/18)	• SI-028 (DCR-TRV230E/TRV235E/TRV325E/TRV330E),
	SCHEMATIC DIAGRAM ·······4-21	SI-029 (DCR-TRV430E/TRV530E) (STEADY SHOT,
	• VC-254 (DV SIGNAL PROCESS-2)(5/18)	REMOTE COMMANDER RECEIVER, LASER LINK)
	SCHEMATIC DIAGRAM4-23	PRINTED WIRING BOARDS4-79
	• FP-272 (LANC, DV IN/OUT)	• FP-273 (MIC, HEADPHONES)
	SCHEMATIC DIAGRAM ··················4-24	FLEXIBLE BOARD (DCR-TRV530) ······· 4-8
	• VC-254 (DIGITAL8 PB RF AMP)(6/18)	<ul> <li>SI-028/029(STEADY SHOT, REMOTE</li> </ul>
	SCHEMATIC DIAGRAM4-25	COMMANDER RECEIVER, LASER LINK)
	• VC-254 (VIDEO IN/OUT)(7/18)	SCHEMATIC DIAGRAM ······4-8
	SCHEMATIC DIAGRAM ······4-27	• LB-068 (EVF BACK LIGHT)
	• FP-270 (S VIDEO, AUDIO/VIDEO)	PRINTED WIRING BOARD
	SCHEMATIC DIAGRAM ······4-27	(DCR-TRV230E/TRV235E/TRV325E/TRV330E) · 4-84
	• VC-254 (VIDEO A/D CONVERTER)(8/18)	• LB-070 (EVF BACK LIGHT)
	SCHEMATIC DIAGRAM ······4-29	PRINTED WIRING BOARD
	• VC-254 (Hi8/STD8/PB RF AMP)(9/18)	(DCR-TRV430E/TRV530E)4-84
	SCHEMATIC DIAGRAM ······4-31	• LB-068/070 (EVF BACK LIGHT)
	• VC-254 (MODE CONTROL)(10/18)	SCHEMATIC DIAGRAM4-8:
	SCHEMATIC DIAGRAM ······4-33	• FP-283 (PANEL REVERSE) FLEXIBLE BOARD4-80
	• VC-254 (CAMERA CONTROL, Hi8/STD8 MECHA	• PD-138 (RGB DRIVE, TIMING GENERATOR,
	CONTROL, STEADY SHOT)(11/18)	LCD DRIVE, BACK LIGHT DRIVE)
	SCHEMATIC DIAGRAM4-35	PRINTED WIRING BOARD
	• VC-254 (EVR, LASER LINK)(12/18)	(DCR-TRV230E/TRV235E/TRV325E/TRV330E) · 4-8'
	SCHEMATIC DIAGRAM4-37	• PD-138 (RGB DRIVE, TIMING GENERATOR)(1/2)
	VC-254 (DIGITAL8 MECHA CONTROL)(13/18)     SCHEMATIC DIACRAM     4.20	SCHEMATIC DIAGRAM4-89
	SCHEMATIC DIAGRAM4-39	• FP-283 (PANEL REVERSE)
	VC-254 (DRUM/CAPSTAN DRIVE)(14/18)     SCHEMATIC DIAGRAM4-41	SCHEMATIC DIAGRAM ·······4-89
	• VC-254 (AUDIO PROCESS)(15/18)	• PD-138 (LCD DRIVE, BACK LIGHT DRIVE)(2/2)
	SCHEMATIC DIAGRAM4-43	SCHEMATIC DIAGRAM4-9
	• VC-254 (MIC AMP)(16/18)	• PD-139 (RGB DRIVE, TIMING GENERATOR,
	SCHEMATIC DIAGRAM ·······4-45	LCD DRIVE, BACK LIGHT DRIVE)
	• VC-254 (CONNECTOR)(17/18)	PRINTED WIRING BOARD
	SCHEMATIC DIAGRAM ·······4-47	(DCR-TRV430E/TRV530E)4-93
	• VC-254 (DC/DC CONVERTER)(18/18)	• PD-139 (RGB DRIVE, TIMING GENERATOR)(1/2)
	SCHEMATIC DIAGRAM4-49	SCHEMATIC DIAGRAM ······4-9

	• FP-283 (PANEL REVERSE)	4.	COM DC Adjustment
	SCHEMATIC DIAGRAM4-95		(CF-079 board (Part No. suffix: 12 or later))
	• PD-139 (LCD DRIVE, BACK LIGHT DRIVE)(2/2)		(CF-080 board (Part No. suffix: 13 or later))5-28
	SCHEMATIC DIAGRAM4-97		LCD SYSTEM ADJUSTMENT5-29
	• FU-150 (POWER SUPPLY)	1. 2.	VCO Adjustment (PD-138/139 board)5-30
	PRINTED WIRING BOARD (DCR-TRV230E/TRV235E/TRV325E/TRV330E) · 4-99	۷.	PSIG Gray Adjustment (PD-139 board) (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E) · 5-30
	• FU-154 (POWER SUPPLY)	3.	RGB AMP Adjustment (PD-138 board)
	PRINTED WIRING BOARD	5.	(DCR-TRV430E)
	(DCR-TRV430E/TRV530E)4-99	4.	RGB AMP Adjustment (PD-139 board)
	• FU-150/154 (POWER SUPPLY)	••	(DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E) · 5-31
	SCHEMATIC DIAGRAM ·······4-101	5.	Black Limit Adjustment (PD-139 board)
4-3.	WAVEFORMS4-103		(DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E) · 5-32
4-4.	MOUNTED PARTS LOCATION4-107	6.	Contrast Adjustment (PD-138 board)(DCR-TRV430E) · 5-32
		7.	Contrast Adjustment (PD-139 board)
5.	ADJUSTMENTS		(DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E) · 5-33
1.	Before starting adjustment 5-2	8.	Center Level Adjustment (PD-139 board)
	Adjusting items when replacing main parts and boards. • 5-2		(DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E) · 5-33
5-1.	CAMERA SECTION ADJUSTMENT5-4	9.	COM AMP Adjustment (PD-138 board)
1-1.	PREPARATIONS BEFORE ADJUSTMENT		(DCR-TRV430E)5-34
	(CAMERA SECTION) 5-4	10.	V-COM Adjustment (PD-138/139 board) ······5-34
	List of Service Tools5-4	11.	White Balance Adjustment (PD-138/139 board) ········ 5-35
	Preparations5-5		MECHANISM SECTION ADJUSTMENT5-36
1-1-3	Precaution5-7		Hi8/STANDARD8 MODE5-36
1.	Setting the Switch	2-1-1.	OPERATING WITHOUT CASSETTE5-36
2.	Order of Adjustments5-7		TAPE PATH ADJUSTMENT5-36
3.	Subjects 5-7	1.	Preparations for Adjustment
	INITIALIZATION OF B, C, D, E, F, 7, 8 PAGE DATA ·· 5-8		
	INITIALIZATION OF C, D, 8 PAGE DATA5-8	2-2-1.	HOW TO ENTER RECORD MODE WITHOUT CASSETTE5-37
1.	Initializing the C, D, 8 Page Data	222	HOW TO ENTER PLAYBACK MODE WITHOUT
2.	Modification of C, D, 8 Page Data5-8 C Page Table5-8	2-2-2.	CASSETTE5-37
3. 4.	D Page Table	2-2-3	OVERALL TAPE PATH CHECK5-37
<del>4</del> . 5.	8 Page Table	1.	Recording of the tape path check signal5-37
	INITIALIZATION OF B PAGE DATA	2.	Tape path check5-37
1-2-2.	(DCR-TRV325E/TRV330E/TRV430E/TRV530E) 5-11	5-3.	VIDEO SECTION ADJUSTMENT5-38
1.	Initializing the B Page Data5-11		PREPARATIONS BEFORE ADJUSTMENTS5-38
2.	Modification of B Page Data ······5-11	3-1-1.	Equipment to Required5-38
3.	B Page Table5-11	3-1-2.	Precautions on Adjusting5-39
1-2-3	INITIALIZATION OF E, F, 7 PAGE DATA5-12	3-1-3.	Adjusting Connectors 5-40
1.	Initializing the E, F, 7 Page Data ······5-12	3-1-4.	Connecting the Equipment5-40
2.	Modification of E, F, 7 Page Data ······5-12		Alignment Tape5-41
3.	F Page Table5-12		Input/output Level and Impedance5-41
4.	E Page Table5-13	3-2.	SYSTEM CONTROL SYSTEM ADJUSTMENT ······· 5-42
5.	7 Page Table 5-14	1.	Initialization of B, C, D, E, F, 7, 8 Page Data ····· 5-42
1-3.	CAMERA SYSTEM ADJUSTMENTS5-15	2.	Serial No. Input5-42
1.	HALL Adjustment5-15		Company ID Input
2.	Flange Back Adjustment (Using Minipattern Box) ······ 5-16	2-2.	Serial No. Input
3.	Flange Back Adjustment (Using Flange Back Adjustment	3-3.	SERVO AND RF SYSTEM ADJUSTMENT5-44
2.1	Chart and Subject More Than 500m Away)5-17	1.	REEL FG Adjustment (VC-254 board)
3-1.	Flange Back Adjustment (1)	2. 3.	PLL fo & LPF fo Pre-Adjustment (VC-254 board) ······ 5-44 Switching Position Adjustment (VC-254 board) ······ 5-45
	Flange Back Adjustment (2)5-17		AGC Center Level and APC & AEQ Adjustment5-45
4. -	Flange Back Check5-18 Optical Axis Adjustment5-19	4. 4-1.	Preparations before adjustments
5.	Picture Frame Setting5-20	4-1. 4-2.	AGC Center Level Adjustment (VC-254 board)5-45
6. 7	Color Reproduction Adjustment5-21	4-3.	APC & AEQ Adjustment (VC-254 board)5-46
7. 8.	Auto White Balance & LV Standard Data Input5-22		Processing after Completing Adjustments5-46
o. 9.	Auto White Balance & Ly Standard Data Input5-22  Auto White Balance Adjustment5-23	5.	PLL fo & LPF fo Fine Adjustment (VC-254 board) ····· 5-47
). 10.	White Balance Check	6.	Hi8/Standard8 Switching Position Adjustment
11.	Angular Velocity Sensor Sensitivity Adjustment5-25		(VC-254 board)5-47
	ELECTRONIC VIEWFINDER SYSTEM	7.	CAP FG Offset Adjustment (VC-254 board)5-48
••	ADJUSTMENT5-26	3-4.	VIDEO SYSTEM ADJUSTMENTS5-49
1.	VCO Adjustment (CF-079/080 board)5-26	1.	36MHz Origin Oscillation Adjustment (VC-254 board) 5-49
2.	RGB AMP Adjustment (CF-079/080 board) ····· 5-27	2.	Chroma BPF fo Adjustment (VC-254 board) 5-49
3.	Contrast Adjustment (CF-079/080 board) ····· 5-27	3.	S VIDEO OUT Y Level Adjustment (VC-254 board) ··· 5-50

4.	S VIDEO OUT Chroma Level Adjustment
	(VC-254 board)5-50
5.	VIDEO OUT Y, Chroma Level Check (VC-254 board) $\cdot$ 5-51
6.	Hi8/Standard8 Y/C Output Level Setting (VC-254 board) · 5-51
7.	Hi8/standard 8mm AFC fo Adjustment (VC-254 board) ·· 5-52
3-5.	IR TRANSMITTER ADJUSTMENTS5-53
1.	IR Video Carrier Frequency Adjustment (VC-254 board) · 5-53
2.	IR Video Deviation Adjustment (VC-254 board)5-53
3.	IR Audio Deviation Adjustment (VC-254 board)5-54
3-6.	AUDIO SYSTEM ADJUSTMENTS5-55
1. 2.	Hi8/Standard8 AFM BPF fo Adjustment (VC-254 board) · 5-55 Hi8/Standard8 AFM 1.5 MHz Deviation Adjustment (VC-254 board) ····································
3.	Hi8/Standard8 AFM 1.7 MHz Deviation Adjustment (VC-254 board)
4	
4.	Digital8 Playback Level Check
5.	Overall Distortion Check
6. 7.	Overall Noise Level Check
8.	Overall Separation Check
5-4.	SERVICE MODE5-58
3-4. 4-1.	ADJUSTMENT REMOTE COMMANDER5-58
1.	Using the Adjustment Remote Commander5-58
2.	Precautions Upon Using the Adjustment Remote
۷.	Commander
4-2.	DATA PROCESS
4-3.	SERVICE MODE
1.	Setting the Test Mode
2.	Emergence Memory Address ······ 5-60
2-1.	C Page Emergence Memory Address5-60
2-2.	F Page Emergence Memory Address5-61
2-3.	EMG Code (Emergency Code)5-61
2-4.	MSW Code
3.	Bit Value Discrimination5-63
4.	Switch check (1)5-63
5.	Switch check (2)5-63
6.	Switch check (3)5-63
7.	Switch check (4)5-64
8.	Record of Use check5-64
9.	Record of Self-diagnosis check 5-65
6.	REPAIR PARTS LIST
6-1.	EXPLODED VIEWS6-1
6-1-1	OVERALL SECTION6-1
6-1-2	.CABINET (L) SECTION-1 ······ 6-2
6-1-3	.CABINET (L) SECTION-26-3
6-1-4	.CABINET (R) SECTION (2.5 INCH LCD MODEL)
	(TRV230E/TRV235E/TRV325E/TRV330E)6-4
6-1-5	.CABINET (R) SECTION (3/3.5 INCH LCD MODEL) (TRV430E/TRV530E)6-5
6-1-6	LCD SECTION (2.5 INCH LCD MODEL)
	(TRV230E/TRV235E/TRV325E/TRV330E)6-6
6-1-7	LCD SECTION (3/3.5 INCH LCD MODEL)
0 1 /	(TRV430E/TRV530E)6-7
6-1-8	LENS, EVF SECTION6-8
	.CASSETTE COMPARTMENT ASSY, DRUM ASSY 6-9
	0. LS CHASSIS BLOCK ASSEMBLY6-10
	1. MECHANICAL CHASSIS BLOCK ASSEMBLY-1 ·· 6-11
	2. MECHANICAL CHASSIS BLOCK ASSEMBLY-2 ·· 6-12
	ELECTRICAL PARTS LIST6-13
-	

<sup>\*</sup> Optical axis frame and color reproduction frame are shown on pages 304 and 305.

## SERVICE NOTE

#### 1. POWER SUPPLY DURING REPAIRS

In this unit, about 10 seconds after power is supplied (8.4V) to the battery terminal using the service power code (J-6082-223-A), the power is shut off so that the unit cannot operate.

These following two methods are available to prevent this. Take note of which to use during repairs.

#### Method 1.


Use the DC IN terminal. (Use the AC power adaptor.)

#### Method 2

Connect the adjustment remote commander RM-95 (J-6082-053-B) to the LANC jack, and set the HOLD switch to the "ADJ" side.

## 2. TO TAKE OUT A CASSETTE WHEN NOT EJECT (FORCE EJECT)

- ① Refer to 2-3. to remove the front panel section.
- 2 Refer to 2-4. to remove the cabinet (Upper) assembly.
- 3 Refer to 2-4. to remove the cabinet (R) assembly.
- Refer to 2-9. to remove the memory stick connector assembly. (DCR-TRV325E/TRV330E/TRV430E/TRV530E)
- **⑤** Refer to 2-10. to remove the battery panel section.
- 6 Refer to 2-11. and 2-12. to remove the cabinet (L) section. (Include the CS frame assembly and control switch block (SS-1380).)
- 7 Disconnect CN4401 (2P) of VC-254 board.
- Add +5V from the DC POWER SUPPLY and unload with a pressing the cassette compertment.



## **SELF-DIAGNOSIS FUNCTION**


## 1. Self-diagnosis Function

When problems occur while the unit is operating, the self-diagnosis function starts working, and displays on the viewfinder or Display window what to do. This function consists of two display; self-diagnosis display and service mode display.

Details of the self-diagnosis functions are provided in the Instruction manual.

## 2. Self-diagnosis Display

When problems occur while the unit is operating, the counter of the viewfinder or Display window shows a 4-digit display consisting of an alphabet and numbers, which blinks at 3.2 Hz. This 5-character display indicates the "repaired by:", "block" in which the problem occurred, and "detailed code" of the problem.




## 3. Service Mode Display

The service mode display shows up to six self-diagnosis codes shown in the past.

## 3-1. Display Method

While pressing the "STOP" key, set the switch from OFF to "VTR or PLAYER", and continue pressing the "STOP" key for 5 seconds continuously. The service mode will be displayed, and the counter will show the backup No. and the 5-character self-diagnosis codes.



## 3-2. Switching of Backup No.

By rotating the control dial, past self-diagnosis codes will be shown in order. The backup No. in the [] indicates the order in which the problem occurred. (If the number of problems which occurred is less than 6, only the number of problems which occurred will be shown.)

[1]: Occurred first time [4]: Occurred fourth time [2]: Occurred second time [5]: Occurred fifth time [6]: Occurred the last time

## 3-3. End of Display

Turning OFF the power supply will end the service mode display.

**Note:** The "self-diagnosis display" data will be backed up by the coin-type lithium battery (CF-079/080 board BT101). When the CF-079/080 board is disconnected, the "self-diagnosis display" data will be lost by initialization.

# 4. Self-diagnosis Code Table

S	elf-dia	agnos	is Co	de		
Repaired by:	Block Detailed Function Code		Code		Correction	
С	0	4	0	0	Non-standard battery is used.	Use the InfoLITHIUM battery.
C	2	1	0	0	Condensation.	Remove the cassette, and insert it again after one hour.
C	2	2	0	0	Video head is dirty.	Clean with the optional cleaning cassette.
С	3	1	1	0	LOAD direction. Loading does not complete within specified time	Load the tape again, and perform operations from the beginning.
С	3	1	1	1	UNLOAD direction. Loading does not complete within specified time	Load the tape again, and perform operations from the beginning.
С	3	1	2	0	T reel side tape slacking when unloading.	Load the tape again, and perform operations from the beginning.
С	3	1	2	1	S reel side tape slacking when unloading.	Load the tape again, and perform operations from the beginning.
C	3	1	2	2	T reel fault.	Load the tape again, and perform operations from the beginning.
C	3	1	2	3	S reel fault.	Load the tape again, and perform operations from the beginning.
С	3	1	3	0	FG fault when starting capstan.	Load the tape again, and perform operations from the beginning.
С	3	1	3	1	FG fault during normal capstan operations.	Load the tape again, and perform operations from the beginning.
С	3	1	4	0	FG fault when starting drum.	Load the tape again, and perform operations from the beginning.
С	3	1	4	1	PG fault when starting drum.	Load the tape again, and perform operations from the beginning.
С	3	1	4	2	FG fault during normal drum operations.	Load the tape again, and perform operations from the beginning.
С	3	1	4	3	PG fault during normal drum operations.	Load the tape again, and perform operations from the beginning.
С	3	1	4	4	Phase fault during normal drum operations.	Load the tape again, and perform operations from the beginning.
С	3	2	1	0	LOAD direction loading motor time- out.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	1	1	UNLOAD direction loading motor time-out.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	2	0	T reel side tape slacking when unloading.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	2	1	S reel side tape slacking when unloading.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	2	2	T reel fault.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	2	3	S reel fault.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	3	0	FG fault when starting capstan.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	3	1	FG fault during normal capstan operations.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	4	0	FG fault when starting drum.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	4	1	PG fault when starting drum.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	4	2	FG fault during normal drum operations.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	4	3	PG fault during normal drum operations.	Remove the battery or power cable, connect, and perform operations from the beginning.
С	3	2	4	4	Phase fault during normal drum operations.	Remove the battery or power cable, connect, and perform operations from the beginning.

S	elf-dia	gnos	is C	ode		
Repaired by:	Blo Func	-		ailed ode	Symptom/State	Correction
Е	6	1	0	0	Difficult to adjust focus (Cannot initialize focus.)	Inspect the lens block focus reset sensor (Pin ③ of CN1551 of VC-254 board) when focusing is performed when the control dial is rotated in the focus manual mode and the focus motor drive circuit (IC1553 of VC-254 board) when the focusing is not performed.
Е	6	1	1	0	Zoom operations fault (Cannot initialize zoom lens.)	Inspect the lens block zoom reset sensor (Pin ② of CN1551 of VC-254 board) when zooming is performed when the zoom lens is operated and the zoom motor drive circuit (IC1553 of VC-254 board) when zooming is not performed.
Е	6	2	0	0	Handshake correction function does not work well. (With pitch angular velocity sensor output stopped.)	Inspect pitch angular velocity sensor (SE301 of SE-028/029 board) peripheral circuits.
Е	6	2	0	1	Handshake correction function does not work well. (With yaw angular velocity sensor output stopped.)	Inspect yaw angular velocity sensor (SE302 of SE-028/029 board) peripheral circuits.

## DCR-TRV230E/TRV235E/TRV325E/ TRV330E/TRV430E/TRV530E

## **SECTION 1 GENERAL**


This section is extracted from instruction manual.

#### Checking supplied accessories

#### Проверка прилагаемых принадлежностей

Make sure that the following accessories are supplied with your camcorder.

Убедитесь, что следующие принадлежности прилагаются к Вашей видеокамере.



- 1 Wireless Remote Commander (1) (p. 210)
- 2 AC-L10A/L10B/L10C AC power adaptor (1), Mains lead (1) (p. 16)
- 3 NP-FM30 battery pack (1) (p. 15, 16) DCR-TRV230E/TRV325E/TRV330E/ TRV530E NP-FM50 battery pack (1) (p. 15, 16) DCR-TRV235E/TRV430E
- R6 (size AA) battery for Remote Commander (2) (p. 211)
- 5 A/V connecting cable (1) (p. 44)
- 6 Shoulder strap (1) (p. 205)
- 7 Lens cap (1) (p. 26)
- 8 USB cable (1)\* (p. 151)
- 9 "Memory Stick" (1)\* (p. 124) 10 CD-ROM (SPVD-004 USB Driver) (1)\* (p. 151)
- 11 21-pin adaptor (1) (p. 45)
- \* DCR-TRV325E/TRV330E/TRV430E/TRV530E

Contents of the recording cannot be compensated if recording or playback is not made due to a malfunction of the camcorder, storage media, etc.

- П Беспроводный пульт дистанционного управления (1) (стр. 210)

  2 Сетевой адаптер переменного тока АС-L10AL10BL/10 (1) (стр. 16)

  3 Батарейный блок NP-FM30 (1) (стр. 15, 16)

  DCR-TRV230E/TRV325E/TRV330E/TRV530E

  Батарейный блок NP-FM50 (1) (стр. 15, 16)

  DCR-TRV235E/TRV430E

  4 Батарейка R6 (размера АА) для пульта дистанционного управления (2) (стр. 211)

  5 Соединительный кабель аудио/видео (1) (стр. 44)

  6 Плечевой ремень (1) (стр. 205)

  7 Курышка объектива (1) (стр. 26)

  8 Кабель USB (1)\* (стр. 151)

- Кабель USB (1)\* (стр. 151)
   "Memory Stick" (1)\* (стр. 124)
   CD-ROM (драйвер USB SPVD-004) (1)\* (CTD, 151)
- 11 **21-штырьковый адаптер** (1) (стр. 45)

\*Только модели DCR-TRV325E/TRV330E/ TRV430E/TRV530E

Содержание записи не может быть компенсировано в случае, если запись или воспроизведение не выполнены из-за неисправности видеокамеры, видеоленты

English

## **Main Features**

#### Taking moving or still images, and playing them back

- Recording a picture (p. 26)
  Recording a still image on a tape (p. 48)
  Playing back a tape (p. 39)
  Recording still images on "Memory Stick" (p. 129) (DCR-TRV325E/TRV330E/TRV430E/TRV530E)
  Recording still images on "Memory Stick" (p. 129)



- Capturing images on your computer

   Using with analog video unit and your computer (p. 98) (DCR-TRV330E only)

   Viewing images recorded on "Memory Stick" using USB cable (p. 150) (DCR-TRV325E/TRV330E/TRV430E/TRV350E only)



Other uses Functions to adjust exposure in the recording mode

- Back light (p. 32)
   NightShot/Super NightShot (p. 33)
   PROGRAM AE (p. 61)
   Adjusting the exposure manually (p. 64)

- Functions to give images more impact

   Digital program editing (p. 86)

   Fader (p. 53)

   Picture effect (p. 56)

   Digital effect (p. 58)

   Title (p. 67, 69)

   MEMORY MIX (p. 135) (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

## Functions to give a natural appearance to your recordings • END SEARCH/EDITSEARCH/Rec Review (p. 37)

- Manual focus (p. 63) Digital zoom [MENU] (p. 107) The default setting is set to OFF. (To zoom greater than  $25 \times$ , select the digital zoom power in D ZOOM in the menu settings.)

#### Functions to use after recording

- Zero set memory (p. 77)
   Hiri SOUND [MENU] (p. 107)
   SUPER LASER LINK (p. 46)
   Tape PB ZOOM (p. 75)/Memory PB ZOOM (p. 157) (DCR-TRV325E/TRV330E/TRV430E/TRV530E)


4

## Quick Start Guide




This chapter introduces you to the basic features of your camcorder. See the page in parentheses "( )" for more information.

### Connecting the mains lead (p. 21)



Inserting a cassette (p. 24)



2 Insert the cassette in a Insert the cassette in a straight line deeply into the cassette compartment with the window facing out. Push the middle portion of the back of the cassette to insert. 3 Close the cassette compartment by pressing the PUSH mark on the casse mark on the cassett compartment. After the cassette compartment goes down completely, close the lid until it









3 Open the LCD panel while pressing OPEN. The picture appears on the LCD screen.

2 Set the POWER switch to CAMERA while pressing the small green button.



4 Press START/STOP. Your camcorder starts recording. To stop recording, press START/STOP button

When the LCD panel is closed, use the viewfinder placing your



eye against its eyecup.

The picture in the viewfinder is black and white. When you purchase your camcorder, the clock setting is set to off. If you want to record the date and time for a picture, set the clock setting before recording (p,22).

Monitoring the playback picture on the LCD



REW ⊕

3 Press ► to start playback. PLAY

Set the POWER switch to PLAYER or VCR (DCR-TRV330E only) while pressing the small green button.

Note
Do not pick up your camcorder beholding the viewfinder, the LCD panel, or the battery pack.





Quick Start Guide

### Using this manual

The instructions in this manual are for the six models listed in the table below. Before you start reading this manual and operating your camcorder, check the model number by looking at the bottom of your camcorder. The DCR-TRV530E is the model used for illustration purposes. Otherwise, the model name is indicated in the illustrations. Any differences in operation are clearly indicated in the text, for example. "DCR-TRV530E only."
As you read through this manual, buttons and settings on your camcorder are shown in capital letters.
e.g. Set the POWER switch to CAMFPA models listed in the table below. Before you start

Set the POWER switch to CAMERA e.g. Set the POWER switch to CAMERA. When you carry out an operation, you can hear a beep sound to indicate that the operation is being carried out. Подготовка к эксплуатации –

#### Использование данного руководства

В данном руководстве по эксплуатации приведены инструкции для шести моделей, перечисленных в приведенной ниже таблице. Перед тем, как прочесть данное руководство и начать эксплуатацию Вашей видеокамеры, проверьте номер модели на нижней стороне Вашей видеокамеры. В качестве иллюстративных целей используется модель ОСК-ТРКУЗОЕ. В других случаях номер модели указан на рисунках. Какие-либо расхождения в эксплуатации четко указаны в тексте, например, "только DCR-TRVS30E." При чтении данного руководства учитывайте, что кнопки и установки на видеокамере показаны заглавными буквами. Прим. Установки на видеокамере показаны всемение выключатель РОМЕВ в положение САМЕВА.
При выполнении операции на видеокамере Вы сможете услышать зуммерный сигнал, подтверждающий выполнение операции.

Note	on T\	/ colou	rsystems

TV colour systems differ from country to country. To view your recordings on a TV, you need a PAL system-based TV.

#### Copyright precautions

Television programmes, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provision of the copyright

#### Using this manual

- The models with MEMORY marked on the
- The models with MEMORY marked on the POWER switch is provided with memory functions. See page 124 for details. The models with VCR marked on the POWER switch can record pictures from other equipment such as VCR. The other models have PLAYER mark on the POWER switch.

Before using your camcorder

With your digital camcorder, you can use Hi8 HiB/Digital8 H video cassettes. Your camcorder records and plays back pictures in the Digital8 H system. Also, your camcorder plays back tapes recorded in the Hi8 HiB/standard 8 B (analog)

recorded in the Hi**B** H**iB**/standard 8 **B** (analog) system. You, however, cannot use the functions in "Advanced Playback Operations" on page 72 system. To enable smooth transition, we recommend that you do not mix pictures recorded in the Hi**B** H**iB**/standard 8 **B** with the Digital8 **H** system on a tape.

# Перед началом эксплуатации Вашей видеокамеры

переключателе РСИWEH оснащены функциями памяти. См. стр. 124 для получения более подробных сведений. Модели с меткой VCR на переключателе РОWER могут записывать изображения с другой аппаратуры, такой, как КВМ. В остальных моделях на переключателе РОWER находится метка PLAYER.

Использование данного

Молели с меткой MEMORY на

переключателе POWER оснащень

руководства

Лля Вашей пифровой видеокамеры Вы дил зашени ципуровом видеокамеры вы можете использовать видеокассеты Hi8 **Fit8/** Digital8 **F).** Ваша видеокамера записывает и воспроизводит изображения в цифровой системе Digital8 **F).** Также, Ваша видеокамера системе Digital8 F). Также, Ваша видеокамеря воспроизводит ленты, записанные в системе His His/стандартной системе 8 В (аналоговой). Однако, Вы не можете использовать функция в разделе "Усовершенствованные операции воспроизведения" на страницах с 72 по 81 для воспроизведения на страницах с 72 по 81 для воспроизведения в системе His His/стандартной системе В В. Для обеспечения плавного перехода рекомендуется не смешивать на ленте изображения, записанные в системе His His/стандартной системе 8 В, с изображениями, записанными в цифровой системе Digital8 F).

# Примечание по системам цветного телевидения

Системы цветного телевидения отличаются в зависимости от страны. Для просмотра Ваших записей на экране телевизора Вам необходимо использовать телевизор, основанный на системе PAL.

# Предостережение об авторском праве

Телевизионные программы, кинофильмы, видеоленты и другие материалы могут быть защищены авторским правом. Нелицензированная запись таких материалов может противоречить положениям закона об авторском праве.

Type of difference/Типы разл

DCR-	TRV230E	TRV235E	TRV325E	TRV330E	TRV430E	TRV530E
MEMORY mark* (on the POWER switch)/ Μετκα ΜΕΜΟRY* (на переключателе POWER)	_	_	•	•	•	•
VCR mark** (on the POWER switch)/ Метка VCR** (на переключателе POWER)	_	-	-	•	-	-
Self-timer/ Таймер самозапуска		_	•	•	•	•
Ψ (USB) jack / Гнездо Ψ (USB)	-	-	•	•	•	•
LCD screen/ Экран ЖКД				6.2 cm (2.5 type)/ (2,5 дюйма по диагонали)		8.8 cm (3.5 type)/ (3,5 дюйма по диагонали)
Digital zoom/ Цифровой вариообъекти	700×	800×	700×	700×	800×	700×

 Provided/Прилагается Not provided/He прилагается

Using this manual

12

## Precautions on camcorder care

Lens and LCD screen/finder (on

- Lens and LCD screen/finder (on mounted models only)

   The LCD screen and the finder are manufactured using extremely high-precision technology so over 99.99% of the pixels are operational for effective use. However, there may be some tiny black points and/or bright points (white, red, blue or green in colour) that constantly appear on the LCD screen and the finder. These points are normal in the manufacturing process and do not affect the recording in any way.

  Do not let your camcorder get wet. Keep your camcorder away from rain and sea water. Letting your camcorder get wet may cause your camcorder to malfunction. Sometimes this malfunction cannot be repaired [a].

   Never leave your camcorder exposed to temperatures above 60 °C (140 °F), such as in a car parked in the sun or under direct sunlight [b].

- [b].

   Be careful when placing the camera near a window or outdoors. Exposing the LCD screen the finder or the lens to direct sunlight for long periods may cause malfunctions [c].

  • Do not directly shoot the sun. Doing so might
- cause your camcorder to malfunction. Tak pictures of the sun in low light conditions such as dusk [d].

#### Использование данного руководства

# Меры предосторожности при уходе за видеокамерой

Объектив и экран ЖКД/видоискатель (только на смонтированных моделях) • Экран ЖКД и видоискатель изготовлены с помощью высокопрецизионной Экран ЖКД и видоискатель изготовлены с помощью высокопрецизионной технологии, так что свыше 99,99% элементов изображения предназначены для эффективного использования.
 Однако на экране ЖКД и в видоискателе черные и/или яркие цветные точки (белые, красные, синие или запеные).
 Появление этих точек вполне нормально для процесса съемки и никоим образом не влияет на записываемое изображение.
 Не допускайте, чтобы видеокамери становилась влажной. Предохраняйте видеокамеру от дождя и морской воды. Если Вы намочите видеокамеру, то это может гривести к немогравности аппарата, которая не всегда может быть устранена [а].

- которая не всегда может быть устранена [а].

  1- Никогда не оставляйте видеокамеру в месте с температурой выше 60 °C (140 °F), как, например, в автомобиле, оставленном на солнце или под прямым солнечным светом [b].

  5 удьте виммательны, когда помещаете камеру около окна или вне помещения. Воздействие на экран ЖКД, видоискатель или объектив прямого солнечного света в течение длительного времени может привести к неисправностим [с].

  3то может привести к неисправности. Проводите съемки солнца в условиях имяжной освещенности, таких, как сумерки [с].

## Step 1 Preparing the power supply

#### Installing the battery pack

We recommend using the battery pack when you our camcorder outdoors

(1) Lift up the viewfinder. (2) Slide the battery pack down until it clicks.

## Установка батарейного блока

источника питания

Пункт 1 Подготовка

Рекомендуется установить батарейный блок, если Вы используете Вашу видеокамеру вне

(1) Поднимите видоискатель. (2) Передвиньте батарейный блок вниз до



To remove the battery pack
(1) Lift up the viewfinder.
(2) Slide the battery pack out in the direction of the arrow while pressing BATT (battery) release lever down.

#### Для снятия батарейного блока

Для снятия оатареилог с этопа.


(1) Поднимите видоискатель.
(2) Передвиньте батарейный блок в направлении, указанном стрелкой, при нажатом вниз фиксаторе ВАТТ (батарея).



If you install the large capacity battery pack If you install the NP-FM70/FM90/FM91 batter pack on your camcorder, extend its viewfinder

Если Вы установили батарейный блок большой емкости
Если Вы установили на Вашу видеокамер батарейный блок NP-MT0/FM90/FM91, выдвиньте видоискатель.

[a] [c]



[b]

14

15

1-2

started

#### Step 1 Preparing the power supply

#### Charging the battery pack

Use the battery pack after charging it for your

Your camcorder operates only with the "InfoLITHIUM" battery pack (M series). See page 188 for details of "InfoLITHIUM" battery pack.

(1) Open the DC IN jack cover and connect the AC power adaptor supplied with your camcorder to the DC IN jack with the plug's ▲ mark facing up.
(2) Connect the mains lead to the AC power

adaptor

(3) Connect the mains lead to a wall socket. (4) Set the POWER switch to OFF (CHG). Charging begins. The remaining battery time is indicated in minutes on the display window.

window. When the remaining battery indicator changes to 
m. normal charge is completed. To fully charge the battery (full charge), leave the battery pack attached after normal charge is completed until FULL appears on the display window. Fully charging the battery allows you to use the battery longer than usual.

Пункт 1 Подготовка источника питания

#### Зарядка батарейного блока

Используйте батарейный блок для Вашей видеокамеры после его зарядки. Ваша видеокамера работает только с батарейным блоком "InfoLITHIUM" (серии М). См. стр. 188 для получения более подробных сведений о батарейном блоке "InfoLITHIUM".


- (1) Откройте крышку гнезда DC IN и подсоедините сетевой адаптер подсоедините сетевой адаптер переменного тока, прилагаемый к Вашей
- подсоедили с естевои адал теру переменного тока, прилагаемый к Вашей видеокамере, к гнезду DCIN, так чтобы штекер & был направлен вверх.

  (2) Подсоедините провод электропитания к сетевому адаптеру переменного тока.

  (3) Подсоедините провод электропитания к сетевой розетке.

  (4) Установите переключатель РОWER в положение ОFF (СНG). Начнется зарядка В окошке диксплея будет отображаться время оставшегося заряда в минутах.

  Если индикатор оставшегося заряда изменится на 🖦 это значит, что нормальная зарядка в веремен для полной зарядки батарейного блока (полная зарядка) сставьте батарейный блок прикрепленным на месте после завершения пормальнай зарядка от еха роду то тех пор, пока в нормальной зарядки до тех пор. пока в пормальной заридны до тех пор, пюка в окошке дисплея не появится индикация FULL. Полная зарядка батарейного блока позволяет Вам использовать батарейный блок дольше чем обычно.



The number in the illustration of the display window may differ from that on your came

Цифры на рисунке окошка дисплея мог отличаться от цифр на Вашей видеока

#### Step 1 Preparing the power supply

After charging the battery pack Disconnect the AC power adaptor from the DC IN jack on your camcorder.

- Prevent metallic objects from coming into Prevent metallic objects from coming into contact with the metal parts of the DC plug of the AC power adaptor. This may cause a short-circuit, damaging the AC power adaptor.
   Keep the battery pack dry.
   When the battery pack is not to be used for a long time, charge the battery pack fully, and then use it until it fully discharges again. Do this once a year. Keep the battery pack in a cool place.

When the battery pack is charged fully The LCD backlight of the display window turned off.

Remaining battery time indicator
The remaining battery time indicator in the
display window roughly indicates the recording
time with the viewfinder.

Until your camcorder calculates the actual remaining battery time "---min" appears in the display window.

While charging the battery pack, no indicator appears or the indicator flashes in the display window in the following cases:

- The battery pack is not installed correctly.

- Something is wrong with the battery pack.

If the power may go off although the battery remaining indicator indicates that the battery pack has enough power to operate Charge the battery pack fully again so that the indication on the battery remaining indicator is

When you use the AC power adaptor Place the AC power adaptor near a wall socket. If any trouble occurs with this unit, disconnect the plug from a wall socket as soon as possible to cut off the power.

#### Пункт 1 Подготовка источника питания

После зарядки батарейного блока Отсоедините сетевой адаптер переменного тока от гнезда DC IN на Вашей видеокамере

- Примечание
   Не допускайте контакта металлических предметов с металлическими частями штекера постоянного тока сетевого адаптера. Это может привести к короткому замыканию и повреждению Вашего
- сетевого адаптера. Содержите батарейный блок в сухом
- Содержите батаремпын обликательное состоянии.
   Если батарейный блок предполагается не использовать длительное время, зарядите его полностью, а затем используйте до тех пор, пока он снова полностью не разрядится. Выполняйте это раз в год. Храните батарейный блок в прохладном месте.

Если батарейный блок заряжен полностью Задняя подсветка ЖКД в окошке дисплея выключится.

Индикатор времени оставшегося заряда батарейного блока Индикатор времени оставшегося заряда батарейного блока в окошке дисплея приблизительно указывает время записи с помощью видоискателя.

До тех пор, пока Ваша видеокамера определит действительное время определит деиствительное время оставшегося заряда батарейного бло В окошке дисплея будет отображаться индикация "———— min".

Во время зарядки батарейного блока никакой индикатор не поялвяется, или индикатор будет мигать в окошке дисплея

индикатор оудет мината в окошке дистие в следующих случаях – Батарейный блок установлен неправильно. – Что-то не в порядке с батарейным блоком.

Если заряд может быть израсходован, а если заряд может оыть израсходован, а индикатор времени оставшегося заряда батарейного блока будет показывать, что заряд батарейного блока вполне достаточный для его эксплуатации. Зарядите батарейный блок еще раз, так чтобы показание на индикаторе оставшегося заряда батарейного блока было правильным.

# Если Вы используете сетевой адаптер переменного тока Разместите сетевой адаптер переменного

тока возле сетевой розетки. В случае тока возле сетевои розетки. В случае неисправности данного аппарата, отсоедините штекер от сетерой розетки как можно быстрее для отключения питания.

17

#### Step 1 Preparing the power supply

#### What is "InfoLITHIUM"?

What is "InfoLITHIUM"?

The "InfoLITHIUM" is a lithium ion battery pack which can exchange data such as battery consumption with compatible electronic equipment. This unit is compatible with the "InfoLITHIUM" battery pack (M series). Your camcorder operates only with the "InfoLITHIUM" battery. "InfoLITHIUM" M series battery packs have the () monormous mark. InfoLITHIUM" is a trademark of Sony Corporation.

## Пункт 1 Подготовка источника

#### Что такое "InfoLITHIUM"?

Что такое "InfoLITHIUM"?
"InfoLITHIUM" представляет собой литиевоионный батарейный блок, который может 
обмениваться данными, такими как 
потребление заряда батарейного блока, с 
совместимой электронной аппаратурой. Это 
устройство совместимо с батарейным блокой 
"InfoLITHIUM" (серии М). Ваша видеокамера 
работает только с батарейных блокам 
"InfoLITHIUM". На батарейных блокам 
"InfoLITHIUM" ммеется знак () 
"InfoLITHIUM" вириется отоговой маркой 
"InfoLITHIUM". Вариется 
"In "InfoLITHIUM" является торговой мар корпорации Sony Corporation.

#### Charging time/Время зарядки

Battery pack/	Full charge (Normal charge)/
Батарейный блок	Полная зарядка (нормальная зарядка)
NP-FM30 <sup>1)</sup>	145 (85)
NP-FM50 2)	150 (90)
NP-FM70	240 (180)
NP-FM90	330 (270)
NP-FM91	360 (300)

Approximate number of minutes to charge an empty battery pack at 25 °C (77 °F)

- Supplied with DCR-TRV230E/TRV325E/ TRV330E/TRV530E Supplied with DCR-TRV235E/TRV430E
- Приблизительное время в минутах для зарядки полностью разряженного батарейного блока при температуре 25 °C (77 °F)
- <sup>1)</sup> Прилагается к DCR-TRV230E/TRV325E/ TRV330E/TRV530E <sup>2)</sup> Прилагается к DCR-TRV235E/TRV430E

# Recording time/Время записи DCR-TRV230E/TRV235E/TRV325E/TRV330E

Recordin	g with	Recordin	g with
the view	finder/	the LCD :	screen/
		Запись с п	
видоисн	кателя	экрана	жкд
Continuous <sup>3)</sup> / Непрерывная <sup>3)</sup>	Typical <sup>4)</sup> / Типичная <sup>4)</sup>	Continuous <sup>3)</sup> / Непрерывная <sup>3)</sup>	ТурісаІ <sup>4)</sup> / Типичная <sup>4)</sup>
100	55	75	40
165	95	125	70
345	200	265	150
520	300	400	230
605	350	465	265
	the view Запись с п видоись  Сопtinuous®/ Непрерывная®  100  165  345  520	Непрерывная в 100         55           165         95           345         200           520         300	the viewFinder/ 3anuce or nowoulso         the LCD : 3anuce or nowoulso           βαρμονεκατεπικ         3anuce or nowoulso         Continuous³/           Continuous³/ Heripepsienar ³/ Tymrivinar °/ Heripepsienar ³/ Tymrivinar °/ 100         55         75           165         95         125           345         200         265           520         300         400

#### Step 1 Preparing the power supply

#### Пункт 1 Подготовка источника питания

#### DCR-TRV430E

	Recordin	g with	Recordin	g with
	the view	finder/	the LCD :	screen/
Battery pack/ Батарейный	Запись с п видоись		Запись с п экрана	
блок	Continuous <sup>3)</sup> / Непрерывная <sup>3)</sup>	ТурісаІ <sup>4)</sup> / Типичная <sup>4)</sup>	Continuous <sup>3)</sup> / Непрерывная <sup>3)</sup>	Typical <sup>4</sup> / Типичная
NP-FM30 <sup>1)</sup>	100	55	70	40
NP-FM50 2)	165	95	115	65
NP-FM70	345	200	245	140
NP-FM90	520	300	370	215
NP-FM91	605	350	430	250

## DCR-TRV530E

Battery pack/ Батарейный	the view Запись с п	Recording with the viewfinder/ Запись с помощью видоискателя		g with screen/ юмощью ЖКД
блок	Continuous <sup>3)</sup> / Непрерывная <sup>3)</sup>	Typical <sup>4)</sup> / Типичная <sup>4)</sup>	Continuous <sup>3)</sup> / Непрерывная <sup>3)</sup>	Typical <sup>4)</sup> / Типичная <sup>4)</sup>
NP-FM30 <sup>1)</sup>	100	60	70	40
NP-FM50 2)	165	105	115	65
NP-FM70	345	220	245	140
NP-FM90	520	335	370	210
NP-FM91	605	390	430	245

Approximate number of minutes when you use a fully charged battery

- upplied with DCR-TRV230E/TRV325E/ TRV330E/TRV530E Supplied with DCR-TRV235E/TRV430E
- Approximate continuous recording time at 25 °C (77 °F). The battery life will be shorter if you use your camcorder in a cold environment.
- Approximate number of minutes when recording while you repeat recording start/ stop, zooming and turning the power on/off. The actual battery life may be shorter.

Приблизительное время в минутах при использовании полностью заряженного батарейного блока

- <sup>1)</sup> Прилагается к DCR-TRV230E/TRV325E/ TRV330E/TRV530E <sup>2)</sup> Прилагается к DCR-TRV235E/TRV430E
- <sup>3)</sup> Приблизительное время непрерывной записи при температуре 25 °C (77 °F). При использовании видеокамеры в холодных условиях срок службы батарейного блока . будет короче.
- Приблизительное время в минутах при записи с неоднократным пуском/остановкой записи, наездом видеокамеры и включением/выключением питания Фактический срок службы заряда батарейного блока может быть короче.

	Playing time	Playing time
Battery pack/ Батарейный блок	on LCD screen/ Время воспроизведения на экране ЖКД	with LCD closed/ Время воспроизведения при закрытом ЖКД
NP-FM30 1)	75	100
NP-FM50 2)	125	165
NP-FM70	265	345
NP-FM90	400	520
NP-FM91	465	605

#### DCR-TRV430E/TRV530E

Battery pack/ Батарейный блок	Playing time on LCD screen/ Время воспроизведения на экране ЖКД	Playing time with LCD closed/ Время воспроизведения при закрытом ЖКД
NP-FM30 <sup>1)</sup>	70	100
NP-FM50 <sup>2)</sup>	115	165
NP-FM70	245	345
NP-FM90	370	520
NP-FM91	430	605

Approximate number of minutes when you use a fully charged battery

- Supplied with DCR-TRV230E/TRV325E/ TRV330E/TRV530E Supplied with DCR-TRV235E/TRV430E

Approximate continuous playing time at 25 °C (77 °F). The battery life will be shorter if you use your camcorder in a cold environment.

The recording and playing times of a normally charged battery are about 90 % of those of a fully charged battery.

Note
The table shows the playing time for tapes
recorded in the Digital8 13 system. The playing
time of tapes recorded in the Hi8/standard 8
system is reduced by about 20 %.

питания

Приблизительное время в минутах при использовании полностью заряженного батарейного блока

<sup>1)</sup> Прилагается к DCR-TRV230E/TRV325E/ TRV330E/TRV530E <sup>2)</sup> Прилагается к DCR-TRV235E/TRV430E

Приблизительное время непрерывного воспроизведения при температуре 25 °C (77 °F). При использовании видеокамеры холодных условиях срок службы батарей блока будет короче.

Время записи и воспроизведения нормальной заряженного батарейного блока составляет около 90 % времени полностью заряженного блока.

Примечание
Таблица показывает время воспроизведения
ленты, записанной в системе Digital8  $\{ b \}$ .
Время воспроизведения ленты, записанной в
системе Hill отандартной системе 8,
сократится на 20 %.

## Connecting to a wall socket

Step 1 Preparing the power

supply

When you use your camcorder for a long time, we recommend that you power it from a wall socket using the AC power adaptor.

(1) Open the DC IN jack cover, and connect the AC power adaptor to the DC IN jack on your camcorder with the plug's \( \Lambda \) mark facing up. (2) Connect the mains lead to the AC power

adaptor.
(3) Connect the mains lead to a wall socket.


#### Пункт 1 Подготовка источника питания

#### Подсоединение к сетевой розетке

Если Вы собираетесь использовать видеокамеру длительное время, рекомендуется использовать питание от сетевой розетки с помощью сетевого адаптера переменного тока.

- (1) Откройте крышку гнезда DC IN и подсоедините сетевой адаптер переменного тока к гнезду DC IN на Вашей видеокамеру, так чтобы знак **▲** на штекере был обращен вверх.
- штелере овит обращен вверх.
  (2) Подсоедините провод электропитания к сетевому адаптеру переменного тока.
  (3) Подсоедините провод электропитания к сетевой розетке.

сетевой розетке.





#### PRECAUTION

The set is not disconnected from the AC power source (the mains) as long as it is connected to a wall socket, even if the set itself has been turned

- The AC power adaptor can supply power even if the battery pack is attached to your
- camcorder.

  \* The DC IN jack has "source priority". This means that the battery pack cannot supply any power if the mains lead is connected to the DC IN jack, even when the mains lead is not plugged into a wall socket.

Using a car battery
Use Sony DC Adaptor/Charger (optional).

#### ПРЕДОСТЕРЕЖЕНИЕ

ПРЕДОСТЕРЕЖЕНИЕ
Аппарата не отключается от источника
переменного тока (электрической сети) до
тех пор, пока он подсоединен к сетевой
розетке, даже если сам аппарат и выключе

- **Примечания**Питание от сетевого адаптера переменного тока может подаваться даже в случае, если батарейный блок прикреплен к Вашей видеокамере. Гнездо DC IN имеет "приоритет источника"
- Это значит, что питание от батарейного блока не может подаваться, если провод электропитания подсоединен к гнезду DC IN, даже если провод электропитания и не подсоединен к сетевой розетке.

Использование автомобильного аккумулятора Используйте адаптер/зарядное устройство постоянного тока фирмы Sony (приобретается отдельно).

21

started

## Step 2 Setting the date and time

Set the date and time settings when you use your camcorder for the first time.

"CLOCK SET" will be displayed each time that you set the POWER switch to CAMERA or MEMORY (DCR-TRV325E/TRV330E/TRV430E/TRV430E) unless you set the date and time settings.

settings.

If you do not use your camcorder for about half a year, the date and time settings may be released (bars may appear) because the built-in rechargeable battery will have been discharged recharg (p. 195)

First, set the year, then the month, the day, the hour and then the minute.

- (1) Set the POWER switch to CAMERA or MEMORY (DCR-TRV325E/TRV330E/ TRV430E/TRV530E only), and then press MENU to display the menu settings.

  (2) Turn the SEL/PUSH EXEC dial to select
- then press the dial.

  (3) Turn the SEL/PUSH EXEC dial to select
- CLOCK SET, then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to adjust the
- (4) Turn the SEL/PUSH EXEC dial to adjust the desired year, then press the dial.
  (5) Set the month, day and hour by turning the SEL/PUSH EXEC dial and pressing the dial.
  (6) Set the minute by turning the SEL/PUSH EXEC dial and pressing the dial by the time signal. The clock starts to move.
  (7) Press MENU to make the menu settings discapped:

#### Пункт 2 Установка даты и времени

Выполните установку даты и времени, когда Вы используете Вашу видеокамеру в первый

Вы используете Вашу видеокамеру в первый раз. До тех пор, пока Вы не выполните установки даты и времени, каждый раз при установке переключателя РОWER в положение САМЕЯА или МЕМОЯУ (только модели DCR-TRV326E/TRV330 час и минуту.


- (1) Установите переключатель POWER в положение CAMERA или MEMORY (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E), а затем нажмите кнопку MENU для отображения установок меню.
  (2) Поверните диск SEL/PUSH EXEC для выбора
- (2) Поверните диск SEL/PUSH EXEC для вы индикации (글), а затем нажмите диск. (3) Поверните диск SEL/PUSH EXEC для выбора команды CLOCK SET, а затем нажмите лиск

- нажмите диск.

  (4) Поверните диск SEL/PUSH EXEC для выбора нужного года, а затем нажмите диск. (5) Установите месяц, день и час путем вращения диска SEL/PUSH EXEC и нажммания диска. (6) Установите минуты путем вращения диска SEL/PUSH EXEC и нажммания диска в момент передачи сигнала точного времени. Часы начнут функционировать. (7) Нажмите кнопку МЕNU для того, чтобы исчезли установки меню.

#### Step 2 Setting the date and time

#### Пункт 2 Установка даты и времени



The year changes as follows

няется следующим образом

1995 ← · · · · → 2001 ← · · · · → 2079

If you do not set the date and time
"-----" "-----" is recorded on the tape and the
"Memory Stick". (DCR-TRV325E/TRV330E/
TRV430E/TRV530E only)

Note on the time indicator The internal clock of your camcorder operates on a 24-hour cycle.

Если Вы не установили дату и время На ленту и "Memory Stick" будет записываться индикация "-- -- "
"-:--:-". (только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Примечание по индикатору времень Встроенные часы Вашей видеокамерь работают в 24-часовом режиме.

20

#### Step 3 Inserting a cassette

We recommend using Hi8 Hi B/Digital8 H video

(1) Prepare the power supply (p. 15).
(2) Slide OPEN/EJECT in the direction of the arrow and open the lid.
The cassette compartment automatically lifts up and opens.

The cassette compartment automatically up and opens.

(3) Insert the cassette in a straight line deeply into the cassette compartment with the window facing out.

Push the middle portion of the back of the

tusin the induction of the back of the cassette to insert.


(4) Close the cassette compartment by pressing the Fusil mark on the cassette compartment. The cassette compartment automatically goes

down.
(5) After the cassette compartment going down completely, close the lid until it clicks.

#### Пункт 3 Установка кассеты

Рекомендуется использовать видеокассеты типа Hi8 **III B**/Digital8 **I**).

- (1) Подготовьте источник питания (стр. 15). (2) Сдвиньте кнопку ОРЕN/ЕЈЕСТ в направлении, указанном стрелкой, и откройте крышку.
  Кассетный отсек автоматически
- Кассетный отсек автоматически поднимается и откроется (3) Установите кассету по прямой линии глубоко в кассетный отсек так, чтобы окошко было обращемо наружу. Нажмите на середину тыльной стороны кассеты для установки. (4) Закройте кассетный отсек, нажав метку шал на отсеке. Кассетный отсек автоматически закроется. (5) После того, как кассетный отсек полностью опустится, закройте крышку, какройте корыстура закройте крышку, закройте крышку, закройте крышку, закройте крышку, закройте крышку, закройте крышку, становительного становку в становку в
- полностью опустится, закройте крышку, чтобы она щелкнула.



#### To eject a cassette

Follow the procedure above, and eject the cassette in step 3.

#### Для извлечения кассеть

#### Step 3 Inserting a cassette

- Do not press the cassette compartment down.
- Doing so may cause malfunction. Your camcorder records pictures in the Digital8
- The recording time when you use your camcorder is 2/3 of indicated time on Hi8 Hi Stape. If you select the LP mode in the menu settings, the recording time is indicated time Hi8 Hi tape. • If you use standard 8 tape, be sure to play the recording time is indicated time on
- back the tape on this camcorder. Mosaic pattern noise may appear when you play back standard 8 🖪 tape on other camcorders (including other DCR-TRV230E/TRV235E/TRV325E/ TRV330E/TRV430E/TRV530E).
- The cassette compartment may not be closed when you press any part of the lid other than the FUSH mark.

To prevent accidental erasure Slide the write-protect tab on the cassette to expose the red mark.

#### Пункт 3 Установка кассеты

#### Примечания Не нажимайте вниз кассетный отсек. Это

- Примечания

  Не нажимайте вниз кассетный отсек. Это может привести к неисправности.

  Ваша видеокамера выполняет запись изображений в системе Digital8 t).

  Время записи при использовании Вашей ифоровой видеокамерь составляет 2/3 времени, указанного на ленте Hi8 HI8. Если Вы выберите режим LP в установких меню, то время записи будет равно времени, указанного на ленте Hi8 HI9. Если Вы используете стандартную ленту 8 В, то ее рекомендуется воспроизводить на этой же видеокамера Саписанные с помощью Вашей видеокамеры, на Вашей же видеокамера. В случае воспроизведения стандартных лент типа 8 В на других видеокамеры. В случае воспроизведения мозаичного типа (включая другие видеокамеры DCR-TRV230E/TRV235E/TRV235E/TRV330E/TRV3
- Кассетный отсек может не закрыться, если Вы нажмете на какое-либо другое место на крышке, а не на метку (РОЗН)

Для предотвращения случайного стира Передвиньте лепесток защиты записи на кассете, так чтобы появилась красная метка.



24 25

## — Recording - Basics —

## Recording a picture

Your camcorder automatically focuses for you.

- (1) Remove the lens cap by pressing both knobs on its sides and attach the lens cap to the grip strap.

  (2) Install the power source and insert a cassette. See "Step 1" to "Step 3" for more information (p. 15 to 25).

  (3) Set the POWER switch to CAMERA while pressing the small green button, Your
- pressing the small green button. Your camcorder is set to the standby mode.

  (4) Open the LCD panel while pressing OPEN.
- The viewfinder automatically turns off.


  (5) Press START/STOP. Your camcorder starts Press JARI/SIOF. Your camcorder starts recording. The REC indicator appears on the screen. The camera recording lamp located on the front of your camcorder lights up. To stop recording, press START/STOP again. The recording lamp lights up in the viewfinder when you record with the viewfinder.

Запись изображения

Ваша видеокамера автоматически выполняет фокусировку за Вас.

- (1) Снимите крышку объектива, нажав обе кнопки на ее кромке, и прикрепите крышку объектива к ремню для захвата. (2) Установите источник питания и вставьте
- кассету. См. "Пункт 1"– "Пункт 3" для получ
- случных сведений (стр. 15 21).
   (3) Нажав маленькую зеленую кнопку, установите переключатель POWER в положение САМЕЯА. Ваша видеокамера переключатель роменты в переключатель в положение САМЕЯА. Ваша видеокамера
- переключится в режим ожидания.
  (4) Нажав кнопку OPEN, откройте панель
  ЖКД. Видоискатель выключится автоматически.
- (5) Нажмите кнопку START/STOP. Ваша видеокамера начнет запись. На экране появится индикатор REC. Высветится также лампочка записи, расположен на передней панели видеокамеры. Для остановки запи STOP еще раз. овки записи нажмите кнопку START/

При записи с помощью видоискателя, внутри него высветится лампочка записи



## Recording a picture

 Fasten the grip strap firmly.
 Do not touch the built-in microphone during recording.

Note on Recording mode Your camcorder records and plays back in the SP (standard play) mode and in the LP (long play) mode. Select SP or LP in the menu settings mode. Select SP or LP in the menu settings (p. 107). In the LP mode, you can record 1.5 times as long as in the SP mode. When you record a tape in the LP mode on your camcorder, we recommend that you play back the tape on your camcorder.

Note on LOCK (DCR-TRV325E/TRV330E/ TRV430E/TRV530E only)
When you slide LOCK to the right, the POWER switch can no longer be set to MEMORY accidentally. The LOCK is released as a default setting.

To enable smooth transition
You can make the transition between the last
scene you recorded and the next scene smooth as
long as you do not eject the cassette if you turn
off your camcorder. When you change the
battery pack, set the POWER switch to OFF
(CHG).

#### If you leave your camcorder in the standby mode for 3 minutes

Your camcorder automatically turns off. This is to save battery power and to prevent battery and tape wear. To resume the standby mode, set the POWER switch to OFF (CHG) once, then turn it to CAMERA again.

When you record in the SP and LP modes on one tape or you record some scenes in the LP

mode
The playback picture may be distorted or the time code may not be written properly between

#### Запись изображения

- Плотно пристегните ремень для захвата видеокамеры
- Не прикасайтесь к встроенному микрофону во время записи

Примечание по режиму записи
Ваша видеокамера выполняет запись и воспроизведение в режиме SP (стандартное воспроизведение) и в режиме LP (долгоиграющее воспроизведение). Выберите команду SP или LP в установках меню (стр. 107). В режиме LP Вы можете выполнять запись в 1,5 раза дольше по времени, чем в режиме SP. При выполнении на Вашей видеокамере записи на ленту в режиме LP рекомендуется воспроизводить эту ленту также на Вашей видеокамере.

# Примечание по режиму LOCK (Только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E)

ТRV\$30E) Если Вы передвинете переключатель LOCK вправо, переключатель POWER уже не может быть случайно установлен в положение MEMORY. Режим LOCK будет устанавливаться по умолчанию.

#### Для обеспечения плавного перехода Вы можете выполнять плавный переход

между последним записанным эпизодом и следующим эпизодом до тех пор. пока не извлечете кассету при выключенном питании. При замене батарейного блока установите переключатель POWER в положение OFF (CHG).

## Если Вы оставите Вашу видеокамеру в режиме ожидания на 3 минуты

Вилеокамера выключится автоматически Видеокамера выключится автоматически. Это предотвращает раскод заряда батарейного блока и износ ленты. Для возобновления режима ожидания установите сначала переключатель РОWER в положение OFF (CHG), а затем снова поверните его в

При выполнении записи в режимах SP и LP на одной ленте или же при записи нескольких эпизодов в режиме LP Воспроизводимое изображение может быть искажено или же код времени может не записываться надлежащим образом между эпизодами.

26

side.

If you turn the LCD panel over so that it faces the other way, the ③ indicator appears on the LCD screen and in the viewfinder (Mirror mode).

## Запись изображения

#### Регулировка экрана ЖКД

ель ЖКД может передвигаться примерно (Зеркальный режим)



When closing the LCD panel, set it vertically until it clicks, and swing it into the camcord body.

When using the LCD screen except in the mirror mode, the viewfinder automatically turns off.

When you use the LCD screen outdoors in sunlight

The LCD screen may be difficult to see. If this happens, we recommend that you use the viewfinder.

When you adjust angles of the LCD panel Make sure if the LCD panel is opened up to 90 degrees.

Picture in the mirror mode

The picture on the LCD is a mirror-image. However, the picture will be normal when recorded.

During recording in the mirror mode You cannot operate the ZERO SET MEMORY on the Remote Commander.

Indicators in the mirror mode

The STBY indicator appears as **II●** and REC as **●**. Some of other indicators appear mirror-reversed and others are not displayed.

When recording with the LCD panel opened Recording time becomes shorter a little compared with when recording with the LCD panel closed.

нии панели ЖКД установите ее вертикально, пока не раздастся шелчок, а затем присоедините ее к корпусу видеокамеры.

При использовании экрана ЖКЛ искатель автоматически

Если Вы используете экран ЖКД вне **щения под прямым солнечным св** ожно будет трудно разглядеть экран ЖКД. В этом случае рекомендуется использовать видоискатель.

Когда Вы регулируете углы панели ЖКД Убедитесь, что панель ЖКД открыта не Убедитесь, что панель ЖК более чем на 90 градусов.

Изображение в зеркальном режиме Изображение на экране ЖКД будет отображаться зеркально. Однако запись изображения будет нормальной.

Во время записи в зеркальном режиме Вы не можете оперировать кнопкой ZERO SET MEMORY на пульте дистанционного

Индикаторы в зеркальном режиме Индикатор STBY появится в виде II • а индикатор REC в виде • Некоторые другие индикатор REC виде • Некоторые другие индикаторы появятся в зеркально отображенном виде, а некоторые из них не будут отображаться совсем.

При записи с открытой панелью ЖКД Время записи при открытой панели ЖКД несколько уменьшается по сравнению с записью при закрытой панели ЖКД.

#### Recording a picture

Brightness of the LCD screen

ess of the LCD screen Select LCD B.L. or LCD BRIGHT in the m settings (p. 107). Even if you adjust the LCD B.L. or LCD BRIGHT, the recorded picture will not be

#### After recording

(1) Set the POWER switch to OFF (CHG).(2) Close the LCD panel.(3) Eject the cassette.

#### Using the zoom feature

Move the power zoom lever a little for a slower zoom. Move it further for a faster zoom. Using the zoom function sparingly results in better-looking recordings.

"I" side: for telephoto (subject appears closer)

"W" side: for wide-angle (subject appears farther away)

#### Запись изображения

#### Яркость экрана ЖКД

Яркость экрана жл.д Вы можете отретулировать яркость экрана ЖКД Выберите пункт LCD В.L или LCD BRIGHT в установках меню (стр. 107). Даже если Вы отретулируете пункты LCD В.L или LCD BRIGHT, это не повлияет на записанное изображение.

#### После записи

(1) Установите переключатель POWER в положение ОFF (CHG).
(2) Закройте панель ЖКД.
(3) Извлеките кассету.

## Использование функции наезда

Передвиньте рычаг приводного вариообъектива слегка для относительно медленного наезда видеокамеры. Передвиньте его сильнее для ускоренного

передвиньте его сильнее для ускоренно наезда видеокамеры. Использование функции наезда видеок: в небольшом количестве обеспечивает наилучшие результаты. Сторона "Т": для телефото (объект

приближается) Сторона "W": для широкоугольного вида (объект удаляется)

Zoom greater than 25× is performed digitally. To activate digital zoom, select the digital zoom power in D ZOOM in the menu settings. (p. 107) The picture quality deteriorates as the picture is processed digitally

Наезд видеокамеры более 25× выполняется Наезд видеокамеры более 25х выполняется ифровым методом. Для приведения в действие цифрового варисобъектива выберите приводной цифрового варисобъектив D ZOOM в установках меню (стр. 107). Поскольку обработка изображения выполняется цифровым способом, качество изображения несколько ухудшится.

The right side of the bar shows the digital zooming zone. The digital zooming zone appears when you select the digital zoom power in D ZOOM in the menu settings./ Правая сторона полосы на экране показывает зону цифровой трансфокации. Если Вы выберите приводной цифровой вариообъектив D ZOOM в установках меню,

появится зона цифровой трансфокации

word)

29

## Recording a picture

Notes on digital zoom

28

- Digital zoom starts to function when zoom exceeds 25x.

   The picture quality deteriorates as you go toward the "T" side.

When you shoot close to a subject

When you shoot close to a subject If you cannot get a sharp focus, move the power zoom lever to the "W" side until the focus is sharp. You can shoot a subject that is at least about 80 cm (about 2 feet 5/8 inch) away from the lens surface in the telephoto position, or about 1 cm (about 1/2 inch) away in the wideangle position.

# To record pictures with the viewfinder - adjusting the viewfinder

If you record pictures with the LCD panel closed, check the picture with the viewfinder. Adjust the viewfinder lens to your eyesight so that the indicators in the viewfinder come into sharp

Lift up the viewfinder and move the viewfinder lens adjustment lever.

## Запись изображения

#### Примечания к наезду видеокамеры ифровым методом

- Цифровой вариообъектив начинает срабатывать в случае, если наезд видеокамеры превышает 25×.
- Качество изображения ухудшается по мере приближения к стороне "T".

#### При съемке объекта с близкого положения Если Вы не можете получить четкой

Если Вы не можете получить четкой фокусировки, передвиньте рычаг приводного вариообъектива сторону "W" до получения четкой фокусировки. Вы можете выполнять съемку объекта в положении телефото, который отстоит по крайней мере на расстоянии 80 см от поверхности объектива или же около 1 см в положении широкоугольного вида.

## Для записи изображений с помощью видоискателя - регулировка видоискателя

Если Вы будете записывать изображения при закрытой панели ЖКД, проверьте изображение с помощью видоискателя. Отрегулируйте объектив видоискателя в соответствии со своим зрением, так чтобы индикаторы в видоискателе были четко

Поднимите видоискатель и подвигайте рыча регулировки объектива видоискателя



Viewfinder backlight You can change the brightness of the backlight. Select VF B.L. in the menu setings. (p. 107)



Задняя подсветка видоискателя Вы можете изменять яркость задней подсветки. Выберите команду VF В.L. в установках меню (стр. 107).

## Recording a picture

#### Indicators displayed in the recording mode

The indicators are not recorded on tape

# Индикаторы, отображаемые в

Индикаторы не записываются на ленту

Запись изображения

Remaining battery time indicator/Индикатор вре оставшегося заряда батарейного блока Format indicator/Индикатор формата Recording mode indicator/Индикатор рех STBY/REC indicator/Индикатор STBY/REC

Time code/Tape counter indicator/Код врег

Remaining tape indicator/Индикатор оставшейся ленты This appears after the POWER switch is set to CAMERA for a while./ Эта индикация появится после того, как переключатель POWER будет установлен на какое-то время в положение CAMERA.

Time indicator/Индикатор времени
This is displayed for five seconds after the POWER switch is set to CAMERA
or MEMORY (DCR-TRV358E/TRV330E/TRV430E/TRV530E only). /Он
отображается около пяти секунд после того, как переключатель
POWER установлен в положение САМЕRA или МЕМОRY (только
модели DCR-TRV325E/TRV330E/TRV430E/TRV530E).

модели UCH-1RV332E/1RV430E/1RV430E/1RV430E/.

Date Indicator/Индикатор даты

This is displayed for five seconds after the POWER switch is set to

CAMERA or MEMORY (DCP-TRV432E/TRV430E/TRV430E/TRV530E

only)./Он отображается около пяти секунд после того, как
переключатель POWER тустановлен в положение CAMERA или

MEMORY (только модели DCR-1RV32E/TRV330E/TRV430E/

TRV530E).

Remaining battery time indicator

4 7 2001 12:05:56

The remaining battery time indicator roughly indicates the recording time. The indicator may not be correct, depending on the conditions in which you are recording. When you close the LCD panel and open it again, it takes about one minute for the correct remaining battery time in minutes to be displayed.

Time code (for tapes recorded in the Digital8

Time code (for tapes recorded in the Digital8 H system only)
The time code indicates the recording or playback time, "0.00:00" (hours:minutes: seconds) in CAMERA mode and "0.00:00.00" (hours:minutes:seconds:frames) in PLAYER or VCR (DCR-TRV330E only) mode. You cannot rewrite only the time code.
When you play back tapes recorded in the Hi8/ standard 8 system, the tape counter appears on the screen.

the screen. You cannot reset the time code or the tape

Индикатор времени оставшегося заряда батарейного блока Индикатор времени оставшегося заряда батарейного блока приблизительно уставшее оставшее свремя записи. Индикатор может быть неточным в индикатор может быть неточным в зависимости от условий, в которых Вы производите запись. Когда Вы закрыва панель ЖКД и открываете е 6-нова, требуется около одной минуты для правильного отображения оставшегося времени работы батарейного блока в минутах.

минутах. Код времени (только для лент, записанных в цифровой системе Digital8 F) Код времени указывает время записи или воспроизведения, "0:00:00" (часы: минуты: секунды) в режиме САМЕЯА и "0:00:00:00" (часы: минуты: секунды: кадры) в режиме PLAYER или VCR (только модель DCR-ТRV330E). Вы не можете перезаписать только код времени. Когда Вы воспроизводите ленты, записанные в системе НВ/Стандартной системе 8, на экране появляется счетчик ленты. Вы не можете переустановить код времени или счетчик ленты.

#### Recording a picture

## Shooting backlit subjects - BACK LIGHT

When you shoot a subject with the light source background, use the backlight function

Press BACK LIGHT in CAMERA or MEMORY (DCR-TRV325E/TRV330E/TRV430E/TRV530E

The ☑ indicator appears on the screen.
To cancel, press BACK LIGHT again.


## Съемка объектов с задней подсветкой – ВАСК LIGHT Если Вы выполняете съемку объекта с

Запись изображения

объекта со светлым фоном, используйте функцию задней подсветки Нажмите кнопку BACK LIGHT в режиме

CAMERA или MEMORY (Тол DCR-TRV325E/TRV330E/TRV430E/TRV530E only). На экране появится индикатор 🖪

а экране появится индикатор டв. пя отмены нажмите кнопку BACK LIGHT це раз.



If you press EXPOSURE when shooting backlit subjects
The backlight function will be canceled.

Если вы нажмете кнопку EXPOSURE при выполнении съемки объектов с задней подсветкой обункция задней подсветки будет отменена

# Shooting in the dark - NightShot/Super NightShot

Recording a picture

The NightShot function enables you to shoot a subject in a dark place. For example, you car satisfactorily record the environment of nocturnal animals for observation when you use

While your camcorder is in CAMERA or MEMORY (DCR-TRV325E/TRV330E/TRV430E/TRV530E only) mode, slide NIGHTSHOT to ON. © and "NIGHTSHOT" indicators flash on the screen.


screen. To cancel the NightShot function, slide NIGHTSHOT to OFF.

## Съемка в темноте - Ночная съемка/Ночная суперсъемка Функция ночной съемки позволяет Вам

выполнять съемку объектов в темных местах. Например, Вы сможете с успехом выполнять съемку ночных животных для наблюдения при использовании данной функции.

В то время, когда видеокамера находится в режиме CAMERA или MEMORY (только модели DCR-TRV325E/TRV330E/TRV430E/ мигать на экране.

Для отмены функции ночной съемки передвиньте переключатель NIGHTSHOT в положении OFF.



## Using SUPER NIGHTSHOT

The Super NightShot mode makes subjects up to 16 times brighter than those recorded in the NightShot mode.

- (1) Slide NIGHTSHOT to ON in CAMERA mode. and "NIGHTSHOT" indic screen.
- SCIECH.

  (2) Press SUPER NIGHTSHOT. S

  and "SUPER NIGHTSHOT" indicators flash on the screen.

  To cancel the Super NightShot mode, press SUPER NIGHTSHOT again.

#### Using the NightShot Light

The picture will be clearer with the NightShot Light on. To enable NightShot Light, set N.S.LIGHT to ON in the menu settings (p. 107).

#### ование режима SUPER NIGHTSHOT

Режим ночной суперсъемки позволяет сделать объекты более чем в 16 раз ярче, чем в случае, если Вы будете выполнять съемку в темноте в режиме ночной съемки

- "NIGHTSHOT".
  (2) Нажимте кнопку SUPER NIGHTSHOT. На экране начнут мигать индикаторы S® и "SUPER NIGHTSHOT".
  Для отмены режима ночной суперсъемки нажмите кнопку SUPER NIGHTSHOT еще

## Использование подсветки для ночной

съемки Изображение станет ярче, если включить функцию ночной подсветки. Для включения функции ночной подсветки установите переключатель N.S.LIGHT в положение ON в установках меню (стр. 107).

32

## Recording a picture

#### Notes

- Do not use the NightShot function in bright places (ex. outdoors in the daytime). This may cause your camcorder to malfunction.
- When you keep NIGHTSHOT set to ON in normal recording, the picture may be recorded in incorrect or unnatural colours.
- in incorrect or unnatural colours.
   If focusing is difficult with the autofocus mode when using the NightShot function, focus manually.

While using the NightShot function, you can not use the following functions:

- Exposure

- PROGRAM AE

While using the Super NightShot function, you can not use the following functions:

- Fader
- Digital effect

- Exposure PROGRAM AE

Shutter speed in the Super NightShot mode The shutter speed will be automatically changed depending on the brightness of the background. The motion of the picture will be slow.

# In MEMORY mode (DCR-TRV325E/TRV330E/TRV430E/TRV530E only) You cannot use the Super NightShot function.

#### NightShot Light

NightShot Light rays are infrared and so are invisible. The maximum shooting distance using the NightShot Light is about 3 m (10 feet)

#### Запись изображения

- Не используйте функцию ночной съемки в ярких местах (например, на улице в дневное время). Это может привести к еисправности Вашей вилеокамерь
- При удержании установки NIGHTSHOT в положении ОN при нормальной записи изображение может быть записано в неправильных или неестественных цветах.
- Если фокусировка затруднена в автоматическом режиме при использо функции ночной съемки, выполните фокусировку вручную.

– Экспозиция – PROGRAM AE

При использовании функции ночной суперсъемки Вы не можете использ следующие функции:

- Цифровой эффект
- Экспозиция PROGRAM AE

## Скорость затвора в режиме ноч

Скорость затвора будет автоматически изменяться в зависимости от яркости фона Воспроизведение изображения будет

# В режиме MEMORY (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E)

Подсветка для ночной съемки
Лучи подсветки для ночной съемки являются
инфракрасными и поэтому невидимыми.
Максимальное расстояние для съемки при
использовании подсветки для ночной съемки

## Recording a picture Self-timer recording

## DCR-TRV325E/TRV330E/TRV430E/

Recording with the self-timer starts in 10 seconds automatically. You can also use the Remote Commander for this operation.

- (1) Press MENU to display the menu settings in

- (1) Press MENU to display the menu settings in the standby mode.

  (2) Turn the SEL/PUSH EXEC dial to select then press the dial.

  (3) Turn the SEL/PUSH EXEC dial to select SELFIIMER, then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select ON, then press the dial.

  (5) Press MENU to make the menu settings disappear.

- (s) Press MENU to make the menu settings disappear.

  (b) Press START/STOP.
  Self-timer starts counting down from 10 with a beep sound. In the last two seconds of the countdown, the beep sound gets faster, then recording starts automatically. To stop recording, press START/STOP again.

#### Запись изображения

## Запись по таймеру самозапуска

# - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Запись с помощью таймера самозапу начнется через 10 секунд автоматич Для этой операции Вы можете также использовать пульт дистанционного

- (1) Нажмите кнопку MENU для отображения установок меню в режиме ожидания.
  (2) Поверните диск SEL/PUSH EXEC для выбора установки 📆 , затем нажмите на
- выоора установки [32], ЗаТем нажмите на диск.

  (3) Поверните диск SEL/PUSH EXEC для выбора установки SELFTIMER, затем нажмите на диск.

  (4) Поверните диск SEL/PUSH EXEC для выбора установки ОN, затем нажмите на диск.

  (5) Нажмите кнопку MENU для исчезновения установку мени.

- установок меню. (6) Нажмите кнопку START/STOP Таймер самозапуска начнет обратный отсчет от 10 с зуммерным сигналом. В последние две секунды обратного отсчета зуммерный сигнал будет звучать чаще, а затем автоматически начнется запись.

Для остановки записи снова нажмите кнопку START/STOP.

6 START/STOP 2-4 START/STOP CAMERA SET SELFTIMER DFF 1,5 MENU

#### Recording a picture

## To stop the countdown Press START/STOP.

To restart the countdown, press START/STOP

## To record still images using the self-

Press PHOTO in step 6. (p. 50)

# To cancel self-timer recording Set SELFTIMER to OFF in the menu settings in

the standby mode.

Note The self-timer recording mode is automatically

- cancelled when:

   Self-timer recording is finished.

   The POWER switch is set to OFF (CHG),
  PLAYER or VCR (DCR-TRV330E only).

Self-timer memory photo recording (DCR-TRV325E/TRV330E/TRV430E/TRV530E only) You can also record still images on "Memory Stick"s with the self-timer (p. 133).

#### Запись изображения

Для остановки обратного отсчета Нажмите кнопку START/STOP. Для перезапуска обратного отсчета нажмите опку START/STOP еще раз.

# Для записи неподвижных изображений с помощью таймера самозапуска Нажмите кнопку РНОТО в пункте 6. (стр. 50)

#### Для отмены записи по таймеру самозапуска

Установите пункт SELFTIMER в установках меню в положение OFF в режиме ожидания

Примечание
Режим записи по таймеру самозапуска будет
автоматически отменен в случаях:
– Окончания записи по таймеру самозапуска.
– Переключатель РОМЕЯ установлен в положение ОFF (CHG), PLAYER или VCR (только модель DCR-TRV330E).

## Фотосъемка в память по тай Фотосъемка в память по таимеру самозапуска (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E)

Вы можете также записывать неподвижных изображения на "Memory Stick" с помощьно таймера самозапуска (стр. 133).


## Checking the recording END SEARCH/EDITSEARCH/Rec

You can use these buttons to check the recorded picture or shoot so that the transition between the last recorded scene and the next scene you record is smooth.

#### Проверка записи END SEARCH/EDITSEARCH/ Просмотр записи

Вы можете использовать эти кнопки для проверки записанного изображения или съемки, так чтобы переход между послед записанным эпизолом и следующ

ging,



#### END SEARCH

You can go to the end of the recorded section after you record.

Press END SEARCH in the standby mode The last 5 seconds of the recorded section The last 5 seconds of the recorded section are played back and returns to the standby mode. You can monitor the sound from the speaker or headphones.

#### EDITSEARCH

You can search for the next recording start point.

Hold down the +/- (s) side of EDITSEARCH in the standby mode. The recorded section is played back.

+: to go forward

-: to go backward Release EDITSEARCH to stop playback. If you press START/STOP, re-recording begins from the point you released EDITSEARCH. You cannot monitor the sound.

#### **END SEARCH**

Вы можете дойти до конца записанной части ленты после выполнения записи.

Нажмите кнопку END SEARCH в режиме пажми е кнопку в по състанот в режиме 5 секунд, после чего видеокамера вернется в режим ожидания. Вы можете контролировать звук через динамик или головные телефоны.

#### EDITSEARCH

Вы можете выполнять поиск места начала следующей записи.

Держите нажатой сторону +/- (ⓐ) кнопки EDITSEARCH в режиме ожидания. Будет воспроизведена записанная часть. +: для продвижения вперед

- -: для продвижения назад Отпустите кнопку EDITSEARCH для остановки воспроизведения. Если Вы нажмете кнопку START/STOP, начнется перезапись с того места, где Вы отпустили кнопку EDITSEARCH. Вы не можете контполировать звук

37 36

# Checking the recording - END SEARCH/EDITSEARCH/Rec

#### **Rec Review**

You can check the section which you have stopped most recently

Press the - (🖘) side of EDITSEARCH Press the - (iii) side of EDITSEARCH momentarily in the standby mode. The section you have stopped most recently will be played back for a few seconds, and then your camcorder will return to the standby mode. You can monitor the sound from the speaker or beach shore.

- END SEARCH, EDITSEARCH and Rec Review work only for tapes recorded in the Digital8 [
- work only for tapes recorded in the Digitals 19 system.

  If you start recording after using the end search function, occasionally, the transition between the last scene you recorded and the next scene may not be smooth.

  Once you eject the cassette after you have recorded on the tape, the end search function does not work.

If a tape has a blank portion in the recorded

The end search function may not work correctly.

## Проверка записи – END SEARCH/EDITSEARCH/ Просмотр записи

#### Просмотр записи

Вы можете проверить последнюю записанную часть.

Нажмите кратковременно сторону – (©) кнопки EDITSEARCH в режиме ожидани Будут воспроизведены последние несколько секунд записанной части. Вы можете секунд записанной части. Вы можете контролировать звук через акустическую систему или головные телефоны.

- Примечания
   Функции END SEARCH, EDITSEARCH и просмотра записи работают только для лент, записанных в цифровой системе Digital8 1).
- Если Вы случайно начали запись после использования функции поиска конца записи, то переход между последним записанным эпизодом и следующим записываемым эпизодом может не быть
- Если Вы вытолкните кассету после того, как будет выполнена запись на ленте, функция поиска конца записи не будет

Если на ленте между записанными частями имеется незаписанный участок Функция поиска может не работать.

## — Playback - Basics —

## Playing back a tape

You can monitor the playback picture on the LCD screen. If you close the LCD panel, you can monitor the playback picture in the viewfinder. You can control playback using the Remote Commander supplied with your camcorder.

- (1) Install the power source and insert the
- recorded tape.
  (2) Set the POWER switch to PLAYER or VCR
  (DCR-TRV330E only) while pressing the small

- (B) Charlevison only while pressing the shad green button.

  (3) Open the LCD panel while pressing OPEN.
  (4) Press 

  to rewind the tape.
  (5) Press 

  to start playback.
  (6) To adjust the volume, press either of the two buttons on VOLUME. The speaker on your camcorder is silent when the LCD panel is

# Воспроизведение ленты

Вы можете контролировать воспроизводимое изображение на экране ЖКД. Если Вы закроете панель ЖКД. Вы можете контролировать воспроизводимое изображение в видоискателе. Вы можете контролировать воспроизведение с помощью пупьта дистанционного управления, прилагаемого к Вашей видеокамере.


- (1) Установите источник питания и вставьте
- Установите источник питания и вставь записанную ленту.
   Нажав маленькую эленую кнопку, установите переключатель РОWER в положение РLAYER или VCR (только модель DCR-TRV330E).
   Нажав кнопку OPEN, откройте панель укля и питания и п
- жкд

- ЖКД

  (4) Нажмите кнопку ◀◀ для ускоренной перемотки ленты назад.

  (5) Нажмите кнопку ▶ для включения воспроизведения.

  (6) Для регулировки громкости нажимайте одну из двух кнопок VOLUME. Если пане. ЖКД на Вашей видеокамере закрыта, динамик не будет работать.



To stop playback

Для остановки воспроизведения

38 39

1-8

Воспроизведение ленты

Во время контроля на экране ЖКД

# To display the screen indicators - Display function

Press DISPLAY on your camcorder or the Remote Commander supplied with your

The indicators appear on the screen To make the indicators disappear, press DISPLAY again.

#### Для отображения экранных индикаторов – Функция индикации

Нажмите кнопку DISPLAY на Вашей амере или на пульте дистанцион ения, который прилагается к Вац

лане ЖКЛ появятся инликаторы. Лля На экране ЖКД появятся индикаторы того, чтобы индикаторы исчезли, нажнеще раз кнопку DISPLAY.



#### Using the data code function

Your camcorder automatically records not only images on the tape but also the recording data (date/time or various settings when recorded) (Data code). Use the Remote Commander for this operation.

Press DATA CODE on the Remote Commander

in the playback mode.
The display changes as follows:
date/time → various settings (SteadyShot,
exposure AUTO/MANUAL, white balance, gain, shutter speed, aperture value) → no indicato

#### Использование функции кода даты

Ваша видеокамера автоматически записывает не только изображения на ленту записывает не только изооражения на ленту, но также и данные записи (дату/время или разные установки при записи). (Код даты). Используйте пульт дистанционного управления для этой операции.

# Нажмите кнопку DATA CODE на пульто дистанционного управления в режиме воспроизведения. Индикация будет изменяться следующим образами.

дата/время → разные установки (устойчива съемка, экспозиция AUTO/MANUAL, баланс белого, усиление, скоростъ затвора, величин диафрагмы) → без индикации

#### Playing back a tape

#### Date/time/ Дата/время



[a] SteadyShot off indicator

- [b] Exposure mode indicator [c] White balance indicator [d] Gain indicator

- [e] Shutter speed indicator [f] Aperture value

Not to display various settings Set DATA CODE to DATE in the menu settings

(p. 107).
The display changes as follows:

3-ta/time → no indicator

#### Notes on the data code function

- The data code function works only for tapes recorded in the Digitals D system.
  Various settings of the recording data are not
- recorded when recording images on "Memory Stick" (DCR-TRV325E/TRV330E/TRV430E/ TRV530E only).

#### Recording data

Recording data is your camcorder's information when you have recorded. In the recording mode, the recording data will not be displayed.

When you use data code function, bars

- ----- and --:---) appear if:

  A blank section of the tape is being played
- The tape is unreadable due to tape damage or
- The tape was recorded by a camcorder without the date and time set.

Data code When you connect your camcorder to the TV, the data code appears on the TV screen.

#### Воспроизведение ленты

#### Various settings/



- [b] Индикатор режима экспозиции[c] Индикатор баланса белого
- [d] Индикатор усиления
- [e] Индикатор скорости затвора[f] Величина апертуры

## Для того, чтобы не отоб

Индикация будет изменяться следующим

дата/время → без индикации

#### Примечания по функции кода данных

- Функция кода данных работает только для лент, записанных в цифровой системе Digital8 [ ).
- Разные установки данных записи не записываются при записи изображений на "Memory Stick" (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E).

#### Записанные данные

Записанные данные несут информацию о записи, выполненной Вашей видеокамерой. В режиме записи данные отображаться не будут

- Если Вы используете функцию кода данных, то появятся полосы (-- -- -- или : -- : --), если: Воспроизводится незаписанный участок на
- Лента является не читаемой из-за повреждения или помех.
- Запись на ленту была выполнена видеокамерой без установки даты и времени

данных и Вы подсоедините Вашу видеокамеру и ввизору, на экране появится код данны

## 40

#### Playing back a tape

Remaining battery time indicator during

playback
The indicator indicates the approximate
continuous playback time. The indicator may ne
be correct, depending on the conditions in whic
you are recording. When you close the LCD
panel and open it again, it takes about 1 minute
for the correct remaining battery time to be
displayed

## Various playback modes

To operate video control buttons, set the POWER switch to PLAYER or VCR (DCR-TRV330E only).

## To view a still image (playback pause) Press II during playback. To resume playback, press II or ▶.

# To advance the tape Press ▶ in the stop mode. To resume normal playback, press ▶.

To rewind the tape

## Press in the stop mode. To resume normal playback, press ▶.

# To change the playback direction Press < on the Remote Commander during playback to reverse the playback direction. To resume normal playback, press ►. To locate a scene monitoring the

picture (picture search)

Keep pressing ◀◀ or ▶▶ during playback. To resume normal playback, release the button.

## To monitor the high-speed picture while advancing or rewinding the

tape (skip scan)
Keep pressing ◀ while rewinding or ▶ while advancing the tape. To resume rewinding or advancing, release the button.

#### Воспроизведение пенты

Индикатор оставшегося времени батарей

Индикатор показывает приблизительное время непрерывного воспроизведения. Индикация может быть неточной, в зависимости от условий, в которых Вы проводите запись. Когда Вы закрываете панель ЖКД и открываете её снова, требуется около одной минуты для правильного отображения оставшегося времени работы батарейного блока в минутах.

## Переменные режимы воспроизведения

Для использования кнопок управления видео установите переключатель POWER в положение PLAYER или VCR (только модель DCR-TRV330E).

## Для просмотра изображения (пауза воспроизведения)

Нажмите во время воспроизведения кнопку

■. Для возобновления обычного воспроизведения нажмите кнопку

■. Или кнопку

■.

#### Для ускоренной перемотки ленты вперед Нажмите в режиме остановки кнопку ►► Для возобновления обычного воспроизведения нажмите кнопку

Для ускоренной перемотки ленты назад Нажмите в режиме остановки кнопку ◀◀. Для возобновления обычного воспроизведения нажмите кнопку ►.

Для изменения направления воспроизведения
Нажмите кнопку < на пульте дистанционног 
управления во время воспроизведения для 
изменении направления воспроизведения. 
Для возобновления обычного воспроизведения, отпустите кнопку

# Для отыскания эпизода во время контроля изображения (поиск изображения) Держите нажатой кнопку ◀◀ или ▶▶ во время всогроизведения. Для восстановления обычного воспроизведения отпустите кнопку.

Для контроля изображения на высокой скорости во время ускоренной перемотки ленты вперед или назад (поиск методом прогона) Держите нажатой кнопку ≪ во время ускоренной перемотки ленты назад или кнопку в> во время ускоренной перемотки ленты вазеред. Для возобновления обычной перемотки

еред или назад отпустите кнопку.

#### Playing back a tape

view the picture at slow speed

(slow playback)
Press ▶ on the Remote Commander during
playback. For slow playback in the reverse
direction, press <, then press ▶ on the Remote
Commander. To resume normal playback, press

#### To view the picture at double speed Press ×2 on the Remote Commander duri

playback. For double speed playback in the reverse direction, press <, then press ×2 on the Remote Commander. To resume normal

# To view the picture frame-by-frame Press II▶ on the Remote Commander in the playback pause mode. For frame-by-frame playback in the reverse direction, press ◄II. To resume normal playback, press ▶.

# To search the last scene recorded (END SEARCH) Press END SEARCH in the stop mode. The last 5

seconds of the recorded section plays back and stops.

- In the various playback modes

  Noise may appear when your camcorder plays back tapes recorded in the Hi8/standard 8 system.

  Sound is muted.

  The previous recording may appear as a mosaic image when playing back in the Digital8 [1] system.

#### Notes on the playback pause mode

- when the playback pause mode lasts for 3 minutes, your camcorder automatically enters the stop mode. To resume playback, press ►.

   The previous recording may appear.

# Slow playback for tapes recorded in the

Digitals () system
The slow playback can be performed smoothly
on your camcorder; however, this function does not work for an output signal from the DV OUT or DV IN/OUT jack.

When you play back a tape in reverse Horizontal noise may appear at the center or top and bottom of the screen. This is not a malfunction.

#### Воспроизведение ленты

Для просмотра воспроизведения изображения на замедленной ск

изображения на замедленной скорости (замедленное воспроизведение) Нажмите во время воспроизведения кнопку № на пульте дистанционног управления. Для замедленного воспроизведения в обратном направлении нажмите кнопку — а затем нажмите кнопку № на пульте дистанционного управления. Для возобновления обычного воспроизведения нажмите кнопку №.

# Для просмотра воспроизведения изображения на удвоенной скорости Нажмите кнопку ×2 на пульте дистанционног правления во время воспроизведения. Для воспроизведения. Для воспроизведения на удвоенной скорости в обратном направлении нажмите кнопку ×, а затем кнопку ×2 на пульте дистанционного управления. Для возобновления обычного воспроизведения нажмите кнопку ▶...

## Для покадрового просмотра

для покадрового просмотра воспроизведения изображения Нажмите кнопку III» на пульте дистанционного управления в режиме паузы воспроизведения. Для покадрового воспроизведения в обратнов направлении нажмите кнопку ◀II. Для возобновления обычного воспроизведения нажмите кнопку ▶..

Для поиска последнего записанного эпизода (END SEARCH)
Нажмите кнопку END SEARCH в режиме остановки. Будут воспроизведены последние 5 секунд записанного участка на ленте, после чего воспроизведение остановится.

- В переменных режимах воспроизведения
   При воспроизведении на видеокамере лент
  Н8/8 могут говянтася помехи
   Звук будет приглушен.
   При воспроизведений и цифровой системе
  Digitale 15 изображение предърждицих
  записей может стать мозаичным.

- Примечания по режиму паузы воспроизведения
   Если режим паузы воспроизведения
  продлится около 3 минут, Ваша видеокамера
  автоматически войдет в режим остановки.
  Для возобновления воспроизведения
- Для возобновления воспроизведения нажмите кнопку ►. Может появиться предыдущая запись

педленное воспроизведение для лент, исанныз в цифровой системе Digital8 [ ) манидиненное воспроизведение может выполняться на Вашей видеокамере без помех; однако эта функция не работает для выходного сигнала через гнездо DV ОUТили DV IN/OUT.

## При воспроизведении ленты в обратном


направлении
На экране могут появиться горизонтальные помехи по центру или же вверху и внизу экрана. Это не является неисправностью.

41

43

Connect your camcorder to your TV with the A/V connecting cable supplied with your camcorder to watch the playback picture on the TV screen. You can operate the playback control buttons in the same way as when you monitor playback pictures on the LCD screen. When monitoring the playback picture on the TV screen, we recommend that you power your camcorder from a wall socket using the AC power adaptor (p. 21). Refer to the operating instructions of your TV.

Open the jack cover. Connect your camcorder to the TV using the A/V connecting cable. Then, set the TV/VCR selector on the TV to VCR.



# If your TV is already connected to a VCR

Connect your camcorder to the LINE IN input on the VCR by using the  $\Lambda / V$  connecting cable supplied with your camcorder. Set the input selector on the VCR to LINE.

# экране телевизора

Подсоедините Вашу видеокамеру к Вашему телевизору с помощью соединительного телевизору с помощью соединительного кабела аудио/видео, который прилагается к Вашей видеокамере для просмотра воспроизводимого изображения на экран етпевизора. Вы можете оперировать кнопками управления воспроизведением таким же способом, как при управлении воспроизводимым изображением на экране ЖКД. При управлении воспроизводимым изображением на экране телевизора рекомендуется подключить питание к Вашей видеокамере от сетевой розетки с помощью сетевого адаптера переменного тока (стр. 21). См. инструкцию по эксплуатации Вашего телевизора.

Откройте крышку гнезд. Подсоедините Вашу видеокамеру к телевизору с помощью соединительного кабеля аудиойвидео. Затем, установите переключатель ТV/VCR на Вашем телевизоре в положение VCR.

# Если Ваш телевизор уже подсоединен к KBM

Полсоелините Вашу вилеокамеру к вхолному Подсоедините Вашу видеокамеру к входи-гнезду LINE IN на КВМ с помощью соединительного кабеля аудио/видео, который прилагается к Вашей видеокаме Установите селектор входного сигнала на КВМ в положение LINE.

#### Viewing the recording on TV

# If your TV or VCR is a monaural

Connect the yellow plug of the A/V connecting cable to the video input jack and the white or the red plug to the audio input jack on the VCR or the TV. If you connect the white plug, the sound is L (left) signal. If you connect the red plug, the sound is R (right) signal.

# If your TV/VCR has a 21-pin connector (EUROCONNECTOR)

Use the 21-pin adaptor supplied with your



If your TV or VCR has an S video lack Connect using an S video cable (optional) to obtain high-quality pictures.

With this connection, you do not need to connect the yellow (video) plug of the A/V connecting cable.

Connect an S video cable (optional) to the S video jacks on both your camcorder and the TV or the VCR.

To display the screen indicators on TV Set DISPLAY to V-OUT/LCD in the menu settings (p. 107). Then press DISPLAY on your camcorder. To turn off the screen indicators, press DISPLAY on your camcorder again.

#### Просмотр записи на экране телевизора

# Если Ваш телевизор или КВМ монофонического типа

Подсоедините желтый штекер Подсоедините жалтым штекер, соединительного кабеля аудио/видео к входному гнезду видеосигнала и белый или красный штекер к входному гнезду аудиосигнала на КВМ или телевизоре. Если Вы подоседините белый штекер, то будет звук L (певый) канал. Если Вы подоседините белый штекер, то будет звук R (правый) канал. Соги Вы подоседините красный штекер, то будет звук R (правый) канал.

# Если в Вашем телевизоре/КВМ имеется 21-штырьковый разъем (EUROCONNECTOR)

Используйте 21-штырьковый адаптер прилагаемый к Вашей видеокамере.



#### Если в Вашем телевизоре имеется гнездо S видео Выполните соединение с помощью каб

видео (приобретается отдельно) для получения высококачественных зображений

изображений.
При данном соединении Вам не нужно подсоединять желтый штекер (видео) соединительного кабеля аудио/видео.
Подсоедините кабель S видео (приобратается отдельно) к гнездам S видео на Вашей видеокамере и Вашем телевизоре или КВМ.

Для отображения экранных индикаторов на телевизоре
Установите опциию DISPLAY в положение VOUT/LCD в установках меню (стр. 107).
Затем нажмите кнопку DISPLAY на Вашей
видеокамере. Для выключения экранных
индикаторов нажмите кнопку DISPLAY на
Вашей вилескаморо еще до Вашей видеокамере еще раз-

45 44

## Viewing the recording on TV

## Using the AV cordless IR

Once you connect the AV cordless IR receiver (optional) to your TV or VCR, you can easily view the picture on your TV. For details, refer to the operating instructions of the AV cordless IR receiver.

#### Просмотр записи на экране телевизора

# Использование беспроводного ИК аудиовидеоприемника



#### Before operation

46

Attach the power supply such as the AC power adaptor to your camcorder, and insert the recorded tape.

суперк


- (1) After connecting your TV and AV cordless IR receiver, set the POWER switch on the AV
- cordless IR receiver to ON.

  (2) Turn the TV on and set the TV/VCR selector on the TV to VCR.
- on the 1 V to VCK.

  (3) Set the POWER switch on your camcorder to PLAYER or VCR (DCR-TRV330E only).

  (4) Press SUPER LASER LINK. The lamp of
- (4) Press SUPER LASER LINK. The lamp of SUPER LASER LINK lights up.
  (5) Press ➤ on your camcorder to start playback.
  (6) Point the super laser link emitter at the AV cordless IR receiver. Adjust the position of your camcorder and the AV cordless IR receiver to obtain clear playback pictures.

После подсоединения беспроводного ИК аудиовидеоприемника к Вашему телевизору (приобретается отдельно) Вы можете легко наблюдать изображение на экране Вашего телевизора. Подробные сведения содержатся в инструкции по эксплуатации беспроводного ИК аудиовидеоприемника.



Перед эксплуатацией Прикрепите источник питания, например, сетевой адаптер переменного тока, к Вашей видеокамере, и вставьте записанную ленту.

- (1) После подсоединения к Вашему телевизору беспроводного ИК аудиовидеоприемника установите переключатель РОМЕЯ на беспроводном ИК аудиовидеоприемнике в положение ОК.
- (2) Включите телевизор и установите селектор TV/VCR на телевизоре в
- положение VCR. (3) Установите переключатель POWER на (з) установите переключатель РСУИЕН на Вашей видеокамере в положение РLAYER или VCR (только модель DCR-ТRV330E). (4) Нажмите кнопку SUPER LASER LINK. Высветится памлочка SUPER LASER LINK. (5) Нажмите кнопку ► на Вашей видеокамере для начала включения

- видеокамере для начала включения воспроизведения. (6) Направьте излучатель лазерного суперканала на беспроводный ИК аудиоприемник. Отретулируйте положение Вашей видеокамеры и беспроводного ИК аудиовидеоприемника для получения четкого воспроизводимого изображения.

## Viewing the recording on TV

## To cancel the super laser link

function Press SUPER LASER LINK. The lamp on the SUPER LASER LINK button goes out.

If you turn the power off Super laser link function turns off automatically.

When super laser link is activated (the SUPER LASER LINK button is lit)
Your camcorder consumes power. Press SUPER LASER LINK to turn off the super laser link function when it is not needed.

is a trademark of Sony Corporation.

#### Просмотр записи на экране телевизора

Для отмены функции лазерного суперканала передачи сигналов Нажмите кнопку SUPER LASER LINK. Лампочка на кнопке SUPER LASER LINK погаснет

Если Вы выключите питание Лазерный суперканал передачи сигналов выключится автоматически.

При включенном лазерном суперканале передачи сигналов (при этом высвечивается кнопка SUPER LASER LINK) Ваша видеокамера потребляет питание. Нажмите кнопку SUPER LASER LINK для выключения функции лазерного суперканала передачи сигналов, если она не требуется.

является фирменным знаком Sony Corporation.

## Recording a still image on a tape - Tape Photo recording

You can record a still image like a photograph. This mode is useful when you want to record an image such as a photograph or when you print a picture using a video printer (optional). You can record about 510 images in the SP mode and about 765 images in the LP mode on a tape which can record for 80 minutes in the SP mode. Besides the operation described here, your camcorder can record still images on "Memory Stick"s (p. 129) (DCR-TRV325E/TRV330E/TRV430E/TRV330E only).

(1) In the standby mode, keep pressing PHOTO lightly until a still image appears. The CAPTURE indicator appears on the screen. Recording does not start yet.

To change the still image, release PHOTO, select a still image again, and then press and hold PHOTO lightly.

(2) Press PHOTO deeper.

The still image on the screen is recorded for about seven seconds. The sound during those seven seconds is also recorded.

The still image is displayed until recording is completed.

#### Запись неподвижного изображения на ленту - Фотосъемка на ленту

изображение подобно фотографии. Этот режим является полезным, если Вы хотите режим вплется полезным, если Вы хотите записать изображение, такое как фотография, или если Вы хотите распечатать изображение с помощью видеопринтера (приобретается отдельно). Вы можете записать около 510 изображений в режиме SP и около 765 изображений в режиме SP и около 765 изображений в режиме SP, пенте, которая позволяет выполнять запись в течение 60 минут в режиме SP. Кроме огисанной здесь операции, Ваша видеокамера может выполнить запись неподвижных изображений на "Memory Stick" (стр. 129) (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E).

- (1) В режиме ожидания держите слегка нажатой кнопку РНОТО до тех пор, пока нажатой кнопку РПОТО до тех пор, пок не появится неподвижное изображение Появится индикатор CAPTURE на экрая Запись пока еще не началась. Для изменения неподвижного
- Для изменения неподвижного изображения отпустите кнопку РНОТО, выберите неподвижное изображение снова, а затем нажмите и держите слегка нажжатой кнопку РНОТО. (2) Нажмите кнопку РНОТО сильнее. Неподвижное изображение на экране будет записываться около семи секунд. В течение этих семи секунд будет записываться и звук. Неподвижное изображение будет отображаться тех пор, пока запись не будет завершена.



Recording a still image on a tape - Tape Photo recording

- During the tape photo recording, you cannot
- change the mode or setting.

  The PHOTO button does not work:

   while the digital effect function is set or in use.

   while the fader function is in use.
- When recording a still image, do not shake your camcorder. Mosaic-pattern noise may appear on the image.

To use tape photo recording function using the Remote Commander Press PHOTO in the Remote Comm

camcorder records an image on the screen immediately

When you use the tape photo recording function during normal CAMERA recording You cannot check an image on the screen by pressing PHOTO lightly. Press PHOTO deeper. The still image is then recorded for about seven seconds, and your camcorder returns to the standby mode.

To record clear and less fluctuated still images (DCR-TRV325E/TRV330E/TRV430E/TRV530E

We recommend that you record on "Me Stick"s.

#### Запись неподвижного изображения на ленту - Фотосъемка на ленту

- . Во время фотосъемки на ленту Вы не
- можете изменять режим или установку Кнопка РНОТО не работает: - если установлена или используется функция цифрового эффекта.
- если используется функция фейдера.
   При записи неподвижного изображения не трясите Вашу видеокамеру. Иначе на изображении могут появиться помехи мозаичного типа.

## Для использования функции фотосъемки на ленту с помощью пульта дистанционного управления Нажмите кнопку РНОТО на пульте

дистанционного управления. Ваша видеокамера тотчас же начнет запись изображения на экране

# При использовании функции фотосъ на ленту во время обычной записи САМЕRA

САМЕГА
Вы не можете проверить изображение
экране, слегка нажав кнопку РНОТО.
Нажмите кнопку РНОТО сильнее.
Неподвижное изображение будет
записываться около семи секунд, а за:
видеокамера вернется в режим ожида

четкими и не так дрожали (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E) Рекомендуется выполнять запись на "Memory Sticks".

48 49

# Recording a still image on a tape - Tape Photo recording

## Self-timer recording

# - DCR-TRV325E/TRV330E/TRV430E/

TRV530E only
You can record still images on tapes with the self-timer. You can also use the Remote Commander for this operation.

- (1) In the standby mode, press MENU to display (1) in the standby mode, press MENU to display the menu settings.

  (2) Turn the SEL/PUSH EXEC dial to select (5), then press the dial.

  (3) Turn the SEL/PUSH EXEC dial to select SELFITMER, then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select ON, then press the dial.

  (5) Press MENU to make the menu settings disappear.

- disappear. (6) Press PHOTO deeper.
  - Self-timer starts counting down from 10 with a beep sound. In the last two seconds of the countdown, the beep sound gets faster, then recording starts automatically.

Запись неподвижного изображения на ленту – Фотосъемка на ленту

# Съемка на ленту с помощью таймера самозапуска


# - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Вы можете записывать неподвижные изображения на ленты с помощью тай самозапуска. Для этой операции Вы также можете использовать пульт дистанционног

- (1) Для отображения установок меню в
- режиме ожидания нажмите кнопку MENU.

  (2) Поверните диск SEL/PUSH EXEC для выбора установки 🗑, затем нажмите на диск.

  (3) Поверните диск SEL/PUSH EXEC для выбора установки SELFTIMER, затем нажмите на диск
- (4) Поверните диск SEL/PUSH EXEC для выбора
- установки ON, затем нажмите на диск. (5) Нажмите кнопку MENU для исчезновения установок меню
- (6) Нажмите кнопку РНОТО сильно. Таймер самозапуска начнет обратн отсчет времени от 10 с зуммерным сигналом. В последние две секунды сигналом. В последние две секунды обратного отсчета времени, частота зуммерного сигнала будет быстрее, а затем начнется запись.



## To cancel self-timer recording

Set SELFTIMER to OFF in the menu settings in the standby mode.
You cannot cancel the self-timer recording using the Remote Commander.

#### Для отмены записи по таймеру самозапуска

самозапуска
Установите пункт SELFTIMER в установках
меню в положении OFF.
Вы не можете отменить запись по таймеру
самозапуска, используя пульт дистанционного управления

#### Recording a still image on a tape - Tape Photo recording

The self-timer recording mode is automatically cancelled when:

- Self-timer recording is finished. The POWER switch is set to OFF (CHG),
- PLAYER or VCR (DCR-TRV330E only)

### Printing the still image

You can print a still image by using the video printer (optional). Connect the video printer using the A/V connecting cable supplied with

using the AV Connecting cable supplied with your camcorder.


Connect the A/V connecting cable to the A/V OUT or AUDIO/VIDEO jack and connect the yellow plug of the cable to the video input of the video printer. Refer to the operating instructions of the video printer as well.

#### Запись неподвижного изображения на ленту – Фотосъемка на ленту

Режим записи по таймеру будет автоматически отменен, если: – Запись по таймеру самозапуска закончится. – Переключатель POWER установлен в положение OFF (CHG), PLAYER или VCR (только модель DCR-TRV330E).

#### Печатание неподвижного изображения

Вы можете выполнить печатание подвижного изображения с помощью видеопринтера (приобретается отдельно). Подсоедините видеопринтер с помощью соединительного кабеля аудио/видео, который прилагается к Вашей видеокамере ните соединительный кабель аудио видео к выходному гнезду A/V OUT или AUDIO/VIDEO и подсоедините желтый мосто упод соедините желтым штекер кабеля к входному гнезду видеосигнала на видеопринтере. Воспользуйтесь также инструкцией по эксплуатации видеопринтера.



: Signal flow/Передача сигнала

If the video printer is equipped with S video

input
Use the S video connecting cable (optional).
Connect it to the S VIDEO OUT or S VIDEO jack
and the S video input of the video printer.


# Если в видеопринтере имеется входное

Если в видеопринтерь ...... гнездо S видео Используйте соединительный кабель S видео (приобретается отдельно). Подсоедините его к гнезду - S VIDEO OUT или - S VIDEO и ко входному гнезду S видео на видеопринтере.

#### Использование широкоэкранного режима


Вы можете записывать широкоформатное изображение16:9 для просмотра на широкоэкранном телевизоре формата16:9 (16:9WIDE).

(16:9WIDE). Во времи в 16:9 WIDE на экране ЖКД или в видоискателе появятся черные полосы [а]. Изображение во время воспроизведения в видоискателе, на обычном телевизоре [b] или на широкозкранном телевизоре [с] будет сжато по ширине. Если Вы установите режим экрана широкозкранного телевизора в полнозкранный режим, Вы сможете наблюдать обычные изображения без искажений [d].



In the standby mode, set 16:9WIDE to ON in the menu settings (p. 107)

В режиме ожидания установите команду 16:9WIDE в положение ON в установках меню (стр. 107)



To cancel the wide mode Set 16:9WIDE to OFF in the menu settings

In the wide mode, you cannot select the following functions

- Old movie - Bounce

52

During recording You cannot select or cancel the wide mode. When you cancel the wide mode, set your camcorder to the standby mode and then set 16:9WIDE to OFF

Для отмены широкоэкранного режима Установите команду 16:9WIDE в положение ОFF в установках меню.

# В широкоэкранном режиме Вы не можете выбирать следующие функции: - Старинное кино

Перескакивание


Во время записи
Вы не можете выбрать или отменить широко-экранный режим. Если Вы отмените широко-экранный режим, установите Вашу видеокамеру в режим ожидания, а затем установите команду 16:9WIDE в положение OFF.

## Using the fader function

You can fade the picture in or out to give your recording a professional appearance.

## Использование функции фейдера

Вы можете выполнять плавное введение и выведение изображения, чтобы придать



MONOTONE

WONOTONE
When fading in, the picture gradually changes
from black-and-white to colour.
When fading out the picture gradually changes
from colour to black-and-white.

- You can use this function when D ZOOM is set to OFF in the menu settings.
- 2) Fade in only

#### MONOTONE

При введении изображение будет постепенно изменяться от черно-белого до цветного. При выведении изображение будет постепенно изменяться от цветного до черно-

- <sup>1)</sup> Вы можете использовать эту функцию, если опция D ZOOM установлена в положение OFF в установках меню.
  <sup>2)</sup> Только введение изображения

53

#### Using the fader function

(1) When fading in [a]
In the standby mode, press FADER until the desired fader indicator flashes.
When fading out [b]
In the recording mode, press FADER until the desired fader indicator flashes.
The indicator changes as follows:
FADER — M.FADER — BOUNCE —
MONOTONE — OVERLAP —
WIPE — DOT
The last selected fader mode is indicated first of all.

(2) Press START/STOP. The fader indicator stops


flashing.
After the fade in/out is carried out, your camcorder automatically returns to the normal mode.

## Использование функции фейдера

(1) При введении изображения [а] В режиме ожидания, нажимайте кнопку FADER до тех пор, пока не начнет мигать нужный индикатор фейдера.
При выведении изображения [b] В режиме записи, нажимайте кнопку FADER до тех пор, пока не начнет мигать нужный индикатор фейдера.
Индикатор будет изменяться следующим образом:

фейдера отображается первым. (2) Нажмите кнопку START/STOP. Индикатор

фейдера перестанет мигать. выведение изображения, Ваша видеокамера автоматически вернется в



To cancel the fader function Before pressing START/STOP, press FADER until the indicator disappears.

- Notes

   The overlap, wipe and dot functions work only for tapes recorded in the Digitals 19 system.

   You cannot use the following functions while using the fader function. Also, you cannot use the fader function while using the following functions:

   Digital effect

   Low lux mode of PROGRAM AE (Overlap, wipe, or dot function only)

   Super NightShot

   Tape photo recording

образом: FADER → M.FADER → BOUNCE → MONOTONE → OVERLAP → WIPE → DOT Последний из выбранных режимов

обычный режим

Для отмены функции фейдера Перед тем, как нажать кнопку START/STOP, нажимайте кнопку FADER до тех пор, пока не

- Примечания

   Функция наложения изображения работает только для лент, записанных в цифровой системе Digitals 14.

   Вы не можете использовать следующие функции во время использоватия функции фейдера также, Вы не можете использоватым следующих функций:

   Цифровой эффект

   Режим низкой освещенности РROGRAM АЕ (только функции наложения, вытеснения шторкой или точечного изображения)
- Ночная суперсъемка Фотосъемка

#### Using the fader function

Before operating the overlap, wipe, or dot

beroire operating the overlap, wipe, or dot function. Your camcorder stores the image on the tape. As the image is being stored, the indicator flashes quickly, and the image you are shooting disappears from the screen. Depending on the tape condition, the image may not be recorded

While using the bounce function, you cannot use the following functions:

- Focus
- Zoom - Picture effect

Note on the bounce function The BOUNCE indicator does not appear in the following mode or functions:

- D ZOOM is activated in the menu settings

- Wide mode Picture effect
- PROGRAM AE

## Использование функции фейдера

Если Вы не записывали ничего перед включением функции наложения изображения Ваша видеокамера хранит изображение на ленте. Во время сохранения изображение индикатор митает быстро, а изображение, которое Вы снимаете, исчезнет с экрана. В зависимости от состояния ленты, изображение может быть записано нечетко

Во время использования функции перескакивания Вы не можете использовать следующие функции:

- Фокусировка
- Трансфокация Эффект изображения

Примечание по функции перескакивания Индикатор BOUNCE не появляется в следующих режимах или при использовании следующих функций:

- Команда D ZOOM приведена в действие в
- установках меню Широкоэкранный режим
- Эффект изображенияPROGRAM AE

ging

NEG. ART [a]: The colour and brightness of the NEG. ART [a]: The colour and brightness of the image is reversed.

SEPIA: The image is sepia.

B&W: The image is monochrome (black-and-white).

SOLARIZE [b]: The light intensity is clearer, and the picture looks like an illustration.

The light intensity is clearer, and the picture looks like an illustration. The image expands vertically. The image expands horizontally. The contrast of the image is emphasized, and the image looks like an animated cartoon. The image is mosaic. SLIM [c]: STRETCH [d]:

PASTEL [e] :

MOSAIC [f]:

#### Использование специальных эффектов Эффект изображения

Вы можете выполнять обработку изображения цифровым методом для получения специальных эффектов, ка кинофильмах или на экранах телевизоров

NEG. ART [а] : Цвет и яркость изображения будут негативными.

SEPIA : Изображение будет в цвете

минохрожание оудет монохрожение оудет усиненой, а изображение белым).

SOLARIZE [b]: Яркость света будет усиненной, а изображение будет выглядеть как иллюстрация.

SLIM [c]: Изображение растянется по вертикали.

STRETCH [d]: Изображение растянется по голизонтали.

горизонтали. Подчеркивается контрастность изображения, которому придается мультипликационный вид. PASTEL [e]:

MOSAIC [f]: Изображение будет









# Using special effects - Picture effect

(1) Press MENU to display the menu settings in CAMERA mode (2) Turn SFI /PUSH FXFC dial to select the

press the dial.

(3) Turn SEL/PUSH EXEC dial to select P


(3) Turn SEL/PUSH EXEC that to select r
EFFECT, then press the dial.
(4) Turn the SEL/PUSH EXEC dial to select the
desired picture effect mode, then press the

#### Использование специальных эффектов - Эффект изображения

Нажмите кнопку MENU для отображения установок меню в режиме CAMERA.
 Поверните диск SEL/PUSH EXEC для выбора установки 面, затем нажмите на диск.

(3) Поверните диск SEL/PUSH EXEC для выбора установки Р EFFECT, зате нажмите на диск.

нажмите на диск.
(4) Поверните диск SEL/PUSH EXEC для выбора режима нужного эффекта изображения, затем нажмите на диск



## To turn the picture effect function

Set P EFFECT to OFF in the menu settings

While using the picture effect function You cannot select OLD MOVIE with the digital effect function.

When you turn the power off
The picture effect is automatically canceled.

Для выключения функции эффекта изображения

изооражения
Установите пункт Р EFFECT в установках меню в положение OFF.

При использовании функции эффекта

**изображения**Вы не можете выбрать режим OLD MOVIE с функцией цифрового эффекта.

Если Вы выключите питание Ваша видеокамера автоматически вернется в обычный режим.

57 56

## **Using special effects** - Digital effect

You can add special effects to recorded image using the various digital functions. The sound is recorded normally.

You can record a still image so that it is

#### FLASH (FLASH MOTION)

You can record still images successively at constant intervals.

#### LUMI. (LUMINANCEKEY)

You can swap a brighter area in a still image with a moving image

You can record the image so that an incidental image like a trail is left

#### SLOW SHTR (SLOW SHUTTER)

You can slow down the shutter speed. The slow shutter mode is good for recording dark images more brightly

#### OLD MOVIE

You can add an old movie type atmosphere to images. Your camcorder automatically sets the wide mode to ON, picture effect to SEPIA, and the appropriate shutter speed.

#### Использование специальных эффектов Цифровой эффект

Вы можете добавлять специальные эффекты к записываемому изображению с помощью разных цифровых функций. Записываемый звук будет обычным.

#### STILL

Вы можете записывать неподвижное изображение, которое можно налагать на подвижное изображение.

#### FLASH (FLASH MOTION)

Вы можете записывать неподвижные изображения в последовательности через

#### LUMI. (LUMINANCEKEY) Вы можете изменять яркие места на

неподвижном изображении на подвижные изображения.

#### TRAIL


Вы можете записывать изображение с эффектом запаздывания.

#### SLOW SHTR (SLOW SHUTTER)

Вы можете замедлить скорость затвора. Режим медленного затвора является подходящим для записи темных изображен в более ярком свете.

#### OLD MOVIE

Вы можете привносить атмосферу старинного кино в изображения. Ваша видеокамера будет автоматически устанавливать широкоэкранный режим в положение ON, эффект изображения в положение SEPIA, и выставлять соответствующую скорость затвора



# Using special effects - Digital effect

- (1) Press MENU to display the menu settings in CAMERA mode.
  (2) Turn SEL/PUSH EXEC dial to select \$\overline{\text{MD}}\$, then press the dial.
  (3) Turn SEL/PUSH EXEC dial to select DEFFECT, then press the dial.
  (4) Turn the SEL/PUSH EXEC dial to select the desired digital effect mode.
  (5) Press the SEL/PUSH EXEC dial. The bars appear on the screen. In the STILL and LUMI. modes, the still image is stored in memory.
  (6) Turn the SEL/PUSH EXEC dial to adjust the effect as follows:
- effect as follows

STILL - The rate of the still image you want to

superimpose on the moving image FLASH - The interval of flash motion LUMI. - The colour scheme of the area in the still image which is to be swapped with a moving image TRAIL - The vanishing time of the incidental

image SLOW SHTR - Shutter speed. The larger the shutter speed. The larger shutter speed number, th slower the shutter speed. OLD MOVIE – No adjustment necessary

The more bars there are on the screen, the stronger the digital effect. The bars appear in the following modes: STILL, FLASH, LUMI. and TRAIL.

#### Использование специальных эффектов – Цифровой эффект

(1) Нажмите кнопку MENU для отображе установок меню в режиме CAMERA

установок меню в режиме CAMERA. (2) Поверните диск SEL/PUSH EXEC для выбора установки 📆, затем нажмите на диск.

диск.
(3) Поверните диск SEL/PUSH EXEC для выбора установки D EFFECT, затем нажмите на диск.
(4) Поверните диск SEL/PUSH EXEC для выбора режима нужного цифрового stableture.


выборы режимы гумных энтретствородии (5) Нажмите на диск SEL/PUSH EXEC. На экране появятся полосы. В режимах STILL или LUMI. неподвижное изображение сохранится в памяти.

(6) Поверните диск SEL/PUSH EXEC для регулировки эффекта следующим образом:

STILL - Интенсивность неподвижного изображения, которое Вы хотите наложить на подвижное

наложить на подвижное изображение FLASH – Интервал прерывистого движения LUMI. – Цвеговая гамма участка на неподвижном изображении, который будет заменен на подвижное изображение TRAL – Время исчезания побочного изображения SLOW SHTR – Скорость затвора. Чем больше величина скорости затвора, тем медленнее скорость затвора ОLD MOVIE – Не требуется никаких регулировок

Чем больше полос на экране, тем сильнее цифровой эффект. Полосы появляются в следующих режимах: STILL, FLASH, LUMI. и TRAIL.



58

- The following functions do not work during
- Low lux mode of PROGRAM AE
- Tape photo recording
  Super NightShot
  The following function does not work in the slow shutter mode:
- PROGRAM AE
- The following functions do not work in the old movie mode:
   Wide mode
- Picture effect
- PROGRAM AE

When you turn the power off The digital effect is automatically canceled.

When recording in the slow shutter mode Auto focus may not be effective. Focus manually using a tripod.

Shutter speed humber	Situater speed
SLOW SHTR 1	1/25
SLOW SHTR 2	1/12
SLOW SHTR 3	1/6
SLOW SHTR 4	1/3

# Использование специальных эффектов – Цифровой эффект

Для отмены цифрового эффекта Установите опцию D EFFECT в положен OFF в установках меню.

- Примечания
   Следующие функции не работают при использовании цифрового эффекта:
- Фейдер
- Режим низкой освещенности PROGRAM
- · Фотосъемка на ленту - Ночная суперсъемка
- Следующие функции не работают в режиме медленного затвора:
- PROGRAM AF
- Следующие функции не работают в режиме старинного кино:
- старинного кино: Широкоэкранный режим Эффект изображения
- PROGRAM AE

**При выключении питания** Цифровой эффект будет автоматически

При записи в режиме медленного затвора Автоматическая фокусировка может быть не эффективной. Выполните фокусировку вручную, используя треногу.

#### Скорость затвора

Величина скорости затвора	Скорость затвора
SLOW SHTR1	1/25
SLOW SHTR2	1/12
SLOW SHTR3	1/6
SLOW SHTR4	1/3

#### Using the PROGRAM AE function

You can select PROGRAM AE (Auto Exposure) mode to suit your specific shooting requirements.

This mode prevents people's faces, for example. from appearing excessively white when shooting subjects lit by strong light in the theatre.

This mode brings out the subject while creating a soft background for subjects such as people or flowers.

 $\hat{X}$  Sports lesson This mode minimizes shake on fast-moving subjects such as in tennis or golf.

#### \* Beach & ski

This mode prevents people's faces from appearing dark in strong light or reflected light, such as at a beach in midsummer or on a ski slope.

Landscape
This mode is for when you are recording distant subjects such as mountains and prevents your camcorder from focusing on glass or metal mesh in windows when you are recording a subject behind glass or a screen.

## **Low lux**

This mode makes subjects brighter in insufficient light

#### Использование функции PROGRAM AE

Вы можете выбрать режим PROGRAM AE (автоматическая съемка) в соответствии со специфическими требова

#### Прожекторное освещение

Опрожекторное освещение Данный режим предотвращает, к примеру, лица людей от появления в чрезмерно белом свете при выполнении съемки людей, освещенных сильным светом на свадебных церемониях или в театре.

№ Мягкий портрет
Этот режим позволяет выделить объект на фоне мягкого фона, и подходит для съемки, например, людей или цветов.

## **П** Спортивные состязания

Этот режим позволяет минимизировать дрожание при съемке быстро движущихся предметов, например, при игре в теннис или гольф

₹ Пляж и лыж Этот режим предотвращает появление темных лиц людей в зоне сильного света или отраженного света, например, на пляже в разгар лета или на снежном склоне.

#### Заход солнца и луня

Этот режим позволяет в точности отражать обстановку при съемке заходов солнца, общих ночных видов, фейерверков и неоновых реклам

Палициаф Зтот режим позволяет выполнять съемку отдаленных объектов, таких как горы, например, и предотвращает фокусировку видеокамеры на стекло или металлическую решетку на окнах, когда Вы выполняете запись объектов позади стекла или решетки.

У Низкая освещенность
Этот режим делает объекты ярче при недостаточном освещении











60

## Using the PROGRAM AE function

# (1) Press MENU to display menu settings in CAMERA or MEMORY (DCR-TRV325E/TRV330E/TRV330E/TRV330E/TRV350E only) mode. (2) Turn SEL/PUSH EXEC dial to select (1) the press the dial. (3) Turn SEL/PUSH EXEC dial to select PROGRAM AE, then press the dial. (4) Turn the SEL/PUSH EXEC dial to select the desired mode.

- (1)Нажмите кнопку MENU в режиме CAMERA или MEMORY (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E).
- диск. (3) Поверните диск SEL/PUSH EXEC для выбора установки PROGRAM AE, затем



## To turn the PROGRAM AE function

Set PROGRAM AE to OFF in the menu settings.

- In the spotlight, sports lesson and beach & ski modes, you cannot take close-ups. This is because your camcorder is set to focus only on subjects in the middle to far distance.
- In the sunset & moon and landscape modes, your camcorder is set to focus only on distant subjects.
- The following functions do not work in the PROGRAM AE mode:
- Slow shutter Old movie
- Bounce
   The following functions do not work in the low

- The following functions do not work in the low lux mode:
   Digital effect
   Overlap
   Wipe
   Dot
   While setting the NIGHTSHOT to ON, the PROGRAM AE function does not work. (The indicator flashes.)

  While shooting in MEMORY mode, the low lux mode does not work. (The indicator flashes.)
- mode does not work. (The indicator flashes.)
  (DCR-TRV325E/TRV330E/TRV430E/TRV530E

#### Использование функции PROGRAM AE

- (2) Поверните диск SEL/PUSH EXEC для выбора установки **т**, затем нажмите на
- нажмите на диск.

  (4) Поверните диск SEL/PUSH EXEC для выбора нужного режима.

Для выключения функции PROGRAM AE Установите пункт PROGRAM AE в установках меню в положение OFF.

спортивных состязаний, а также в пляжном и лыжном режиме Вы можете выполнять съемку крупным планом. Это объясняется тем, что Ваша видеокамера настроена для фокусировки только на объекты, находящиеся

на среднем и дальнем расстояниях.
В режиме захода солнца и луны, а также в ландшафтном режиме Ваша видеокамера настроена на фокусировку только на дальние объекты.

дальние объекты.

«Следующие функции не работают в режиме РВОGRAM АЕ:

— Медленный затвор

Старинное кино

— Перескакивание

«Опедующие функции не работают в режиме низкой освещенности:

— Цифровой эффект

— Нагложение изображения

— Ночная съвмка

— Точечное изображения

— Во время установки команды NIGHTSHOT в

— почечное изооражение
Во время установки команды NIGHTSHOT в
положение ОN, функция PROGRAM АЕ не
работает. (Индикатор будет мигать.)
Во время съемки в режиме МЕМОRY режим
низкой освещенности не работает.

низкои освещенности не расотает. (Индикатор будет мигать.) (только модели DCR-TRV325E/TRV330E/TRV430E/

Примечания
В режимах прожекторного освещения,

# Using the PROGRAM AE function

If you are recording under a discharge tube such as a fluorescent lamp, sodium lamp o

such as a fluorescent lamp, sodium lamp or mercury lamp Flickering or changes in colour may occur in the following modes. If this happens, turn the PROGRAM AE function off.

- Soft portrait mode

- Sports lesson mode

#### Использование функции PROGRAM AF

использовании газоразрядной лампы, натриевой лампы или ртутной лампы в следующих режимах может возникнуть мерцание или неустойчивые процессы. Если это произойдет, выключите функцию РРОGRAM AE.

— Мягкий портретите:

- Постький де. Мягкий портретный режим Режим спортивных состяза

61

Recording Operations

You can manually adjust and set the exposure. Adjust the exposure manually in the following

- Adjust accesses:


   The subject is backlit
   Bright subject and dark background
   To record dark pictures (e.g. night scenes)
  faithfully
- (1) Press EXPOSURE in CAMERA or MEMORY (DCR-TRV325E/TRV330E/TRV430E/TRV530E only) mode. The exposure indicator appears on the screen.

  (2) Turn the SEL/PUSH EXEC dial to adjust the brightness.

#### Регулировка экспозиции вручную

Вы можете отрегулировать и установить экспозицию вручную. Отрегулируйте экспозицию вручную в следующих случаях: - Объект на фоне задней подсветки - Яркий объект на темном фоне - Для залиси темных изображений (наприм ночных сцен) с большой достоверностью

- (1) Нажмите кнопку EXPOSURE в режиме CAMERA или MEMORY (только модели DCR-TRV325E/TRV330E/TRV430E/ TRV530E). На экране ЖКД или в видоискателе появится индикатор
- экспозиции. (2) Поверните диск SEL/PUSH EXEC для регулировки яркости.



#### To return to the automatic exposure mode Press EXPOSURE.

#### Note

When you adjust the exposure manually, the backlight function does not work in CAMERA or MEMORY (DCR-TRV325E/TRV330E/TRV430E/ TRV530E only) mode.

Your camcorder automatically returns to the automatic mode:

- if you change the PROGRAM AE mode

- if you slide NIGHTSHOT to ON

Для возврата в режим автоматической экспози Нажмите кнопку EXPOSURE.

Тримечания Если Вы отрегулируете экспозицию вручную, функция задней подсветки не будет работать в режиме САМЕЯА или МЕМОЯУ (только модели DCR-TRV325E/TRV330E/TRV430E/ TRV530E).

# Ваша видеокамера автоматически

- еспозиции: -если Вы измените режим PROGRAM AE -если Вы передвинете переключатель NIGHTSHOT в положение ON

## Focusing manually

You can gain better results by manually adjusting the focus in the following cases:

•The autofocus mode is not effective when shooting:

- subjects through glass coated with water

- subjects through glass coated with water droplets.
   horizontal stripes.
   subjects with little contrast with backgrounds such as walls and sky.
   When you want to change the focus from a subject in the foreground to a subject in the background.
   Shooting a stationary subject when using a tripod.



(1) Set FOCUS to MANUAL in CAMERA or MEMORY (DCR-TRV325E/TRV330E/ TRV430E/TRV530E only) mode. The 🕾

indicator appears on the screen.


(2) Turn the focus ring to sharpen focus.

(1) Установите переключатель FOCUS в положение MANUAL в режиме CAMERA или MEMORY (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E). На экране появится индикатор 🙉

Фокусировка вручную

Вы можете получить лучшие результаты путем регулировки вручную в следующих случаях:
• Режим автоматической фокусировки является неэффективным при выполнении

(2) Поверните кольцо фокусировки для



To return to the autofocus mode Set FOCUS to AUTO.

Для возвращения в режим фокусировки Установите переключатель FOCUS в положение AUTO.

64

Focusing manually

To focus precisely
Adjust the zoom by first focusing at the "T"
(telephoto) position and then shooting at the "W"
(wide-angle) position. This makes focusing easier.

When you shoot close to the subject Focus at the end of the "W" (wide-angle) position.

- changes to the following indicators:
- when recording a distant subject.

  when the subject is too close to focus on

## Фокусировка вручную

## Для точной фокусировки

Отрегулируйте объектив, сначала выполнив фокусировку в положении "Т" (телефото), а затем выполнив съемку в положении "W" (широкого угла охвата). Это упростит

При выполнении съемки вблизи объекта Выполните фокусировку в конце положения "W" (широкого угла охвата).

## Индикация 🕒 изменится на следу

дикация ( рамениты па отедующь дикаторы: при записи удаленного объекта. если объект находится слишком близко, чтобы выполнить фокусировку на него.

## Superimposing a title

You can select one of eight preset titles and two custom titles (p. 69). You can also select the language, colour, size and position of titles.

предварительно установленных титров и двух собственных титров (стр. 69). Вы можете также выбирать язык, цвет, размер и положение

- (1) Press TITLE to display the title menu in the standby mode. The title menu display appears on the screen.
  (2) Turn the SEL/PUSH EXEC dial to select □,
- then press the dial.

  (3) Turn the SEL/PUSH EXEC dial to select the desired title, then press the dial. The titles are displayed in the language you selected.

  (4) Change the colour, size, or position, if
- necessary.
  ① Turn the SEL/PUSH EXEC dial to select
- ① Turn the SEL/PUSH EXEC dial to select the colour, size, or position, then press the dial. The item appears on the screen.
  ② Turn the SEL/PUSH EXEC dial to select the desired item, then press the dial.
  ③ Repeat steps ① and ② until the title is laid out as desired.
  (5) Press the SEL/PUSH EXEC dial again to complete the setting.
  (6) Press TART/STOP to start recording.
  (7) When you want to stop recording the title, press TITLE.

(1) Нажмите кнопку ТІТЬЕ для отображения

Наложение титра

Вы можете выбрать один из восьм

- (1) Нажмите кнопку ТПТЕ для отображения меню титров в режиме ожидания. На экране появится индикация меню титров. (2) Поверните диск SEL/PUSH EXEC для выбора установки С., а затем нажмите диск. (3) Поверните диск SEL/PUSH EXEC для выбора нужного титра, а затем нажмите диск. Титры будут отображаться на выбранном Вами языме. Положение титра, если нужно.

  (4) Измените цвет, размер или положения титра, если нужно.

  (5) Поверните диск SEL/PUSH EXEC для выбора цвета, размера или положения титра, а затем нажмите диск. На экране появится этот пункт.

- титра, а затем нажмите диск. На зкране появится тот пункт.


  ② Поверните диск SEL/PUSH EXEC для выбора нужного пункта, а затем нажмите диск.

  ③ Повторяйте пункты ① и ② до тех пор, пок титр не будет расположен так, как нужно.

  (5) Нажмите диск SEL/PUSH EXEC для завершения установки.

  (6) Нажмите кнопку START/STOP для начала записи.

- записи. (7) Если Вы захотите остановить запись



ding Ope

ъемки

66

67

To superimpose the title while you are recording
Press TITLE while you are recording, and carry
out steps 2 to 5. When you press the SEL/PUSH
EXEC dial at step 5, the title is recorded.

# To select the language of a preset title

If you want to change the language, select a before step 2. Then select the desired language and return to step 2.

If you display the menu while superimposing a title

The title is not recorded while the menu is displayed.

To use the custom title
If you want to use the custom title, select 🗈 in step 2.

$$\label{eq:time_state} \begin{split} &\text{Title setting} \\ &\text{• The title colour changes as follows:} \\ &\text{WHITE} \longleftrightarrow \text{YELLOW} \longleftrightarrow \text{VIOLET} \longleftrightarrow \text{RED} \longleftrightarrow \\ &\text{CYAN} \longleftrightarrow \text{GREEN} \longleftrightarrow \text{BLUE} \end{split}$$

The title size changes as follows SMALL ← LARGE

SMALL ← LARGE
You cannot input more than 12 characters in LARGE size.
• The title position changes as follows:

The larger the position number, the lower the title is positioned.

When you select the title size LARGE, you cannot choose position 9.

When you are selecting and setting the title You cannot record the title displayed on the screen.

When you superimpose a title while you are recording
The beep does not sound.

68

While you are playing back
You can superimpose a title. However, the title is not recorded on tape.
You can record a title when you dub a tape connecting your camcorder to the VCR with the A/V connecting cable. If you use the i.I.INK cable instead of the A/V connecting cable, you cannot record the title.

#### Наложение титра

Для наложения титра во время записи Нажмите кнопку ТІТLE во время записи и выполните действия пунктов 2-5. Если Вы нажмете диск SEL/PUSH EXEC в пункте 5, титр будет записан

Для выбора языка предварительно установленного титра Если Вы хотите изменить язык, выберите индикацию ба перед пунктом 2. Затем выберите нужныи язык и вернитесь к пункту

## В случае отображения меню во время

в случае отображения меню во врем наложения титра Титр не будет записываться во время отображения меню.

Для использования собственного тит Если Вы хотите использовать собственн титр, выберите установку ඎ в пункте 2.

Установка титра

образом. WHITE (белый)  $\longleftrightarrow$  YELLOW (желтый)  $\longleftrightarrow$  VIOLET (фиолетовый)  $\longleftrightarrow$  RED (красный)  $\longleftrightarrow$  CYAN (голубой)  $\longleftrightarrow$  GREEN (зеленый)

←→ BLUE (синий) Размер титра изменяется следующим

Размер титра изменяется следующим образом: SMALL (маленький) → LARGE (большо Вы не можете ввести более 12 символо для размера титра LARGE.
 Позиция титра изменяется следующим образом:

образом: 06разом:  $1 \leftarrow 2 \leftarrow 3 \leftarrow 4 \leftarrow 5 \leftarrow 6 \leftarrow 7 \leftarrow 8 \leftarrow 9$  Чем выше номер позиции титра, тем ниж чем выше номер позиции титра, тем ниже расположен титр. Если Вы выберите размер титра LARGE, Вы не сможете выбрать положение 9.

**При выборе и установке титра**Вы не можете записать титр, отобража

Во время воспроизведения
Вы можете наложить титр. Однако титр не
будет записан на ленту.
Вы можете записать титр при перезаписи
ленты, подсоединив Вашу видеокамеру к
КВМ с помощью соединительного кабеля
аудио/видео. Если Вы используете кабель
i.LINK вместо соединительного кабеля ауди идео. Вы не можете записать титры

#### Making your own titles

You can make up to two titles and store them in your camcorder. Each title can have up to 20 characters.

- (1) Press TITLE in the standby, PLAYER or VCR (DCR-TRV330E only) mode. (2) Turn the SEL/PUSH EXEC dial to select ₺, then press the dial. (3) Turn the SEL/PUSH EXEC dial to select CUSTOMI SET or CUSTOM2 SET, then press
- CUSTOM1 3E1 6. 2. the dial.

  (4) Turn the SEL/PUSH EXEC dial to select the column of the desired character, then press

- column of the desired character, then press the dial.

  (S) Turn the SEL/PUSH EXEC dial to select the desired character, then press the dial.

  (6) Repeat steps 4 and 5 until you have selected all characters and completed the title.

  (7) To finish making your own titles, turn the SEL/PUSH EXEC dial to select [SET], then press the dial. The title is stored in memory.


  (8) Press TITLE to make the title menu disappea

#### Создание Ваших собственных титров

Вы можете составить до двух титров и сохранить их в памяти Вашей видеокам Каждый титр может содержать до 20 си

- (1) Нажмите кнопку ТТГLE в режиме ожидания, в режиме PLAYER или VCR (DCR-TRV330E). (2) Поверните диск SEL/PUSH EXEC для выбора установки 1°2, а затем нажмите диск. (3) Поверните диск SEL/PUSH EXEC для выбора опции CUSTOM1 SET или CUSTOM2 SET, а затем нажмите диск. (4) Поверните диск SEL/PUSH EXEC для выбора колонки с нужным символом, а затем нажмите диск. (5) Поверните диск SEL/PUSH EXEC для выбора колонки с нужным символом, а затем нажмите диск. (6) Повторяйте пункты 4 и 5 до тех пор, поск Вы не выборите все символы и полностью Вы не выборите все символы и полностью Вы не выборите все символы и полностью

- (6) повторияте пункты 4 и о до тех пор, пожа Вы не выберите все символы и попностью не составите титр. (7) Для завершения составления своих собственных титров поверните диск SEL/ PUSH EXEC для выбора клманды (SET), а затем нажмите диск. Титр будет сохранен
- (8) Нажмите кнопку TITLE, чтобы исчезло меню титров.



## 69

## Making your own titles

To change a title you have stored In step 3, select CUSTOM1 SET or CUSTOM2 SET, depending on which title you want to change, then press the SEL-PUSH EXEC dial. Turn the SEL-PUSH EXEC dial to select [♠], then press the dial to delete the title. The last character is erased. Enter the new title as desired.

If you take 3 minutes or longer to enter characters in the standby mode while a cassette is in your camcorder. The power automatically goes off. The characters you have entered remain stored in memory. Set the POWER switch to OFF (CHG) once, and turn it to CAMERA again, then proceed from step 1. We recommend setting the POWER switch to PLAYER or VCR (DCR-TRV330E only) or removing the cassette so that your camcorder does not automatically turn off while you are entering title characters.

If you select [→P2] The menu for selecting alphabet and Russian characters appear. Select [→P1] to return to the

To enter a space Select [Z& ?!], then select the blank part.

To erase a character Select [←]. The last character is erased.

#### Создание Ваших собственных титров

## Для изменения сохраненного в

Для изменения с охраненного в памяти титра
В пункте 3 выберите установку CUSTOM1
SET или CUSTOM2 SET. в зависимости от титра, который Вы хотите изменить, а затем нажмите диск SELPUSH EXEC. Поверните диск SELPUSH EXEC для выбора установки (е], а затем нажмите диск для удаления титра. Последний симвоп будет стерт. Введите новый нужный титр.

# Если Вы вводите символы 3 минуты или более в режиме ожидания в то время, когда кассета находится в Вашей

когда кассета находится в Вашей видеохамере
Питание выключится автоматически.
Символы, которые Вы ввели, сохранятся в памяти видеохамеры. Установите сначала переключатель РОWER в положение СКМЕRA, а затем начните с пункта 1. Рекомендуется установить переключатель РОWER в положение СВМЕRA, а затем начните с пункта 1. Рекомендуется установить переключатель РОWER в положение РLAYER или VCR (только модели ОСR-TRV330E) или вынуть кассету, чтобы Ваша видеохамера автоматически не Ваша видеокамера автоматически не выключалась во время ввода символов

Если Вы выбрали установку [→P2] Появится меню для выбора алфавита и русских символов. Для возврата к прежнему экрану выберите установку [→P1].

**Для удаления титра** Выберите установку [**←**]. Последний символ будет стерт.

Для ввода интервала Выберите знак [Z& ?!], а затем выберите пустую ячейку.

## Inserting a scene

You can insert a scene in the middle of a recorded tape by setting the start and end poin The previously recorded frames between these start and end points will be erased. Use the Remote Commander for this operation.

## Вставка эпизода Вы можете вставить эпизод в середин

Вы можете вставить эпизод в середине записанной ленты путем установки точек начала и окончания. Предыдущие записанные кадры между этими точками начала и окончания будут стерты. Вы можете выполнить это, используя пульт дистанционного управления.



- (1) While your camcorder is in the standby mode, keep pressing EDITSEARCH, and release the button at the insert end point [b].
  (2) Press ZERO SET MEMORY. The ZERO SET MEMORY indicator flashes and the counter present is easily as a series of the series of

- resets to zero.

  (3) Keep pressing the @ side of EDITSEARCH and release the button at the insert start point [a].

  (4) Press START/STOP to start recording. The scene is inserted. Recording stops automatically near the counter zero point. Your camcorder returns to the standby mode.
- (1) В режиме ожидания видеокамеры, держите нажатой кнопку EDITSEARCH и отпустите кнопку в точке окончания эпизода **[b**].

- эпизода [b].

  (2) Нажимте кнопку ZERO SET MEMORY. Начнет мигать индикатор ZERO SET MEMORY. а счетчик ленты будет установлен в нулевое положение.

  (3) Держите нажатой сторону © кнопки EDITSEARCH и отпустите кнопку в точке начала эпизода [а].

  (4) Нажимте кнопку START/STOP для начала записи. Эпизод вставлен. Запись остановится автоматически в нулевой точке счетчика. Ваша видеокамера вернется в режим ожидания.



- Notes

  'The zero set memory function works only for tapes recorded in the Digitals H system.

  'The picture and the sound may be distorted at the end of the inserted section when it is played back.

If a tape has a blank portion in the recorded

portions
The zero set memory function may not work correctly.

- Примечания
   Функция памяти нуля не работает для лент, записанных в цифровой системе Digitalis II.
   Изображение и звук могут быть искажены в конце вставленного эпизода при воспроизведении.

## Если на ленте имеется незаписан

**участок** Функция памяти нуля может не работать надлежащим образом.


70

### Playing back a tape with picture effects

During playback, you can process a scene using the picture effect functions: NEG.ART, SEPIA, B&W and SOLARIZE

- (1) Press MENU to display the menu settings in the playback or playback pause mode.
  (2) Turn SEL/PUSH EXEC dial to select me, then press the dial.
  (3) Turn SEL/PUSH EXEC dial to select P
- (3) Turn SEL/PUSH EXEC dial to select P EFFECT, then press the dial.
  (4) Turn the SEL/PUSH EXEC dial to select the desired picture effect mode, then press the dial.
  For ditails of a control of the press the dial.

For ditails of each picture effect function, see page 56



To cancel the picture effect function Set P EFFECT to OFF in the menu settings.

- The picture effect function works only for tapes recorded in the Digitals H system.
   You cannot process externally input scenes using the picture effect function.
   You cannot record pictures that you have processed.
- processed using the picture effect function with this camcorder. To record pictures that you have processed using the picture effect function, record the pictures on the VCR using your camcorder as a player.

Pictures processed by the picture effect function

Pictures processed by the picture effect function are not output through the DV OUT or DV IN/OUT jack.

When you set the POWER switch to OFF (CHG) or stop playing back
The picture effect function is automatically canceled.

#### Воспроизведение ленты с эффектами изображения

Во время воспроизведения, Вы можете видоизменять изображение с помощью функций: NEG.ART, SEPIA, B&W и SOLARIZE.

- функций: NEG.ART, SEPIA, B&W и SOLARIZE.

  (1) Нажмите кнопку MENU для отображения установок меню в режиме воспроизведения или паузы воспроизведения или паузы воспроизведения или паузы установки быть выбора установки БЕГ



Для отмены функции цифровых эффектов
Установите пункт Р EFFECT в установках меню в положение OFF.

- Примечания
   Функция эффектов изображения работает только для лент, записанных в цифровой системе Digitals B1.
  Вы не можете видоизменять изображения от КВМ или телевизора с помощью функции
- от КВМ или телевизора с помощью функц эффектов изображения. Вы не можете записывать обработанные изображения с помощью функции эффектов изображения на данной видеокамере. Для записи изображения исполызованием эффектов изображения, запишите изображения на КВМ, использу Вашу видеокамеру в качестве плейера.

Маображения, обработанные с помощью функции эффектов изображения Изображения, обработанные с помощью функции эффектов изображения, не передаются через гнездо DV ОUТили DV IN/ OUT.

Если Вы установили переключатель POWER в положение OFF (CHG) или остановили воспроизведение ункция эффектов изображения будет этоматически отменена.

#### Playing back a tape with digital effects

During playback, you can process a scene using the digital effect functions: STILL, FLASH, LUMI. and TRAII

- (1) Press MENU to display the menu settings in

- (1) Press MENU to display the menu settings in the playback mode.

  (2) Turn SEL/PUSH EXEC dial to select M., then press the dial.

  (3) Turn SEL/PUSH EXEC dial to select D EFFECT, then press the dial.

  (4) Turn SEL/PUSH EXEC dial to select the desired digital effect mode, then press the dial. The bars appear on the screen. In the STILL or LUML mode, the image where you press the SEL/PUSH EXEC dial is stored in memory as a still image. memory as a still image.

  (5) Turn the SEL/PUSH EXEC dial to adjust the
- For details of each digital effect function, see page 58.

#### Воспроизведение ленты с цифровыми эффектами

Во время воспроизведения, Вы можете видоизменять изображение с помощью функций: STILL. FLASH. LUMI. и TRAIL.


- функции: SIILL, FLASH, LOWII. И ТНАIL.

  (1) Нажмите кнопку МЕNU для отображения установок меню в режиме воспроизведения.

  (2) Поверните диск SEL/PUSH EXEC для выбора установки Ш, затем нажмите на диск.

  (3) Поверните диск SEL/PUSH EXEC для выбора установки D EFFECT, затем нажмите на диск.

  (4) Поверните диск SEL/PUSH EXEC для выбора режима нужного цифрового эффекта, а затем нажмите на диск. На экране появятся полосы. В режиме STILL или LUMI, изображение, на котором Вы нажали диск SEL/PUSH EXEC, сохранится в памяти как неподвижное изображение.
- в памяти как неподвижное изображение. (5) Поверните диск SEL/PUSH EXEC для регулировки эффекта изображения. Подробные сведения по каждой функции цифровых эффектов приведены на стр. 58.



ancel the digital effect function Set D EFFECT to OFF in the menu settings

эффектов Установите пункт D EFFECT в установках меню в положение OFF.

73

## Playing back a tape with digital

- The digital effect function works only for tapes
- recorded in the Digitals system.
   You cannot process externally input scenes using the digital effect function.
- using the digital effect function.

  'You cannot record images that you have processed using the digital effect function with this camcorder. To record images that you have processed using the digital effect function, record the images on the VCR using your camcorder as a player.

Pictures processed by the digital effect function
Pictures processed by the digital effect function are not output through the DV OUT or DV IN/OUT jack.

When you set the POWER switch to OFF (CHG) or stop playing back
The digital effect function is automatically

#### Воспроизведение ленты с цифровыми эффектами

- Функция цифровых эффектов работает только для лент, записанных в цифровой системе Digital8 I).
   Вы не можете видоизменять изображения
- от КВМ или телевизора с помощью функции
- цифровых эффектов.
   Вы не можете записывать обработанные . Вы не можете записывать обработанные изображения с помощью функции цифровых эффектов на данной видеокамере. Для записи изображения с цифровыми эффектами, запишите изображения на КВМ, используя Вашу видеокамеру в качестве плейера.

Изображения, обработанные с помощью функции цифровых эффектов Изображения, обработанные с помощью функции цифровых эффектов, не передаются через гнездо DV OUT или DV IN/

Если Вы установили переключател POWER в положение OFF (CHG) или остановили воспроизведение Функция цифровых эффектов будет автоматически отменена.

## **Enlarging recorded** images - Tape PB ZOOM

You can enlarge moving and still images recorded on tapes. You can also dub the enlarged images to tapes or copy to "Memory Stick"s (DCR-TRV325E/TRV330E/TRV430E/TRV530E

only).

Besides the operation described here, your camcorder can enlarge still images recorded on "Memory Stick"s (DCR-TRV325E/TRV330E/TRV430E/TRV530E only).

- (1) Press PB ZOOM on your camcorder in the playback or playback pause mode. The image is enlarged, and ↑ ↓ indicators which showing the direction to move the image appear on the
- (2) Turn SEL/PUSH EXEC dial to move the
  - arged image, then press the dial.

    ↑:The image moves downwards.
- ↓:The image moves upwards.

  ↓:The image moves upwards.

  ← → becomes available.

  (3) Turn SEL/PUSH EXEC dial to move the
- or The Mage, then press the dial.


  ←: The image moves rightward (Turn the dial downwards.)

  - →: The image moves leftward (Turn the dial upwards.)

#### Увеличение записанных изображений - Функция PB ZOOM ленты

Вы можете увеличивать движущиеся и неподвижные изображения, записанные на ленты. Вы можете также перезаписывать увеличенные изображения на ленты или копировать на "Метогу Stick" (голько модел» DCR-TRV325E/TRV330E/TRV430E/TRV530E). Помимо операций, описанных в данном руководстве, Ваша видеокамера позволяет увеличивать неполамичьие изображения увеличивать неподвижные изображения, записанные на "Memory Stick" (только модели DCR-TRV325E/TRV330E/TRV430E/TRV530E).

- (1) В режиме воспроизведения или паузь воспроизведения нажмите кнопку PB ZOOM на Вашей видеокамере. Изображение увеличится, а на экране появятся индикаторы ↑↓, показывающие направление для переноса изображения
- (2) Поверните диск SEL/PUSH EXEC для ещения увеличенного изображения а затем нажмите диск.
  - † : Изображения перемещается вниз. ↓ : Изображение перемещается вверх.
- → появится на дисплее
- ← → появится на дисплее.
   (3) Поверинга диск SEL/PUSH EXEC для перемещения увеличенного изображения, а затем нажмите диск.
   ← изображение перемещается вправо (поверните диск вниз.)
   → изображение перемещается влево (поверните диск вверх.)



To cancel PB ZOOM function Press PB ZOOM

Для отмены функции PB ZOOM Нажмите кнопку PB ZOOM.

- Notes

  -PB ZOOM works only for tapes recorded in the Digitals I is system.

   You cannot process externally input scenes using PB ZOOM function.

   You cannot record pictures that you have processed using PB ZOOM function with this camcorder. To record pictures that you have processed using PB ZOOM function, record the pictures on the VCR using your camcorder as a nlaver.

Pictures processed by PB ZOOM function Pictures processed by PB ZOOM function are not output through the DV OUT or DV IN/OUT jack.

#### PB ZOOM function is automatically canceled

- when: the POWER switch is set to OFF (CHG)
- the FOWER SWITCH is S you stop playing back you press MENU you press TITLE

76

78

# Увеличение записанных изображений – Функция РВ ZOOM ленты

- Примечания
   Функция РВ ZOOM работает только для лент, записанных в системе Digital8 F).
   Вы не можете обрабатывать введенные с внешней аппаратуры изображения с помощью функции PB ZOOM.
- Вы не можете записывать изображения обработанные с помощью функции РВ ZOOM, на данной видеокамере. Для записи изображений, обработанных с помощью функции PB ZOOM, запишите изображения на КВМ с помощью видеокамеры, используя ее в качесте плейера.

## Изображения, обработанны

изооражения, обработанные с помощном ункции РВ ZOOM Изображения, обработанные с помощью функции РВ ZOOM, не передаются через гнездо DV OUT или DV IN/OUT.

## Функция РВ ZOOM автоматически

- оункция РВ ZOUM автоматически отменяется, если:

   переключатель POWER установлен в положение ОFF (CHG)

   Вы остановили воспроизведение

   Вы нажали кнопку MENU

   Вы нажали кнопку TITLE

#### Quickly locating a scene using the zero set memory function

corder goes forward or backward to automatically stop at a desired scene having a counter value of "0:00:00".

Use the Remote Commander for this operation. Use this function, for example, to view a desired scene later on during playback.

- scene later on during playback.

  (1) In the playback mode, press DISPLAY.
  (2) Press ZERO SET MEMORY at the point you want to locate later. The counter shows "0:00:00" and the ZERO SET MEMORY indicator flashes on the screen.
  (3) Press when you want to stop playback.

  (4) Press ◄ to rewind the tape to the counter's zero point. The tape stops automatically when the counter reaches approximately zero. The ZERO SET MEMORY indicator disappears and the time code appears.

  (5) Press ► Playback starts from the counter's zero point.
- zero point.

#### Быстрое отыскание эпизода с помощью функции памяти нулевой отметки

Ваша видеокамера выполняет продвижение Ваша видеокамера выполняет продвижение вперед или назад с автоматической остановкой в нужном эпизоде, где показание счетчика равно "0.00.00". Вы можете выполнять это с помощью пульта дистанционного управления. Используйте эту функцию, например, для просмотра нужного эпизода позже во время воспроизведения.

- (1) В режиме воспроизведения нажмите кнопку DISPLAY. (2) Нажмите кнопку ZERO SET MEMORY в месте, которое Вы захотите найти позже. Показание счетчика станет равным "0.00.00." и дашет истать индикатор толказание счетчика станет равным "0:00:00", и начнет милать индикатор ZERO SET MEMORY на экране. (3) Нажиите кнопку ■, если Вы захотите остановить воспроизведение. (4) Нажмите кнопку ◄ для ускоренной предмотил приты изала к имперей экс.
- перемотки ленты назад к нулевой точке счетчика. Лента остановится автоматически, если счетчик достигнет нулевой отметки. Индикатор ZERO SET MEMORY исчезнет, и появится код
- времени.

  (5) Нажмите кнопку ►. Воспроизведение начнется с нулевой отметки счетчика.



- wotes

  The zero set memory function works only for
  tapes recorded in the Digitals (1) system.

  When you press ZERO SET MEMORY before
- rewinding the tape, the zero set memory function is canceled.

   There may be a discrepancy of several seconds from the time code.

If a tape has a blank portion in the recorded

portions
The zero set memory function may not work correctly

- Примечания
   Функция памяти нулевой отметки работает только для лент, записанных в цифровой системе Digitals B1.
   Если Вы нажмете кнопку ZERO SET МЕМОRY до начала обратной перемотки ленты, то функция памяти нулевой отметки будет отменена.
   Может быть расхождение в несколько секунд между кодом времени и действительным временем.


Если на ленте имеется незаписанный участок между записанными изображениям Функция памяти нулевой отметки может не работать надлежащим образом.

#### Searching a recording by date - Date search

You can automatically search for the point where the recording date changes and start playback from that point (Date search). Use the Remote Commander for this operation. Use this function to check where recording dates change or to edit the tape at each recording date.

#### Поиск записи по дате Поиск даты

Вы можете выполнять автоматически поиск места, где изменяется дата записи и начинать воспроизведение с этого места (поиск даты). Используйте пульт дистанционного управления для таких операций. использумтот, управления для таких операций. Используйте эту функцию для проверки, где изменяются даты записи, или же для выполнения монтажа ленты в каждом месте



- (1) Set the POWER switch to PLAYER or VCR (DCR-TRV330E only).

  (2) Press SEARCH MODE on the Remote Commander repeatedly, until the date search indicator appears on the screen.

  The indicator changes as follows:

  → DATE SEARCH → PHOTO SEARCH → LONG SEARCH → PHOTO SEARCH → PHO
- changes. Each time you press ◄ or ►►I, the camcorder searches for the previous or next date.
- (1) Установите переключатель POWER в положение PLAYER или VCR (только модели DCR-TRV330E).
- модели DCR-TRV330E).

  (2) Нажимайте повторно кнопку SEARCH MODE на пульте дистанционного управления до тех пор, пока не появится индикатор поиска даты на экране. Индикатор будет изменяться следующим образова.
- образом:

  DATE SEARCH → PHOTO SEARCH | Ges индикатора) → PHOTO SCAN → Econ текущее положение соответствует варианту [Б], нажмите кнопку [◄4] для выполнения поиска в направлении [а] или нажмите кнопку № 1 для выполнения поиска в направлении [с]. Ваша видеожамера автоматически начнет воспроизведение в месте, где изменяется лата.
- дата. Всякий раз при нажатии кнопки ◄ или ►Н, видеокамера будет выполнять поиск предыдущей или следующей даты.

# 2 SEARC 3 DATE 01

# Searching a recording by date - Date search

To stop searching Press ■.

- The date search works only for tapes recorded
- The date search works only for tapes recorded in the Digital8 f) system.
   If one day's recording is less than two minutes your camcorder may not accurately find the point where the recording date changes.

If a tape has a blank portion in the recorded

portions
The date search function may not work correctly

#### Поиск записи по дате - Поиск даты

Для остановки поиска Нажмите кнопку ■.

- Примечания
   Режим поиска даты функционирует только для лент, записанных в цифровой системе
- для лент, записанных в цифровои системе Digitals  $\hat{\mathbf{H}}$ . Если в какой-либо из дней Ваша запись продолжалась менее одной минуты, Ваша видеокамера может точно не найти место, где изменяется дата записи.

Если на записанной ленте имеются незаписанные участки Функция поиска даты будет работать неправильно.

### Searching for a photo

- (1) Set the POWER switch to PLAYER or VCR
- (DCR-TRV330E only).
  (2) Press SEARCH MODE on the Remote Commander repeatedly, until the photo
- Commander repeatedly, until the photo search indicator appears on the screen.
  The indicator changes as follows:

  → DATE SEARCH → PHOTO SEARCH → (no indicator) ← PHOTO SCAN


  (3) Press I≪4 or ▶ It to select the photo for playback. Each time you press I≪4 or ▶ I, the camcorder searches for the previous or next photo. Your camcorder automatically starts playback from the photo.

#### Поиск фото Фотопоиск/ Фотосканирование

Вы можете выполнять поиск изображ записанного на ленту (фотоп Вы также можете выполнять Вы также можете выполнять поиск неподвижных изображений одно за другим и отображать каждое изображение пять секнд автоматически (фотосканирование). Используйте пульт дистанционного управления для этих операций.

#### Поиск фото

- (1) Установите переключатель POWER в положение PLAYER или VCR (только модели DCR-TRV330E).
- (2) Нажимайте повторно на пульте дистанционного управления кнопку SEARCH MODE до тех пор, пока не появится индикатор фотопоиска на Индикатор будет изменяться следующим
  - DATE SEARCH → PHOTO SEARCH



To stop searching

Для остановки поиска Нажмите кнопку ■

# Searching for a photo - Photo search/Photo scan

#### Scanning photo

- (1) Set the POWER switch to PLAYER or VCR
- (DCR-TRV330E only).
  (2) Press SEARCH MODE on the Remo (2) Press SEARCH → MODE on the Remote Commander repeatedly, until the photo scan indicator appears on the screen. The indicator changes as follows:


  → DATE SEARCH → PHOTO SEARCH (in indicator) ← PHOTO SCAN (3) Press | ← OP > PHOTO SEARCH (3) PRESS | ← O
- Each photo is played back for about 5 seconds automatically

#### Поиск фото - Фотопоиск/ Фотосканирование

#### Сканирование фото

- (1) Установите переключатель POWER в положение PLAYER или VCR (только модели DCR-TRV330E).
  (2) Нажимайте повторно на пульте
- дистанционного управления кнопку SEARCH MODE до тех пор, пока не появится индикатор фотосканирования. Индикатор будет изменяться следующим
- oбразом:

  → DATE SEARCH → PHOTO SEARCH → PHOTO SCAN (без индикатора) ← PHOTO SCAN
- (3) Нажмите кнопку І или ▶Ы. Каждое фото будет автоматически отображаться примерно 5 секунд.



To stop scanning

Note The photo search and photo scan work only for tapes recorded in the Digital8  $\Theta$  system.

If a tape has a blank portion in the recorded

portions
The photo search and photo scan functions may not work correctly.

#### Для остановки сканирования Нажмите кнопку

Примечание
Фотопоиск и фотосканирование
функционируют только для лент, записав
в цифровой системе Digital8 D.

незаписанные участки Функция фотопоиска и фотоска может работать неправильно.

80 81

— Editing —

## **Dubbing a tape**

Using the A/V connecting cable You can dub or edit on the VCR connected your camcorder using your camcorder as a

player.
Connect your camcorder to the VCR using the A/V connecting cable supplied with your

82

- Before operation
   Set DISPLAY to LCD in the menu settings. (The
- default setting is LCD.)

   Press the following buttons to make the indicators disappear so that they will not be
- Indicators disappears of that they will not be superimposed on the edited tape: DISPLAY on your camcorder DATA CODE on the Remote Commander SEARCH MODE on the Remote Commander
- (1)Insert a blank tape (or a tape you want to record over) into the VCR, and insert the recorded tape into your camcorder. (2)Set the input selector on the VCR to LINE. Refer to the operating instructions of your VCR for more information.
  (3)Set the POWER switch to PLAYER or VCR (DCR-TRV330E only). (4) Play back the recorded tape on your camcorder.
  (5)Start recording on the VCR. Refer to the operating instructions of your VCR for more information.

Монтаж -

# Перезапись ленты

кабеля аудио/видео
Вы можете выполнять перезапись или
монтаж на КВМ, подсоединенном к Вашей
видеокамере, используя Вашу видеокамеру
как проигрыватель.
Подсоедините Вашу видеокамеру к КВМ с
помощью соединительного кабеля аудио/
видео, который прилагается к Вашей
видеокамере.

- Перед эксплуатацией

   Установите пункт DISPLAY в установках меню в положение LCD. (По умолчанию установлено положение LCD.)

   Нажмите следующие кнопки для исчезновения индикаторов, чтобы они не были наложены на монтируемую ленту:


   кнопку DISPLAY на Вашей видеокамере

   кнопку DATA CODE на пульте листаниюновног уплавления
- дистанционного управления кнопку SEARCH MODE на пульте
- дистанционного управления
- (1) Вставьте незаписанную ленту (или ленту, на которую Вы хотите выполнить запись) в КВМ и вставьте записанную ленту в Вашу видеокамеру.
- (2) Установите селектор входного на КВМ в (2) Установите селектор входного на КВМ в положение LINE. Болое подробные сведения Вы сможете найти в инструкции по эксплуатации Вашего КВМ. (3) Установите переключатель РОWER в положение PLAYER или VCR (только

- положение РLАYEH или VCH (только модели DCR-TRV330);

  (4) Начните воспроизведение записанной ленты на Вашей видеокамере.

  (5) Начните запись на Вашем КВМ. Более подробные сведения Вы сможете найти в инструкции по эксплуатащии Вашего КВМ.



#### Dubbing a tape

When you have finished dubbing a

tape
Press ■ on both your camcorder and the VCR.

You can edit on VCRs that support the

If your VCR is a monaural type Connect the yellow plug of the A/V connecting cable to the video input Jack and the white or the dp lug to the audio input Jack on the VCR or the TV. When the white plug is connected, the left channel audio is output, and the red plug is connected, the right channel audio is output.

If your VCR has an S video jack Connect using an S video cable (optional) to

obtain high-quality pictures. With this connection, you do not need to connect the yellow (video) plug of the A/V connecting cable.

Connect an S video cable (optional) to the S video jacks of both your camcorder and the VCR

#### Перезапись ленты

Если Вы закончили перезапись ленты на КВМ.

Вы можете выполнять монтаж на КВМ, которые поддерживают следующие

системы: В 8 мм, НІВ Нів, ЖІБ VHS, SVIIS S-VHS, ЖІБЕ VHSC, SWISE S-VHSC, В Betamax, \*\*\*D,\* мини DV, D,\* DV или D Digital8

#### Если Ваш КВМ монофонического типа Подсоедините желтый штекер

соединительно кабеля аудио/видео к входному видеогнезду, а белый или красный штекер к входному аудиогнезду на КВМ или телевизоре. Если подсоединен белый штекер, то выходным сигналом будет звук певого канала, а если полсоели дным сигналом будет звук

Если в Вашем КВМ имеется гнездо S в

Если в Вашем КВМ имеется гнездо S видее Выполните подсоединение с помощью кабеля S видео (приобретается отдельно) для получения высококачественных изображений. При таком подсоединении Вам не нужно подсоединять желтый (видео) штекер соединительного кабеля аудио/видео. Подсоедините кабель S видео (приобретается отдельно) к гнездам S видео на Вашей видеокамере и КВМ.

Using the i.LINK cable (DV connecting cable)
Simply connect the i.LINK cable (DV connecting cable) (optional) to DV OUT or DV IN/OUT and to DV IN/OUT of the DV products. With digital-to-digital connection, video and audio signals are transmitted in digital form for high-quality editing. You cannot dub the screen indicators.

- (1)Insert a blank tape (or a tape you want to record over) into the VCR, and insert the recorded tape into your camcorder. (2)Set the input selector on the VCR to DV IN if it is available. Refer to the operating instructions of your VCR for more information.
- information.

  (3)Set the POWER switch to PLAYER or VCR (DCR-TRV330E only).

  (4) Play back the recorded tape on your
- camcorder.
  (5)Start recording on the VCR. Refer to the operating instructions of your VCR for more information.

#### Перезапись ленты

#### Использование кабеля і LINK (соединительного кабеля цифрового


(соединительного кабеля цифрового видеосигнала DV)
Просто подсоедините кабель i.LINK
(соединительный кабель цифрового видеосигнала DV) (приобретается отдельно) к гнезду DV ОUТ или DV IN/OUT и к гнезду DV OUT или DV IN/OUT и к гнезду DV OUT или DV IN/OUT и к гнезду DV OUT или DV IN/OUT и к гнезду DV IN/OUT имфоровых видеомзделий. При иффо-ифоровом соединении видео- и аудиосигналь передаются в иффором форме для последующего высококачественного монтажа. В нь можете выполнить перезапис монтажа. Вы не можете выполнить перезапись нных индикаторов

- (1) Вставьте незаписанную ленту (или ленту, на которую хотите выполнить запись) в КВМ и вставьте записанную ленту в Вашу видеокамеру.
- (2) Установите селектор входного сигнала на КВМ в положение DV IN, если оно имеется в наличии. Более подробные сведения приведены в
- волее подроные сведения приведены в инструкции по эксплуатации Вашего КВМ. (3) Установите переключатель РОМЕЯ в положение PLAYER или VCR (только иолели DCR-TRV330F)

- модели DCR-TRV330E).

  (4) Начните воспроизведение записанной ленты на Вашей видеокамере.

  (5) Начните запись на КВМ. Волее подробные оведения приведены в инструкции по эксплуатации Вашего КВМ.



## When you have finished dubbing a

tape
Press ■ on both your camcorder and the VCR.

Если Вы закончили перезапись ленты Нажмите кнопку **■** как на Вашей видеокамере, так и на КВМ.

#### Dubbing a tape

Note on tapes that are not recorded in the Digital8 P system The picture may fluctuate. This is not a malfunction.

During playback of tapes recorded in the Hi8/ standard 8 system Digital signals are output as the image signals from the DV OUT or DV IN/OUT jack.

You can connect one VCR only using the i.LINK cable (DV connecting cable). See page 190 for more infomation about i.LINK.

#### The following functions do not work during digital editing

- Picture effect Digital effect
- PB ZOOM

If you record playback pause picture via the DV OUT or DV IN/OUT jack
The recorded picture becomes rough. Also, when you play back the recorded pictures on other video equipment, the picture may jitter.

#### Перезапись ленты

## Примечание относительно лент, которые были записаны не в цифро Digital8 **I** Э

Возможно подрагивание изображения. Это не является неисправностью.

#### Во время воспроизведения лент, записанных в системе Hi8/стандартной системе 8

Цифровые сигналы выводятся в качестве сигналов изображения гнездо DV OUT или гнездо DV IN/ OUT.

#### Вы можете подсоединить только один КВМ с помощью кабеля i.LINK (соединительного кабеля цифрового идеосигнала DV). олее подробные сведения относительно

i.LINK приведены на стр. 190

Editing

# Следующие функции не работают во время цифрового монтажа: - Эффект изображения - Цифровой эффект - РВ ZООМ

При записи на паузе воспроизводимого изображения через гнездо DV OUT или DV IN/OUT Записанное изображение будет искаженным Также, при воспроизведении записанных изображений на другой видеоаппаратуре, изображение может подрагивать.

84

#### **Dubbing only desired** scenes - Digital program editing

You can duplicate selected scenes (programmes) for editing onto a tape without operating the VCR.
Scenes can be selected by frame. You can set up to 20 programmes.

Unwanted scene/ Unwanted scene Ненужный эпизод Ненужный эпизод ₹. Switch the order. порядок ₹. 

## Before operating the Digital program

Before operating the Digital program editing function Step 1 Connecting the VCR (p. 87). Step 2 Setting the VCR for operation (p. 87, 92) Step 3 Adjusting the synchronicity of the VCR (p. 93). When you dub using the same VCR again, you can skip steps 2 and 3.

## Using the Digital program editing

Operation 1
Operation 2
Operation 2
Operation 2
Operation 2
Operation 2
Operation 3
Operation 2
Operation 3
Operation 3
Operation 4
Operation 5
Operation 6
Operation 7
Operation 9
Operat

- Notes

   The Digital program editing works only for tapes recorded in the Digital8 1 system.

   You cannot dub titles or display indicators.


   When you connect with an i.LINK cable (DV connecting cable), you may not be able to operate the dubbing function correctly, depending on the VCR.
- Set CONTROL to IR in the menu settings of
- your camerorder .

   When editing digital video, the operation signals cannot be sent with LANC .

#### Перезапись только нужных эпизодов - цифровой монтаж программы

Вы можете копировать нужные эпизодь (программы) для монтажа на ленту без включения КВМ.

включения КВМ. Эпизоды можно выбирать покадрово. Вы можете установить до 20 программ.



## Перед применением функции пирименением функции цифрового монтажа программы Пункт 1 Подсоедините КВМ (стр. 87) Пункт 2 Подготовьте КВМ к работе (стр. 87,

92)
Пункт 3 Отрегулируйте синхронизацию КВМ (стр. 93)
Когда Вы перезаписываете, используя снова тот же КВМ, Вы можете пропустить пункты 2

Использование функции цифрового монтажа программы. Действие 1 Создание программы (стр. 95). Действие 2 Выполнение цифрового монтажа программы (перезапись ленты) (стр. 97).

- Примечания

   Цифровой монтаж программы работает только для лент, записанных в системе Digitale IP.

   Вы не можете перезаписывать титры или экранные индикаторы.

   Когда Вы выполняете подсоединение с помощью кабеля LLINK (соединительного имбеле имбеленоситнала DV), в кабеля цифрового видеосигнала DV), в зависимости от КВМ функция перезаписи
- зависимости от КВМ функция перезаписи может работать неправильно. Установите пункт СОЛТЯОL в установках меню Вашей видеокамеры в положение ІВ. При монтаже цифрового видео сигналы операции не могут быть посланы через интерфейс LANC .

# Dubbing only desired scenes - Digital program editing

## Step 1: Connecting the VCR

You can connect both an A/V connecting cable and an i.LINK cable (DV connecting cable). When you use the A/V connecting cable, connect the devices as illustrated in page 82. When you use an i.LINK cable (DV connecting cable), connect the devices as illustrated in page 84.

If you connect using an i.LINK cable (DV connecting cable)
With a digital-to-digital connection, video and

audio signals are transmitted in digital format for high-quality editing.

## Step 2: Setting the VCR to operate with the A/V connecting cable

To edit using the VCR, send the control signal by infrared ray to the remote sensor on the VCR. When you connect using an A/V connecting cable, follow the procedure below, (1) to (4), to send the control signal correctly.

#### Перезапись только нужных эпизодов · Цифровой монтаж программы

## Пункт 1: Подсоединение КВМ

Вы можете выполнить подсоединение с использованием как соединительного аудио/ видео кабеля, так и кабеля i.LINK (соединительного кабеля цифрового видеоситнала DV). Если Вы используете видеоси нала DV). Если вы используете соединительный аудио/видео кабель, подсоедините устройства, как показано на странице 82. Если Вы используете кабель i.LINK (соединительный кабель цифрового плик (соединительный кабель цифрового видеосигнала DV), подсоедините устройства, как показано на странице 84.

## Если Вы выполняете подсоеди использованием кабеля i.LINK (соединительного кабеля цифро

видеосигнала DV)
При цифро-цифровом соединении видео- и аудиосигналы передаются в цифровой форме

## Пункт 2: Настройка КВМ для работы с соединительным аудио/видео кабелем

ТДля монтажа с помощью КВМ пошлите ТДля монтажа с помощью КВМ пошлите управляющий сигнал инфракрасным лучом удаленному датчику на КВМ. Если Вы выполняете подсоединение с использованием соединительного аудио/ видео кабеля, следуйте описанным ниже процедурам (1)—(4), чтобы послать управляющий сигнал правильно.

# Dubbing only desired scenes - Digital program editing

# (1) Set the IR SETUP code

- (1) Set the IR SETUP code

  ① Set the POWER switch to PLAYER or VCR
  (DCR-TRV330E only) on your camcorder.

  ② Turn the power of the connected VCR on,
  then set the input selector to LINE.
  When you connect a video camera recorder,
  set its power switch to VCR-VTR.

  ③ Press MENU to display the menu.

  ④ Turn the SEL/PUSH EXEC dial to select Enten press the dial.

  ③ Turn the SEL/PUSH EXEC dial to select EDIT
  SET, then press the dial.

  ④ Turn the SEL/PUSH EXEC dial to select IR,
  then press the dial.

  ⑤ Turn the SEL/PUSH EXEC dial to select IR,
  then press the dial.

  ⑤ Turn the SEL/PUSH EXEC dial to select IR,
  SETUP, then press the dial.

  ⑤ Turn the SEL/PUSH EXEC dial to select IR
  SETUP, then press the dial.

  ⑤ Turn the SEL/PUSH EXEC dial to select IR
  SETUP code number of your VCR, then
  press the dial number of your VCR, then

- IR SETUP code number of your VCR, then press the dial.
  Check the code in "About the IR SETUP code." (p. 89)

#### Перезапись только нужных эпизодов – Цифровой монтаж программы

- (1) Установка кода IR SETUP

  ① Установите переключатель РОWER на Вашей видеокамере в положение PLAYER или VCR (только модель DCR-TRV330E).
  ② Включите питание подсоединенного КВМ и установите ослектор входов в положение LINE.
  Если Вы подсоединяете записывающую видеокамеру, установите ее переключатель титания в положение VCR/VTR.
  ② Нажмите кнопку МЕNU, чтобы отобразить меню.

- меню.


  ③ Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт сс. затем нажмите диск.
  ⑤ Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт EDIT SET, затем нажмите

- диск.

  © Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт CONTROL, затем нажмите диск.

  Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт IR, затем нажмите диск.

  В Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт IR SETUP, затем нажмите диск.



# Dubbing only desired scenes - Digital program editing

About the IR SETUP code
The IR SETUP code is stored in the memory of
your camcorder. Be sure to set the correct code
depending on your VCR. Default setting is code
number 3.

Brand/Mapka	IR SETUP code/
	Koд IR SETUP
Sony	1, 2, 3, 4, 5, 6
Aiwa	47, 53, 54
Akai	62, 50, 74
Alba	73
Aristona	84
Baird	36, 30
Blaupunkt	83, 78
Bush	74
Canon	97
CGM	47, 83, 36
Clatronic	73
Daewoo	26
Ferguson	76
Fisher	73
Funai	80
Goldstar	47
Goodmans	26, 84
Grundig	83, 9
Hitachi	42, 56
ITT/Nokia Instant	36
JVC	12, 21, 15, 11
Kendo	47
Loewe	16, 47, 84
Luxor	89
Mark	26*
Matui	47, 60, 58*
Mitsubishi	28, 29

\* TV/VCR component

#### Note on IR SETUP code

Digital program editing is not possible if the VCR does not support IR SETUP codes.

# Перезапись только нужных эпизодов – Цифровой монтаж программы

#### O KOZE IR SETUP

О коде IR SETUP Код IR SETUP хранится в памяти Вашей видеокамеры. Убедитесь, что Вы выбрали правильный код в зависимости от Вашего КВМ. По умолчанию установлено значени кода, равное 3.

. 63 * . 96 . 86
* , 96 , 86
* , 96 , 86
* , 96 , 86
, 96 , 86
, 86
,
, 52, 22
0
, 47

#### Примечание о коде IR SETUP

**Цифровой монтаж программы нев** если KBM не поддерживает кодов IR SETUP

89

Editing

# Dubbing only desired scenes - Digital program editing

88

90


- (2) Setting the modes to cancel recording pause on the VCR
  ① Turn the SEL/PUSH EXEC dial to select PAUSEMODE, then press the dial.
  ② Turn the SEL/PUSH EXEC dial to select the mode to cancel recording pause on the VCR, then press the dial.

#### Перезапись только нужных эпизодов - Цифровой монтаж программы

PRETURN

- (2) Установка режимов для отмены паузы записи на КВМ

  ① Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт PAUSEMODE, затем
- нажмите диск.
  ② Поверните диск SEL/PUSH EXEC, чтобы выбрать режим отмены паузы записи на КВМ, затем нажмите диск.



## Buttons for canceling recording pause on the VCR The buttons vary depending on your VCR. To

cancel recording pause:

- Select PAUSE if the button to cancel recording

- pause is  $\blacksquare$ . Select REC if the button to cancel recording
- pause is ●. -Select PB if the button to cancel recording pause

(3) Setting your camcorder and the VCR to face each other Locate the infrared rays emitter of your camcorder and face it towards the remote sense of the VCR. Set the devices about 30 cm (117/8 in.) apart, and remove any obstacles between the devices.


#### Кнопки для отмены паузы записи на КВМ Кнопки могут отличаться, в зависимости от Вашего КВМ. Чтобы отменить паузу записи:

- вашето към. посы отменять пързу записи. Выберите кнопку PAUSE, если для отмены паузы записи служит кнопка **II**. Выберите кнопку REC, если для отмены
- паузы записи служит кнопка ●. Выберите кнопку РВ, если для отмень паузы записи служит кнопка

## (3) Установка Вашей видеока

(3) Установка Вашей видеокамерь КВМ друг напротив друга
Определите, где находится излучатель инфракрасных лучей на Вашей видеокам и направьте его на удаленный датчик на КВМ.
Установите устройства на расстоянии ок 30 см длуг от длуга и удалите все

30 см друг от друга и удалите все препятствия между ними.



# Dubbing only desired scenes - Digital program editing

- (4) Confirming VCR operation
  ① Insert a recordable tape into the VCR, then set
- to recording pause.
  ② Turn the SEL/PUSH EXEC dial to select IR
- TEST, then press the dial.

  ③ Turn the SEL/PUSH EXEC dial to select EXECUTE, then press the dial. If the VCR starts recording, the setting is correct. When finished, the indicator on the screen

nges to COMPLETE.


#### Перезапись только нужных эпизодов - Цифровой монтаж программы


- (4) Подтверждение действия КВМ

  ① Установите записываемую кассету в КВМ и установите его на паузу записи.

  ② Поверните диск SEL/PUSH EXEC, чтобы
- выбрать пункт IR TEST, затем нажмите диск.

  ③ Поверните диск SEL/PUSH EXEC, чтобы
- выбрать пункт EXECUTE, затем нажмите диск. Если КВМ начал запись, настройка если към начал запись, настроика выполнена правильно. По окончании индикатор изменится на COMPLETE.





- When the VCR does not operate correctly
   After checking the code in "About the IR
  SETUP code", set the IR SETUP or the
  PAUSEMODE again.

## Если КВМ не работает надлежащим

- образом
   После проверки кода в пункте "О коде IR
   SETUP", установите пункт IR SETUP или
   PAUSEMODE еще раз.
   Поместите Вашу видеокамеру на
   расстоянии, по крайней мере, 30 см от КВМ.
   Обращайтесь к руководству по
  -

# Dubbing only desired scenes - Digital program editing

# Step 2: Setting the VCR to operate with the i.LINK cable (DV connecting cable)

When you connect using an i.LINK cable (DV connecting cable) (optional), follow the

- (1) Set the POWER switch to PLAYER or VCR (DCR-TRV330E only) on your camcorder.

  (2) Turn the power of the connected VCR on, then set the input selector to DV input. When you connect a digital video camera recorder, set its power switch to VCR/VTR.

  (3) Press MENU to display the menu.

  (4) Turn the SEL/PUSH EXEC dial to select Enter press the dial
- then press the dial.
  (5) Turn the SEL/PUSH EXEC dial to select EDIT
- (5) Turn the SEL/PUSH EXEC dial to select SET, then press the dial.
  (6) Turn the SEL/PUSH EXEC dial to select CONTROL, then press the dial.
  (7) Turn the SEL/PUSH EXEC dial to select i.LINK, then press the dial.

#### Перезапись только нужных эпизодов – Цифровой монтаж программы

# Пункт 2: Настройка КВМ для работы с кабелем i.LINK (соединительным кабелем цифрового видеосигнала DV)

Если Вы выполняете подсоединиспользованием кабеля i.LINK (соединительного кабеля цифрового видеосигнала DV) (не прилагается), следуйте описанным ниже процедурам.

- описанным ниже процедурам.

  (1) Установите переключатель POWER на Вашей видеокамере в положение PLAYER или VCR (только модель DCR-TRV330E).

  (2) Включите питачие подсоединенного КВМ и установите селектор входов в положение входа цифрового видеоситнала.


  Если Вы подсоединяете записывающую цифровую видеокамеру, установите ее переключатель питания в положение VCR/VTR.


  (3) Нажмите кнопку MENU, чтобы отобразить меню.
- меню.

  (4) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт [тс], затем нажмите диск.

  (5) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт EDIT SET, затем нажмите
- диск. (6) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт CONTROL, затем нажмите
- диск. (7) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт i.LINK, затем нажмите диск

## 3 0 0 MENI 6,7 ♦





# Dubbing only desired scenes - Digital program editing

# Step 3: Adjusting the synchronicity of the VCR

You can adjust the synchronicity of your camcorder and the VCR. Have a pen and paper ready for notes. Before operation, eject the cassette from your camcorder.

- Set the POWER swiich to PLAYER or VCR
- (DCR-TRV330E only) on your camcorder.
  Insert a blank tape (or a tape you want to record down into the VCR, then set to
- record over) into the VCR, then set to recording pause. When you select ILINK in CONTROL, you do not need to set to recording pause. Turn the SEL/PUSH EXEC dial to select ADJ TEST, then press the dial. Turn the SEL/PUSH EXEC dial to select EXECUTE, then press the dial. In and OUT are recorded on an image for 5 times each to calculate the numerical values for adjusting the synchronicity. The EXECUTING indicator flashes on the screen. When finished, the indicator changes to COMPLETE. Rewind the tape in the VCR, then start slow playback.
- playback.
  Take a note of the opening numerical value for each IN and the closing numerical value for each OUT.
- Calculate the average of all the opening numerical values for each IN, and the average of all the closing numerical values for each OUT. Turn the SEL/PUSH EXEC dial to select
- "CUT-IN", then press the dial. Turn the SEL/PUSH EXEC dial to select the
- average numerical value of IN, then press the dial. The calculated start position for recording is
- set.

  (9) Turn the SEL/PUSH EXEC dial to select
  "CUT-OUT", then press the dial.

  (10) Turn the SEL/PUSH EXEC dial to select the
  average numerical value of OUT, then press
  the dial. The calculated stop position for recording is
- set.

  (11) Turn the SEL/PUSH EXEC dial to select 

  RETURN, then press the dial.

# Перезапись только нужных эпизодов – Цифровой монтаж программы

# Пункт 3: Регулировка синхронизации КВМ

Вы можете отрегулировать синхронизацию Вашей видеокамеры и КВМ. Приготовьте ручку и бумагу для записей. Перед началом выполнения операций извлеките кассету из Вашей видеокамеры.

- Установите переключатель POWER на
- Установите переключатель РОWER на Вашей видкокамере в положение PLAYER или VCR (только модель DCR-TRV330E). Установите чистую ленту (или ленту, на которую Вы хотите записать) в КВМ и установите его на паузу записи. Если в пункте меню CONTROL Вы выберете пункт LINK, Вам не нужно устанавливать на паузу записи. Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт ADJ TEST, затем нажмите диск.
- - поверити в дика доста и выбрать пункт ADJ TEST, затем нажмите диск. Поверите диск SEL/PUSH EXEC, чтобы выбрать пункт EXECUTE, затем нажмите диск. На изображении будут записаны сигналы IN и OUT по 5 раз каждый, чтобы вычислить числовые значения для регулировки синхронизации. Индикатор EXECUTING мигает на экране ЖКД или в видомскателе. По окончании индикатор изменится на СОМРLETE. Перемотайте ленту в КВМ назад и начните замедление на состроизведение. Запишите начальное численное значение для каждого сигнала IN и конечное численное значение для
- значение для каждого сигнала ії и и конечное численное значение для каждого сигнала ОUТ. Подсчитайте ореднее для всех начальных численных значенных численных значенных численных значений каждого сигнала IN и среднее для всех конечных численных значений каждого сигнала ОUТ. Поверните диск SEU/PUSH EXEC, чтобы выбрать пункт "CUT-IN", затем нажмите лигк
- диск. Поверните диск SEL/PUSH EXEC, чтобы
- диск.

  Поверните диск SEL/PUSH EXEC, чтобы выбрать среднее численное значение величины IN, затем нажмите диск. Установится вычисленная позиция старта записи.

  (9) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт "CUT-OUT", затем нажмите диск.

  (10) Поверните диск SEL/PUSH EXEC, чтобы выбрать среднее численное значение величины OUT, затем нажмите диск. Установите выписиненная позиция остановки записи.

  (11) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт ⊋ RETURN, затем нажмите диск.


93

iting

#### **Dubbing only desired scenes** - Digital program editing

92

#### Перезапись только нужных эпизодов - Цифровой монтаж программы



- When you complete step 3, the image to adjust the syncronicity is recorded for about 50 seconds
- seconds.

  If you start recording from the very beginning of the tape, the first few seconds of the tape may not record properly. Be sure to allow about 10 seconds' of lead before starting the recording.

  When you connect using an i.LINK cable (DV connecting cable) you may not be able to operate the dubbing function correctly, depending on the VCR.

  Keep the i.LINK connection, and set CONTROL to IR in the menu settings. (p. 107)

  Video and audio signals are transmitted in digital format.

- Примечания
   Когда Вы выполните шаг 3, изображение
- Когда Вы выполните шаг 3, изображение для регулировки оинхронизации будет записываться около 50 секунд.

   Если Вы начнете запись с самого начала ленты, первые некоколько секунд, ленты могут записаться некачественно. Убедитесь, что Вы оставили пустой участ около 10 секунд перед началом записи.

   Если Вы выполняете подсоединение с использованием кабеля LLMK (соединительного кабеля цифрового видеоситнала DV), Вы можете не суметь правильно выполнить функцию перезапи в зависимости от КВМ.
  Поддерживайте соединение LLINK и в зависимисти от КВМ. Поддерживайте соединение i.LINК и установите пункт CONTROL в установиеню в положение IR. (стр. 107) Видео- и аудиосигналы передаются в цифровой форме.

# Dubbing only desired scenes - Digital program editing

#### Operation 1: Making the programme

- (1) Insert the tape for playback into your camcorder, and insert a tape for recording into the VCR.

  (2) Press MENU to display the menu.

  (3) Turn the SEL/PUSH EXEC dial to select ₹€0, then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select VIDEO EDIT, then press the dial.

  (5) Search for the beginning of the first scene you want to insert using the video operation buttons, then pause playback.

  (6) Press the SEL/PUSH EXEC dial.

  The IN point of the first programme is set,
- (6) Press the SEL/PUSH EXEC dial. The IN point of the first programme is set, and the top part of the programme mark changes to light blue.
  (7) Search for the end of the first scene you want to insert using the video operation buttons,
- then pause playback.
  (8) Press the SEL/PUSH EXEC dial.
- The OUT point of the first programme is set, then the bottom part of the programme mark changes to light blue.
- (9) Set the programme by repeating steps 5 to 8. When the programme is set, the programme mark changes to light blue.
  You can set a maximum of 20 programmes.

#### Перезапись только нужных эпизодов - Цифровой монтаж программы

## Действие 1: Создание программы

- (1) Установите ленту для воспроизведения в Вашу видеокамеру, а затем установите ленту для записи в КВМ.
  (2) Нажмите кнопку МЕNU для отображения
- меню.
  (3) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт [тт], затем нажмите диск.
  (4) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт VIDEO EDIT, затем нажмите диск.

- выбрать пункт VIDEO EDIT, затем нахимите диск.


  (5) Выполните поиск начала первого эгизода, который Вы хотите вставить, используя кнопки управления видео, и поставьте воспроизведение на паузу.

  (6) Нажмите диск SEL/PUSH EXEC. Точка IN первой программы установлена, и цвет верхней части метки программы изменяется на светло-голубой.

  (7) Выполните поиск конца первого эпизода, который Вы хотите вставить, используя кнопки управления видео, и поставьте воспроизведение на паузу.

  (8) Нажмите диск SEL/PUSH EXEC. Точка OUT первой программы установлена, и цвет нижней части метки программы изменяется на светло-голубой.

  (9) Установите программу, повторяя пункты 5-8. Когда программы изменяется на светло-голубой. Вы можее установите, аком 6 большее, 20 программ.



# питания в положение VCRVTR. (1) Выберите режим VIDEO EDIT. Поверните диск SELPUSH EXEC, чтобы выбрать пункт START, автем нажмите диск. (2) Поверните диск SELPUSH EXEC, чтобы выбрать пункт EXECUTE, затем нажмите диск. (2) Поверните диск EU-PUSH EXEC, чтобы выбрать пункт EXECUTE, затем нажмите диск. В поражмы и начните перезапись. Начнет мигать метка программы. Индикатор SEARCH появляется во время поиска, а индикатор EDIT появляется во время монтажа на экране. Метка программы изменяет свой цвет на светло-голубой после завершения перезаписи. По окончании перезаписи, Ваша видеокамера и КВМ автоматически останавливаются. Для остановки перезаписи во время

Перезапись только нужных эпизодов – Цифровой монтаж программы

цифрового монтажа программы

Убедитесь, что Ваша видеокамера и КВМ соединены, а КВМ установлен на паузу записи. Если Вы использует в кабель I.LINK (соединеньый кабель цифрового видеосигнала DV), выполнять следующую процедуру не нужно. Если Вы используете записывающую цифровую видеокамеру, установите ее переключатель питания в положение VCR/VTR.

Действие 2: Выполне

(перезапись ленты)

Нажмите кнопку ■ на Вашей видеокамере.

Для окончания функции цифрового монтажа программы
Ваша видеокамера останавливается, когда перезапись завершена. Затем отображение перезапись завершена. Затем отооражен установок меню возвращается к пункту VIDEO EDIT. Нажмите кнопку MENU для окончания функции цифрового монтажа программы.

#### Вы не можете записывать на КВМ, если:

- Лента закончилась.
  Лепесток защиты от записи установлен в положение блокировки.
  Код IR SETUP неверный. (Если выбран режим IR.)
- режим IR.) Кнопка для отмены паузы записи неверна. (Если выбран режим IR.)

## На экране высвечивается индикация NOT READY, если:

- READY, если:
   Не создана программа для выполнения
  цифрового монтажа программы.
   Выбран режим і. LINК, но кабель і. LINК
  (соединительный кабель і. LINК
  соединительный кабель іцфрового
  видеосигнала) не подсоединен.
   Питание приосоединенного КВМ не включен
  (если Вы установили режим і. LINК.)

97

#### **Dubbing only desired scenes** - Digital program editing

Erasing the programme you have set Erase OUT first and then IN from the last set

(1) Turn the SEL/PUSH EXEC dial to select UNDO, then press the dial. (2) Turn the SEL/PUSH EXEC dial to select EXECUTE, then press the dial. The last set programme mark flashes, then the setting is canceled.

## Erasing all programmes

(1) Select VIDEO EDIT in the menu settings. Turn the SEL/PUSH EXEC dial to select ERASE

ALL, then press the dial.
(2) Turn the SEL/PUSH EXEC dial to select EXECUTE, then press the dial. All the programme marks flash, then the settings are canceled.

To cancel erasing all programmes Select RETURN in step 2

To cancel a programme you have set Press MENU

The programm tape is ejected. ime is stored in memory until the

96

- The Digital program editing does not work when PB MODE is set to FIE in the menu
- You cannot operate recording during Digital program editing.

You cannot set IN or OUT to the following

- portions of the tape:
   a blank portion of the tape
   a portion recorded in a system other than
  Digital8 [ )

- The total time code may not be displayed correctly in the following cases:
   there is a blank portion between IN and OUT on the tape the tape is not recorded in the Digital8  $\Theta$  system.

Перезапись только нужных эпизодов

Erasing the programme you have set

Стирание программы, которую Вы установилі Первой удалите точку OUT, а затем точку IN

(1) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт UNDO, затем нажмите

диск. (2) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт EXECUTE, затем нажмите

диск. Метка последней установленной

**Для отмены стирания**Выберите пункт RETURN в пункте 2.

программы мигает, затем установка

Стирание всех программ
(1) Выберите пункт VIDEO EDIT в установках меню. Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт ERASE ALL, затем

(2) Поверните диск SEL/PUSH EXEC, чтобы выбрать пункт EXECUTE, затем нажмите

диск. Метки всех установленных программ мигают, затем установки отменяются.

Для отмены стирания всех програми Выберите пункт RETURN в пункте 2.

Для отмены программы, которую Вы

Программа сохраняется в памяти до тех пор, пока лента не будет извлечена.

Примечания

• Цифровой монтаж программы не работает, если пункт РВ МОDE в установках меню установлен в положение **НВИВ**. Вы не можете выполнать запись во время цифрового монтажа программы.

Вы не можете устанавливать точки IN и

-на участке ленты, записанном в системе, отличной от Digital8 **→**.

OUT на следующих участках ленты:
- на незаписанном участке ленты

Общий код времени может отображ ощии код времени может отогражатьс еправильно в следующих случаях: – если между точками IN и OUT есть незаписанный участок ленты – лента записана не в системе Digital8 [•).

установили Нажмите кнопку MENU.

Цифровой монтаж программы

последней програмы

отменяется.

DCR-TRV330E only
You can capture images and sound from an analog video unit connected to your computer which has the i.LINK (DV) jack to your

Using with analog video

unit and your computer

- Signal convert function

Before operation Set DISPLAY to LCD in the menu settings. (The default setting is LCD.)

(1)Set the POWER switch to VCR.

(2)Set A/V → DV OUT in to ON in the menu settings. (P. 107)

(3) Start playback on the analog video unit.

(4)Start capturing procedures on your computer
The operation procedures depend on your
computer and the software which you use. For details on how to capture images, refer to the instruction manual of your computer and

## Использование с аналоговым видеоаппаратом и персональным компьютером – Функция преобразования сигналов


## – Только DCR-TRV330E

Вы можете закватывать изображения и с аналоговых видеоаппаратов, присоединенных через Вашу видеокамер персональному компьютеру со штекером персональному компьютеру со шт i.LINK (цифрового видеосигнала).

Перед применением Установите пункт DISPLAY в установках меню в положение LCD. (По умолчанию выбрано положение LCD.)

- Установите переключатель POWER в положение VCR.
- (2) Установите опцию A/V → DV OUT в положение ☑ ON в установках мен (стр. 107).
- ите воспроизведение на аналоговом
- (4) Начните процедуру записи на Вашем

) Начните процедуру ос.... компьютере. Эти процедуры зависят от Вашего эти процедуры зависят от Вашего компьютера и программного обеспечения, которое Вы используете. Подробные сведения о записи изображений приведены в руководстве по использованию программного



## After capturing images and sound top capturing procedares on your computer, nd stop the playback on the analog video unit.

После записи изображений и звука Остановите процедуру записи на Вашем компьютере и остановите воспроизведение на аналоговом видеоаппарате.

# Using with analog video unit and your computer - Signal convert function

Dubbing only desired scenes
- Digital program editing

Operation 2: Performing Digital

program editing (Dubbing a tape)

Make sure that your camcorder and VCR are connected, and that the VCR is set to recording

(1) Select VIDEO EDIT. Turn the SEL/PUSH EXEC dial to select START, then press the

(2) Turn the SEL/PUSH EXEC dial to select

To stop dubbing during editing

To quit the Digital program editing

Your camcorder stops when dubbing is complete. Then the display returns to VIDEO EDIT in the

menu settings. Press MENU to quit the Digital program editing

The tape has run out.
The write-protect tab on the cassette is set to lock.
The IR SETUP code is not correct. (when IR is

selected)
- The button to cancel recording pause is not correct. (when IR is selected)

NOT READY appears on the screen when:

The programme to operate Digital program editing has not yet been made.

-i.LINK is selected but an i.LINK cable (DV connecting cable) is not connected.

-The power of the connected VCR is not turned on. (when you set i.LINK)

You cannot record on the VCR when

)Turn the SEL/PUSH EXEC dial to select EXECUTE, then press the dial. Search for the beginning of the first programme, then start dubbing. The programme mark flashes. The SEARCH indicator appears during a search, and the EDIT indicator appears during editing on the screen. The programme mark changes to light blue after dubbing is complete. When dubbing ends, your camcorder and the VCR automatically stop.

pause. This procedure is not necessary when you use an i.LINK cable (DV connecting cable). When you use a digital video camera recorder, set its power switch to VCR/VTR.

function.

- You need to install software which can
- You need to install software which can exchange video signals.
  Depending on the condition of the analog video signals, the computer may not be able to output the images correctly when you convert analog video signals into digital video signals via your camcorder. Depending on the analog video unit, the image may contain noise or incorrect colours.
- via your cannot record or capture the video output via your camcorder when the video tapes include copyright protection signals.

#### Использование с аналоговым видеоаппаратом и персональным компьютером – Функция преобразования сигналов

- Вам нужно установить программное обеспечение, позволяющее выполнять обмен видеосигналов.
- В зависимости от состояния аналоговых видеосигналов, компьютер может не передавать изображения надлежащим передавать изооражения надлежащим образом при преобразовании аналоговых видеосигналов в цифровые видеосигналы с помощью Вашей видеокамеры. В зависимости от аналогового видеоаппарата,
- зависимости от аналогового видеоаппарата, изображение может содержать помехи или искаженные цвета.

  Вы не можете выполнять запись или съемку выходных видеосигналов с помощью Вашей видеокамеры, если видеокассеты содержат сигналы защиты авторских прав.

#### Recording video or TV programmes

#### - DCR-TRV330F only

Using the A/V connecting cable
You can record a tape from another VCR or a TV
programme from a TV that has video/audio
outputs. Use your camcorder as a recorder.

Before operation Set DISPLAY to LCD in the menu settings. (The default setting is LCD.)

- (1) Insert a blank tape (or a tape you want to record over) into your camcorder. If you are recording a tape from the VCR, insert a recorded tape into the VCR.

  (2) Set the POWER switch to VCR.

- (2) set the FOWER SWITCH TO VEX.

  3) Press ♥ REC and the button on its right simultaneously on your camcorder, then immediately press II on your camcorder.

  (4) Press ▶ on the VCR to start playback if you are recording a tape from VCR. Select a TV programme if you are recording from TV. The picture from a TV or VCR appears on the screen of your camcorder.

#### Запись видео или телевизионных программ

#### - Tonsko DCR-TRV330F

## Использование соединительного

Использование соединительного кабеля аудио/видео Вы можете записать ленту с другого КВМ или телевизионной программы с телевизора, в котором имеются выходы видео/аудио. Используйте Вашу видеокамеру в качестве матнитогиють.

Перед экплуатацией Установите опцию DISPLAY в положение LCD в установках меню. (Установке по умолчанию соответствует LCD.)

- (1) Вставьте незаписанную ленту (или ленту, на которую Вы хотите выполнить перезапись) в Вашу видеокамеру. Если Вы записываете ленту с КВМ, вставьте записанную ленту в КВМ.
  (2) Установите переключатель POWER в положение VCR.
- (3) Нажмите кнопку REC и кнопку справа
- ) Нажмите кнопку Ф REC и кнопку справа от нее одновременно на Вашей видеокамере, а затем тотчас же нажмите кнопку II на Вашей видеокамере. Нажмите кнопку ► на КВМ для начала воспроизведения, если Вы записываете ленту с КВМ. Выберите телевизмонную программу, если Вы записываете программу, если Вы записываете программу стивем записываете записываете телерамора или КВМ
- телевизора или КВМ.

  (5) Нажмите кнопку II на Вашей видеокамере в том месте, где Вы хотите начать запись.

#### Recording video or TV programmes

## When you have finished dubbing a tape Press ■ on both your camcorder and the VCR.

- Notes To enable smooth transition, we recommend that you do not mix pictures recorded in the Hi8/standard 8 with the Digital8 [3] system on a
- rino' sandard or with the Digitalo PS system cape.

  If you fast-forward or slow-playback on the other equipment, the image being recorded may fluctuate. When recording from other equipment, be sure to play back the original tape at normal speed.

If your VCR is a monaural type Connect the yellow plug of the A/V connecting cable to the video output jack and the white or the red plug to the audio output jack on the VCR or the TV. When the white plug is connected, the left channel audio is output, and the red plug is connected, the right channel audio is output.

# If your TV or VCR has an S video jack

Connect using an S video cable (optional) to obtain high-quality pictures. With this connection, you do not need to connect be yellow (video) plug of the A/V connecting cable.

Connect an S video cable (optional) to the S video jacks of both your camcorder and the TV or VCR.

#### Запись видео или телевизионных программ

## Если Вы закончили перезапись на

# тенту Нажмите кнопку ■ на видеокамере и на КВМ.

- Для обеспечения плавного перехода рекомендуется не смешивать изображения, записанные в системе Hi8/стандартной системе 8 с цифровой системой Digital8 1) на


Editing

## Если Ваш КВМ монофоническ

Если Ваш КВМ монофонического типа Подсоедините желтый штекер соединительного кабеля аудио/видео к выходному видео-пезду, а белый или красный штекер к выходному аудиогнезду на КВМ или телевизоре. Если подсоединен белый штекер, то выходной сигнал будет передаваться через левый канал, а если подсоединен красный штекер, то выходной сигнал будет штекер, то выходной сигнал будет передаваться через правый канал.

Если в Вашем телевизоре или КВМ имеется гнездо S видео Выполните подсоединение с помощью кабеля S видео (приобретается отдельно) для получения высококачественных изображений

При данном подсоединении Вам не нужно подсоединять желтый (видео) штекер соединительного кабеля аудио/видео Подсоедините кабель S видео (приобретается отдельно) к гнездам S видео на вилеокамереи телевизоре или КВМ.



100 101

#### Recording video or TV programmes

## Using the i.LINK cable (DV connecting

cable)
Simply connect the i.LINK cable (DV connecting cable) (optional) to DV IN/OUT and to DV IN/OUT of the DV products. With digital-to-digital connection, video and audio signals are transmitted in digital form for high-quality editing.

Before operation Set DISPLAY to LCD in the menu settings. (The default setting is LCD.)

- (1) Insert a blank tape (or a tape you want to
- (1) Insert a blank tape (or a tape you want to record over) into your camcorder, and insert the recorded tape into the VCR.
  (2) Set the POWER switch to VCR.
  (3) Fress REC and the button on its right simultaneously on your camcorder, then immediately press on your camcorder.
  (4) Press on the VCR to start playback. The picture from a TV or VCR appears on the screen of your camcorder.
  (5) Press on your camcorder at the scene where you want to start recording from.


#### Запись видео или телевизионных программ

# Использование кабеля Использование кабеля i.LINK (соединительного кабеля цифрового видеосигнала DV) Просто подсоедините кабель i.LINK (соединительный кабель цифрового

видеосигнала DV) (приобретается отдельно) к гнезду DV IN/OUT или DV IN/OUT и к гнезду DV IN/OUT цифровых видеоизделий. При цифро-цифровом подсоединении видеоаудиосигналы передаются в цифровой форме для высококачественного монтажа

Перед экплуатацией Установите опцию DISPLAY в положение LCD в установках меню. (Установке по умолчанию соответствует LCD.)

- Вставьте незаписанную ленту (или ленту, на которую Вы хотите выполнить перезапись) в Вашу видеокамеру и вставьте ленту для записи в КВМ.
   Установите переключатель POWER в положение VCR.
   Нажмите кнопку ВЕС и кнопку справа от вее опиреромение в Вашей.
- от нее одновременно на Вашей видеокамере, а затем тотчас же нажмите кнопку **II** на Вашей видеокамере. (4) Нажмите кнопку **>** на КВМ для начала
- воспроизведения. Изображение от телевизора или KBM
- появится на экране. (5) Нажмите кнопку **II** на Вашей видеокамере в том месте, где Вы хотите начать запись



: Signal flow/(приобретается отдельно)

## When you have finished dubbing a

tape
Press ■ on both your camcorder and the VCR.

Если Вы закончили перезапись на ленту Нажмите кнопку ■ на видеокамере и на КВМ.

## Recording video or TV programmes

You can connect one VCR only using the i.LINK

During digital editing
The colour of the display may be uneven.
However this does not affect the dubbed picture.

## If you record playback pause picture with the

The recorded picture becomes rough. And when you play back the picture using your camcorder, the picture may jitter.

Before recording
Make sure if the DV IN indicator appears on the
screen of your camcorder by pressing DISPLAY.
The DV IN indicator may appear on both

#### Запись видео или телевизионных программ

Вы можете подсоединить один КВМ только с помощью кабеля i.LINK (соединительный кабель DV).

#### Во время цифрового монтажа

Цвет дисплея может быть неравномерным Однако это не влияет на перезаписываемо изображение

# При записи изображения в режиме паузы воспроизведения через гнездо DV IN/OUT Записанное изображение станет искаженным. А если Вы воспроизводите изображение с помощью Вашей видеокамеры, изображение может подрагивать.

Перед записью Убедитесь, появится ли индикатор DV IN на экране Вашей видеокамеры, путем нажатие кнопки DISPLAY. Индикатор DV IN может появиться на обоих аппаратах.

### Вставка эпизода с КВМ Монтаж вставок


(1) Установите переключатель POWER в положение VCR.
(2) На КВМ, найдите место как раз перед точкой начала вставки [а], затем нажмите кнопку III для установки КВМ в режим паузы воспроизведения.
(3) На Вашей видеокамере, найдите точку конца вставки [с], нажав кнопку ◄◄ или установки видеокамеры в режим паузы воспроизведения.

установки видеокамеры в режим науза-воспроизведения. (4) Нажмите кнопку ZERO SET MEMORY на пульте дистанционного управления. Начнет мигать индикатор ZERO SET МЕМОRY, а точка конца вставки будет сохранена в памяти. (5) На Вашей видеокамере, найдите точку начала вставки [b], нажав кнопку ◄4.

затем одновременно нажмите кнопку • REC и кнопку справа для установки Вашей видеокамеры в режим паузы

Вашей видеокамеры в режим паузы записи.

(6) Сначала нажмите кнопку II на КВМ, а через несколько секунд нажмите кнопку II на Вашей видеокамере для начала вставки нового эпизода. Вставка автоматически остановится возле нулевой точки на счетчике. Ваша видеокамера автоматически остановится. Точка конца вставки (с), сохраненная в ламети. Купат вънкуписована. памяти, будет аннулирована.



#### Inserting a scene from a VCR - Insert Editing

## - DCR-TRV330E only


You can insert a new scene from a VCR onto your originally recorded tape by specifying the insert start and end points. Use the Remote Commander for this operation. Connections are the same as in "Recording video or TV programmes" on page 100, 102. Insert a cassette containing the desired scene to insert into the VCR.

## – Только DCR-TRV330E

Вставка эпизода с

- Только DCR-TRV330E
Вы можете вставить новый эпизод с КВМ на
Вашу первоначально записанную ленту,
указав точки начала и конца вставок.
Для этой операции используйте пульт
дистанционного управления.
Подсоединения являются такими же, как и в
разделе "Запись видео или телевизионных
программ" на стр. 100, 102. Вставьте кассету,
на которой содержится нужный эпизод для
вставки в КВМ.

КВМ - Монтаж вставок



- [A]: A tape that contains the scene to be superimposed
- [B]: A tape before editing
- [C]: A tape after editing
- [А]: Лента, содержащая эпизод для
- [В]: Лента перед монтажем
- [С]: Лента после монтажа

104 105

# Inserting a scene from a VCR - Insert Editing

# To change the insert end point Press ZERO SET MEMORY again after step 5 to erase the ZERO SET MEMORY indicator and begin from step 3.

- Notes

  'The zero set memory function works only for tapes recorded in the Digital8 19 system.

  'The picture and sound recorded on the section between the insert start and end points will be erased when you insert the new scene.

When the inserted picture is played back The picture may be distorted at the end of the inserted section. This is not a malfunction.

To insert a scene without setting the insert

end point Skip step 3 and 4. Press ■ when you want to stop inserting.

#### Вставка эпизода с КВМ - Монтаж вставок

Для изменения точки конца вставки Нажмите кнопку ZERO SET MEMORY еще раз после пункта 5 для удаления индикатора ZERO SET MEMORY и начните с действия пункта 3.

- Примечания 
  Функция памяти установки нуля работает 
  только для лент, записанных в цифровой 
  системе Digitals F1. 
  Члображение и звук, записанные на участке 
  между точками начала и конца вставки, 
  будут стерты, если Вы вставите новый 
  эпизол.

При воспроизведение вставленного изображения
Изображение может быть искажено в конце вставленного участка. Это не является неисправностью.

## Для вставки эпизода без установки точки

конца вставки
Пропустите пункт 3 и 4. Нажмите кнопку ■, если Вы хотите остановить вставку.

#### — Customizing Your Camcorder —

Inserting a scene from a VCR - Insert Editing

(1) Set the POWER switch to VCR.

(2) On the VCR, locate just before the insert start point [a], then press II to set the VCR to the playback pause mode.

(3) On your camcorder, locate the insert end point [c] by pressing ← or ▶ Then press II to set it to the playback pause mode.

(4) Press ZERO SET MEMORY on the Remote Commander. The ZERO SET MEMORY indicator flashes and the end point of the insert is stored in memory.

insert is stored in memory.

(5) On your camcorder, locate the insert start point [b] by pressing ◀◀, then press • REC and the button on its right simultaneously to set your camcorder to the recording pause mode.

(6) First press ■ on the VCR, and after a few

PIRST press II on the VCK, and after a few seconds press II on your camcorder to start inserting the new scene. Inserting automatically stops near the zero point on the counter. Your camcorder automatically stops. The end point [c] of the insert stored in memory is canceled.

## Changing the menu settings

To change the mode settings in the menu settings, select the menu items with the SEL/PUSH EXEC dial. The default settings can be partially changed. First, select the icon, then the menu item and then the mode.


(1) In CAMERA, PLAYER, VCR (DCR-TRV330E only) or MEMORY (DCR-TRV325E/ TRV330E/TRV430E/TRV530E only) mode, TRV330E/TRV430E/TRV530E only) mode, press MENU.
(2) Turn the SEL/PUSH EXEC dial to select the desired icon, then press the dial to set.
(3) Turn the SEL/PUSH EXEC dial to select the desired item, then press the dial to set.
(4) Turn the SEL/PUSH EXEC dial to select the desired item, then press the dial to set.
(5) If you want to change other items, select ⊋
RETURN and press the dial, then repeat steps from 2 to 4.

For details, see "Selecting the mode setting of each item" (p. 108).

## Выполнение индивидуалы тановок на видеокамере —

#### Изменение установок меню

Для изменения установок режима в установках меню выберите пункты меню с помощью диска SELPUSH EXEC. Установки по умолчанию можен частнено мыенить. Сначала выберите пистограмму, затем пункт меню, а затем режим. (1) В режиме САМЕРА, РАУЕЯ, VCR (только модель DCR-TRV330E) или режиме МЕМОЯ? Чтолько модель DCR-TRV325E), нажмите кнопку МЕМИ. (2) Поверните диск БЕЛ-РUSH EXEC для выбора нужной пиктограммы, а затем нажмите диск для выполнения установки. (3) Поверните диск SELPUSH EXEC для выбора нужной пиктограммы, а затем нажмите диск для выполнения установки. (4) Поверните диск SELPUSH EXEC для выбора нужной пиктограммы, а затем нажмите диск для выполнения установки. (5) Если Вы хотите изменить другие пункты, выберите команду ⊋? RETURN, а затем нажмите диск, для выполнения установки. Всли Вы хотите изменить другие пункты, выберите команду ⊋? RETURN, а затем нажмите диск, подле чего повторите действия пунктов. 2-4.



107

Menu items are displayed as the following

icons: MANUAL SET

CAMERA SET
PLAYER SET (DCR-TRV230E/
TRV235E/TRV325E/TRV430E/ TRV530E)

VCR SET (DCR-TRV330E) LCD/VF SET MEMORY SET (DCR-TRV325E/

TRV330E/TRV430E/TRV530E only) PRINT SET (DCR-TRV325E/ TRV330E/TRV430E/TRV530E only) TAPE SET 

(TO) SETUP MENU

OTHERS

Для того, чтобы исчезла индикация меню Нажмите кнопку MENU.

Изменение установок меню

Пункты меню отображаются в виде приведенных ниже пиктограмм:

ТОТ МАNUAL SET CAMERA SET PLAYER SET (DCR-TRV230E/ TRV235E/TRV325E/TRV430E/ TRV530E) VCR SET (DCR-TRV330E) o

LCD/VF SET MEMORY SET (модель DCR-TRV325E/TRV330E/TRV430E/ TRV530F) 

POWER

PRINT SET (MODEND DCR-TRV325E/ TRV330E/TRV430E/TRV530E) TAPE SET SETUP MENU <u></u> OTHERS

ı	Eng	llis	h
---	-----	------	---

## Selecting the mode setting of each item ● is the default setting.

Menu items differ according to the position of the POWER switch. The screen shows only the items you can operate at the moment.

Icon/item	Mode	Meaning	switch
m PROGRAM AE	-	To suit your specific shooting requirement (p. 61)	CAMERA MEMORY
P EFFECT	-	To add special effects like those in films or on the TV to images (p. 56)	CAMERA PLAYER/VCR
D EFFECT	-	To add special effects using the various digital functions (p. 58)	CAMERA PLAYER/VCR
AUTO SHTR	• ON	To automatically activate the electronic shutter when shooting in bright conditions	CAMERA MEMORY
	OFF	To not automatically activate the electronic shutter even shooting in bright conditions	

on/item	Mode	Meaning	POWER switch
SELFTIMER 1)	• OFF	Not to use the self-timer function	CAMERA
	ON	To use the self-timer function	MEMORY
D ZOOM	• OFF	To deactivate digital zoom. Up to 25× zoom is carried out.	CAMERA MEMORY
	50×	To activate digital zoom. More than 25× to 50× zoom is performed digitally. (p. 29)	
	700× ²)	To activate digital zoom. More than 25× to 700× zoom is performed digitally. (p. 29)	
16:9WIDE	• OFF	_	CAMERA
	ON	To record a 16:9 wide picture (p. 52)	
STEADYSHOT	● ON	To compensate for camera-shake	CAMERA
	OFF	To cancel the SteadyShot function. Natural pictures are produced when shooting a stationary object with a tripod.	MEMORY
N.S. LIGHT	● ON	To use the NightShot Light function (p. 33)	CAMERA
	OFF	To cancel the NightShot Light function	MEMORY
FLASH MODE	• ON	To fire the flash (optional) regardless of the brightness of the surroundings	CAMERA MEMORY
	AUTO	The flash fires automatically	
	AUTO •	To fire the flash before recording to reduce the red-eye phenomenon	
FLASH LVL	HIGH	Makes the flash level higher than normal	CAMERA
	<ul><li>NORMAL</li></ul>	Normal setting	MEMORY
	LOW	Makes the flash level lower than normal	

DCR-TRV325E/TRV330E/TRV430E/TRV530E only

0× (DCR-TRV235E/TRV430E only)

Notes on the SteadyShot function

• The SteadyShot function will not correct excessive camera-shake.

• Attachment of a conversion lens (optional) may influence the SteadyShot function.

If you cancel the SteadyShot function
The SteadyShot off indicator 🍇 appears on the screen. Your camcorder prevents excessive compensation for camera-shake.

Notes on FLASH MODE and FLASH LVL

• You cannot adjust FLASH MODE or FLASH LVL if the flash (optional) is not compatible with
FLASH MODE or FLASH LVL

• FLASH MODE and FLASH LVL are displayed only when an external flash (optional) is

connected to the intelligent accessory shoe

108 109

## Changing the menu settings

Icon/item	Mode	Meaning	POWER switch
HiFi SOUND	● STEREO	To play back a stereo tape or dual sound track tape with main and sub sound	PLAYER/VCR
	1	To play back a stereo tape with the left sound or a dual sound track tape with main sound	
	2	To play back a stereo tape with the right sound or a dual sound track tape with sub sound	
TBC*	● ON	To correct jitter	PLAYER/VCR
	OFF	To not correct jitter. Set TBC to OFF when playing back a tape on which you have dubbed over and recorded the signal of a TV game or similar machine.	
TBC stands for	"Time Base Correct	or".	
DNR*	● ON	To reduce picture noise	PLAYER/VCR
	OFF	To reduce a conspicuous afterimage when the picture has a lot of movement	
DNR stands for	"Digital Noise Red	luction".	
AUDIO MIX	_	To adjust the balance between the stereo 1 and stereo 2	PLAYER/VCR
		ST1 A ST2	
NTSC PB	• ON PAL TV	To palyback a tape recorded on your camcorder on a PAL system TV	PLAYER/VCR
	NTSC 4.43	To palyback a tape recorded in the NTSC colour system on a TV with the NTSC 4.43 mode	
PB MODE	● AUTO	To automatically select the system (Hi8/ standard 8 or Digital8 1) that was used to record on the tape, and play back the tape	PLAYER/VCR
	Hj8/8	To play back a tape that was recorded in the Hi8/standard 8 system when your camcorder does not automatically distinguish the recording system	
A/V→DV OUT (DCR-	● OFF	To convert digital video signals into analog video signals via your camcorder.	VCR
TRV330E only)	ON	To convert analog video signals into digital video siginals via your camcorder.	

<sup>\*</sup> When you play back tapes recorded in the Hi8/standard 8 system only.

Notes on NTSC PB
When you play back a tape on a Multi System TV, select the best mode while viewing the picture on the TV.

110

Note on PB MODE
The mode will return to the default setting when:
- you remove the battery pack or power source.
- you turn the POWER switch.

## Changing the menu settings

on/item	Mode	Meaning	switch
] LCD BRIGHT	-	To adjust the brightness on the LCD screen with the SEL/PUSH EXEC dial.	CAMERA PLAYER/VCF MEMORY
		To darken To lighten	
LCD B. L.	BRT NORMAL	To set the brightness on the LCD screen backlight normal	CAMERA PLAYER/VCI
	BRIGHT	To brighten the LCD screen backlight	MEMORY
LCD COLOUR	_	To adjust the colour on the LCD screen, turning the SEL/PUSH EXEC dial to adjust the following bar	CAMERA PLAYER/VCF MEMORY
		To reduce To increase intensity	
VF B.L.	BRT NORMAL	To set the brightness in the viewfinder normal	CAMERA
	BRIGHT	To brighten the viewfinder	PLAYER/VCF MEMORY
] * STILL SET			
PIC MODE	<ul> <li>SINGLE</li> </ul>	Not to record continuously	MEMORY
	MULTI SCRN	To record 9 images continuously (p. 130)	
QUALITY	• FINE	To record still images in the fine image quality mode	PLAYER/VCF MEMORY
	STANDARD	To record still images in the standard image quality mode (p. 127)	
FLD/FRAME	• FIELD	To record moving subjects correcting jitter	MEMORY
	FRAME	To record stopping subjects in high quality	
PRINT MARK	ON	To write a print mark on the recorded still images you want to print out later (p. 166)	PLAYER/VCF MEMORY
	● OFF	To cancel print marks on still images	
PROTECT	ON	To protect selected still images against accidental erasure (p. 161)	PLAYER/VCF MEMORY
	● OFF	Not to protect still images	

Notes on LCD B.L. and VF B.L.

• When you select BRIGHT, battery life is reduced by about 10 percent during recording.

• When you use power sources other than the battery pack, BRIGHT is automatically selected.

POWER

Customizing

<sup>Notes on AUDIO MIX

When playing back a tape recorded in the 16-bit mode, you cannot adjust the balance.

You can adjust the balance only for tapes recorded in the Digital8 (1) system.</sup> 

Icon/item	Mode	Meaning	POWER switch
*SLIDE SHOW	-	To play back images in a continuous loop (p. 159)	MEMORY
DELETE ALL	_	To delete all the images (p. 163)	MEMORY
FORMAT	● RETURN	To cancel formatting	MEMORY
	FORMAT	To format an inserted "Memory Stick."  1. Select FORMAT with the SEL/PUSH EXEC dial, then press the dial.  2. Turn the SEL/PUSH EXEC dial to select FORMAT, then press the dial.  3. After EXECUTE appears, press the SEL/ PUSH EXEC dial. FORMATTING appears during formatting; COMPLETE appears when formatting is finished.	
PHOTO SAVE	_	To duplicate still images in the tape to "Memory Stick" (p. 144)	PLAYER/VCR
* 9PIC PRINT	● RETURN	To cancel prints of split screen	MEMORY
	SAME	To make prints of same split screen (p. 168)	
	MULTI	To make prints of different split screen	
	MARKED	To make prints of images with print marks in recording order	
DATE/TIME	• OFF	To make prints without the recording date and time	MEMORY
	DATE	To make prints with the recording date	
	DAY&TIME	To make prints with the recording date and time (p. 168)	

- Notes on formatting\*
   Supplied or optional "Memory Stick"s have been formatted at factory. Formatting with this To not turn the POWER switch or press any button while the display shows "FORMATTING"
   You cannot format the "Memory Stick" if the write-protect tab on the "Memory Stick" is set to

- Format the "Memory Stick" if "

  FORMAT ERROR" appears.

- Formatting erases all information on the "Memory Stick"\*
  Check the contents of the "Memory Stick" before formatting.
  Formatting erases sample images on the "Memory Stick."
  Formatting erases the protected image data on the "Memory Stick."

### Note on PRINT SET

9PIC PRINT and DATE/TIME are displayed only when an external printer (optional) is connected to the intelligent accessory shoe.

\* DCR-TRV325E/TRV330E/TRV430E/TRV530E only

## Changing the menu settings

Icon/item	Mode	Meaning	POWER switch
REC MODE	● SP	To record in the SP (Standard Play) mode	CAMERA
	LP	To increase the recording time to 1.5 times the SP mode	PLAYER/VCR
AUDIO MODE	● 12BIT	To record or play back in the 12-bit mode (two stereo sounds)	CAMERA PLAYER/VCR*
	16BIT	To record or play back in the 16-bit mode (the one stereo sound with high quality)	
™ REMAIN	● AUTO	To display the remaining tape bar:  • for about 8 seconds after your camcorder is turned on and calculates the remaining amount of tape  • for about 8 seconds after a cassette is inserted and your camcorder calculates the remaining amount of tape  • for about 8 seconds after ▶ is pressed in PLAYER or VCR mode  • for about 8 seconds after DISPLAY is pressed to display the screen indicators  • for the period of tape rewinding, forwarding or picture search in the PLAYER or VCR mode	CAMERA PLAYER/VCR
	ON	To always display the remaining tape bar	
DATA CODE	● DATE/CAM	To display date, time and recording data during playback	PLAYER/VCR
	DATE	To display date and time during playback	

Note on REC MODE When you record on the standard 8  $\blacksquare$  tape, your camcorder records in the SP mode even you select the LP mode in the menu settings. In this case, the indicator "8mm TAPE  $\rightarrow$  SP REC, Hi8 TAPE  $\rightarrow$  LP/SP REC" appears on the screen. Use the Hi8  $\blacksquare$   $\blacksquare$  Depends on the LP mode.

- Notes on the LP mode

  \*When you record a tape in the LP mode on your camcorder, we recommend playing the tape on your camcorder. When you play back the tape on other camcorders or VCRs, noise may occur in images or sound.

  \*When you record in the SP and LP modes on one tape or you record some scenes in the LP mode, the playback image may be distorted or the time code may not be written properly between scenes.

Note on AUDIO MODE
When playing back a tape recorded in the 16-bit mode, you cannot adjust the balance in AUDIO MIX.

\*To dub a tape to another VCR You cannot select AUDIO MODE for tapes recorded in the Digital8  $\Theta$  system. You, however, can select AUDIO MODE when you dub tapes recorded in the Hi8/standard 8 system to another VCR using the i.LINK cable.

112

## Changing the menu settings

Icon/item	Mode	Meaning	POWER switch
CLOCK SET	_	To set the date or time (p. 22)	CAMERA MEMORY
LTR SIZE	<ul><li>NORMAL</li></ul>	To display selected menu items in normal size	CAMERA
	2×	To display selected menu items at twice the normal size	PLAYER/VCR MEMORY
DEMO MODE	● ON	To make the demonstration appear	CAMERA
	OFF	To cancel the demonstration mode	

- Notes on DEMO MODE

   You cannot select DEMO MODE when a cassette is inserted in your camcorder.

   DEMO MODE is set to STBY (Standby) at the factory and the demonstration starts about 10 minutes after you have set the POWER switch to CAMERA without a cassette inserted. To cancel the demonstration, insert a cassette, set the POWER switch to other than CAMERA, or set DEMO MODE to OFF.

   When NIGHTSHOT is set to ON, the "NIGHTSHOT" indicator appears on the screen and you cannot select DEMO MODE in the menu settings.

## Changing the menu settings

lcon/item	Mode	Meaning	POWER switch
FT WORLD TIME	_	To set the clock to the local time. Turn the SEL/PUSH EXEC dial to set a time difference. The clock changes by the time difference you set here. If you set the time difference to 0, the clock returns to the originally set time.	CAMERA MEMORY
BEEP	● MELODY	To output the melody when you start/stop recording or when an unusual condition occurs on your camcorder	CAMERA PLAYER/VCR MEMORY
	NORMAL	To output the beep instead of the melody	
	OFF	To cancel all sound including shutter sound	
COMMANDER	• ON	To activate the Remote Commander supplied with your camcorder	CAMERA PLAYER/VCR
		To deactivate the Remote Commander to avoid remote control misoperation caused by other VCR's remote control	MEMORY
DISPLAY	● LCD	To show the display on the LCD screen and in the viewfinder	CAMERA PLAYER/VCR
	V-OUT/LCD	To show the display on the TV screen, LCD screen and in the viewfinder	MEMORY
REC LAMP	● ON	To light up the camera recording lamp at the front of your camcorder	CAMERA MEMORY
	OFF	To turn the camera recording lamp off so that the subject is not aware of the recording	
VIDEO EDIT	_	To make programme and perform video editing (p. 86)	PLAYER/VCR
EDIT SET	_	To adjust and set the synchronicity of your camcorder and a VCR for dubbing in edit set mode (p. 86)	PLAYER/VCR
INDICATOR	● BL OFF	To turn off the backlight on display window	CAMERA
	BL ON	To turn on the backlight	PLAYER/VCR MEMORY

NOTE

If you press DISPLAY with DISPLAY set to V-OUT/LCD in the menu settings, the picture from a TV or VCR will not appear on the screen even when your camcorder is connected to outputs on the TV or VCR. (Except when your camcorder is connected with the i.LINK cable)

In more than 5 minutes after removing the power source The AUDIO MIX, FLASH LVL, COMMANDER and HiFi SOUND items are returned to their

The AUDIO MIA, FLEATH LYA, COLUMN AND THE METERS THE METERS THE Other menu items are held in memory even when the battery is removed.

- Notes on INDICATOR

   When you select BL ON, battery life is reduced by about 10 percent during recording.

   When you use power sources other than the battery pack, BL ON is automatically selected.

Customizing

## Using "Memory Stick" - introduction

## - DCR-TRV325E/TRV330E/TRV430E/

- DUR-IRV332b/IRV330b/IRV430b/IRV430b/IRV530b only
You can record and play back still images on the
"Memory Stick" supplied with your camcorder.
You can easily play back, record or delete still
images. You can exchange image data with other
equipment such as your computer etc., using the
USB cable for "Memory Stick" supplied with

## On file format (JPEG)

Your camcorder compresses image data in JPEG format (extension .jpg).

Typical image data file name
100-0001: This file name appears on the
screen of your camcorder.
Dsc00001.jpg: This file name appears on the
display of your computer.

### Before using "Memory Stick"

Terminal/Гнездо



- You cannot record or erase still images when the write-protect tab on the "Memory Stick" is set to LOCK.
   We recommend backing up important data.
   Image data may be damaged in the following
- Image data Iray to Commentary Stick", turn the power off, or detach the battery for replacement when the access lamp is flashing If you use "Memory Stick's near static electricity or magnetic flelds.

  Prevent metallic objects or your finger from coming into contact with the metal parts of the connecting section.

- coming muo contact with the metal parts of connecting section. Stick its label on the labelling position. Do not bend, drop or apply strong shock to "Memory Stick"s. Do not disassemble or modify "Memory Stick"s.

— Операции с "Memory Stick" -

## Использование "Метогу Stick"-Введение

### - Только модели DCR-TRV325E/ TRV330F/TRV430F/TRV530F

ТRV330E/TRV430E/TRV530E
Вы можете записывать и воспроизводить
неподвижные изображения на "Метлогу
Sick", прилагаемой к Вашей видеокамере. Вы
можете легко выполнять воспроизведение,
перезапись или удаление неподвижных
изображений. Вы можете выполнять обмен
данными изображения с другой аппаратурой,
такой, как Ваш персональный компьютер и
т.п., использун кабель USB для "Метолу
Stick", прилагаемый к Вашей видеокамере.

О формате файлов (JPEG)
Ваша видеокамера сжимает данные изображения в формат JPEG (с расшире

расовот. Умин этого файла появится на экране

расовот. Умин этого файла появится на дисплее Вашего компьютера.

### Перед использованием "Memory Stick"



- Вы не можете записывать или стирать неподвижные изображения, если лепесток защиты записи на "Memory Stick" установлен в положение LOCK.
   Рекомендуется выполнять копино важных данных.
   Данные изображения могут бытоврежлены в следующих случаях:
- "Данные изображения могут быть повреждены в спедующих случаях:
  —Если Вы вынули "Метолу Stick", выключили питание или отсоединили обатарейный блок для замены в то время, когда мигает лампочка доступа.
  —Если Вы используете "Метолу Stick" возле магнитов или магнитных полей.
- магнитов или магнитных полей.
  Не прикасайтесь металлическими частями или Вашими пальцами к металлическим частям соединительных секций.
  Наклейте этикетку в позиции маркировки.
  Не стибати, не роняйте и сильно не трясите "

Использование "Memory Stick"

Вставьте "Memory Stick" в отсек для "Memory Stick" до упора, так чтобы знак ▲ был обращен к отсеку "Memory Stick", как показано на рисунке.

Установка "Memory Stick"

-Введение

## Using "Memory Stick" - introduction

- Do not let "Memory Stick"s get wet.
   Do not use or keep "Memory Stick"s in locations that are:
   Extremely hot such as in a car parked in the

- sun or under the scorching sun

   Under direct sunlight

   Very humid or subject to corrosive gases
  When you carry or store a "Memory Stick", put it in its case.

"Memory Stick"s formatted by a computer
"Memory Stick"s formatted by Windows OS or Macintosh computers do not have a guaranteed compatibility with this camcorder.

### Notes on image data compatibility

- Notes on image data compatibility

  Image data files recorded on "Memory Stick"s
  by your camcorder conform with the Design
  Rules for Camera File Systems universal
  standard established by the JEIDA (Japan
  Electronic Industry Development Association),
  You cannot play back on your camcorder still
  images recorded on other equipment (DCRTRV980E-TRV9807-TRV9806-TRV9007-TRV9006-TSC-D700
  D770) that does not conform with this universal
  standard. (These models are not sold in some
  areas.)

  If you cannot use the "Memory Stick" that has
  been used on other equipment, format the
  "Memory Stick" on your camcorder following
  the steps on page 112. Note that all images on
  the "Memory Stick" will be deleted if you
  format it.

"Memory Stick" and Mawain Silts on are trademarks of Sony Corporation.

- Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other
- Macintosh and Mac OS are trademarks of
- Macintosh and Mac OS are trademarks of Apple Computer, Inc.
   All other product names mentioned herein may be the trademarks or registered trademarks of their respective companies.
   Furthermore, """ and "@" are not mentioned in each case in this manual.

## Использование "Memory Stick"

- He допускайте, чтобы "Memory Stick" становились влажными.
   He используйте и не храните "Memory Stick"
- Не используйте и не храните "Метогу эшсь в местах:
   Чрезмерно жарких, например, в припаркованном под солнцем автомобиле или под палищим солнцем.
   Под прямым солнечным светом
   В местах очень влажных или содержащих коррозионные газы
   Три переноске или хранении "Memory Stick" положите ее в футляр.

## "Memory Stick", отформатированная

на компьютере
"Memory Stick", отформатированная в
операционной системе Windows или
Масіпtosh, может оказаться не совместимой с
данной видеокамерой.

даннои видеокамерои.
Примечания по совместимости
данных изображения

• Файлы данных изображения, записанные на
"Memory Stick" с помощью данной
видеокамеры, отвечают проектным
требованим для универсального стандарта
файловых остоя видеокамеры
ассоциацией электронной промышленности).
Вы не можете воспроизводить на Вашей
випескамеле неполажиные изоблюжения

9

Вы не можете воспроизводить на Вашей видеокамере неподвижные изображения, записанные на другой аппаратуре (DCR-ТRV900ETRV900TRV900E или DCS-D700/D770), которые не соответствуют этому универсальному стандарту, (Эти модели не продаются в некоторых регионах.) "Если Вы не можете использовать "Метогу Stick", которая использовать "Метогу Stick", а в в неможете использовать "Метогу Stick", которая использовать "Метогу Stick", в Вашей видеокамере, следуя инструкции на стр. 120. Имейте в виду, что все изображения на "Метогу Stick" буду удалены, если Вы отформатируете ее.

"Memory Stick" и ммануятих являются фирменными знаками Sony Corporation

- Microsoft® и Windows® являются официально
- Містозоft и Windows\* являются официально зарегистрированными марками или фирменными знаками Microsoft Corporation в соединенных Штатах имил других странах.
   Масіліоsh и Мас ОЅ являются фирменными знаками Арріе Computer, ілс.
   Все другие названия изделий, упомянутые в данном руководстве, могут быть фирменными знаками или официально зарегистрированными торговыми марками соответствующих компаний.


зарегистрированными компаний. соответствующих компаний. В дальнейшем, знаки "™" и "⊛" не будут указываться каждый раз в данном руководстве. 125

### 124

### Using "Memory Stick" introduction

## Inserting "Memory Stick"

Insert a "Memory Stick" in the "Memory Stick" slot as far as it can go with the ▲ mark facing toward the "Memory Stick" slot as illustrated



"Memory Stick" eject button/ Кнопка выталкивания "Memory Stick"

"Memory Stick" slot/ Отсек "Memory Stick"

## To eject the "Memory Stick"

Press the "Memory Stick" eject button. The "Memory Stick" pops up.

When the access lamp is lit or flashing when the access railing is in on installing both of the because your camcorder is reading the data from the "Memory Stick" or recording the data on the "Memory Stick". Do not turn the power off, eject the "Memory Stick" or remove the battery pack. Otherwise, the image data breakdown may

If "30 MEMORY STICK ERROR" is displayed The "Memory Stick" may be corrupted. If this occurs, use another "Memory Stick."

## Access lamp/ Лампочка доступа

Для извлечения "Memory Stick" Нажмите кнопку извлечения "Memory Stick". "Memory Stick" выйдет из отсека.

Если лампочка доступа горит или мигает Не трясите и не стучите по Вашей видеокамере, потому что видеокамера читает данные с "Memory Stick" или записывает данные на "Memory Stick". Не выключайте питание, не извлекайте "Memory Stick" и не снимайте батарейный блок. В противном случае данные изображения могут быть повреждены.

## Если отображается индикатор " ™ MEMORY STICK ERROR"

"Memory Stick", возможно, повреждена. Если это произошло, используйте другую "Memory Stick".

### Using "Memory Stick" · introduction

## Selecting image quality mode

You can select image quality mode in still image recording. The default setting is FINE.

- (1) Set the POWER switch to PLAYER, VCR (DCR-TRV330E only) or MEMORY. Make sure that the LOCK is set to the left (unlock)
- (2) Press MENU to make the menu display
- appear.
  (3) Turn the SEL/PUSH EXEC dial to select \_\_\_\_\_,
- (3) Turn the SEL/PUSH EXEC dial to select then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select STILL SET, then press the dial.

  (5) Turn the SEL/PUSH EXEC dial to select QUALITY, then press the dial.

  (6) Turn the SEL/PUSH EXEC dial to select the desired image quality, then press the dial.

## -Введение Выбор режима качества изображения

Использование "Memory Stick"

Вы можете выбрать режим качества изображения при записи неподвижного изображения.
Установкой по умолчанию является FINE.

- (1) Установите переключатель РОМЕR в положение PLAYER, VCR (только модели DCR-TRV330E) или МЕМОRY. Убедитесь, что фиксатор LOCK установлен в правом (незафиксированном) положении. (2) Нажмите кнопку МЕМU, чтобы на дисплее появилась индикация меню.


- попвилась индикация меню.

  (3) Поверните диск SEL/PUSH EXEC для выбора установки [☐], а затем нажмите диск.

  (4) Поверните диск SEL/PUSH EXEC для выбора установки STILL SET, а затем нажмите диск.

  (5) Поверните диск SEL/PUSH EXEC для выбора установки GUALITY, а затем нажмите диск.

  (6) Поверните диск SEL/PUSH EXEC для выбора подходящего качества изображения, а затем нажмите диск.









6

127

In some cases, changing the image quality mode may not affect the image quality, depending on the types of images you are shooting.

### Image quality settings

ago quanty o	ogo
Setting	Meaning
FINE (FINE)	Use this mode when you want to record high quality images. The image is compressed to about 1/6.
STANDARD (STD)	This is the standard image quality. The image is compressed to about 1/10.

Differences in image quality mode Differences in image quality mode Recorded images are compressed in JPEG format before being stored into memory. The memory capacity allotted to each image varies depending on the selected image quality mode. Details are shown in the table below. (The number of pixels is 640 × 480, regardless of image quality mode. The data size before compression is about 600 KB.)

Image quality mode	Memory capacity
FINE	About 100 KB
STANDARD	About 60 KB

Approximate number of images you can record on a "Memory Stick"
The approximate number of images you can record on a "Memory Stick" formatted using this camcorder varies depending on which image quality mode you select and the complexity of the subject.

### Использование "Memory Stick" -Введение

Примечание
В некоторых случаях, изменение режима качества изображения может отразиться на качестве изображений, в зависимости от типов изображений, которые Вы снимаете.

### Установки качества изображения

Установка	Значение
FINE (FINE)	Используйте этот режим, если Вы хотите записать высококачественные изображения. Изображение сжимается примерно до 1/6.
STANDARD (STD)	Это соответствует стандартному качеству изображения. Изображение сжимается примерно до 1/10.

### Отличия в режиме качества изображения изображения сжимаются в

формат JPEG перед сохранением в памяти Емкость памяти, выделенная для каждого изображения, изменяется в зависимости от изооражения, изменнется в зависимости от выбранного режима качества изображения. Подробности содержатся в приведенной ниже таблице. (Количество элементов изображения равно 640 × 480, независимо режима качества изображения. Размер перед сжатием составляет около 600 Кб.)

Режим качества изображения	Емкость памяти	
FINE	Около 100 Кб	
STANDARD	Около 60 Кб	

Приблизительное количество изображений, которое Вы можете записать на "Memory Stick" Приблизительное количество изображений, которое Вы можете записать на "Memory Stick", отформатированную с помощью данной видеокамеры, изменяется в зависимости от выбранного Вами режима качества изображения и сложности объекта.

Maximum number of images you can record on a "Memory Stick"/
Максимальное количество изображений, которое Вы можете записать на "Memory Stick"

Setting/ Установка	4MB (supplied)/ (приобретается отдел	8МВ њно)	16MB	32MB	64MB
FINE	40	81	164	329	659
STANDARD	60	122	246	494	988

Note on the image quality mode indicator This is only displayed during recording.

Recording still images on

"Memory Stick"

- Memory Photo recording

128

Примечание по индикатору режима качества изображения
Этот индикатор отображается только во время записи.

# Запись неподвижных изображений на "Memory Stick" – Фотосъемка с сохранением в памяти

При записи быстро движущихся объектов в режиме FRAME, изображение будет размытым. При записи в режиме FRAME функция

три записи в режимет гизите дупиции компенсации подрагивания Вашей видеокамеры может работать неправильно. Рекомендуется выполнять съемку объектов с помощью треноги.
 Во время записи неподвижных изображений в пункте 2 с нажатой РНОТО, изображение будет временно мерцать. Это не является неисплавностью.

певилувалоство.

Если переключатель POWER установлен в положение MEMORY

Следующие функции не будут работать:

широкозкранный телевизионный режим

эффект изображения

цифоровой эффект

титр

режим низкой освещенности функции

PROGRAM AE.

Если Вы записываете неподвижное

Если Вы нажмете РНОТО на пульте дистанционного управления
Ваша видеокамера тотчас же запишет

Вы не можете ни выключить питание, ни нажать кнопку РНОТО.

## Notes

- When recording fast-moving subjects in the FRAME mode, the recorded image blurry.
   When recording in the FRAME mode, your camcorder may not correct camera-shake. We recommend that you shoot objects with a
- When recording still images at step 2 with PHOTO pressed lightly, the image momen flickers. This is not a malfunction.

# When the POWER switch is set to MEMORY The following functions do not work: - wide mode - picture effect - digital effect - title - low lux mode of PROGRAM AE.

When you are recording a still image You can neither turn off the power nor press PHOTO.

## When you press PHOTO on the Remote

Your camcorder immediately records the image that is on the screen when you press the button

Recording images continuously You can record still images continuously.

Multi screen mode You can record 9 still images continuously on a single page.

## изображение, которое будет на экране при Запись изображений непрерь

Вы можете записывать неподвиж изображения непрерывно.

Многоэкранный режим Вы можете записывать 9 неподвижных изображений непрерывно на одной странице



## Recording still images on "Memory Stick" - Memory Photo recording

## - DCR-TRV325E/TRV330E/TRV430E/

- DCR-TRV325E/TRV330E/TRV430E/ TRV530E only You can select the FIELD or FRAME mode in still image recording. Your camcorder compensates for camera-shake when recording moving subjects in the FIELD mode. Your camcorder records still images in high quality in the FRAME mode. Select the FIELD or FRAME in the menu settings (p. 107).

Before operation Insert a "Memory Stick" into your camcorder.

- (1) Set the POWER switch to MEMORY. Make sure that the LOCK is set to the left (unlock) position.
- position.

  (2) Keep pressing PHOTO lightly. The green mark stops flashing, then lights up. The brightness of the image and focus are adjusted, being targeted for the middle of the image and are fixed. Recording does not start
- yet.

  (3) Press PHOTO deeper. The image displayed on the screen will be recorded on the "Memory Stick". Recording is complete when the bar scroll indicator disappears.

### Запись неподвижных изображений на "Memory Stick" - Фотосъемка с сохранением в памяти

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

TRV330E/TRV430E/TRV530E
Вы можете выбрать режим FIELD или FRAME
при записи неподвижных изображений. Ваша
видеокамера компенсирует подрагивания при
записи движущихся объектов в режиме FIELD.
Ваша видеокамера записывает неподвижные раша видеоманера записывает неподвижные изображения с высоким качеством в режиме FRAME. Выберите опцию FIELD или FRAME в установках меню (стр. 107).


Перед началом работы Вставьте "Memory Stick" в Вашу видеокамеру.

- Вставьте "Метогу Stick" в Вашу видеокамеру.

  (1) Установите переключатель POWER в положение MEMORY. Убедитесь, что фиксатор LOCK установлен в левом (незафиксированном) положении.

  (2) Держите слегка нажатой кнопку PHOTO. Зеленый зана прекратит мигать и будет высвечиваться постоянно. Яркость изображения и фокусное расстояние будут отрегулированы при наводке на середину изображения и том.

  (3) Нажмите кнопку PHOTO слынее. Изображение, отображемом на экране, будет записано на "Memory Stick". Запись считается завершенной, если исчезнет перемещающийся полосатый индикатор.



## Recording still images on

"Memory Stick" - Memory Photo recording

- (1) Set the POWER switch to MEMORY. Make (1) Set the POWER SWITCH TO MEMORY. MISSURE that the LOCK is set to the left (unl position.

  (2) Press MENU to make the menu display
- (2) Press MEINU to make the menu display appear.

  (3) Turn the SEL/PUSH EXEC dial to select \_\_\_\_, then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select STILL SET, then press the dial.

  (5) Turn the SEL/PUSH EXEC dial to select PIC MODE, then press the dial.

  (6) Turn the SEL/PUSH EXEC dial to select the desired setting then press the dial.

- desired setting, then press the dial.

  (7) Press MENU to erase the menu display.


  (8) Press PHOTO deeper.

# Запись неподвижных изображений на "Memory Stick" – Фотосъемка с сохранением в памяти

- (1) Установите переключатель POWER в положение MEMORY. Убедитесь, что переключатель LOCK установлен в левое (незафиксированное положение).
  (2) Нажмите кнопку MENU, чтобы на дисплее попвилась индикация меню.
  (3) Поверните диск SEL/PUSH EXEC для выбора установки [...], а затем нажмите диск

- Выборы установичения (4) Поверните диск SEL/PUSH EXEC для выбора установки STILL SET, а затем нажмите диск.

  (3) Поверните диск SEL/PUSH EXEC для поверните диск ВЕL/PUSH EXEC для датем достанов диск ВЕL/PUSH EXEC для датем диск ВЕL/PUSH
- выбора установки PIC MODE, а затем нажмите диск. (6) Поверните диск SEL/PUSH EXEC для
- выбора желаемой установки, а затем нажмите диск.
- (7) Нажмите кнопку MENU для стирания индикации меню. (8) Твердо нажмите кнопку РНОТО.



If the capacity of the "Memory Stick" becomes full
"STILL" appears on the screen and you cannot record still images on the "Memory Stick".

## Если емкость "Memory Stick" е**реполнена** ы экране появится индикация "ဩ FULL", и

е сможете записывать неподви ажения на эту "Memory Stick".

operations Stick

Stick"

Setting	Meaning (indicator on the screen)
SINGLE	Your camcorder shoots one image at a time. (no indicator)
MULTI SCRN	Your camcorder shoots 9 still images at about 0.5 sec intervals and displays the images on a single page divided into 9 boxes. ( )

When recording in the multi screen mode The image is recorded in the FIELD mode automatically even you select the FRAME mode in the menu settings

Запись неподвижных изображений на "Memory Stick" – Фотосъемка с сохранением в памяти

Установка	Значение (индикатор на экране)	
SINGLE	Ваша видеокамера снимает одно изображение за раз (без индикатора).	
MULTI SCRN	Ваша видеокамера снимает 9 неподвижных изображений примерно с 0,5-секундными интервалами и отображает изображения на одной странице, разделенной на 9 прямоугольников. ( ВВВ) )	

При записи в многоэкранном режиме
Изображение автоматически записывается в
режиме FIELD, даже если Вы выбрали в
установках меню режим FRAME.

## Recording still images on "Memory Stick" - Memory Photo recording

### Self-timer memory photo recording

You can record still images on "Memory Stick"s with the self-timer. You can use the Remote Commander for this operation.

- (1) Set the POWER switch to MEMORY. Make sure that the LOCK is set to the left (unlock)
- (2) Press MENU to display the menu settings in

- (2) Press MENU to display the menu settings in the standby mode.

  (3) Turn the SEL/PUSH EXEC dial to select then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select SELFITMER, then press the dial.

  (5) Turn the SEL/PUSH EXEC dial to select ON, then press the dial.

  (6) Press MENU to make the menu settings disappear.

disappear. (7) Press PHOTO deeper.
Self-timer starts counting down from 10 with a beep sound. In the last two seconds of the countdown, the beep sound gets faster, then recording starts automatically.


Запись неподвижных изображений на "Memory Stick" – Фотосъемка с сохранением в памяти

## Фотосъемка в память по таймеру самозапуска

Вы можете записывать неподвижные изображения на "Memory Stick" с помощью таймера самозапуска. Для этой операции Вы можете использовать пульт дистанционного

- (1) Установите переключатель POWER в

- (1) Установите переключатель POWER в положение MEMORY. Убедитесь, что переключатель LOCK установлен в левом (незафикерованном) положения. (2) Нажмите кнопку MENU для отображения установок меню в режиме ожидания. (3) Поверните диск SEL/PUSH EXEC для выбора пункта SEL-RUSH EXEC для выбора пункта ON, а затем нажмите диск. (5) Поверните диск SEL/PUSH EXEC для выбора пункта ON, а затем нажмите диск. (6) Нажмите кнопку MENU для исчезновения установок меню. (7) Сильнее нажмите кнопку PHOTO. Таймер самозатуска начнет обратный отсчет от 10 с зуммерным сигналом. В последние две секунды обратного тогчета зуммерный сигнал будет звучать чаще, после автоматически начнется запись.



132 133

## Recording still images on

"Memory Stick"

- Memory Photo recording

To cancel self-timer recording
Set SELFTIMER to OFF in the menu settings
while your camcorder is in the standby mod
You cannot cancel self-timer recording with
Remote Commander.

The self-timer recording mode is automatically

- cancelled when:

   Self-timer recording is finished.

   The POWER switch is set to OFF (CHG),
  PLAYER or VCR (DCR-TRV330E only).

To check the image to be recorded You can check the image with pressing PHOTO lightly, then press it deeper to start the self-timer

## Запись неподвижных изображений на "Memory Stick" – Фотосъемка с сохранением в памяти

## Для отмены записи по таймеру самозапуска

ДЛЯ ОТМЕНЫ ЗАПИСИ ПО ТАЙМЕРУ САМОЗАПУСКА

УСТАНОВИТЕ ПУНКТ В БИТАНОВКАХ МЕНО В ПОЛОЖЕНИЕ ОБЕТ, КОГДА ВАША ВИДВОКАМИРА НЕМОЗИТЕЛЬНИЕ ОЖИДАНИЯ ВЫ НЕ МОЖЕТЕ ОТМЕНИТЬ ЗАПИСЬ ПО ТАЙМЕРУ САМОЗАПУСКА С ПОМОЩЬЮ ПУЛЬТВ

Режим записи по таймеру самозапуска булет

Режим записи по таймеру самозапуска будет автоматически отменен, если: 
— Запись по таймеру самозапуска закончилась. 
— Переключатель РОЖЕР установлен в положение ОРГ (CHG), PLAYER или VCR (только модели DCR-TRV330E).

записываться
Вы можете проверить изображение, нажав спегка кнопку РНОТО, а затем нажав ее сильнее для начала записи по таймеру самозапуска.

# Superimposing a still image in the "Memory Stick" on an image – MEMORY MIX

- DCR-TRV325E/TRV330E/TRV430E/ TRV530E only
You can superimpose a still image you have recorded on the "Memory Stick" on top of the moving image you are recording. You can record the superimposed images on a tape or a "Memory Stick". (However, you can record only superimposed still images on the "Memory Stick".)

M. CHROM (Memory chroma key) You can swap a blue area of a still image such as an illustration or a frame with a moving image.

M. LUMI (Memory luminance key)
You can swap a brighter area of a still image such as a handwritten illustlation or title with a moving image. Record a title on the "Memory Stick" before a trip or event for convenience.

C. CHROM (Camera chroma key)
You can superimpose a moving image on top of still image such as an image can be used as background. Shoot the subject against a blue background. The blue area of the moving image will be swapped with a still image.

M. OVERLAP\* (Memory overlap)
You can make a moving image fade in on top of a still image recorded on the "Memory Stick" as the overlap function.

## Наложение неподвижного изображения из "Memory Stick" на подвижное изображение – MEMORY MIX

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Вы можете наложить неподвижное изображение, записанное на "Memory Stick", на записываемое подвижное изображение. Вы можете записать наложенные ы може в записа в напоженные изображения на ленту или на "Memory Stick". (Тем не менее, Вы можете записать на "Memory Stick" только наложенные неподвижные изображения.)


М. CHROM (кнопка цветности памяти) Вы можете менять местами синюю часть неподвижного изображения с подвижным

М. LUMI (кнопка яркости памяти)
Вы можете менять местами более яркую
часть неподвижного изображения с
подвижным изображением. Запишите титр на
"Memory Stick" перед путешествием или
каким-либо событием для удобства.

С. Ситим (кнопика цветности видеокамеры)
Вы можете напожить движущееся
изображение поверх неподвижного
изображения, которое может служить фоном.
Например, Вы можете выполнить съемку
объекта на голубом фоне. Голубая часть
подвижного изображения поменяется
местами с неподвижным изображением.

M. OVERLAP\* (перекрытие памяти) Вы можете выполнить плавный ввод движущегося изображения поверх неподвижного изображения, записанного на "Memory Stick" как функцию перекрытия.

Наложение неподвижного изображ из "Memory Stick" на подвижное изображение – MEMORY MIX



\* The superimposed image using Memory overlap function can be recorded on tapes only

## Recording superimposed images on a tape

Superimposing a still image in the "Memory Stick" on an image the "Memory S - MEMORY MIX

(5) Press the SEL/PUSH EXEC dial. The still image is superimposed on the

moving image.

(6) Turn the SEL/PUSH EXEC dial to adjust the effect.

M. CHROM - The colour (blue) scheme of

the area in the still image which is to be swapped with a moving image The colour (bright) scheme M. LUMI

of the area in the still image which is to be swapped with a moving image The colour (blue) scheme of C. CHROM -

the area in the moving image which is to be swapped with a still image M. OVERLAP - No adjustment necessary The fewer bars there are on the screen, the

stronger the effect.
(7) Press START/STOP to start recording.

Наложение неподвижного изображения из "Memory Stick" на подв изображение – MEMORY MIX


Неподвижное изображение будет наложено на подвижное. (6) Поверните диск SEL/PUSH EXEC для

M. LUMI

регулировки эффекта. М. CHROM – Цветовая гамма (голубая)

будет заменен на подвижное изображение

одвижное изображение С СНВОМ – Пветовая гамма (голубая)



Before operation
• Insert a Hi8 Hi8/Digital8 H) tape for recording

(1) Set the POWER switch to CAMERA.

(2) Press MEMORY MIX in the standby mode. The last recorded or last composed image appears on the lower part of the screen as a thumbnall image.

(3) Press MEMORY +/- to select the still image you want to superimpose.

To see the previous image, press MEMORY -. To see the next image, press MEMORY +.

(4) Turn the SEL/PUSH EXEC dial to select the desired mode.

The mode changes as follows:

M. CHROM → M. LUMI → C. CHROM →

M. OVERLAP

136

Superimposing a still image in the "Memory Stick" on an image – MEMORY MIX

## To change the still image to

superimpose
Do either of the following:
- Press MEMORY+/- before step 7.
- Press the SEL/PUSH EXEC dial before step 7, and repeat the procedure from step 4

To change the mode setting
Press the SEL/PUSH EXEC dial before step 7, and repeat the procedure from step 4.

### To cancel MEMORY MIX Press MEMORY MIX

The "Memory Stick" supplied with your camcorder stores 20 images - For M. CHROM: 18 images (such as a frame)

100-0001~100-0018

For C. CHROM: 2 images (such as a background) 100-0019~100-0020

Sample images

Sample images stored in the "Memory Stick" supplied with your camcorder are protected (p.

When you select M. OVERLAP mot change the still image or the mode setting.

During recording You cannot change the mode setting.

To record the superimposed image as a still

image Press PHOTO in step 7.

# Recording superimposed images on a "Memory Stick" as a still image

Before operation Insert a "Memory Stick" is recorded still images

into your camcorder.

- (1) Set the POWER switch to MEMORY. Make sure that the LOCK is set to the left position.
  (2) Press MEMORY MIX in the standby mode. The last recorded or last composed image appears on the lower part of the screen as a
- you want to superimpose.
  To see the previous image, press MEMORY –.
  To see the next image, press MEMORY+. 138

thumbnail image.
(3) Press MEMORY+/- to select the still image

Наложение неподвижного изображе из "Memory Stick" на подвижное изображение – MEMORY MIX

Запись наложен изображения на ленту

Перед началом работы

- Вставьте ленту Hill HIB/Digital8 Н для записи
в Вашу видескамеру,

- Вставьте "Меттоту Stick" с записанными изображениями в Вашу видеокамеру.

(1) Установите переключатель РОWER в положение САМЕГА. (2) Нажмите кнопку МЕМОRY МІХ в режиме ожидания. Последнее записанное или скомпонованни изображение появится в нижней части экрана в виде крохитого изображения. (3) Нажмите кнопку МЕМОRY4-для выбора неподалжного изображения, которое Вы

неподвижного изображения, которое Вы хотите напожить на подвижное. Для просмотра предыдущего изображении нажмите кнопку МЕМОRY -Для просмотра следующего изображения нажмите кнопку МЕМОRY -(4) Поверните диск SEL/PUSH EXEC для выбора нужного режима. Режим будет изменяться следующим облазом.

oбразом: M. CHROM ← M. LUMI ← C. CHROM ← M. OVERLAP

мил вышеления неподвижного изображения для наложения Выполните следующее: - Нажмите кнопку МЕМОRY+/- перед пунктом 7. - Нажмите диск SEL/PUSH EXEC перед пунктом 7 и повторите процедуру, начиная с пункта 4.

Для изменения установки режима Нажмите диск SEL/PUSH EXEC перед пунктом 7 и повторите процедуру с пункта 4.

Для отмены установки MEMORY MIX Нажмите кнопку MEMORY MIX.

"Метогу Stick", прилагаемая к Вашей видеокамере, вмещает 20 изображений -Для М. СНЯСМ: 18 изображений (например, кадр) 100-0001-100-0018 -Для С. СНЯСМ: два изображения (например, фон) 100-0019-100-0020

Образцы изображений Образцы изображений на "Memory Stick", прилагаемой к Вашей видеокамере, защищены от стирания (стр. 161).

Если Вы выберите М. OVERLAP Вы не можете изменять неподвижно изображение или установку режима

**Во время записи** Вы не можете изменить установку режима.

Для записи наложенного изображене неподвижного изображения Нажмите кнопку РНОТО в пункте 7.

## Запись наложенных изображений на "Memory Stick" как неподвижного изображения

Перед эксплуатацией Вставьте "Memory Stick" с записанны изображениями в Вашу видеокамеру.

- (1) Установите переключатель РОМЕR в положение МЕМОRY. Убедитесь, что ручка LOCK установлена в левое положение (2) Нажмите кнопку МЕМОRY MIX в режиме ожидании, Изображение, записанное или составленное последним, появится в нижней части экрана в виде крохотного изображения.
- изображения.
  (3) Нажмите кнопку MEMORY+/- для выбора неподвижного изображения, которое Вы хотите наложить.
  Чтобы увидеть предыдущее изображение, нажмите кнопку MEMORY-.
  Чтобы увидеть сперующее изображение, нажмите кнопку MEMORY+.

## Superimposing a still image in he "Memory Stick" on an image MEMORY MIX

(4) Turn the SEL/PUSH EXEC dial to select the

(4) I'um the SEL/PUSH EXEC dial to select the desired mode.
The mode changes as follows:
M. CHROM → M. LUMI → C. CHROM
(5) Press the SEL/PUSH EXEC dial.
The still image is superimposed on the moving image.
(6) I'um the SEL/PUSH EXEC dial to adjust the effect

effect.
M. CHROM – The colour (blue) scheme of the area in the still image which is to be swapped with a

moving image The colour (bright) scheme of M. LUMI the area in the still image which is to be swapped with a moving image

C. CHROM - The colour (blue) scheme of the area in the moving image which is to be swapped with a still image The fewer bars there are on the screen, the

stronger the effect.
(7) Press PHOTO deeper to start recording.

(5) Нажмите диск SEL/PUSH EXEC (а) нажмите диск SEL/FUSH EXEC. Неподвижное изображение будет наложено на подвижное. (6) Поверните диск SEL/FUSH EXEC для регулиовки эффекта.

(4) Поверните диск SEL/PUSH EXEC для выбора нужного режима. Режим будет изменяться следующим


образом: M. CHROM ↔ M. LUMI ↔ C. CHROM

регулировки эффекта.
М. СНЯОМ – Цветовая гамма (голубая) участка в неподвижном изображении, который будет заменен на движущееся изображением.
М. LUMI – Цветовая гамма (пркая)

участка в неподвижном изображении, который будет

заменен на движущееся изображение С. CHROM – Цветовая гамма (голубая) цветован гамма (изгусан) участка в движущемся изображении, который будет заменен на неподвижное изображение полос на экране, тем сильнее

эффект. (7) Твердо нажмите кнопку РНОТО для



(5) Нажмите диск SEL/PUSH EXEC

участка в неподвижном изображении, который

Цветовая гамма (яркая)
 участка в неподвижном изображении, который

С. СННОМ – Цветовая гамма (голубаг участка в неподвижном изображении, который будет заменен на подвижное изображение М. OVERLAP—Не требуется никаких регулировоч Чем меньше полос на экране, тем силь экране.

эффект. (7) Нажмите кнопку START/STOP для начала записи.

Операции Stick'

137

Наложение неподвижного изображе из "Memory Stick" на подвижное изображение – MEMORY MIX

- To change the still image to superimpose
  Do either of the following:
   Press MEMORY+/- before step 7.
   Press the SEL/PUSH EXEC dial before step 7, and repeat the procedure from step 4.

To change the mode setting Press the SEL/PUSH EXEC dial befor and repeat the procedure from step 4.

## To cancel MEMORY MIX

### Press MEMORY MIX.

During recording You cannot change the mode setting

- The "Memory Stick" supplied with your camcorder stores 20 images
  -For M. CHROM: 18 images (such as a frame)
  100-0001-100-0018
  -For C. CHROM: 2 images (such as a background) 100-0019-100-0020

### Sample images

Sample images Sample images stored in the "Memory Stick' supplied with your camcorder are protected

Наложение неподвижного изображ из "Memory Stick" на подвижное изображение – MEMORY MIX

## Лля изменения неполвижного

- для изменения неподвижного изображения для наложения Выполните любое из следующих действий: Нажмите кнопку МЕМОRY+/– перед пунктом 7.
- пунктом 7. Нажмите диск SEL/PUSH EXEC перед пунктом 7 и повторите процедуру, начиная с пункта 4.

## Для изменения установки режима Нажмите диск SEL/PUSH EXEC перед

пунктом 7 и повторите процедуру, начиная с

## Для отмены установки MEMORY MIX Нажмите кнопку MEMORY MIX.

Во время записи

- "Memory Stick", прилагаемая к Вашей видеожамере, вмещает 20 изображений Для М. СНЯСМ: 18 изображений (например, кадр) 100-0001-100-0018 Для С. СНЯСМ: 2 изображения (напри фон) 100-0019-100-0020

Образцы изображений Образцы изображений на "Memory Stick", прилагаемой к Вашей видеокамере, защищены от стирания (стр. 161)

## Recording an image from a tape as a still image

## - DCR-TRV325E/TRV330E/TRV430E/

- DCR-TRV33DE/TRV33DE/TRV43DE/ TRV53DE only
Your camcorder can read moving image data recorded on a tape in the Digital8 P system, and record it as a still image on a "Memory Stick."
Your camcorder can also take in moving image data through the input connector and record it as a still image on a "Memory Stick."

Before operation Insert a tape recorded in the Digital8  $\Theta$  system and a "Memory Stick" into your camcorder.

- (1) Set the POWER switch to PLAYER or VCR (DCR-TRV330E only).

  (2) Press ► The image recorded on the tape is played back.

  (3) Keep pressing PHOTO lightly until the image from the tape freezes. "CAPTURE" appears on the screen. Recording does not start yet.

  (4) Press PHOTO deeper. The image displayed on the screen will be recorded on the "Memory Stick". Recording is complete when the bar scroll indicator disappears.

## Запись изображения с ленты как неподвижного изображения


- Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E Ваша видеокамера может считывать данн подвижного изображения, записанные на ленте в цифровой системе Digital8 Ŋ, и ленте в цифровом системе Dидиаю F, и записывать его как неподвижное изображение на "Memory Stick". Ваше видеокамера также позволяет вводить данные подвижного изображения через разъем входного сигнала и записывать их как неподвижное изображение на "Memory Stick".

### Перед началом работы

Вставьте ленту, записанную в системе Digital8 19 и "Memory Stick" в Вашу

- Установите переключатель РОWER в положение РLAYER или VCR (только модели DCR-TRV330E).
   Нажмите кнопку ►. Начнется воспроизведение изображения, записанного на ленте
   Лахимите сперез чажатий кирлиу PHOI
- записанного на ленте.

  (3) Держите слегка нажатой кнопку РНОТО до тех пор, пока изображение с ленты не будет "заморожено". На экране появится индикация "CAPTURE". Запись пока не начнется.
- (4) Нажмите кнопку РНОТО сильнее Изображение, отображаемое на экране, будет записано на "Memory Stick". Запись считается завершенной, если исчезнет перемещающийся полосатый индикатор.



## 140

## Recording an image from a tape as a still image

When the access lamp is lit or flashing Do not shake or strike the unit. Also do not turn the power off , eject the "Memory Stick" or remove the battery pack. Otherwise, an image data breakdown may occur.

If ③ appears on the screen
The inserted "Memory Stick" is incompatible
with your camcorder because its format does not
comform with your camcorder. Check the format
of the "Memory Stick".

## If you press PHOTO lightly in the playback mode

Your camcorder stops momentarily

## Sound recorded on a tape You cannot record the audio from a tape

Titles superimposed on tapes You cannot record the titles on the "Memory Stick." However, you can record titles which have already been recorded on tapes.

## When you press PHOTO on the Remote

Your camcorder immediately records the image that is on the screen when you press the button.

## Recording a still image from other equipment

## DCR-TRV330E only

Before operation Set DISPLAY to LCD in the menu settings. (The default setting is LCD.)

- (1) Set the POWER switch to VCR.
- (1) set the PUWER switch to VCR.
  (2) Play back the recorded tape, or turn the TV
  on to see the desired programme.
  The image from TV or VCR appears on the
  screen of your camcorder.
  (3) Follow the steps 3 and 4 on page 141.

### Запись изображения с ленты как неподвижного изображения

Если лампочка доступа горит или мигает Не трясите и не стучите по Вашей видеокамере. Также не выключайте питание, не извлекайте "Memory Stick" из отсека и не снимайте батарейный блок. В противном случае данные изображения могут быть повреждены.

## Если на экране появится индикация < Вставлена "Метогу Stick", которая несовместима с Вашей видеокамерой, поскольку ее формат не соответствуе видеокамере. Проверьте формат "Мег

# Если в режиме воспронажать кнопку РНОТО Ваша видеокамера на мостановится.

Звук, записанный на ленту Вы не можете записывать звук с ленты

Титры, наложенные на ленты Вы можете записывать титры на "Memory Stick". Однако, Вы можете записывать титры, которые уже записаны на лентах.

## Если Вы нажмете кнопку РНОТО на пульте

дистанционного управления
Ваша видеокамера тотчас же запишет
изображение, отображаемое на экране, если Вы нажмете эту кнопку.

## Запись неподвижного изображения с другого аппарата

## Только модели DCR-TRV330E

Перед выполнением операции
Установите пункт DISPLAY в установках меню в положение LCD. (По умолчанию установлено положение LCD.)

- (1) Установите переключатель POWER в
- (1) установите переключатель РОWER в положение VCR.

  (2) Начните воспроизведение записанной ленты или включите телевизор для просмотра нужной программы.


  Изображение с телевизора или КВМ отображается на экране Вашей
- (3) Выполните действия пунктов 3 и 4 на стр.

### Recording an image from a tape as a still image

## Using the A/V connecting cable

### Запись изображения с ленты как неподвижного изображения

## Использование соединительного кабеля аудио/видео



Connect the yellow plug of the A/V connecting cable to the video jack on the VCR or the TV.

# If your TV or VCR has an S video jack Connect using an S video cable (optional) to obtain high-quality pictures. With this connection, you do not need to connect

the yellow (video) plug of the A/V connecting

Connect an S video cable (optional) to the S video jacks of both your camcorder and the TV or VCR.

Подсоедините желтый штекер соединительного кабеля аудио/видео к видеогнезду на КВМ или телевизоре.

водеог незду на пъли или телевизоре.

Если в Вашем телевизоре или КВМ

имеется гнездо S видео

Выполните подсоединение с помощью

кабеля Ѕ видео (приобретается отдельно)

для получения высококачественных

изображенить желтый (видео) штекер

соединительного кабеля аудио/видео.


Подсоедините кабель Ѕ видео

(приобретается отдельно) к гнездам Ѕ видео

на Вашей видеокамере и КВМ.

## Using the i.LINK cable (DV connecting cable)

## Использование кабеля i.LINK (соединительный кабель DV)



143

## 145

## To stop copying Press MENU to stop copying

## When the memory of the "Memory

Copying still images from a tape - Photo save

# "MEMORY FULL" appears on the screen, and the copying stops. Insert another "Memory Stick" and repeat the procedure from step 2.

When the access lamp is lit or flashing Do not shake or strike your camcorder. As well do not turn the power off, eject the "Memory Stick" or remove the battery pack. Otherwise, the image data breakdown may occur.

If the write-protect tab on the "Memory Stick" is set to LOCK
"NOT READY" appears on the screen when you select PHOTO SAVE in the menu settings.

When you change the "Memory Stick" in the middle of copying Your camcorder resumes copying from the last image recorded on the previous "Memory Stick".

Если лампочка доступа горит или мигает Никогда не трясите и не стучите по Вашей видеокамере. Также, не выключайте питание, не извлекайте "Метпоту Stick" из отсека и не снимайте батарейный блок. В противном случае данные изображения могут быть повреждены.

Копирование неподвижных изображений с ленты – Сохранение

фотоснимков в памяти

Для остановки копирования Нажмите кнопку MENU для остановки копирования.

В случае переполнения памяти "Memory Stick"

ментот у заск На экране появится индикация "МЕМОRY FULL", и копирование остановится. Вставьте другую "Memory Stick" и повторите процедуру, начиная с пункта 2.

Если лепесток защиты записи на "Memory Stick" установлен в положение LOCK На экране появится индикация "NOT READY", если Вы выберите PHOTO SAVE в установках меню.

Если Вы замените "Memory Stick" в середине копирования
Ваша видеокамера возобновит копирование,
начиная с последнего изображения,
записанного на предыдущей "Memory Stick".

### Копирование неподвижных Copying still images изображений с ленты - Сохранение from a tape - Photo save фотоснимков в памяти

## - DCR-TRV325E/TRV330E/TRV430E/

- DCR-IRV32DE/IRV33UE/IRV43UE/ TRV53UE only Using the search function, you can automatically take in only still images from tapes recorded in the Digital8 by system and record them on a "Memory Stick" in sequence.

- Before operation
   Insert a tape recorded in the Digital8 D system and rewind the tape.
   Insert a "Memory Stick" into your camcorder.
- (1) Set the POWER switch to PLAYER or VCR (DCR-TRV330E only).
  (2) Press MENU to make the menu display
- appear.

  (3) Turn the SEL/PUSH EXEC dial to select ,
- (3) Turn the SEL/PUSH EXEC dial to select ... then press the dial.
  (4) Turn the SEL/PUSH EXEC dial to select PHOTO SAVE, then press the dial. PHOTO BUTTON appears on the screen.
  (5) Press PHOTO deeper. The still image from the tape is recorded on the "Memory Stick". The number of still images copied is displayed. END is displayed when copying is completed.

 Вставьте "Метолу Stick" в Вашу видеокамеру.
 (1) Установите переключатель POWER в положение PLAYER или VCR (только модели DCR-ТRV330E).
 (2) Нажиміте кнопку MENU, чтобы на дисплее появилась индикация меню.
 (3) Поверните диск SEL/PUSH EXEC для выбора установки СП, а затем нажмите диск.
 (4) Поверните диск SEL/PUSH EXEC для выбора установки PHOTO SAVE, а затем нажмите диск. На экране появится индикация PHOTO BUTTON.
 (5) Твердо нажмите кнопку PHOTO.
 Неподвижное изображение с ленты будет записано на "Метолу Stick". Будет отображено количество неподвижных отображено количество неподвижных скопированных изображений. По завершении копирования на дисплее будет отображена индикация END. 1


- Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E Используя функцию поиска, Вы можете

Перед началом работы

Используя функцию поиска, Вы можете автоматически выполнять фотоснимки только

неподвижных изображений с лент, записанных в системе Digital8 **F**), и записывать их на "Memory Stick" в последовательности.

Вставьте ленту, записанную в системе Digital8 () и перемотайте ленту.
• Вставьте "Memory Stick" в Вашу ви



## Viewing a still image Memory Photo playback

– DCR-TRV325E/TRV330E/TRV430E/ TRV530E only You can play back still images recorded on a "Memory Sitck". You can also play back 6 images at a time by selecting the index screen.

Before operation Insert a "Memory Stick" into your camcorder.

- (1) Set the POWER switch to MEMORY, PLAYER or VCR (DCR-TRV330E only). Make sure that the LOCK is set to the left (unlock) position. (2) Open the LCD panel while pressing OPEN.
  (3) Press MEMORY PLAY. The last recorded
- image is displayed.

  (4) Press MEMORY +/- to select the desired still image. To see the previous image, press MEMORY -. To see the next image, press MEMORY +.


## Просмотр неподвижного изображения - Воспроизведение фотоснимков из памяти

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Вы можете воспроизводить неподвижные изображения, записанные на "Memory Stick". Вы можете также воспроизводить 6 изображений одновременно путем выбора

### Перед началом работы Вставьте "Memory Stick" в Вашу видеокамеру

- (1) Установите переключатель POWER в положение MEMORY, PLAYER или VCR (только модель DCR-TRV330E). Убедитесь, что фиксатор LOCK установлен в левом (незафикси положении.
- (2) Нажав кнопку OPEN, откройте панел
- (2) Нажав кнопку ОРЕN, откройте панель ЖКД.
  (3) Нажмите кнопку МЕМОRY PLAY. Будет отбражено последнее записанное изображение.
  (4) Нажмите кнопку МЕМОRY +/- для выбора нужного неподвижного изображения. Для того, чтобы увидеть предыдущее изображение, нажмите кнопку МЕМОRY -. Для того, чтобы увидеть следующее изображение, нажмите кнопку МЕМОRY +.



To stop memory photo playback Press MEMORY PLAY.

Для остановки воспроизведения фотоснимков из памяти Нажмите кнопку MEMORY PLAY.

### Viewing a still image · Memory Photo playback

## Notes on the file name

- The directory is not displayed if the structure of the directory does not conform to the DCF98
- the screen if the structure of the directory does not conform to the DCF98 standard. While this
- not conform to the DCF98 standard: While this message appears, you can play back images but cannot record them on the "Memory Stick".

   The file name flashes on the screen if the file is corrupted or the file is unreadable.

- To play back recorded images on a TV screen

  Connect your camcorder to the TV with the

  A/V connecting cable supplied with your
  camcorder before the operation.

  When operating memory photo playback on a

  TV or the LCD screen, the image quality may
  appear to have deteriorated. This is not a
  malfunction. The image data is as good as ever.

  Turn the audio volume of the TV down before
  operation, or noise (howling) may be output
  from the TV speakers.

If " NO FILE" appears on the screen No image is recorded on the "Memory Stick."

Image data modified with your computer or shot with other equipment You may not be able to play them back with your camcorder.

## Просмотр неподвижного изображения – Воспроизведение фотоснимков из памяти

## Примечания о названии файла

- Каталог не отображается, если структура каталога не соответствует требованиям
- каталога не соответствует требованиям стандарта DCF98. 
  Индикация "₹О ¬¬ DIRECTORY ERROR" может появиться на экране, если структура каталога не соответствует требованиям стандарта DCF98. Пока это сообщение отображается, Вы сможете воспроизводить изображения, но не сможете записывать их на "Метолу Slick". 
  Название файла мигает на экране, если файл поврежден или не читается.

- Для воспроизведения записанных изображений на экране телевизора
   Перед началом воспроизведения подсоедините Вашу видеокамеру к телевизору с помощью соединительног кабеля аудио/видео, прилагаемого к Ва видеокамере.
- При воспроизведении фотоснимков из При воспроизведении фотоснимков из памяти на экране телевизора или ЖКД, качество изображения может ухудшиться. Это не является неисправностью. Данные изображения находятся в том же
- посоражения находятся в том же состоянии, как и прежде. Перед началом воспроизведения уменьшите громкость телевизора вниз, иначе через акустическую систему телевизора может послышаться шум (завывание).

Если на экране появится индикация "Ѕ NO FILE" На "Memon√Sha"." . nory Stick" нет записанных изображений

Данные изображения, видоизмененные с помощью вашего компьютера или снятые с помощью другой аппаратуры Вы не сможете воспроизвести их с помощью с помощью Вашей видеокамеры.

### Screen indicators during still image playback

## Экранные индикаторы во время воспроизведения неподвижных изображений



146

### laving back 6 recorded images at a time (index screen)

You can play back 6 recorded images at a time. This function is especially useful when searching for a particular image.

- (1) Set the POWER switch to MEMORY, PLAYER or VCR (DCR-TRV330E only). Make sure that the LOCK switch is set to the left (unlock) position
- (2) Press MEMORY INDEX to display the index

# Просмотр неподвижного изображения – Воспроизведение фотоснимков из памяти

# Воспроизведение 6 записанн изображений одновременно (индексный экран)


Вы можете воспроизвести 6 записанных изображений одновременно. Эта функц является особенно полезной при выпол поиска отдельных изображений.

- (1) Установите переключатель POWER в положение MEMORY, PLAYER или VCR (только модель DCR-TRV330E). Убедитесь, что переключатель LOCK установлен в левое (открытое)
- положение. (2) Нажмите кнопку MEMORY INDEX для отображения индиксного экрана



A red ▶ mark appears above the image that is displayed before changing to the index screen

Красная метка ▶ появится над изображением, которое будет отображаться



- To display the following 6 images, keep
- To display the following 6 images, keep pressing MEMORY +.
   To display the previous 6 images, keep pressing MEMORY -.
- Для отображения следущих 6 изображе держите нажатой кнопку МЕМОRY +.
   Для отображения предыдущих 6 изображений держите нажатой кнопку МЕМОRY -.

### Viewing a still image - Memory Photo playback

## To return to the normal playback

screen (single screen)
Press MEMORY +/- to move the ▶ mark to the image you want to display on full screen, then press MEMORY PLAY.

When displaying the index screen, the number appears above each image. This indicates the order in which images are recorded on the "Memory Stick". These numbers are different from the data file names.

Image data modified with your computer or shot with other equipment
These files may not be displayed on the index

# Просмотр неподвижного изображения – Воспроизведение фотоснимков из памяти

Для возврата к экрану обычного воспроизведения (одиночный экран) Нажимайте кнопку МЕМОЯУ +/– для перемещения знака № к изображению, которое Вы котите отобразить на полный экран, а затем нажмите кнопку МЕМОЯУ рі АУ. PI AV

При отображении индексного экрана над каждым изображением будет появляться номер. Он означает порядок, в котором изображения записаны на "Memory Stick". Эти номера отличаются от имен файлов

# Данные изображения, измененного Вашем компьютере или снятого с помощью другой аппаратуры Эти файлы могут не отображаться на индексном экране.

Операции

148 149

## Viewing images using your computer

# - DCR-TRV325E/TRV330E/TRV430E/ TRV530E only You can view data recorded on the "Memory Stick" using your computer.

## On file format

On file format
Data recorded on the "Memory Stick" is stored in
the JPEG format. Make sure that an application
that supports JPEG file format is installed on your computer.

### Recommended computer environment

mended Windows environment Microsoft Windows 98, Windows 98SE, Windows Me or Windows 2000 Professional standard installation is

Professional standard and required.

Operation is not assured in an environment upgraded from:
Windows 3.1, Windows 95 to Windows 98 to Windows 98.5.
Windows 98.5 Windows 98.8. Windows 98SE. Windows 98SE, Windows 973.5 10 r Windows NT3.40 to Windows NT3.5 10 r Windows NT4.0 to Windows NT4.0 to

The USB connector must be provided as

## Macintosh computer with the Mac OS 8.5.1/8.6/ 9.0 standard installation.

- 9.0 standard installation.

  However, note that the update to Mac OS 9.0 should be used for the following models.

   iMac with the Mac OS 8.6 standard installation
- and a slot loading type CD-ROM drive iBook or G4 with the Mac OS 8.6 standard installation

The USB connector must be provided as

## Notes

- Operations are not guaranteed for either the Windows or Macintosh environment if you connect 2 or more USB equipment to a single computer at the same time or when using a
- Depending on the type of USB equipment that is used simultaneously, some equipment may not operate.

  Operations are not guaranteed for all the
- recommended computer environments mentioned above.

## Просмотр изображений с использованием персонального компьютера

- Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E Вы можете просматривать записанные "Метогу Stick" данные, используя Вашкомпьютер.

## О формате файлов

О формате фаилов Данные, записанные на "Memory Stick", хранятся в формате JPEG. Убедитесь, что на Вашем компьютере установлены прикладные программы, поддерживающие файловый

## Рекомендованные компьютерные

Рекомендованные компьютерные конфигурации Рекомендованная конфигурация Wind OC: Microsoft Windows 98, Windows 98SE, Windows Me или Windows 2000 Professional Professional
Требуется стандартная установка
Выполнение операций не
гарантируется в конфигурациях, обновленных от: Windows 3.1, Windows 95 до Windows 98 windows 3, windows 98 до windows 985. Windows 98, Windows 98, Windows 98, Windows 98, Windows 98, Windows 98, Windows 2000 Profession. NT4.0 до Windows 2000 Profession. Процесор: Pentium MMX 200 МГц или быстрее. Разъем USB должен входить в стандарт комплектация.

Рекомендованная конфигурация Macintosh Компьютер Macintosh с Mac OS 8.5.1/8.6/9.0 в стандартной установке. Однако, обратите внимание на то, что спедует использовать обновление до Mac OS 9.0 для спедующих моделей: "

- загрузкой iBook или G4 со стандартно установленной Mac OS 8.6 Разъем USB должен входить в стандартную комплектацию

- Примечания

   Выполнение операций не гарантируется для среды и Windows, и Macintosh, если Выподсоедините 2 или более устройств USB одновременно к одному персональному компьютеру или при использовании концентратора.

  В зависимости от типа оборудования USB, используемого одновременно, некоторое оборудование может не работать.

   Выполнение операций не гарантируется для всех рекомендованных вышеупомянтутых
- всех рекомендованных вышеупомянутых компьютерных сред.

### Viewing images using your computer

## Installing the USB driver

Before connecting your camcorder to your computer, install the USB driver to the computer. The USB driver is contained together with application software for viewing images on a CD-ROM which is supplied with your

## For Windows 98/98SE/Me and

- Windows 2000 users
  (1) Turn on your computer and allow Windows
- to load.

  (2) Insert the supplied CD-ROM in the CD-ROM drive of your computer.

  (3) Launch the application programme on CD-ROM. After a moment, the dialog box appears on your desktop. Set the cursor on "USB Driver Installation for Windows 9 89.98SE/Me and Windows 9 2000" and click.

  (4) The Setup norgramme starts. Complete the
- (4) The Setup programme starts. Complete the installation on CD-ROM.
- (5) Connect the Ψ (USB) jack on your camcorder with the USB connector on your computer using the supplied USB cable.

  (6) Insert a "Memory Stick" into
- norv Stick" into vour camcorder connect the AC power adaptor and set the POWER switch to MEMORY.
  - "PC MODE" appears on the screen of your camcorder. Your computer recognizes the camcorder, and the Windows Add Hardware Wizard starts
- (7) The Add Hardware Wizard starts twice because 2 different USB drivers are installed. Be sure to allow the installation to complete

## Просмотр изображений с использованием персонального компьютера


## Установка драйвера USB

Перед подсоединением Вашей видеокамерь к Вашему персональному компьютеру установите на компьютер драйвер USB. Драйвер USB содержится вместе с программным обеспечением на CD-прилагаемом к Вашей видеокамере ным обеспечением на СD-ВОМ

### Для пользователей Windows 98/98SE/ Me и Windows 2000

- (1) Включите Ваш персональный компы-дайте Windows загрузиться. (2) Установите прилагаемый CD-ROM в накопитель CD-ROM Вашего
- накопитель СЭ-н-ОМ вашего персонального компьютера.

  (3) Запустите программу на CD-ROM. Через некоторое время на Вашем рабочем стопе появится диалоговое окно. Установите курсор на пункте "USB Driver Installation for Windows ® 98/98SE/Me и Windows ® 2000" и щелкните кнопкой мыши.
- (4) Запустится программа установки Завершите установку с CD-ROM.
- (5) Подсоедините разъем  $\Psi$  (USB) на Вашей видеокамере к гнезду USB Вашего персонального компьютера, используя
- персонального компьютера, используя прилагаемый кабель USB. (6) Установите "Memory Stick" в Вашу видеокамеру, подсоедините адаптер питания переменного тока и установите переключатель POWER в положение MEMORY
- переключател \* СWEIT в положение МЕМОRY. На экране Вашей видеокамеры появится индикация \* РС МОDE\*. Ваш персональный компьютер распознает видеокамеру, и запустится "мастер" Windows \* Установка оборудования\*. (7) Мастер \* Установка оборудования\* запустится два раза, потому что устанавливаются два разичных драйвери USB. Обязательно двате установке завершиться, не прерывая ее.



You cannot install the USB driver if a "Memory Stick" is not in your camcorder. Be sure to insert a "Memory Stick" into your camcorder before installing the USB driver.

### For Macintosh users

- (1) Turn on your computer and allow the Mac OS (2) Insert the supplied CD-ROM in the CD-ROM
- drive of your computer.
  (3) Double-click the CD-ROM drive icon to open
- the window.

  (4) Double-click the icon of the hard disk
- (4) Double-click the icon of the hard disk containing the OS to open the window.

  (5) Move the following 2 files from the window opened in step 3 to the System Folder icon in the window opened in step 4 (drag and drop).

  Sony Camcorder USB Driver
  Sony Camcorder USB Shim
  (6) When "Put these items into the Extensions folder?" appears, click OK.

  (7) Restart your computer.

## Viewing images For Windows 98 users

- (1) Turn on the power of your computer and allow Windows 98 to load.
  (2) Connect one end of the USB cable to the Ψ
- (2) Connect one end of the USB cable to the \( \psi\) (USB) jack on the cameorder and the other end to the USB connector on your computer (3) Insert a "Memory Stick" into your cameorde and connect the AC power adaptor to your camcorder and then to a wall socket.
  (4) Set the FOWER switch to MEMORY.
- "PC MODE" appears on the screen of your
- camcorder.

  (5) Open "My Computer" on Windows 98 and double click the newly recognized drive. (Example: "Removable Disk (D:)")

  The folders inside the "Memory Stick" are
- Select and double-click the desired image file from the folder. Double-click the folder or the file in the folder. Double-click the folder or the file in the following order.

  "Deim" folder → "100msdcf" folder → Image file
- For the detailed folder and file name, see "Image file storage destinations and image files" (p. 154).

152

## Просмотр изображений с использованием персонального компьютера

Примечание
Вы не можете установить драйвер USB, если
в Вашей видеокамере нет "Memory Stick".
Убедитесь, что установили "Memory Stick" в
Вашу видеокамеру перед установкой

- Для пользователей Macintosh
  (1) Включите Ваш персональный компьюте дайте Мас ОЗ загрузиться:
  (2) Установите припагаемый СО-РОМ в накопитель СО-РОМ Вашего персонального компьютера.
  (3) Двойным шенчком по пиктограмме СО-
- жесткого диска, содержащего ОС, откройте окно.

  (5) Переместите следующие 2 файла из окна, открытого в пункте 3 на пиктограмму System Folder в окне, открытом в пункте 4 (потаните и отпустите).

   Sony Camcorder USB Driver Sony Camcorder USB Shim (6) Когда появител вопрос 7 the these items into Campana (7) Перезапустите Ваш персональный компьютер.

## Просмотр изображений

## Для пользователей Windows 98 (1) Включите Ваш персоновичей

- Для пользователей Windows 98
  (1) Включите Ваш персональный компьютер и дайте Windows 98 загрузиться.
  (2) Подсоедините один конец кабеля USB к гнезду (У USB) на видеокамере, а другой конец к разъему USB Вашего персонального компьютера.
  (3) Установите "Метолу Stick" в Вашу видеокамеру и подсоедините адаптер питания переменного тока к Вашей видеокамере, а затем к стенной розетке.
  (4) Установите переключаты РОЖЕЯ в положение МЕМОЯУ.
  На зкране появится индикация "РС

- (\*) установите переключатель РОУИЕН в положение МЕМОRУ.
   На экране появится индикация "РС МОDE".
   (5) Откройте "Мой компьютер" в Windows 98 и дважды щелкните по вновь распознанному накопителю (Пример: "Съемный Диск (D:)").
   Отобразятся папки внутри "Memory Stick".
   (6) Выберите и дважды щелкните по файлу нужного изображении из папки. Два раза щелкните по папке или файлу в следующем порядке.
   Папка "Dcim" папка "100msdcf" → файл изображения Для подробного описания названий папок и файлов обращайтесь к разделу "Места хранения файлов изображений и файлы изображений" (стр. 154).

Просмотр изображений с использованием

Программы
В зависимости от прикладной программы, размер файла может увеличиться, когда Вы открываете файл с неподвижным

компьютера в видеокамеру или когда Вы напрямую изменяете изображение в видеокамере, формат изображения

изменится, так что может появиться индикатор ошибки файла, и Вы, возможно,

Связь между Вашей видеокамерой и Вашим персональным компьютером может не восстановиться после выхода компьютера из режимов Suspend, Resume или Sleep.

Файлы изображений, записанные с помощью Вашей видеокамеры, сгруппированы в папке. значения названий файлов таковы. 

□□□□ обзначает любое число в диапазоне от 0001 до 9999.

Для пользователей Windows 98

(Устройство, представля видеокамеру – [D:])

изображением. Когда Вы загружаете изображение измененное с помощью программы для ретуширования, из Вашего персонального

персонального компьютера

не сможете открыть файл.

компьютером


Связь с Вашим персональным

Места хранения файлов

изображений и файлы изображений

### Viewing images using your computer

## Просмотр изображений с использованием персонального компьютера



## Unplug the USB cable/Eject the "Memory Stick"

To unplug the USB cable or eject the "Memory Stick", follow the procedure below.

### For Windows 2000 users

- For windows 2000 users

  (1) Move the cursor to the "Unplug or Eject
  Hardware" icon on the TaskTray and click to
  cancel the applicable drive.

  (2) A message to remove the device from the
  system appears, then unplug the USB cable or
  eject the "Memory Stick."

### For Macintosh users

- (1) Quit application programmes opened. Make sure that the access lamp of the hard disk does not lit.
- disk does not lit.

  (2) Drag and drop the "Memory Stick" icon to the Trash or select Eject under the Special menu.

  (3) Eject the "Memory Stick."

## Notes on using your computer

## "Memory Stick"

- "Memory Stick"

   "Memory Stick" operations on your camcorder cannot be assured if the "Memory Stick" has been formatted on your computer.

   Do not optimize the "Memory Stick" on a Windows machine. This will shorten the "Memory Stick" life.

   Do not compress the data on the "Memory Stick." Compressed files cannot be played back on your camcorder.

# Отсоединение кабеля USB/ Извлечение "Memory Stick"

Для отсоединения кабеля USB или извлечения "Memory Stick" следуйте нижеописанной процедуре

Лля пользователей Windows 2000

для пользователем windows zuuu
(1) Переместите курсор на пиктограмму "Unplug
or Eject Hardware" в панели задачи щелкните
для отмены подходящего устройства, зас (2) Появится сообщение об удалении
устройства, затем отсоедините кабель
USB или извлеките "Memory Stick".

## Для пользователей Macintosh

- (1) Закройте открытые программы Убедитесь, что лампочка доступа жёсткого диска не горит
- жесткого диска не горит.

  (2) Потяните пиктограмму "Memory Stick" и отпустите ее над Корзиной или выделите эту пиктограмму одинарным щелчком и выберите команду Ејест в меню Special. (3) Извлеките "Memory Stick"

### Примечания об использовании Вашего персонального компьютера

### "Memory Stick"

- "Работа "Memory Stick" на Вашей Расита метногу зску на дашей видеокамере не гарантируется, если "Метногу Stick" была отформатирована на Вашем компьютере.
  • Не выполняйте оптимизацию "Memory Stick"
- не выполняите оптимизацию метноту з на компьютере с Windows. Это сократит срок службы "Memory Stick".
   не сжимайте данные на "Memory Stick".
   Сжатые файлы не воспроизводятся на Вашей видеокамере.

153

## Viewing images using your computer

- Software
  Depending on your application software, the
  file size may increase when you open a still
  image file.
  When you load an image modified using a
  retouch software from your computer to the
  camcorder or when you directly modify the
  image on the camcorder, the image format will
  differ as a flat every indicator, may appear and differ so a file error indicator may appear and you may be unable to open the file.

## Communications with your computer Communications between your camcorder and your computer may not recover after recovering from Suspend, Resume, or Sleep.

### Image file storage destinations and image files

Image files recorded with your camcorder are

Image nies reconsection.....grouped in a folder.
The meanings of the file names are as follows.

## For Windows 98 users (The drive recognizing the camera is [D:])



Folder containing still image data/ Папка, содержащая данные неподвижных изображений

Folder/Папка	File/Файл	Meaning/Значение
100msdcf	DSC0□□□□.JPG	Still image file/ Файл неподвижного изображения

## Copying the image recorded on "Memory Stick" to tapes

- DCR-TRV330E only
You can copy still images or titles recorded on
"Memory Stick"s and record them to
Hi8 Hi⊠/Digital8 H stapes.

Before operation
Insert a Hi8 Hi8/Digital8 H tape for recording
and a "Memory Stick" into your camcorder.

- (1) Set the POWER switch to VCR.
  (2) Using the video control buttons, search a point where you want to record the desired still image. Set the Hi8 Hi 🖪/Digital8 🖁 tape
- to playback pause mode.

  (3) Press REC and the button on its right simultaneously on your camcorder. The Hi8 Hi 日/Digital8 H tape is set to the recording
- pause mode. (4) Press MEMORY PLAY to play back the still
- image you want to copy.

  (5) Press II to start recording and press II again
- to stop. **(6)** If you have more to copy, repeat steps 4 and 5.


## Копирование изображений, записанных на "Memory Stick", на ленты

## - Только DCR-TRV330E

Вы можете копировать неподвижные изображения или титры, записанные на "Memory Stick", и записывать их на ленты Hi8 **HiB**/Digital8 **f**).

Перед началом работы
Вставьте ленту Hi8 **Hi⊡**/Digital8 **F)** для записи и "Memory Stick" в Вашу видеокамеру.

- (1) Установите переключатель POWER в положение VCR.
- Установите переключатель РОWEH в положение VCR.
   Используя кнопки видеоконтроля, найдите точку, где Вы хотите записать нужное неподвижное изображение. Установите ленту Ні8 НІВ/Digital8 19 в режим паузы воспроизведения.
   Нажмите одновременно кнопку REC и кнопку справа от нее на Вашей видеокамере. Лента Hi8 HIB/Digital8 19 будет установлена в режим паузы воспроизведения.
   Нажмите кнопку МЕМОЯУ РLАУ для воспроизведения неподвижного изображения, которое Вы хотите скопировать.
   Нажмите кнопку II для начала записи и нажжите кнопку II для начала записи и нажжите кнопку II шеце раз для остановки. Посторите действия пунктов 4 и 5.



To stop copying

Для остановки копирования Нажмите кнопку ■.

## Copying the image recorded on "Memory Stick" to tapes

### During copying

You cannot operate the following buttons:
- MEMORY PLAY

- MEMORY INDEX MEMORY DELETE
- MEMORY +/-- MEMORY MIX

## Note on the index screen You cannot record the index screen.

If you press EDITSEARCH during pause mode

Image data modified with your computer or

You may not be able to copy them with your camcorder.

If you press DISPLAY in the standby or recording mode
You can see memory playback and the file name indicators in addition to the indicators pertinent to His Hist/Digitals H tapes, such as the time code indicators

When copying
You cannot copy the image recorded on
"Memory Stick" with titles to tapes.

## Копирование изображений, записанных на "Memory Stick", на ленты

### Во время копирования

Вы не можете оперировать следующими

- KHONKAMU: MEMORY PLAY MEMORY INDEX MEMORY DELETE

- MEMORY +/-- MEMORY MIX

**Примечание по индексному экрану** Вы не можете записать индексный экран

## Если Вы нажмете EDITSEARCH в режиме

**паузы** Воспроизведение из памяти остановится.

# Данные изображения, преобразованного помощью компьютера или снятого с помощью другого аппарата Возможно, Вы не сможете их скопировать с

помощью Вашей видеокал

Если Вы нажмете DISPLAY в режиме ожидания или записи Вы можете увидеть воспроизведение из памяти и индикаторы названий файлов в дополнение к индикаторам, относящимся к лентам Hi8 Hi8/Digital8 Н, таким как индикатор кола влемени.

Вы не можете копировать изображения, записанные на "Memory Stick", с титрами на

## **Enlarging still images** recorded on "Memory Stick"s - Memory PB ZOOM

## - DCR-TRV325E/TRV330E/TRV430E/

TRV530E only
You can enlarge still images recorded on a "Memory Stick."

Before operation Insert a "Memory Stick" into your camcorder

- (1) Set the POWER switch to MEMORY, PLAYER or VCR (DCR-TRV330E only). Make sure that the LOCK is set to the left (unlock) position.

  (2) Press PB ZOOM on your camcorder while you are playing back limages recorded on "Memory Stick." The still image is enlarged, and ↑ | indicators showing the direction to move the image appear on the screen.

  (3) Turn SEL/PUSH EXEC dial to move the enlarged image, then press the dial.

  † The image moves downwards.

  | The image moves upwards.

↓:The image moves upwards.
↓:The image moves upwards.
← → becomes available.
(4) Turn SEL/PUSH EXEC dial to move the

- Turn SEL/PUSH EXEC dial to move the enlarged image, then press the dial.

  ←: The image moves rightward (Turn the dial downwards.)

  →: The image moves leftward (Turn the dial upwards.)

## Увеличение неподвижных записанных изображений на "Memory Stick" – Память PB ZOOM

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Вы можете увеличивать изображ записанные на "Memory Stick".


Перед операцией Вставьте "Memory Stick" в Вашу видеокамеру

- Вставьте метпоту экіс в Вашу видеокаме (
  1) Установите переключатель РОМЕВ в положение МЕМОRY, PLAYER или VCR (только модели DCR-TRV330E). Убедитесь, что переключатель LOCK установлен в левом (незафиксированно положении). (2) Нажмите кнопку РВ ZOOM на Вашей видеокамере во время воспроизведении изображений, записанных на "Метпоту Stick". Неподвижное изображение увеличится, и на экране ЖКД или в видоискателе появтсям нидикаторы 1 [... увеличится, и на экране ЖКД или в видоискателе появятся индикаторы 1, показывающие направление движения изображения.

  (3) Поверните диск SEUPUSH EXEC для перемещения увеличенного изображени а затем нажмите диск.
- - : Изображение перемещается вниз. : Изображение перемещается вверх
  - появится на лисплее
- (4) Поверните диск SEL/PUSH EXEC для перемещения увеличенного изображе

  - перемещении увеличенного изооражении, а затем нажиите диск. : Изображение перемещается вправо. (Поверните диск вниз) : Изображение перемещается влево. (Поверните диск вверх)

Stick



## 156

## Enlarging still images recorded on "Memory Stick"s - Memory PB ZOOM

## To cancel memory PB ZOOM function Press PB ZOOM.

You cannot record the images enlarged by the PB ZOOM mode on "Memory Stick"s.

In the PB ZOOM mode The digital effect function does not work

# The PB ZOOM function is cancelled when the following buttons are pressed: - MENU - MEMORY PLAY - MEMORY INDEX - MEMORY 1-/- MEMORY -/-

Pictures in the PB ZOOM mode
Pictures in the PB ZOOM mode are not output
through the DV OUT or DV IN/OUT jack when
the POWER switch is set to MEMORY.

## Увеличение неподвижных записанных изображений на "Memory Stick" – Память PB ZOOM

## Для отмены функции PB ZOOM Нажмите кнопку PB ZOOM.

Примечание
Вы не можете записывать изображения увеличенные в режиме PB ZOOM, на "Memory Stick".

## В режиме РВ ZOOM

нкция цифрового эффекта не работает

## Функция РВ ZOOM отменяется при нажатии на следующие кнопки:

- MENU
- MENU MEMORY PLAY MEMORY INDEX MEMORY +/-

Изображения в режиме PB ZOOM Изображения в режиме PB ZOOM не передаются через гнездо DV OUT иг OUT, если переключатель POWER установлен в положение MEMORY.

## Playing back images in a continuous loop SLIDE SHOW

- DCR-TRV325E/TRV330E/TRV430E/ TRV530E only
You can automatically play back images in sequence. This function is useful especially when checking recorded images or during a

Before operation Insert a "Memory Stick" into your camcorder.

- (1) Set the POWER switch to MEMORY. Make sure that the LOCK is set to the left (unlock) position.
  (2) Press MENU to make the menu display
- appear.
  (3) Turn the SEL/PUSH EXEC dial to select \_\_\_\_\_,
- (3) Turn the SEL/PUSH EXEC dial to select ... then press the dial.

  (4) Turn the SEL/PUSH EXEC dial to select SLIDE SHOW, then press the dial.

  (5) Press MEMORY PLAY, Your camcorder plays back the images recorded on the "Memory Stick" in sequence.

## Воспроизведение изображений в непрерывной последовательности по замкнутому циклу – SLIDE SHOW

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E


Вы можете автоматически воспроизводить изображения в непрерывной последовательности. Эта функция является полезной особенно при проверке записанных изображений или во время презентации.

Перед началом работы Вставьте "Memory Stick" в Вашу видеокамеру.

- (1) Установите переключатель POWER в (1) Установите переключатель РОУМЕН в положение MEMORY. Убедитесь, что фиксатор LОСК установлен в левом (незафиксированном) положении. (2) Нажмите кнопку MENU, чтобы на дисплее
- появилась индикация меню
- (3) Поверните диск SEL/PUSH EXEC для выбора установки , а затем нажми
- выбора установки Г., а затем нажмите диск.

  (4) Поверните диск SEL/PUSH EXEC для выбора установки SLIDE SHOW, а затем нажмите диск.

  (5) Нажмите кнопку МЕМОRY РLАY. Ваша видеокамера будет воспроизводить изображения, записанные на "Метогу Stick", в непрерывной последовательности.



To stop the slide show Press MENU.

To pause during a slide show Press MEMORY PLAY.

## To start the slide show from a particular image

Select the desired image using MEMORY +/-buttons before step 2.

To view the recorded images on TV Connect your camcorder to a TV with the A/V connecting cable supplied with your camcorder before operation.

If you change the "Memory Stick" during

The slide show does not operate. If you change the "Memory Stick", be sure to follow the steps again from the beginning.

Воспроизведение изображений в непрерывной последовательности по замкнутому циклу – SLIDE SHOW

Для остановки показа слайдов Нажмите кнопку MENU.

Для паузы во время показа слайдов Нажмите кнопку MEMORY PLAY.

## Для начала показа слайдов с определенного изображения

Выберите нужное изображение с помо кнопок MEMORY +/- перед пунктом 2.

Для просмотра записанных изображений на экране телевизора
Перед началом процедуры подсоедините
Вашу видеокамеру к телевизору с помощью
соединительного кабеля аудиойвидео,
прилагаемого к Вашей видеокамере.

## В случае замены "Memory Stick" во время

просмотра
Показ слайдов приостановится. В случае замены "Memory Stick" Вам следует начать действия сначала.

## Preventing accidental erasure - Image protection

## - DCR-TRV325E/TRV330E/TRV430E/

TRV530E only
To prevent accidental erasure of important images, you can protect selected images.

Before operation Insert a "Memory Stick" into your camcorder

- (1) Set the POWER switch to MEMORY, PLAYER or VCR (DCR-TRV330E only). Make sure that the LOCK is set to the left (unlock) position. (2) Play back the image you want to protect. (3) Press MENU to make the menu display
- appear.
  (4) Turn the SEL/PUSH EXEC dial to select ,
- then press the dial.
  (5) Turn the SEL/PUSH EXEC dial to select PROTECT, then press the dial.
  (6) Turn the SEL/PUSH EXEC dial to select ON,
- then press the dial.
  (7) Press MENU to erase the menu display. The om mark is displayed beside the data file name of the protected image.

## Предотвращение случайного стирания Защита изображения

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Для предотвращения случайного стирания важных изображений Вы можете защитить выбранные изображения.

## Перед началом работы Вставьте "Memory Stick" в Вашу видеокамеру.

- (1) Установите переключатель POWER в положение MEMORY, PLAYER или VCR (только модели DCR-TRY330E). Убедитесь, что фиксатор LOCK установлен в левом (незафиксированном) положении. (2) Воспроизведите изображение, которое Вы устутст защитить.

- (2) Воспроизведите изображение, которое Вы хотите защитить.

  3) Нажмите кнопку МЕNU, чтобы на дисплее появилась индикация меню.


  4) Поверните диск SEL/PUSH EXEC для выбора установки раз затем нажмите диск.

  5) Поверните диск SEL/PUSH EXEC для выбора установки РРОТЕСТ, а затем нажмите диск.

  (6) Поверните диск SEL/PUSH EXEC для выбора установки РВОТЕСТ, а затем установки ОN, а затем нажмите диск.

  (7) Нажмите киск.

  (7) Нажмите кнопку МЕNU для стирания индикации меню. На дисплее появится знак Отра раз раз на стирания на установки меню. На дисплее появится защищенного изображения.



160

## Preventing accidental erasure - Image protection

To cancel image protection Select OFF in step 6, then press the SEL/PUSH Select OFF EXEC dial.

## Note

Note
Formatting erases all information on the
"Memory Stick", including the protected image
data. Check the contents of the "Memory Stick"
before formatting.

# If the write-protect tab on the "Memory Stick" is set to LOCK You cannot carry out image protection.

### Предотвращение случайного стирания – Защита изображения

Для отмены защиты изображения Выберите установку ОFF в пункте 6, а за Выберите установку OFF в пункте 6, а затем нажмите диск SEL/PUSH EXEC.

примечание Форматирование стирает всю информацию на "Memory Stick", включая данные защищенного изображения. Проверьте содержание "Memory Stick" перед

Если лепесток защиты записи на "Men Stick" установлен в положение LOCK Вы не сможете выполнить защиту изображения.

## **Deleting images**

## DCR-TRV325E/TRV330E/TRV430E/

TRV530E only
You can delete images stored in a "Memory Stick."

Before operation Insert a "Memory Stick" into your camcorder.

## Deleting selected images

(1) Set the POWER switch to MEMORY, PLAYER or VCR (DCR-TRV330E only). Make sure that the LOCK is set to the left (unlock) position. (2) Play back the image you want to delect (3) Press MEMORY DELETE. "DELETE?"

appears on the screen.
(4) Press MEMORY DELETE again. The selected

## Удаление изображений

## - только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E


Вы можете удалить изображ на "Memory Stick".

## Перед началом работы

Вставьте "Memory Stick" в Вашу видеокамеру.

## Удаление выбранных изображений

- (1) Установите переключатель POWER в положение MEMORY, PLAYER или VCR (только модели DCR-TRY930E). Убедитесь, что фиксатор LOCK установлен в левом (незафиксированном) положении.
- (2) Воспроизведите изображение, которое Вы хотите удалить.
- хотите удалить.
  (3) Нажмите кнопку MEMORY DELETE. На экране появится индикация "DELETE?" (4) Нажмите кнопку MEMORY DELETE еще раз. Выбранное изображение будет удалено.



To cancel deleting an image Press MEMORY - in step 4.

To delete an image displayed on the index screen

Press MEMORY +/- to move the ▶ indicator to the desired image and follow steps 3 and 4.

- Notes

   To delete a protected image, first cancel image
- protection.

  Once you delete an image, you cannot restore it. Check the images to delete carefully before deleting them.

Для отмены удаления изображения Нажмите кнопку MEMORY – в пункте 4.

## Для отмены изображения.

для отмены изооражении, отображаемого на индексном экране Нажмите кнопку МЕМОRY +/- для перемещения индикатора ▶ к нужному изображению и выполните действия пунктов 3 и 4.

Примечания

• Для удаления защищенного изображения сначала отмените защиту изображения.

• После удаления изображения вы не сможете восстановить его. Проверьте изображения внимательно, прежде чем удалить их.

is displayed.

Deleting all the images

appear.
(3) Turn the SEL/PUSH EXEC dial to select □,

then press the dial.

(4) Turn the SEL/PUSH EXEC dial to select
DELETE ALL, then press the dial.

(5) Turn the SEL/PUSH EXEC dial to select OK, then press the dial. OK changes to EXECUTE.

(6) Turn the SEL/PUSH EXEC dial to select EXECUTE, then press the dial. DELETING appears on the screen. When all the unprotected images are deleted, COMPLETE is displayed.

## Удаление всех изображений

Вы можете удалить все незащище изображения на "Memory Stick". You can delete all the unprotected images in the "Memory Stick".

- (1) Установите переключатель POWER в положение MEMORY. Убедитесь, что фиксатор LOCK установлен в левом (1) Set the POWER switch to MEMORY. Make sure that the LOCK is set to the left (unlock) position.
  (2) Press MENU to make the menu display

  - положение миси-т л узедитесь, что фиксатор LOCK установлен в левом (незафиксированном) положении. (2) Нажмите киопку МЕNU, чтобы на дисплее появилась индикация меню. (3) Поверните диск SEL/PUSH EXEC для выбора установки ☐ , а затем нажмите диск. (4) Поверните диск SEL/PUSH EXEC для выбора установки DELETE ALL, а затем нажмите диск. (5) Поверните диск SEL/PUSH EXEC для выбора установки ОК, а затем нажмите диск. Индикация ОК изменится на индикацию EXECUTE. (6) Поверните диск SEL/PUSH EXEC для выбора установки EXECUTE, а затем нажмите диск. На экране появится индикация DELETING. Когда все незащищенные изображения будут удалены, на дисплее появится индикация COMPLETE.



To cancel deleting all the images in the "Memory Stick" Select RETURN in step 5, then press the SEL/PUSH EXEC.

While DELETING appears
Do not turn the POWER switch or press any

If the write-protect tab on the "Memory Stick"

is set to LOCK
You cannot delete images

### Удаление изображений

Для отмены удаления всех изображений на "Memory Stick" Выберите установку RETURN в пункте 5, а затем нажмите кнопку SEL/PUSH EXEC


## Во время отображения индикации DELETING

няйте положение переключателя POWER и не нажимайте каких-либо кнопок

Если лепесток защиты записи на "Mem Stick" установлен в положение LOCK Вы не можете удалить изображения.

"Memory Stick Операции

165



## Writing a print mark - PRINT MARK

- DCR-TRV325E/TRV330E/TRV430E/ TRV530E only You can specify the recorded still image to print out. This function is useful for printing out still

images later. Your camcorder conforms with the DPOF (Digital Print Order Format) standard for specifying the still images to print out.

164

Before operation Insert a "Memory Stick" into your camcorder.

- (1) Set the POWER switch to MEMORY, PLAYER or VCR (DCR-TRV330E only). Make sure that the LOCK is set to the left (unlock) position.

  (2) Play back the image you want to write a print mark

- (2) Play back the image you want to write a printmark.

  (3) Press MENU to display the menu.

  (4) Turn the SEL/PUSH EXEC dial to select .

  (5) Turn the SEL/PUSH EXEC dial to select PRINT MARK, then press the dial.

  (6) Turn the SEL/PUSH EXEC dial to select ON, then press the dial.

  (7) Press MENU to erase the menu display. The mark is displayed beside the data file name of the image with a print mark.

## Запись печатных знаков - PRINT MARK

## - Только модели DCR-TRV325E/ TRV330E/TRV430E/TRV530E

Вы можете указать записанные изображения для распечатки. Эта функция является полезной для распечатки неподвижных изображений позже.

изооражении позже. Ваша видеокамера соответствует стандарту DPOF (цифровой служебный формат распечатки) для указания неподвижных изображений для распечатки.


- Перед началом работы Вставьте "Memory Stick" в Вашу видеокамеру.
- Вставъте "Метойу Stick" в Вашу видеокамеру.

  (1) Установите переключатель РОWER в положение MEMORY, PLAYER или VCR (только модели DCR-TIRV330E). Убедитесь, что фиксатор LOCK установлен в левом (незафиксированном) положении.

  (2) Воспроизведите изображение, на котором Вы хотите записать печатный знак.

  (3) Нажмите кнопку MENU, чтобы на дисплее появилось меню.

  (4) Поверните диск SEL/PUSH EXEC для выбора установки [7], а затем нажмите диск.



## Writing a print mark - PRINT MARK

To cancel writing print marks Select OFF in step 6, then press the SEL/PUSH EXEC dial.

If the write-protect tab on the "Memory Stick" is set to LOCK

ot write print marks on still images

## Запись печатных знаков – PRINT MARK

Для отмены записи печатных знаков Выберите установку ОFF в пункте 6, а затем нажмите диск SEL/PUSH EXEC.

Если лепесток защиты записи на "Memory Stick" установлен в положение LOCK Вы не можете записать печатные знаки на неподвижные изображения.

rations

166

## DCR-TRV325E/TRV330E/TRV430E/

- DCR-TRV330E/TRV430E/TRV530E only
You can use the printer (optional) on your camcorder to print images on the print paper. For details, refer to the operating instructions of the printer.
There are various ways of printing still images. The folowing, however, describes how to print by selecting 
in the menu on your camcorder. (p. 107)

- Before operation
   Insert a recorded "Memory Stick" into your camcorder.
   Connect the printer to your camcorder as

9PIC PRINT

PRINT SET

W PRINT SET


DATE/TIME SAME
PRETURN

## Использование принтера (приобретается отдельно)

Только модели DCR-TRV325E/
TRV330E/TRV430E/TRV530E
Вы можете использовать принтер
(приобретается отдельно) с Вашей
видеокамерой для печати изображений на
бумате для отпечатков. Для получения более
подробной информации см. руководство по
эксплуатации принтера.
Существуют различные способы печати
неподвижных изображений. Следующий
способ, тем не менее, описывает, как
выполнить печать путем выбора пункта
из меню Вашей видеокамеры. (стр. 107)

- Перед применением
   Вставьте записанную "Memory Stick" в Вашу
- видеокамеру.
   Подсоедините принтер к Вашей видеокамере, как показано на рисунке.

## Printer/Принтер



You can print 9 still images on the 9 split print paper. Select the desired mode in the menu settings.

SAME PICS/

DATE/TIME



\* 9 still images with print marks are printed

You can make prints with the recording date and/or recording time. Select the desired mode in the menu settings.

DATE

168

Вы можете напечатать 9 неподвижных изображений на 9 составных листах бумаги для отпечатков. Выберите нужный режим в установках меню.

MULTI PICS or \*MARKED PICS/ имы MULTI PICS или \*MARKED PICS



\*9 неподвижных изображений с метками печати печатаются вместе.

Вы можете делать отпечатки с датой записи и/или временем записи. Выберите нужный режим в установках меню.



- Troubleshooting -

## English

## Types of trouble and their solutions

If you run into any problem using your camcorder, use the following table to troubleshoot the problem. If the problem persists, disconnect the power source and contact your Sony dealer or local authorized Sony service facility. If "CIDICIDI" appears on the screen or the display window, the self-diagnosis display function has worked. See page 174.

→ Set it to CAMERA. (p. 28)  The tape has run out.  Rewind the tape or insert a new one. (p. 24, 39)  The write-protect tab is set to expose the red mark.  Use a new tape or slide the tab. (p. 24, 25)  The tape is stuck to the drum (moisture condensation).  Remove the cassette and leave your camcorder for at least 1 hour to acclimatize. (p. 193)  The power goes off.  While being operated in CAMERA mode, your camcord has been in the standby mode for more than 3 minutes.  Set the POWER swite to OFF (CHG) and then to CAMERA again, p. 26)  The image on the viewfinder screen is not clear.  The image on the viewfinder screen is not clear.  The SteadyShot function does not work.  The SteadyShot function does not work.  The autofocusing function does not work.  The autofocusing function does not work.  FOCUS is set to MANUAL.  Set it to ON. (p. 107)  FOCUS is set to MANUAL.  Set it to AUTO. (p. 65)  Shooting conditions are not suitable for autofocus.  Set FOCUS to MANUAL to focus manually. (p. 65)  The LCD panel is open.  **COUS the LCD panel. (p. 28)  The capte is the standard 8 tape.  **Use His His Joigtals 15 tapes. (p. 113)  The contrast between the subject and background is too high. This is not a malfunction.	Symptom	Cause and/or Corrective Actions
has been in the standby mode for more than 3 minutes.  Set the POWER switch to OFF (CHG) and then to CAMERA again. (p. 26)  The image on the viewfinder screen is not clear.  The SteadyShot function does not work.  The SteadyShot function does not work.  The picture does not appear in the viewfinder.  The picture does not appear in the viewfinder lens is not suitable for autofocus.  Set it to AUTO. (p. 63)  Shooting conditions are not suitable for autofocus.  Set POCUS to MANUAL to focus manually. (p. 65)  The LCD panel is open.  You cannot record in the LP mode.  The LCD panel is open.  You Hill Hill Digitals P tapes. (p. 113)  The contrast between the subject and background is too high. This is not a malfunction.  Shoot a very bright subject.  This is not a malfunction.  Some tiny white spots appear on the Slow shutter, low lux or Super NightShot mode is	START/STOP does not operate.	Set it to CAMERA. (p. 26) The tape has run out. Rewind the tape or insert a new one. (p. 24, 39) The write-protect tab is set to expose the red mark. Use a new tape or slide the tab. (p. 24, 25) The tape is stuck to the drum (moisture condensation). Remove the cassette and leave your camcorder for at
is not clear.  → Adjust the viewfinder lens. (p. 30)  The SteadyShot function does not work.  → Set it to ON. (p. 107)  → FOCUS is set to MANUAL. → Set it to AUTO. (p. 65)  → Shooting conditions are not suitable for autofocus. → Set FOCUS to MANUAL to focus manually. (p. 65)  The picture does not appear in the viewfinder.  The LCD panel is open. → Close the LCD panel. (p. 28)  → Vertical band appears when you shoot a subject such as lights or a candle flame against a dark background.  A vertical band appears when you shoot a subject such as lights or a candle flame against a dark background.  A vertical band appears when you shoot a subject and background is too high. This is not a malfunction.  Some tiny white spots appear on the  → Slow shutter, low lux or Super NightShot mode is	The power goes off.	<ul> <li>→ Set the POWER switch to OFF (CHG) and then to CAMERA again. (p. 26)</li> <li>• The battery pack is dead or nearly dead.</li> </ul>
work.  → Set it to ON. (p. 107)  FOCUS is set to MANUAL.  → Set it to AUTO. (p. 65)  - Shooting conditions are not suitable for autofocus.  → Set FOCUS to MANUAL to focus manually. (p. 65)  The picture does not appear in the viewfinder.  The LCD panel is open.  → Close the LCD panel. (p. 28)  The appear is open.  → Use Hill Hill Digitals IP tapes. (p. 113)  The contrast between the subject and background is too high. This is not a malfunction.  A vertical band appears when you shoot a very bright subject.  A vertical band appears when you shoot a very bright subject.  Some tiny white spots appear on the  Slow shutter, low lux or Super NightShot mode is	The image on the viewfinder screen is not clear.	
work.  Set it to AUTO. (p. 65) Shooting conditions are not suitable for autofocus. Set POCUS to MANUAL to focus manually. (p. 65)  The picture does not appear in the viewfinder.  You cannot record in the LP mode. The LCD panel is open. Close the LCD panel. (p. 28) The tage is the standard 8 tape. Use Hill Hill /Digitals P tapes. (p. 113)  The contrast between the subject and background is too high. This is not a malfunction.  A vertical band appears when you shoot a subject such as lights or a candle flame against a dark background.  A vertical band appears when you shoot a very bright subject.  This is not a malfunction.  This is not a malfunction.  Some tiny white spots appear on the Slow shutter, low lux or Super NightShot mode is	The SteadyShot function does not work.	
viewfinder.  → Close the LCD panel. (p. 28)  → Use HIS HIB /Digital8 P tapes. (p. 113)  - The contrast between the subject and background is too high. This is not a malfunction.  A vertical band appears when you shoot a subject such as lights or a candle flame against a dark background.  A vertical band appears when you shoot a very bright subject.  - This is not a malfunction.  - This is not a malfunction.  - This is not a malfunction.  - Slow shutter, low lux or Super NightShot mode is	The autofocusing function does not work.	<ul> <li>→ Set it to AUTO. (p. 65)</li> <li>• Shooting conditions are not suitable for autofocus.</li> </ul>
→ Use Hill Hill / Digitals H tapes. (p. 113)  A vertical band appears when you shoot a subject such as lights or a candle flame against a dark background.  A vertical band appears when you shoot a very bright subject.  A vertical band appears when you shoot a very bright subject.  Some tiny white spots appear on the  Slow shutter, low lux or Super NightShot mode is	The picture does not appear in the viewfinder.	
high. This is not a malfunction.  high. This is not a malfunction.  high. This is not a malfunction.  A vertical band appears when you shoot a very bright subject.  Some tiny white spots appear on the Slow shutter, low lux or Super NightShot mode is	You cannot record in the LP mode.	
shoot a very bright subject.  Some tiny white spots appear on the  • Slow shutter, low lux or Super NightShot mode is	A vertical band appears when you shoot a subject such as lights or a candle flame against a dark background.	
	A vertical band appears when you shoot a very bright subject.	This is not a malfunction.
	Some tiny white spots appear on the screen.	

(Continued on the following page)

## Types of trouble and their solutions

ymptom Cause and/or Corrective Actions			
An unknown picture is displayed on the screen.	<ul> <li>If 10 minutes elapse after you set the POWER switch to CAMERA or DEMO MODE is set to ON in the menu settings without a cassette inserted, your camcorder automatically starts the demonstration.</li> <li>Insert a cassette and the demonstration stops. You can also cancel DEMO MODE. (p. 107)</li> </ul>		
The picture is recorded in incorrect or unnatural colours.	NIGHTSHOT is set to ON.     Set it to OFF. (p. 33)		
Picture appears too bright, and the subject does not appear on the screen.	NIGHTSHOT is set to ON in a bright place. Set it to OFF. (p. 33) The backlight function is active. Set it off. (p. 32)		
The click of the shutter does not sound.	<ul> <li>BEEP is set to OFF in the menu settings.</li> <li>→ Set it to MELODY or NORMAL. (p. 107)</li> </ul>		
A horizontal black band appears when shooting a TV screen or computer screen.	Set STEADYSHOT to OFF in the menu setting. (P. 107)		
An external flash (optional) does not work.	<ul> <li>The power of the external flash (optional) is off or the power source does not installed.</li> <li>Turn on the external flash or install the power source.</li> <li>Two or more external flashes (optional) are attached.</li> <li>Only one external flash (optional) can be attached.</li> <li>AUTO is selected in FLASH MODE in the menu settings while recording in a bright place.</li> <li>Set it to ON. (p. 107)</li> </ul>		

	<ul> <li>AUTO is selected in FLASH MODE in the menu settings while recording in a bright place.</li> <li>→ Set it to ON. (p. 107)</li> </ul>
In the playback mode	
Symptom	Cause and/or Corrective Actions
The tape does not move when a video control button is pressed.	The POWER switch is not set to PLAYER or VCR (DCR-TRV330E only).     Set it to PLAYER or VCR (DCR-TRV330E only). (p. 39)
The playback button does not work.	The tape has run out.     Rewind the tape. (p. 39)
There are horizontal lines on the picture or the playback picture is not clear or does not appear.	The video head may be dirty.     Clean the heads using the Sony V8-25CLD cleaning cassette (optional). (p. 194)
No sound or only a low sound is heard when playing back a tape.	The stereo tape is played back with HiFi SOUND set to 2 in the menu settings.  Set it to STEREO. (p. 107) The volume is turned to minimum.  Press VOLUME +. (p. 39) AUDIO MIX is set to ST2 side in the menu settings.  Adjust AUDIO MIX. (p. 107)
The date search does not work correctly.	The tape has a blank portion in the recorded portion. (p. 78)
The picture which is recorded in the Digital8 (1) system is not played back.	<ul> <li>PB MODE is set to ►ii ☑ / ☑ in the menu settings.</li> <li>Set it to AUTO. (p. 107)</li> </ul>
The tape which is recorded in the Hi8 /standard 8 system is not played back correctly.	• Set PB MODE to FIE/B in the menu settings. (p. 107)

## Types of trouble and their solutions

Symptom	Cause and/or Corrective Actions
The power does not turn on.	The battery pack is not installed, or is dead or nearly dead Install a charged battery pack. (p. 15, 16) The AC power adaptor is not connected to a wall socket. Connect the AC power adaptor to a wall socket. (p. 21)
The end search function does not work.	The tape was ejected after recording.     You have not recorded on the new cassette yet.
The end search function does not work correctly.	The tape has a blank portion in the beginning or middle.
The battery pack is quickly discharged.	The operating temperature is too low. The battery pack is not fully charged. Charge the battery pack fully again. (p. 16) The battery pack is completely dead, and cannot be recharged. Replace with a new battery pack. (p. 15)
The battery remaining indicator does not indicate the correct time.	You have used the battery pack in an extremely hot or cold environment for a long time.     The battery pack is completely dead, and cannot be recharged.     Replace with a new battery pack. (p. 15)     The battery is dead.     Use a fully charged battery pack. (p. 15, 16)     A deviation has occurred in the remaining battery time.     Charge the battery fully. (p. 16)
The power goes off although the battery remaining indicator indicates that the battery pack has enough power to operate.	<ul> <li>A deviation has occurred in the remaining battery time.</li> <li>Charge the battery fully so that the battery remaining indicator indicates correct time. (p. 16)</li> </ul>
The cassette cannot be removed from the holder.	<ul> <li>The power source is disconnected.</li> <li>→ Connect it firmly. (p. 15, 21)</li> <li>The battery is dead.</li> <li>→ Use a charged battery pack. (p. 15, 16)</li> </ul>
The ■ and ▲ indicators flash and no functions except for cassette ejection work.	<ul> <li>Moisture condensation has occurred.</li> <li>→ Remove the cassette and leave your camcorder for at least 1 hour to acclimatize. (p. 193)</li> </ul>

(Continued on the following page)

Symptom

The "Memory Stick" does not function.

Recording does not function

The image cannot be deleted.

You cannot format the "Memory Stick"

Deleting all the images cannot be carried out. You cannot protect the image.

You cannot write a print mark on the still image

The photo save function does not

When operating using the "Memory Stick" - DCR-TRV325E/TRV330E/TRV430E/TRV530E only

Cause and/or Corrective Actions

LOCK

LOCK.

The POWER switch is not set to MEMORY.

Set it to MEMORY. (p. 129)
The "Memory Stick" is not inserted.

Insert a "Memory Stick", (p. 126)
The "Memory Stick" has already been recorded to its full canacity.

Delete unnecessary images and record again.

[p. 129, 165 lick" formatted incorrectly is inserted.
Format the "Memory Stick" on your camcorder or use another "Memory Stick." [p. 112]
The write-protect tab on the "Memory Stick" is set to LOCK.
Release the lock. (p. 124)
The write-protect tab on the "Memory Stick" is set to LOCK.

The write-protect tab on the "Memory Stick" is set to

Release the lock. (p. 124)
 The image is protected.
 Cancel image protection. (p. 161)
 The write-protect tab on the "Memory Stick" is set to

LOCK.

Release the lock. (p. 124)

The write-protect tab on the "Memory Stick" is set to LOCK.

Release the lock. (p. 124)

The write-protect tab on the "Memory Stick" is set to

LOCK.

Release the lock. (p. 124)

The image to protect is not played back.

Press MEMORY PLAY to play back the image. (p. 146)

The write-protect tab on the "Memory Stick" is set to LOCK.

Release the lock. (p. 124)

The image to write a print mark is not played back.

Press MEMORY PLAY to play back the image. (p. 146)

The "Memory Stick" has been recorded to its full capacity.

Delete unnecessary images and write a print mark again. (p. 163, 168)

The write-protect tab on the "Memory Stick" is set to

The write-protect tab on the "Memory Stick" is set to LOCK.

→ Release the lock. (p. 124)

capacity.

→ Delete unnecessary images and record again

Symptom	Cause and/or Corrective Actions
Digital program editing does not function.	The input selector on the VCR is not set correctly. Check the connection and set the input selector on the VCR again. (p. 87) The camcorder is connected to DV equipment of other than Sony. Set it to IR. (p. 88) Set it to IR. (p. 88) Set it programme on a blank portion of the tape is attempted. Set in programme again on a recorded portion. (p. 95) The camcorder and the VCR are not synchronized. Adjust the synchronizity. (p. 93)
The Remote Commander supplied with your camcorder does not work.	COMMANDER is set to OFF in the menu settings. Set it to ON. (p. 107) Something is blocking the infrared rays. Remove the obstacle. The batteries are inserted in the battery holder with the + polarities incorrectly matching the + - marks. Insert the batteries with the correct polarity. (p. 211) The batteries are dead. Insert new ones. (p. 211)
The picture from a TV or VCR does not appear even when your camcorder is connected to outputs on the TV or VCR.	DISPLAY is set to V-OUT/LCD in the menu settings.     → Set it to LCD. (p. 107)
The melody or beep sounds for 5 seconds.	Noisture condensation has occurred. Remove the cassette and leave your camcorder for at least 1 hour to acclimatize. (p. 193) Some troubles has occurred in your camcorder. Remove the cassette and insert it again, then operate your camcorder.
You cannot charge the battery pack.	<ul> <li>The POWER switch is not set to OFF (CHG).</li> <li>→ Set it to OFF (CHG).</li> </ul>
While charging the battery pack, the backlight of the display window does not light.	<ul> <li>Charging the battery pack is completed.</li> <li>The AC power adaptor is disconnected.</li> <li>→ Connect it firmly. (p. 21)</li> </ul>
While charging the battery pack, the remaining battery time indicator flashes.	The battery pack is not properly installed. Install it properly. Something is wrong with the battery pack. Contact your Sony dealer or local authorized Sony service facility.
No function works though the power s on.	<ul> <li>Disconnect the power cord of the AC power adaptor or remove the battery, then reconnect it in about one minute. Turn the power on. If the functions still do not work, oper the LCD panel and press the RESET button under DISPLAY button using a sharp-pointed object. (If you press the RESET button, all the settings including the date and time return to the default.) (p. 205)</li> </ul>

172 173

## English

## Self-diagnosis display

Your camcorder has a self-diagnosis display

Your camcorder has a self-diagnosis display function.
This function displays the current condition of your camcorder as a 5-digit code (a combination of a letter and figures) on the screen or in the display window.
If a 5-digit code is displayed, check the following code chart. The last two digits (indicated by \( \subseteq \subseteq \)) will differ depending on the state of your camcorder.

LCD screen, viewfinder or display window



Self-diagnosis display

C:□□:□□

You can service your camcorder yourself.

•E:00:00

Contact your Sony dealer or local authorized Sony facility.

Five-digit display	Cause and/or Corrective Actions	
C:04:□□	<ul> <li>You are using a battery pack that is not an "InfoLITHIUM" battery pack.</li> <li>→ Use an "InfoLITHIUM" battery pack. (p. 188)</li> </ul>	
C:21:□□	<ul> <li>Moisture condensation has occurred.</li> <li>→ Remove the cassette and leave your camcorder for at least 1 hour to acclimatize. (p. 193)</li> </ul>	
C:22:□□	<ul> <li>The video heads are dirty.</li> <li>→ Clean the heads using the Sony V8-25CLD cleaning cassette (optional). (p. 194)</li> </ul>	
C:31:□□ C:32:□□	<ul> <li>A malfunction other than the above that you can service has occurred.</li> <li>Remove the cassette and insert it again, then operate your camcorder.</li> <li>Disconnect the power cord of the AC power adaptor or remove the battery pack. After reconnecting the power source, operate your camcorder.</li> </ul>	
E:61:□□ E:62:□□	<ul> <li>A malfunction that you cannot service has occurred.</li> <li>→ Contact your Sony dealer or local authorized Sony service facility and inform them of the 5-digit code. (example: £61:10)</li> </ul>	

If you are unable to rectify the problem even if you try corrective actions a few times, contact your Sony dealer or local authorized Sony service facility.

## English

## Warning indicators and messages

If indicators and messages appear on the screen or in the display window, check the following. See the page in parentheses "(  $\,$  )" for more information.

## Warning indicators



100-0001 Warning indicator as to file Slow flashing:

The file is corrupted.

The file is unreadable

- C:21:00 Self-diagnosis display (p. 174)
- The battery is dead or nearly dead
   Slow flashing:

   The battery is nearly dead.

   The battery is nearly dead.

   The Sundictor sometimes blinks even if the remaining battery time is about five to ten minutes depending on the operating conditions, environment and battery conditions.

condition.

- Fast flashing:
   The battery is dead.
- Moisture condensation has occurred\*
- Moisture concension....
   State of the cassette, turn off your camcorder, and leave it for about 1 hour with the cassette compartment open (p. 193).
- Warning indicator as to "Memory Stick"\* (DCR-TRV325E/TRV330E/TRV430E/ TRV530E only)
  Slow flashing:
  • No "Memory Stick" is inserted.
- Fast flashing:
   The "Memory Stick" is not readable with your camcorder (p. 124).
- ③ Warning indicator as to "Memory Stick" formatting (DCR-TRV325E/TRV330E/ TRV430E/TRV30E only)
  Fast flashing:
   "Memory Stick" is not formatted correctly (p. 112).
   The "Memory Stick" data is corrupted.\*

- Real Warning indicator as to tape
  Slow flashing:
   The tape is near the end.
   No tape is inserted.\*
   The write-protect tab on the cassette is out (red) (p. 25).\*
  Fast flashing:
- Fast flashing:
   The tape has run out.\*
- ◆ You need to eject the cassette\*
  Slow flashing:
   •The write-protect tab on the cassette is out (red) (p. 25).
  Fast flashing:
   •Moisture condensation has occurred.

- (p. 193).
   The tape has run out.
   The self-diagnosis display function is activated (p. 174).
- → The still image is protected \* (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)
- Flow flashing:

   The still image is protected (p. 161).
- Warning indicator as to the flash (optional)
   Fast flashing:
   There is something wrong with the external flash (optional).
- You hear the melody or beep sound.

174 175

1-40

oting

- Additional Information -

Usable cassette tapes We recommend using Hi8 Hi⊠/Digital8 → video

We recommend using Hi8 HiB/Digital8 19 video cassette. \*
The recording time when you use your Digital8 Psystem camcorder on Hi8 HiB/Standard 8 Bi tape is 2/3 the recording time when using the conventional Hi8 HiB/Standard 8 Bi system camcorder. (90 minutes of recording time becomes 60 minutes in the SP mode.) \*
If you use standard 8 Bi tape, be sure to play back the tape on this camcorder. Mosaic pattern noise may apnear when you play back standard

noise may appear when you play back standard 8 **B** tape on other VCRs (including other DCR-TRV230E/TRV235E/TRV330E/TRV430E/TRV530E).

Tapes recorded in the Digital8 19 system cannot be played back on His Hi @/standard 8 (analog) system machine.

a trademark Hi 🖪 is a trademark → is a trademark.

### Playback system

system is automatically detected before the tape is played back.

During playback The Digital8 1) system or Hi8 11 13/standard 8 13

is prayed back.
During playback of tapes recorded in the Hi8
HiB/standard 8 B system, digital signals are
output as the image signals from the DV OUT or
DV IN/OUT jack.

Display during automatic detection of system The Digitals D system or His HiB/standard 8 B system is automatically detected, and the playback system is automatically switched to. During switching of systems, the screen turns blue, and the following displays appear on the screen. A hissing noise also sometimes can be heard. Display during automatic detection of system

Дополнительная информация -

## Цифровая система Digital8 €), запись и воспроизведение

Что такое "Цифровая система Digital8 [→"? обеспечения цифровой записи на видеокассеты Hi8 HIB/Digital8 [).

## Используемые кассеты

используемые кассеты
Рекомендуется использовать видеокассеты
НіВ НіВОідіана 13-т
Время записи при использовании Вашей
видеокамеры системы Digitala 13-т
НіВОстандартной ленте 8 В составляет 2/з
времни записи при использовании обычной
видеокамеры НіВ НіВ/видеокамеры
стандартной системы 8 В. (90 минут времени
записи становтого равными 60 минутам в
режиме SP).

режиме SP).
При мопользовании стандартной ленты 8 В, ее спедует воспроизводить на этой же видеожмере. Пли воспроизведении стандартной ленты 8 В на других КВМ (вихлочая другие аппарать DCR-TRV230E/ TRV235E/TRV325E/TRV330E/TRV430E/ TRV530E) могут появится помехи типа

Примечание
Ленты, записанные в цифровой системе
Digitals 19, не могут быть воспроизведены наппаратуре системы НВ НЕВ/стандартной системы 8 (3) (аналоговой).

В является фирменным знаком.
Нів является фирменным знаком.
В является фирменным знаком.

## Система воспроизведения

Цифровая система Digital8 → или Ні8 Ні В/ стандартная система 8 В автоматически стандартная система в ві автоматически детектируется перед воспроизведеним ленты. Во время воспроизведения лент, записанных в системе НІВ НІВ/стандартной системе в Ві цифровые сигналы выводятся в качестве сигналов изображения через гнездо DV OUT или DV IN/OUT.

# Индикация во время автоматического детектирования системы Цифровая система Digitals [ ) или Нів Ні [ ]/ стандартная система 8 [ ] автоматически

детектируется, а система воспроизведения автоматически включается. Во время выключения систем, экран становится голубым и появляются следующие индикации на экране. Может быть также слышен свистящий шум

Может быть также опышел соложения с состемы Digital8 € на системы Bigital8 € на систему Hi8 Hi8/GT андартную систему 8 В Нi8/GT андартную систему 8 В оистемы Hi8 Hi8/GT андартной системы 8 В на шуфровую систему Digital 8 €

185

176

## Digital8 ( ) system, recording and playback

Warning indicators and messages

Set the date and time. (p. 22)

in the LP mode.\* (p. 113)

The tape has run out.\*

Insert a cassette tape.

The video heads are dirty. (p. 194)

Use an "InfoLITHIUM" battery pack. (p. 188)

Use Hi8 | | Digital8 | tapes when you record

You tried to record a picture that has a copyright control signal.\* (p. 186)

mory Stick" is full.\* (p. 131)

LOCK.\* (p. 124) (DCR-TRV325E/TRV330E/ TRV430E/TRV530E only) No still image is recorded on the "Memory Stick".\* (p. 147) (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

No "Memory Stick" is inserted.\* (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

The "Memory Stick" data is corrupted.\* (p. 126) (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

Check the type of formatting.\* (p. 112) (DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

(DCR-TRV325E/TRV330E/TRV430E/TRV530E only)

The "Memory Stick" has more than one directory

such as 100msdcf.\* (p. 147)

\* You hear the melody or beep sound.
\*\* The ② indicator and "the CLEANING CASSETTE" message appear one after another on the screen.

(DCR-TRV325E/TRV330E/TRV430E/TRV530E only) The write-protect tab on the "Memory Stick" is set to

Warning messages

• FOR "InfoLITHIUM

Hi8 TAPE → LP/SP REC

• 📥 CLEANING CASSETTE\*\*

BATTERY ONLY • 8mm TAPE → SP REC

• 🖄 ≜ TAPE END

• ⊵⊚ NO TAPE

• COPY INHIBIT

• 🖾 FULL

• ₺ NO FILE

• ☼ NO MEMORY STICK

• 35 FORMAT ERROR

• 

■ MEMORY STICK ERROR

• ☼ ⊶ DIRECTORY ERROR

· 🖾 ⊶

• CLOCK SET

## When you play back

Playing back an NTSC-recorded tape You can play back tapes recorded in the NTSC video system on the LCD screen, if the tape is recorded in the SP mode.

## Copyright signal

## When you play back

Using any other video camera recorder, you cannnot record on a tape that has recorded copyright control signals for copyright protection of software which is played back on your camcorder.

## When you record (DCR-TRV330E only)

You cannot record to the record to the record to the record software on your camcorde that contains copyright control signals for copyright protection of software.

COPY INHIBIT appears on the LCD screen, in the viewfinder or on the TV screen if you try to the viewfinder or on the TV screen if you try to record such software. Your camcorder does not record copyright control signals on the tape when it records.

## When you playback a dual sound track tape

When you use tapes recorded in the Digital8 †) system When you play back a Digital8 †) system tape which is dubbed from a dual sound track tape recorded in the DV system, set HIFI SOUND to the desired mode in the menu settings (p. 107).

## Sound from speaker

HiFi Sound Mode		Playing back a dual sound track tape
STEREO	Stereo	Main sound and sub sound
1	Lch	Main sound
2	Rch	Sub sound

### Цифровая система Digital8 1. запись и воспроизведени

### При воспроизведении Воспроизведение лент, записанных в системе NTSC

системе N I SC
Вы можете воспроизводить ленты,
записанные в видеосистеме NTSC, на экране
ЖКД, если лента записана в режиме SP.

## Сигнал авторского права

При воспроизведении
При использовании какой-либо другой видеокамеры Вы не можете выполнят запись на ленту, на которой записаны контрольные сигналы авторского права для защиты авторских прав программ, которые воспроизводятся на Вашей видеокамере.

## При записи (Только модели DCR-TRV330E)

Вы не можете записывать на Вашей видеокамере программы, содержащие контрольные сигналы авторского права для защиты авторских прав программ. Если Вы попытаетесь записать такую программу, на экране ЖКД, в видоискателе или на экране телевизора появится индикация СОРУ INHIBIT. При записи Ваша видеокамера не будет записывать контрольные сигналы авторского права

## двойной звуковой дорожкой

### При использовании лент, за в цифровой системе Digital8 [ )

При воспроизведении ленты в цифровой системе Digital8 1), на которую выполнена перезапись ленты с двойной звуковой дорожкой, записанной в цифровой росистеме DV, установите команду "HiFi ND" в нужный режим в установках меню (стр. 107)

Режим звучания НіГі	Воспроизведение стереофонической ленты	Воспроизведение ленты с двойной звуковой дорожкой		
STEREO	Стереофонический звук	Основной звук и вспомогательный звук		
1	Левый канал	Основной звук		
2	Правый канал	Вспомогательный звук		

## Digital8 ( ) system, recording and playback

When you use a tape recorded in the Hi8/standard 8 system When you play back a dual sound track tape recorded in an AFM HilFi stereo system, set HiFi SOUND to the desired mode in the menu settings

## Sound from speaker

HiFi Sound Mode	Playing back a stereo tape	Playing back a dual sound track tape
STEREO	Stereo	Main sound and sub sound
1	Monaural	Main sound
2	Unnatural Sound	Sub sound

You cannot record dual sound programmes on your camcorder.

## Цифровая система Digital8 →, запись и воспроизведение

При использовании лент, записанных в системе Нів/стандартной системе 8 При воспроизведении ленты с двойной звуковой дорожкой, записанной в стереофонической системе АFM НІГі, установите команду "НІГІ SOUND" в нужный режим в установите команду "НІГ SOUND" в нужный режим в установите ком

звук от динамика				
	жим учания =i	Воспроизведение стереофонической ленты	Воспроизведение ленты с двойной звуковой дорожкой	
S	TEREO	Стереофонический звук	Основной звук и вспомогательный звук	
	1	Монофонический звук Основной звук		
	2	Необычный звук	Вспомогательный звук	

Вы не можете записывать программы с

power adaptor.

The "InfoLITHIUM" battery pack calculates the power consumption according to the operating conditions of your camcorder, and displays the remaining battery time in minutes.

## Charging the battery pack

- re to charge the battery pack before you
- start using your camcorder.

   We recommend charging the battery pack in an ambient temperature of between 10 °C to 30 °C (50 °F to 86 °F) until the backlight of the display (50 °F to 86 °F) until the backlight of the display window goes out, indicating that the battery pack is fully charged. If you charge the battery pack outside of this temperature range, you may not be able to effiently charge the battery pack.

  • After charging is completed, either disconnect the cable from the DC IN jack on your camcorder or remove the battery pack.

## Effective use of the battery pack

- Battery performance decreases in low-temperature surroundings. So, the time that the battery pack can be used is shorter in cold places. We recommend the following to use the battery pack longer:

  —Put the battery pack in a pocket close to your
- body to warm it up, and insert it in your camcorder immediately before you start taking shots.
- taking shots.

   Use the large capacity battery pack (NP-FM70/FM90/FM91, optional).

   Frequently using the LCD panel or frequently operating playback, fast forward or rewind wears out the battery pack faster. We recommend using the large capacity battery pack (NP-FM70/FM90/FM91, optional).
- Be certain to turn the POWER switch to OFF (CHG) when not taking shots or playing back on your camcorder. The battery pack is also consumed when your camcorder is in the standby mode or playback is paused.
- Have spare battery packs handy for two or three times the expected recording time, and make a trial recording before the actual
- nake a trial recording before the actual recording.

  Do not expose the battery pack to water. The battery pack is not water resistant.

## 188

## О батарейном блоке "InfoLITHIUM"

## Что такое батарейный блок "InfoLITHIUM"?

"InfoLTHIUM"?
"InfoLTHIUM"?
"InfoLTHIUM" работь который оснащен функцией обмена данными, связанными с условимир ваботы, между Вашей видеокамерой условимир ваботы, между Вашей видеокамерой вамосимент от условимир вамосимент от условий работы Вашей видеокамеры и отображает сотавшеем время работы башей видеокамеры и отображает оставшеем время работы батарейного блока в минутах.

## Зарядка батарейного блока • Перед началом использования в

- пред пачалим использования видесканери удостоверьтесь, что батарейный блок заряж Рекомендуется заряжать батарейный блои при температуре окружающей среды от 10 до 30°C (от 50°F до 86°F) до тех пор, пока до 30°C (от 50°F до 88°F) до тех пор, пока задняя подсерятка экрана не погаснет, указывая на то, что батарейный блок заряжен полностью. Если Вы зарядите батарейный блок при температуре, не попадающей в указанный выше дияпазон, Вы не сможете эффективно зарядить батарейный блок. После завершения зарядки либо отсоедините кабель от тензад то CIN Вашей видеокамеры, либо снимите батарейный блок.

## Эффективное использование батарейного блока

- атарейного блока
  Производительность батареи снижается в условиях низких температур. Поэтому в холодных местах время, в течение которого можно пользоваться батарейным блоком, меньше. Для продолжительного использования рекомендуется следующее: —Помещайте батарейный блок во внутренни карман, чтобы нагреть его, и устанавливайте его на видеокамеру непосредственно перед съемкой. —Используйте батарейный блок большой емкости (NP-FMT0/FM90/FM91, приобретается отлельно.

- Неподредь веста поредь у стиго дова обращей в праводите сатория обращей в праводите в поред обращей в поред о

## About the "InfoLITHIUM" battery

- Remaining battery time indicator

  If the power may go off although the remaining
  battery time indicator indicates that the battery
  pack has enough power to operate, charge the
  battery pack fully again so that the indication
  on the remaining battery time indicator is
  correct. Note, however, that the correct battery
  indication sometimes will not be restored if it is
  used in high temperatures for a long time or left
  in a fully charged state, or the battery pack is
  frequently used. Regard the remaining battery
  time indication as the approximate shooting
  time.
- time.

  The □ mark indicating there is little remainir battery time sometimes flashes depending on the operating conditions or ambient temperature and environment even if the remaining battery time is about five to ten

### How to store the battery pack

- Even if the battery pack is not used for a lot time, store it in a dry, cool place after fully
- time, store it in a dry, cool place after fully charging it once per year and then using the battery pack up on your camcorder. This is to maintain the battery pack s functions.

  To use the battery pack up on your camcorder leave your camcorder, leave your camcorder in the shooting mode until the power goes off without a cassette inserted.

## Battery life

- Battery life

  The battery life is limited. Battery capacity
  drops little by little as you use it more and
  more, and as time passes. When the available
  battery time is shortened considerably, a
  probable cause is that the battery pack has
  reached the end of its life. Please buy a new
  battery pack.

  The battery life varies according to how it is
  stored and operating conditions and
  environment for each battery pack.

### О батарейном блоке "InfoLITHIUM"

- Индикатор времени оставшегося заряда батарейного блока Если питание может выключиться нес на то, что индикатор времени оставше заряда батарейного блока. Указывает на то, что батарейный блок достаточно заряжен для функцион достаточно зарижен дли фулкционировали видеокамеры, снова зарядите батарейный блок полностью, так чтобы индикация времени оставшегося заряда батарейного
- времени оставшегося заряда оатареиног блока была правильной. Заметьте, тем не менее, что точная индикация времени заряда батарейного блока иногда не будет восстанавливать если он длительное время использовалс при высоких температурах или был оставлен в полностью заряженном состоянии, или при частом использовании батарейного блока. Считайте индикацию
- оставшегося времени заряда батарейного блока приблизительным временем съемки Иногда метка 🖾, указывающая на то, что времени заряда батарейного блока осталось мало, мигает в зависимости от условий окружающей температуры и среды, даже если заряда осталось на 5-10 минут.

### Как хранить батарейный блок

- Даже если батарейный блок не используется длительное время, храните его в сухом, прохладном месте, полностьк заряжая его один раз в год, а затем используя батарейный блок на вашей видеокамере. Это необходимо для поддержания функционирования батарейного блока.
- батареиного олока. Для того, чтобы полностью разрядить батарейный блок на Вашей видеокамере, оставьте Вашу видеокамеру в режиме съемки без вставленной кассеты, пока не выключится питание без вставле

Срок службы батарейного блока
• Срок службы батарейного блока огранич
Емкость батарейного блока мало-помалу падает, по мере того, как Вы с течение времени используете его все больше и времени используете его все больше и больше. Когда доступное время заряда батарейного блока значительно сократится, возможной причиной является то, что срок службы батарейного блока закончился. Приобретайте, пожалуйста новый сатарейный блок.

- Срок службы батарейного блока различается в соответствии с тем, как он хранился, а также в зависимости от условий использовании и окружающей среды для каждого батарейного блока.

## About i.LINK

The DV jack on this unit is an i.LINK-compliant DV input/output jack. This section describes th DV input/output jack. This secti i.LINK standard and its features.

## What is "i.LINK"?

i.LINK is a digital serial interface for handling digital video, digital audio and other data in t directions between equipment having the i.LINK jack, and for controlling other equipment. jack, and for controlling other equipment.
LILINK-compatible equipment can be connected
by a single i.LINK cable. Possible applications are
operations and data transactions with various
digital AV equipment.
When two or more i.LINK-compatible equipment

are connected to this unit in a daisy chain, operations and data transactions are possible with not only the equipment that this unit is connected to but also with other devices via the

connected to but also with other devices via the directly connected equipment. Note, however, that the method of operation sometimes varies according to the characteristics and specifications of the equipment to be connected, and that operations and data transactions are sometimes not possible on some connected equipment.

Normally, only one piece of equipment can be connected to this unit by the i.LINK cable (DV cable). When connecting this unit to i.LINK-compatible equipment having two or more i.LINK jacks (DV jacks), refer to the instruction manual of the equipment to be connected

## About the Name "i.LINK

i.LINK is a more familiar term for IEEE 1394 data transport bus proposed by SONY, and is a trademark approved by many corporations. IEEE 1394 is an international standard standardized by the Institute of Electrical and Electronic Engineers.

## Относительно i.LINK

довлетворнет стандарту I.LINK и нвляется овместимым с входнымбыходным гнездом ифровых видеосигналов DV. В этом разде-писан стандарт I.LINK и его основные собенности. Цифровое гнездо DV на данном аппарате

## Что такое "i.LINK"?

i.LINK является цифровым последовательным интерфейсом для управления цифровыми видеосигналами, цифровыми аудиосигналами и другими данными в двух направлениях м аппаратами, имеющими гнезда i.LINK, а также для управления другими аппаратами i.LINK-совместимый аппарат можно подсоединить с помощью одного кабеля i.LINK. Возможные применения этой функции охватывают операции и передачи данных с разными цифровыми аудиовидеоаппаратами Если к данному аппарату подсоединены два или более i.LINK-совместимых аппарата в или более I.LINK-совместимых аппарата в последовательной цени, то возможны операции и передачи данных не только с подсоединенным аппаратом, но и с други аппаратами через непосредственно подсоединенный аппарат.

подсоединенный аппарат.
Однако имейте в виду, что метод управл иногда отличается в зависимости от характеристики и технических данных подсоединемого аппарата с двумя или более гнездами i.LINK (гнезда DV), и что операции и передачи данных иногда невозможны на некоторых подсоединям аппаратах.

Примечание
Обычно, только один аппарат можно
подсоединить к данному аппарату с помощью
кабеля і.І.ПК (цифрового кабеля DV). При
подсоединении данного аппарата к двум или
более і.І.ПКК-совместимым аппаратам изучите
руководство по эксплуатации
соответствующего подсоединяемого аппарата

## Относительно названия "i.LINK"

i.LINK является более привычным термином для шины передачи данных IEEE 1394, предложенной фирмой SONY, и он является фирменным знаком, утвержденным многими

корпорациями. IEEE 1394 является международным стандартом, утвержденным Институтом инженеров по электротехнике и электронике

## About i LINK

i.LINK's maximum baud rate varies according to the equipment. Three maximum baud rates andefined:

S100 (approx. 100Mbps\*) S200 (approx. 200Mbps) S400 (approx. 400Mbps)

i.LINK Baud rate

The baud rate is listed under "Specifications" in the instruction manual of each equipment. It is also indicated near the i.LINK jack on some

also indicated near the i.LINK jack on some equipment. The maximum baud rate of equipment on which it is not indicated such as this unit is "\$100". When units are unit is connected to equipment having a different maximum baud rate, the baud rate sometimes differs from the indicated baud

\*What is \*Mbps\*?

Mbps stands for megabits per second, or the amount of data that can be sent or received in one second. For example, a baud rate of 100Mbps means that 100 megabits of data can be sent in

## i.LINK Functions on this unit

For details on how to dub when this unit is connected to other video equipment having DV

connected to other video equipment having DV jacks, see page 84. This unit can also be connected to other i.LINK (DV) compatible equipment made by SONY (e.g. VAIO series personal computer) other than video

equipment. Before connecting this unit to a personal computer, make sure that application software supported by this unit is already installed on the

personal computer.
For details on precautions when connecting this unit, also refer to the instruction manuals for the equipment to be connected.

## Required i.LINK Cable

Use the Sony i.LINK 4-pin-to-4-pin cable (during DV dubbing

i.LINK and i are trademarks

## Относительно i.LINK

Скорость передачи i.LINK Максимальная скорость передачи i.LINK изменяется в зависимости от аппарата. Имеются три максимальные скорости передачи

. \$100 (приблиз. 100 Мбит/с\*) \$200 (приблиз. 200 Мбит/с) \$400 (приблиз. 400 Мбит/с)

Скорость передачи указывается в разделе "Технические характеристики" в руководств по эксплуатации каждого аппарата 14 некоторых аппаратах она может быть также указана возле гнезда I.IINK. Максимальная скорость передачи аппарата, на котором она не указана, например, для данного аппарата, равна "\$100" В случае если аппаратать, подоселиненотся к В случае, если аппараты подсоединяются к оборудованию с другой максимальной скоростью передачи, то скорость передачи иногда может отличаться от указанной

«Что такое "Мбит/с"?
Мбит/с означает количество мегабит за секунду или количество данных, которое можно посыпать или принимать за одну секунду. Например, скорость передачи 100 Мбит/с означает, что 100 мегабит данных может быть послано за одну секунду.

## Функции i.LINK на данном аппарате

Подробные сведения о том, как выполнять перваапись, когда данный аппарат подсоединен к другому видеооборудованию с гнездами DV, см. на стр. 84. Данный аппарат может бъть также подсоединен к другому, i.LINK (DV)-совместимсму оборудованию фирмы SONY (нагример, персональному компьютеру серии VAIO), не относящемуся к видеоаппаратуре. Перед подсоединением данного аппарата к персональному компьютеру убедитесь, что компьютеру уже установлено программное приложение, поддерживаемое данным аппаратом.

аппаратом. Подробные сведения относительно мер предосторожности при подсоединении данного аппарата приведены также в руководстве по эксплуатации для каждого подсоединяемого аппарата.

## Требуемый кабель i.LINK

Используйте 4-штырьковый-к- 4-штырьковому кабель i.LINK фирмы Sony (во время цифровой видеоперезаписи)

i.LINК и i являются фирменными знаками.

## Moisture condensation

If your camcorder is brought directly from a cold place to a warm place, moisture may condense inside your camcorder, on the surface of the tape, or on the lens. In this condition, the tape may stick to the head drum and be damaged or your camcorder may not operate correctly. If there is moisture inside your camcorder, the beep sounds and the 10 indicator flashes. When the ≜ indicator flashes with same time, the second in the conditions of the same time, the second is the condition of the same time, the second is the same time, the same time, the same time is the same time the same time is the same time. indicator flashes at the same time, the cassette is inserted in your camcorder. If moisture condenses on the lens, the indicator will not

### If moisture condensation occurred

None of the functions except cassette ejection will work. Eject the cassette, turn off your camcorder, and leave it for about 1 hour with the cassette compartment open. Your camcorder can be used again if the B indicator does not appear when the power is turned on again.

Note on moisture condensation
Moisture may condense when you bring your
camcorder from a cold place into a warm place
(or vice versa) or when you use your camcorder
in a hot place as follows:

- You bring your camcorder from a ski slope into
a place warmed up by a heating device.
- You bring your camcorder from an airconditioned car or room into a hot place
outside

- You use your camcorder after a squall or a
- You use your camcorder in a high temperature and humidity place.

How to prevent moisture condensation When you bring your composed from When you bring your camcorder from a cold place into a warm place, put your camcorder in a plastic bag and tightly seal it. Remove the bag when the air temperature inside the plastic bag has reached the surrounding temperature (after about 1 hour).

## Maintenance information and precautions

### Конденсация влаги

Если видеокамера принесена прямо из холодного места в теплое, то внутри видеокамеры, на поверхности ленты или на объективе может произойти конденсанция влаги. В таком состоянии лента может прилипнуть к барабану головки и будет повреждена или же видеокамера не сможет работать надлежащим образом. Если внутри видеокамеры произошла конденсация влаги то прозвучит зуммерный сигнал, а на экране будет мигать индикатор ■. Если в то же самое время будет мигать индикатор ≜, это значит, что в видеокамеру вставлена кассета. Если влага сконденсировалась на объективе, индикатор появляться не будет

Информация по уходу

за аппаратом и меры

предосторожности

## Если произошла конденсация влаги

Ни одна из функций, кроме выталкивания кассеты, не будет работать. Извлеките кассету, выключите видеокамеру и оставые е приблизительно на 1 час с открытым кассетным отсеком. Если при повторном включении питания индикатор 

на рисплее, Вы можете снова пользоваться

### Примечание по конденсации влаги

Влага может образоваться, если Вы принесете Вашу видеокамеру из холодного места в теплое (или наоборот) или когда Вы используете Вашу видеокамеру в жарком месте в следующих случаях: - Вы принесли Вашу видеокамеру с лыжного

- склона в помещение, где функционирует обогреватель. - Вы принесли Вашу видеокамеру из
- автомобиля или из комнаты с воздушным кондиционированием в жаркое место на
- Вы используете видеокамеру после грозы или дождя
- Вы используете Вашу видеокамеру в очень жарком и влажном месте.

Как предотвратить комденсацию влаги Если видеокамера принесена из холодного места в теплое, то положите видеокамеру в полизтиленовый пакет и плотно заклейте ев Выньте видеокамеру из полизтиленового пакета, когда температура воздуха внутри пакета достигнет температуры окружающег воздуха (приблизительно через 1 час).

192

# precautions

## Maintenance information

Maintenance information and

Using your camcorder

Using your camcorder abroad

You can use your camcorder in any country or area with the AC power adaptor supplied with your camcorder within 100 V to 240 V AC, 50/60 Hz.

camcorder. If you want to view the playback picture on a TV, it must be a PAL system based TV with VIDEO/AUDIO input jack.
The following shows TV colour systems used

PAL system Australia, Austria, Belgium, China, Czech Republic, Denmark, Finland, Germany, Great Firiain, Holland, Hong Kong, Italy, Kuwait, Malaysia, New Zealand, Norway, Portugal, Singapore, Slovak Republic, Spain, Sweden, Switzerland, Thailand, etc.

NTSC system Bahama Islands, Bolivia, Canada, Central America, Chile, Colombia, Ecuador, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the U.S.A., Venezuela, etc.

Bulgaria, France, Guyana, Hungary, Iran, Iraq, Monaco, Poland, Russia, Ukraine, etc.

Simple setting of clock by time

You can easily set the clock to the local time by setting a time difference. Select WORLD TIME in the menu settings. See page 107 for more

Your camcorder is a PAL system based

abroad

overseas.

PAL system

PAL-M system

SECAM system

PAL-N system Argentina, Paraguay, Uruguay

Использование Вашей

видеокамеры за границей

в любой стране или области с помощью сетевого адаптера переменного тока

видеокамеры за границей

Вы можете использовать Вашу видеокамеру

прилагаемого к Вашей видеокамере, которы можно использовать в пределах от 100 В до

240 В переменного тока с частотой 50/60 Гц

Ваша видеокамера основана на системе PAL Если Вы хотите просмотреть воспроизводимое изображение на телевизоре, то это должен быть телевизор, основанный на системе PAL, с входными гнездами VIDEO/AUDIO.

Ниже приведены системы цветного телевидения, используемые за рубежом

Норвегия, Португалия, Сингапур, Словацкая Республика, Таиланд, Финляндия, Чешская

Республика, Швейцария, Швеция и т.д.

Система NTSC
Багамские острова, Боливия, Венесуэла,
Канада, Колумбия, Корея, Мексика, Перу,
Суринам, США, Тайвань, Филиппины,
Центральная Америка, Чили, Эквадор,
Ямайка, Япония и т.д.

Болгария, Венгрия, Гвиана, Ирак, Иран, Монако, Польша, Россия, Украина, Франция и

Вы можете легко установить часы на местное время путем установки разницы во времени. Выберите команду WORLD TIME в установках меню. Подробные сведения приведены на стр. 107.

Информация по уходу за аппаратом

Для обеспечения нормальной записи и четкого изображения следует периодически чистить видеоголовки.

системе Digital8 [\*)
Видеоголовки возможно загрязнены, если
- На воспроизводимом изображении
появляются помехи типа мозаики.
- Воспроизводимое изображение не

толовок весь экран станет

и меры предосторожности

Информация по уходу

Чистка видеоголовок

стеме Digital8 [+)

Австралия, Австрия, Бельгия Великобритания, Германия, Голландия, Гонконг, Дания, Испания, Италия, Китай, Кувейт, Малайзия, Новая Зеландия,

Аргентина, Парагвай, Уругвай

Система PAL

Система PAL-M

Система PAL-N

Cucrema NTSC

Система SECAM

времени на часах

## Cleaning the video head

To ensure normal recording and clear pictures, clean the video heads.

## When you playback/record in the Digital8 []

- system
  The video head may be dirty when:
   mosaic-pattern noise appears on the playback

- mosaic-pattern noise appears on the playbac picture.
   playback pictures do not move.
   playback pictures do not appear.
   the & indicator and "ac CLEANING CASSETTE" message appear one after anoth during recording. If the video head gets dirtier, the entire screen becomes blue.

When you play back in the Hi8/Standard 8 (analog) system
The video head may be dirty when:
- playback pictures contain noise.
- playback pictures are hardly visible.
- playback pictures do not appear.







При загрязне



# При воспроизведении в системе Ні8

- стандартной системе 8 (аналоговой)
  Видеоголовки возможно загрязнены, если:
   Воспроизводимое изображение содержит
- помехи.
   Воспроизводимое изображение с трудом различимо.
   Воспроизводимое изображение не появляется на экране.





If the above problem occurs, clean the video heads with the Sony V8-25CLD cleaning cassette (optional). Check the picture and if the above problem persists, repeat cleaning.

## Cleaning the LCD screen

If fingerprints or dust make the LCD screen dirty, we recommend using a LCD Cleaning Kit (optional) to clean the LCD screen.

В случае возникновения указанных выше очистите видеоголовки с помог очистительной кассеты Sony V8-25CLD (приобретается отдельно). Проверьте изображение и, если описанные выше проблемы не устранились, повторите чистку,

Чистка экрана ЖКД Если на экране ЖКД появятся отпечатки папыве или пыль, рекомендуется воспользоваться очистительным набором для ЖКД (приобретается отдельно) для чистки ЖКД.

### Maintenance information and precautions

## Charging the built-in rechargeable battery

Your camcorder is supplied with a built-in rechargeable battery so as to retain the date and time, etc., regardless of the setting of the POWER switch. The built-in rechargeable battery is always charged as long as you are using your camcorder. The battery, however, will get discharged gradually if you do not use your camcorder. It will be completely discharged in about half a year if you do not use your camcorder at all. Even if the built-in rechargeable battery is not charged, it will not affect the camcorder operation. To retain the date and time, etc., charge the battery if the battery is discharged. discharged.

## Charging the built-in rechargeable battery: Connect your camcorder to a wall socket using the AC power adaptor supplied with your camcorder, and leave your camcorder with the POWER switch turned off for more than 24

hours.
Or install the fully charged battery pack in your camcorder, and leave your camcorder with the POWER switch turned off for more than 24

## Precautions

## Camcorder operation

- Operate your camcorder on 7.2 V (battery pack) or 8.4 V (AC power adaptor).
- or 8.4 V (AC power adaptor).

  For DC or AC operation, use the accessories recommended in this operating instructions.

  If any solid object or liquid get inside the casing, unplug your camcorder and have it checked by a Sony dealer before operating it
- any further any turther.

  • Avoid rough handling or mechanical shock. Be particularly careful of the lens.

  • Keep the POWER switch set to OFF (CHG)

- when you are not using your camcorder.

   Do not wrap your camcorder with a towel, for example, and operate it. Doing so might cause heat to build up inside.

### Информация по уходу за аппаратом и меры предосторожности

## Зарядка встроенной аккумуляторной батарейки

аккумуляторной батарейки

Ваша видеокамера оснащена встроенной аккумуляторной батарейкой для того, чтобы поддерживать дату, время и т.д., вне зависимости от установки переключателя РОWER. Встроенная аккумуляторная батарейка всегда заряжается, когда Вы используете Вашу видеокамеру. Однако, батарейка постепенно разрядится, если Выне будете использовать Вашу видеокамеру. Осна будет полностью разряжена примерно через полгода, если Вы вообще не будете пользоваться Вашей видеокамерой. Даже если встроенная аккумуляторная батарейка не заряжена, она не повтимет на рабокамеры. Чтобы поддерживать дату и время, зарядите батарейку, если она разрядилась.

Зарядка встроенной аккумуляторной

## Зарядка встроенной аккумуляторной батарейки:

- зарядка всі рісенной аккумулін іорной батарейки:

   Подсоедините Вашу видеокамеру к стенной розетке, используя адаптер питания переменного тока, прилагаемый к Вашей видеокамере, и оставьте Вашу видеокамеру с выключенным переключателем РОЖЕВ более чем на 24 часа.

   Или прикрепите полностью заряженный батарейный блок к Вашей видеокамере и оставьте Вашу видеокамеру с выключенным переключателем РОЖЕВ более чем на 24 часа.

## Меры предосторожности

# Эксплуатация видеокамеры • Эксплуатируйте видеокамеру от 7,2 В (батарейный блок) или 8,4 В (сетевой адаптер переменного тока)

- адаптер переменного тока)

  «Что каасется эксплуатации видеокамеры от постоянного и переменного тока, используйте принадлежности, рекомендуемые в данной инструкции по эксплуатации.

  «Если какой-нибудь твердый предмет или жидкость попали внутрь корпуса, выключите видеокамеру и проверьте ее у дилера Sony перед дальнейшей ее эксплуатацией.

  «Избегайте грубого обращения с видеокамерой или механических ударов. Будьте особенно осторожны с объективом.

  «Если видеокамера не используется.

- БУДЬТЕ оссовенно осторожны с объективом.

   Если видеокамера не используется,
  установите выключатель РОЖЕТ в
  положении ОFF (СНБ).

   Не заворачивайте Вашу видеокамеру,
  например, в полотенце, и не эксплуатируйте
  ее в таком состоянии. В противном случае
  может промозоти повышение температуры
  внутри видеокамеры.

magnetic fields or mechanical vibration. Noise may appear on the image.

• Do not touch the LCD screen with your fingers or a sharp-pointed object.

• If your camcorder is used in a cold place, a residual image may appear on the screen. This is not a malfunction.

• While using your camcorder, the back of the LCD screen may heat up. This is not a malfunction.

- On handling tapes
   Do not insert anything into the small holes on the rear of the cassette. These holes are used to sense the type and thickness of the tape and if the recording tab is in or out
- Do not open the tape protect cover or touch the

### Camcorder care

- Camcorder care

  Remove the tape, and periodically turn on the power, operate the CAMERA and PLAYER or VCR (DCR-TRV330E only) sections and play back a tape for about 3 minutes when your camcorder is not to be used for a long time.

  Clean the lens with a soft brush to remove dust. If there are fingerprints on the lens, remove them with a soft cloth.

  Clean the camcorder body with a dry soft cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent which may damage the finish.

  Do not let sand get into your camcorder. When you use your camcorder on a sandy beach or in a dusty place, protect it from the sand or dust. Sand or dust may cause your camcorder to malfunction, and sometimes this malfunction cannot be repaired.

## Connection to your computer

- when recording with i.LINK cable the image processed or edited by your computer, use a new Hi8 High Digitals H stape.

  When inputting the image recorded by Hi8/ standard 8 (analog) system into your computer, dub the image into a Digitals H or DV tape first, and then input it into your computer.

When inputting the image recorded by Hi8/standard 8 system into Sony VAIO
The Program Capture function of DVgate motion
doesn't work. To use this function, dub the image
into a Digital8 19 or DV tape first, and then input
196 it into your Sony VAIO.

### Информация по уходу за аппаратом и меры предосторожности

- Держите Вашу видеокамеру подальше от сильных магнитных полей или механическ вибрации. На изображении могут появить
- вибрации. На изоирижелия ими, у помежи.

   Не прикасайтесь к экрану ЖКД своими пальцами или острыми предметами.

   При эксплуатации Вашей видеокамеры в холодном месте, на экране ЖКД может появляться остаточное изображение. Это не является неисправность.

   При эксплуатации Вашей видеокамеры, задняя сторона экраны ЖКД может нагреваться. Это не является неисправностью.

- Обращение с лентами

   Не вставляйте ничего в маленькие отверстия
  на задней стороне кассеты. Эти отверстия
  используются для определения типа и
  топцины ленты, а также для определения
  наличия или отсутствия лепестка защиты
  записи на ленте.

   Не открывайте защитную крышку ленты и не
  приксайтесь к ленте.

- прикасайтесь к ленте.

  Укол за Видеокамерой

   Периодически выникайте кассету и включайте питание, оперируйте устройствами САМЕЯА и РLAYER или VCR (только модель DCR: ТRV330E) и воспроизвоит ленту порядка 3-х минут, если Ваша видеокамера не будет использоваться длительное время.

   Чистите объектив с помощью мягкой кисточки для удаления пыли. Если имеются отпечатки ляг удалите их с помощью мягкой тисточкой ткани, чистом учистие, удалите их с помощью мягкой ткани, слегка смоченной ткани или мягкой ткани, слегка смоченной раствором умеренного мюющего
- кой ткани или мягкой ткани, слегка рченной раствором умеренного моющег дства. Не используйте каких-либо типс створителей, которые могут повредить

- иногда может быть неисправимой.

  Подключение к Вашему компьютеру

  При записи с помощью шируа LLINK, изображение можно обрабатывать и редактировать на Вашем компьютеру (используйте при этом невую ленту HiB HiB) цифровую ленту нету Digitala It 9.

  При вводе изображения, записанного в системе В (аналоговой), в Ваш компьютер, слечала сделайте компо изображения на цифровую ленту Digitala It 9 или DV, а затем введите его в компьютер.

При вводе изображения, записанного в системе Hi8/стандартной системе 8, в программу Sony VAIO Функция захвата изображения DVgate motion не работает. Для использования этой функции

### Maintenance information and precautions

- AC power adaptor

   Unplug the unit from a wall socket when you are not using the unit for a long time. To disconnect the mains lead, pull it out by the plug. Never pull the mains lead itself.

   Do not operate the unit with a damaged cord or if the unit has been dropped or damaged.

   Do not bend the mains lead forcibly, or place a heavy object on it. This will damage the cord and may cause fire or electrical shock.

   Prevent metallic objects from coming into contact with the metal parts of the connecting section. If this happens, a short may occur and the unit may be damaged.

   Always keep metal contacts clean.

   Do not disassemble the unit.

   Do not apply mechanical shock or drop the unit.

- while the unit is in use, particularly during charging, keep it away from AM receivers and video equipment. AM receivers and video equipment disturb AM reception and video
- The unit becomes warm during use. This is not a malfunction.

  • Do not place the unit in locations that are:
- Extremely hot or cold
- Dusty or dirty Very humid

- About care and storage of the lens
   Wipe the surface of the lens clean with a soft cloth in the following instances:
   When there are fingerprints on the lens

- When there are ingerprints on the lens surface
- In hot or humid locations
- When the lens is used in environments susceptible to salt such as the seaside
Store the lens in a well-ventilated location subject to little dirt or dust.

To prevent mold from occurring, periodically perform the above. We recommend turning on and operating the video camera recorder about once per month to keep the video camera recorder in an optimum state for a long time.

### Информация по уходу за аппаратом и меры предосторожности

- Сетевой адаптер переменного тока
   Отсоедините аппарат от стенной розетки, если он не используется длительное время. Для отсоединения сетевого шнура потяните его за разъем. Никогда не тяните за сам
- ынур.

   Не эксплуатируйте аппарат с поврежденным шнуром или же в случае, если аппарат упал или был поврежден.

   Не слибате с ествой провод силой и не ставьте на него тяжелые предметы. Это повредит провод и может привести к пожеру или поражению электрическим
- током. Будьте осторожны, чтобы никакие металлические предметы не соприкасались с металлическими контактами соединительной пластины. Если это случится, то может произойти короткое замыкание, и аппарат может быть поврежден. Следите за тем, чтобы металлические контакты были чистыми. Не разбирайте аппарат.

## Об уходе за объективом и его хранении • Протирайте поверущост, сес-

- b уходе за объективом и его хранен Протирайте поверхность объектива сухо чистой тканью в следующих случаях:
   Если на поверхности линзы остались отпечатки пальцев
   В жарких или влажных местах
   Если объектив используется в соленой среде, например, на побережье моря
- Храните объектив в хорошо вентилируемом месте, недоступном для пыли и грязи.

Для предотвращения появления плесени периодически выполняйте указания приведенные выше. Рекомендуется включать и использовать

Оперативный справочник —

регуляторов

видеокамеру примерно один раз в месяц для сохранения записывающего устройства видеокамеры в оптимальном состоянии в ение ллительного времени

Обозначение частей и

### Maintenance information and precautions

- Battery pack

  Use only the specified charger or video equipment with the charging function.

  To prevent accident from a short circuit, do not allow metal objects to come into contact with the battery terminals.

  Keep the battery pack away from fire.

  Never expose the battery pack to temperatures above 60°C (140°F), such as in a car parked in the sum or under direct sunited.

- the sun or under direct sunlight.

   Keep the battery pack dry.

   Do not expose the battery pack to any mechanical shock.

   Do not disassemble nor modify the battery
- pack.

   Attach the battery pack to the video equipment
- Charging while some capacity remains does not

## affect the original battery capacity

Note on dry batteries
To avoid possible damage from battery leakage or corrosion, observe the following:
- Be sure to insert the batteries with the + - polarities matched to the + - marks.
- Dry batteries are not rechargeable.
- Do not use a combination of new and old batteries.

- batteries.

   Do not use different types of batteries.

   Current flows from batteries when you are not using them for a long time.

   Do not use leaking batteries.

- If batteries are leaking

   Wipe off the liquid in the battery compartment carefully before replacing the batteries.

  If you touch the liquid, wash it off with water.

   If the liquid get into your eyes, wash your eyes with a lot of water and then consult a doctor.

If any problem occurs, unplug your camcorder and contact your nearest Sony dealer.

### Информация по уходу за аппаратом и меры предосторожности

- Батаречный отнок Используйте только рекомендуемое зарядное устройство или видеоаппаратуру с зарядной функцией. Для предотвращения несчастного случая из-за короткого замыкания не допускайте контакта металлических предметов с полюсами батарейного блока
- Не располагайте батарейный блок вблизи
- огня.
   Не подвергайте батарейный блок озгарсил остаренный олок воздействию температур свыше 60°С, например, в припаркованном под солнц-автомобиле или под прямым солнечным
- светом.
   Следите за тем, чтобы батарейный блок был сухим.
   Не подвергайте батарейный блок воздействию каких-либо механических
- ударов. Не разбирайте и не видоизменяйте батарейный блок.
  • Прикрепляйте батарейный блок к
- видеоаппаратуре плотно.
   Зарядка в случае оставшейся емкости заряда не отражается на емкости первоначального заряда.

## Примечание к сухим батарейкам

Во избежание возможного повреждения видеокамеры вследствие утечки внутреннего вещества батареек или коррозии соблюдайте

- вещества оатареек или коруложи соллюдали следующее.

   При установке батареек соблюдайте правильную полярность + в соответствии с метками + –.

   Сухие батарейки нельзя перезаряжать. Не используйте новые батарейки вместе си старыми.

- старыми. Не используйте батарейки разного типа. Если батарейки не используются длительное время, они постепенно разряжаются. Не используйте батарейки, которые потекли.


## **Если произошла утечка внутреннего** вещества батареек

- Перед тем, как заменить батарейки, тщательно протрите остатки жидкости в
- тщательно протрите остатки жидкости отсеке для батареек. 
  В случае попадания жидкости на кожу, промойте жидкость водой. 
  В случае попадания жидкости в глаза, промойте свои глаза большим количест воды, после чего обратитесь к врачу.

В случае возникновения каких-либо проблем, отключите Вашу видеокамеру от источника питания и обратитесь в ближайший сервисный центр Sony.

## Identifying the parts and controls

## Camcorder



- 1 Lens cap (p. 26)
- 2 LCD screen (p. 26)
- 3 OPEN button (p. 26)
- 4 VOLUME buttons (p. 39)
- 5 Battery pack (p. 15)
- 6 BATT (battery) release lever (p. 15) 7 POWER switch (p. 26)
- 8 START/STOP button (p. 26) 9 Hooks for shoulder strap (p. 205)

10 DC IN jack (p. 16)



This mark indicates that this This mark indicates that this product is a genuine accessory for Sony video products. When purchasing Sony video products, Sony recommends that you purchase accessories with this "GENUINE VIDEO ACCESSORIES" mark

1 Крышка объектива (стр. 26)

2 Экран ЖКД (стр. 26) 3 Кнопка OPEN (стр. 26)

10 Гнездо DC IN (стр. 16)

4 **Кнопки VOLUME** (стр. 39) 5 Батарейный блок (стр. 15)

**6** Фиксатор ВАТТ (батарея) (стр. 15)

7 Переключатель POWER (стр. 26) 8 KHORKA START/STOP (CTD. 26)

9 Крючки для плечевого ремня (стр. 205)



Данный знак означает, что это Данный знак означает, что это изделие является подлинной принадлежностью для видеоаппаратуры Sony. При покупке видеоаппаратуры Sony рекомендуется приобретать для нее принадлежности Sony с таким знаком "GENUINE VIDEO ACCESSORIES'

197

11

REW B-PLAY - FF

STOP PAUS REC



- II Video control buttons (p. 39, 42)
   STOP (stop)

  ◄ REW (rewind)

  ► PLAY (playback)

  ► FF (fastforward)
  II PAUSE (pause)

   REC (recording) (DCR-TRV330E only)
- 12 SUPER LASER LINK button (p. 46)
- 13 SUPER NIGHTSHOT button (p. 33)
- 14 Focus ring (p. 65)
- 15 Lens

12

13 14

15

16

17

18

- 16 Microphone
- 17 Camera recording lamp (p. 26)
- 18 Infrared rays emitter (p. 33, 46)
- 19 NIGHTSHOT switch (p. 33)
- 20 Display window (p. 212) 21 FOCUS switch (p. 65)
- 22 BACK LIGHT button (p. 32)
- 23 FADER button (p. 53)
- 24 Remote sensor

204

## What is SUPER LASER LINK?

wrnat is SUPER LASER LINK?

The super laser link system sends and receives pictures and sound between video equipment having the super laser link mark 4 by using inferred are super. infrared rays.


- Кнопки видеоконтроля (стр. 39, 42)
   В STOP (остановка)
   ◄ REW (ускоренная перемотка назад)
   ► PLAY (воспроизведение
   ► FF (ускоренная перемотка вперед)
   II PAUSE (пауза)
   ◆ REC (запись) (только DCR-TRV330E)

- 12 Кнопка SUPER LASER LINK (стр. 46)
- 13 Кнопка SUPER NIGHTSHOT (стр. 33)
- 14 Кольцо фокусировки (стр. 65)
- 15 Объектив
- 16 Микрофон
- 17 Лампа записи видеокамеры (стр. 26)
- 18 Излучатель инфракрасных лучей (стр. 33, 46)
- 20 Окошко дисплея (стр. 212)
- 21 Переключатель FOCUS (стр. 65)
- **22 Кнопка ВАСК LIGHT** (стр. 32)
- 23 Кнопка FADER (стр. 53)
- 24 Датчик дистанционного уг

Что такое SUPER LASER LINK? Система лазерного суперканала передачи сигналов посылает и принимает изображен и звук между видеоаппаратурой <u>м</u> имеющ знак лазерного суперканала передачи сигналов , о помощью инфракрасных лучей.

Identifying the parts and controls

Обозначение частей и регуляторов



- 25 EDITSEARCH buttons (p. 37)
- 26 MEMORY PLAY button\* (p. 146)
- 27 Speaker
- 28 MEMORY button\* (p. 137, 146) 29 RESET button (p. 173)
- 30 MEMORY INDEX button\* (p. 148)
- 31 MEMORY DELETE button\* (p. 163)
- 32 EXPOSURE button (p. 64)
- 33 MEMORY MIX button\* (p. 137) 34 MEMORY + button\* (p. 137, 146)
- \* DCR-TRV325E/TRV330E/TRV430E/TRV530E

Attaching the shoulder strap Attach the shoulder strap supplied with your camcorder to the hooks for the shoulder strap

25 KHORKA EDITSEARCH (CTD. 37)

- 26 **Кнопка MEMORY PLAY\*** (стр. 146)
- 28 Кнопка MEMORY -\* (стр. 137, 146)
- 29 Кнопка RESET (стр. 181)
- 30 Кнопка MEMORY INDEX\* (стр. 148)
- 31 KHORKA MEMORY DELETE\* (CTP. 163)
- 32 KHORKA EXPOSURE (CTp. 64)
- 33 **Кнопка MEMORY MIX\*** (стр. 137) 34 Кнопка MEMORY +\* (стр. 137, 146)
- <sup>\*</sup> Только модели DCR-TRV325E/TRV330E/ TRV430E/TRV530E


Прикрепление плечевого ремня Прикрепите плечевой ремень, прилага Вашей видеокамере, к крючкам для плечевого ремня.



205

## Identifying the parts and controls

### Обозначение частей и регуляторов




- 35 Intelligent accessory shoe
- 36 END SEARCH button (p. 37)
- 37 DISPLAY button (p. 40) 38 TITLE button (p. 67)
- 39 PB ZOOM button (p. 75, 157)
- 40 Power zoom lever (p. 29)
- 41 PHOTO button (p. 48, 129)
- 42 "Memory Stick" eject button\* (p. 126)
- 43 "Memory Stick" slot\* (p. 126) 44 Access lamp\* (p. 126)
- 45 SEL/PUSH EXEC dial (p. 107)
- 46 MENU button (p. 107)
- \* DCR-TRV325E/TRV330E/TRV430E/TRV530E

- 35 Держатель для устано принадлежностей
- 36 Кнопка END SEARCH (стр. 37) **37 Кнопка DISPLAY** (стр. 40)
- 38 **Кнопка TITLE** (стр. 67)
- 39 **Кнопка РВ ZOOM** (стр. 75, 157) 40 Рычаг приводного вариообъект
- (стр. 29)
- **41 Кнопка РНОТО** (стр. 48, 129)
- 42 Кнопка извлечения "Memory Stick (стр. 126)
- 43 Отсек "Memory Stick"\* (стр. 126) 44 Лампочка доступа\* (стр. 126)
- 45 Диск SEL/PUSH EXEC (стр. 107)
- 46 **Кнопка МЕNU** (стр. 107)
- \*Только модели DCR-TRV325E/TRV330E/ TRV430E/TRV530E

## Identifying the parts and controls

Обозначение частей и регуляторов



- 47 Viewfinder (p. 30)
- 48 LOCK knob (p. 26) (DCR-TRV325E/TRV330E/TRV430E/ TRV530E only)
- 49 Grip strap
- 50 (headphones) jack
- 51 MIC (PLUG IN POWER) jack Connect an external microphone (optional). This jack also accepts a "plug-in-power" microphone.
- Fastening the grip strap

- 47 Видоискатель (стр. 30)
- 48 Ручка LOCK (стр. 26) ли DCR-TRV325E/TRV330E/ (только модели DCF TRV430E/TRV530E)
- 49 Ремень для захвата
- 50 Гнездо ( (головные телефоны)
- 51 Гнездо MIC (PLUG IN POWER) Для подсоединения внешнего микрофона (приобретается отдельно). Это гнездо также позволяет подключить микрофон "с выключателем питания".

Пристегивание ремня для захвата



Fasten the grip strap firmly

Пристегните ремень для захвата плотно

206 207

1-45

регуляторов

52 Окуляр

53 Рычаг регулировки об видоискателя (стр. 30)

56 Кассетный отсек (стр. 24)

Intelligent Accessory Shoe

вки объектива

54 Переключатель ОРЕN/EJECT (стр. 24)

55 Гнездо для треноги (основание) Убедитесь, что длина винта треноги менее 6,5 мм. В противном случае Вы не сможете

надежно прикрепить треногу, а винт может повредить Вашу видеокамеру

54

55

56

57 Гнездо A/V OUT (стр. 44, 82) (DCR-TRV230E/TRV235E/TRV325E/ TRV430E/TRV530E)

Гнездо AUDIO/VIDEO (стр. 44, 82, 143) (DCR-TRV330E)

(DCR-TRV230E/TRV235E/TRV325E/ TRV430E/TRV530E) Гнездо DV IN/OUT (стр. 84, 143) (DCR-TRV330E)

(DCH-TRV330E) Гнездо DV OUT или DV IN/OUT является совместимым с каналом i.LINK.

совместимым с каналом I.LINK.

®С Гнездо LANC ©
LANC означает систему шины
управления местным приложением.
Гнездо управления LANC используется
для контроля за перемещением ленты
видеоаппаратуры и других
периферийных устройств,
подключенных к нему. Данное гнездо
имеет такую же функцию, как и гнездо,
обозначенное как CONTROL L или
REMOTE.

61 Гнездо <sup>₩</sup> (USB) (стр. 151) (только модели DCR-TRV325E/TRV330E/ TRV430E/TRV530E)

209

53

52 Eyecup

52

53 Viewfinder lens adjustment lever (p. 30)

54 OPEN/EJECT switch (p. 24)

55 Tripod receptacle (base)
Make sure that the length of the tripod screw is less than 6.5 mm (9/32 inch). Otherwise, you cannot attach the tripod securely and the screw may damage your camcorder.

56 Cassette compartment (p. 24)

Intelligent Accessory Shoe

Notes on the intelligent accessory shoe

- The intelligent accessory shoe
   The intelligent accessory shoe supplies powe to optional accessories such as a video light, microphone or printer (DCR-TRV325E/
- to optional accessories such as a video light, microphone or printer (DCR-TRV352E/TRV3

Identifying the parts and controls

The buttons that have the same name on the

Remote Commander as on your camcorder function identically to the buttons on your

Remote Commander

М Ассевзогу Shoe
Примечания о держателе для установки
вспомогательных принадлежностей
Держатель для установки вспомогательных
принадлежностей поставляет питание для
дополнительных принадлежностей, таких
как видеофонарь, микрофон или принтер
(только модели DCR-TRV35E/TRV330E/
ТRV430E/TRV530E).

Лержатель лля установки вспомогательных

ППЧЧЭЮ ППЧЭОСЛЬ ПРИ И СПОМОГАТЕЛЬНЫХ ПРИНАДЛЕЖНОСТЕЙ СВЯЗАН С ПЕРЕКЛЮЧАТЕЛЬНЫХ ПРИНАДЛЕЖНОСТЕЙ СВЯЗАН С ПЕРЕКЛЮЧАТЬ И ВЫКЛЮЧАТЬ И ТОТАВЛЯЕМОЕ ДЕРЖАТЕЛЬНЫХ ОБРАЩАТЬ И БИТОТОТЬ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПЕРЕКЛЮЧЕТЬ В ПЕРЕКЛЮЧЕТЬ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬНЫХ ПЕРЕКЛОВИТЬ ПОТОТЕЛЬНЫХ ПОТОТЕЛЬ

- screw.
   To remove an accessory, loosen the screw, and then press down and pull out the accessory.

208


Обозначение частей и регуляторов

## Пульт дистанционного управления

держателем. Обращайтесь к руководствам по эксплуатации вспомогательных принадлежностей для получения дальнейшей информации. 
• Держатель для установки вспомогательны принадлежностей оснащен устройством безопасности для надежного закрепления установленной принадлежности нажмите вниз и подвеньне е до упора, а затем затяните винт

затяните винт.
• Для удаления принадлежности отпустите винт, а затем нажмите вниз и вытащите принадлежность.

Кнопки пульта дистанционного управления которые имеют одинаковые наи кнопками на видеокамере, функционируют идентично



- 1 PHOTO button (p. 48, 129)
- 2 DISPLAY button (p. 40)
- 3 SEARCH MODE button (p. 78, 80)
- 4 **|**√►► buttons (p. 78, 80)
- 5 Tape transport buttons (p. 42)
- 6 Transmitter Point toward the remote sensor to control the camcorder after turning on the camcorder.
- 7 ZERO SET MEMORY button (p. 71, 77)
- 8 START/STOP button (p. 26)
- 9 DATA CODE button (p. 41)
- 10 Power zoom button (p. 29)

- **1 Кнопка РНОТО** (стр. 48, 129)
- 2 KHORKA DISPLAY (CTP. 40)
- 3 Кнопка SEARCH MODE (стр. 78, 80)
- 4 Кнопки Н (стр. 78, 80)
- 5 Кнопки перемещения ленты (стр. 42)
- 6 Передатчик Направьте на датчик для управления видеокамерой после включения видеокамеры.
- 7 Kнопка ZERO SET MEMORY (стр. 71, 77)
- 8 Кнопка START/STOP (стр. 26)
- **9 Кнопка DATA CODE** (стр. 41)
- 10 Кнопка пр (стр. 29)

Identifying the parts and controls

57 A/V OUT jack (p. 44, 82) (DCR-TRV230E/TRV235E/TRV325E/ TRV430E/TRV530E) AUDIO/MIDEO jack (p. 44, 82, 143) (DCR-TRV330E)

58 S VIDEO OUT jack (p. 44) (DCR-TRV230E/TRV235E/TRV325E/ TRV430E/TRV530E)

59 DV OUT jack (p. 84) (DCR-TRV230E/TRV235E/TRV325E/ TRV430E/TRV530E) DV IN/OUT jack (p. 84, 143) (DCR-TRV330E) The DV OUT or DV IN/OUT jack is i.LINK compatible.

LANC stands for Local Application Control

LANC stands for Local Application Control Bus System. The LANC control jack is used for controlling the tape transport of video equipment and other peripherals connected to the video equipment. This jack has the same function as the jack indicated as CONTROL L or REMOTE.


61 ♥ (USB) jack (p. 151) (DCR-TRV325E/TRV330E/TRV430E/ TRV530E only)

S VIDEO jack (p. 44) (DCR-TRV330E)

To prepare the Remote Commander Insert 2 R6 (size AA) batteries by matching the and – polarities on the batteries to the + – marks inside the battery compartment.

Обозначение частей и регуляторов

дистанционного управления
Вставъте две батарейки R6 (размера AA),
соблюдая надлежащую полярность + и – н батарейках со знаками + - внутри отсека для



Notes on the Remote Commander

- Votes on the Remote Commander
  Point the remote sensor away from strong light
  sources such as direct sunlight or overhead
  lighting. Otherwise, the Remote Commander
  may not function properly.
  Your camcorder works in the Commander
  mode VTR 2. Commander modes
  1, 2 and 3 are used to distinguish your camcorder from other Sony VCRs to avoid remote control misoperation. If you use another Sony VCR in the Commander mode VTR 2, we recommend changing the Commander mode or covering the sensor of the VCR with black

Примечания к пульту дистанцио

управления
• Держите дистанционный датчик подаль от сильных источников света, как например прямые солнечные лучи или иллюминация В противном случае дистанционное управление может не действовать. • Данная видеокамера работает в режиме

пульта дистанционного управления VTR 2. пульта дистанционного управления VTR 2. Режимы пульта дистанционного управления 1, 2 и 3 используются для отличия данной видеокамеры от других КВМ фирмы Sony во избежание неправильной работы дистанционного управления. Если Вы используете другой КВМ фирмы Sony, работающий в режиме VTR 2, мы рекомендуем Вам изменить режим пульта дистанционного управления или закрыть дистанционный датчик КВМ черной бумагой.

210


211

1-46

## Identifying the parts and controls

### Operation indicators

## LCD screen and Viewfinder/ Экран ЖКД и видоискатель



- Recording mode indicator (p. 26)
  //Mirror mode indicator (p. 28)
   Format indicator (p. 185)
   Hi id or id indicator appears.
   Remaining battery time indicator (p. 16, 31, 41)
- 4 Zoom indicator (p. 29)/Exposure indicator
- 4. Zoom Indicator (p. 59/ Exposer ... (p. 64)

  5. Fader Indicator (p. 54)/Digital effect indicator (p. 58, 73)

  6. Wide mode indicator (p. 52)/
  FRAME indicator\* (p. 129)

- #RAME indicator\* (p. 129)

  7 Picture effect indicator (p. 56, 72)

  8 Volume indicator (p. 39)/Data code indicator (p. 41)

  9 PROGRAM AE indicator (p. 61)

- 10 Backlight indicator (p. 32)
  11 SteadyShot off indicator (p. 109)
  12 Manual focusing indicator (p. 65)
  13 Self-timer indicator\* (p. 35, 50, 133)
- \* DCR-TRV325E/TRV330E/TRV430E/TRV530E

### Обозначение частей и регуляторов

### Функциональные индикаторы

### Display window/Окошко дисплея



- 1 Индикатор режима записи (стр. 26)/ индикатор зеркального режима (стр. 28)
- Индикатор формата (стр. 185)
  Появится индикатор Р Н П или В
- 3 Индикатор времени оставшегося зар батарейного блока (стр. 16, 31, 41)
- 4 индикатор вариообъектива (стр. 29)/ Индикатор экспозиции (стр. 64)
- 5 Индикатор фейдера (стр. 54)/инд цифрового эффекта (стр. 58, 73)
- Мидикатор широкоформатного режи (стр. 52)/индикатор FRAME\* (стр. 129)
- (стр. 52)индикатор гнамист (стр. 1. 7 Индикатор эффекта изображения (стр. 56, 72)

  8 Индикатор громкости (стр. 39)/ индикатор кода данных (стр. 41)

  9 Индикатор PROGRAM AE (стр. 61)

- 10 Индикатор задней подсветки (стр. 32)
- 11 Индикатор выключенной функции устойчивой съемки (стр. 117)
- 12 Индикатор ручной фокусировки (стр. 65)
- 13 Индикатор таймера самозапуска\* (стр. 35, 50, 133)
- \* Только модели DCR-TRV325E/TRV330E/ TRV430E/TRV530E

## Identifying the parts and controls


- 14 STBY/REC indicator (p. 26)/Video control mode (p. 42)
- 15 Tape counter indicator (p. 31)/Time code indicator (p. 31)/Self-diagnosis display indicator (p. 174)/Tape photo recording indicator (p. 48)
- 16 Remaining tape indicator (p. 31)
- 17 ZERO SET MEMORY indicator (p. 71, 77, 105)
- 18 Search mode indicator (p. 37, 78, 80)
- 19 NIGHTSHOT indicator (p. 33)
- 20 A/V → DV indicator (p. 98)/ DV IN indicator (p. 103)
- 21 Audio mode indicator (p. 113)
- 22 Warning indicators (p. 175)
- 23 Recording lamp (p. 26)
  This indicator appears in the viewfinder. Video flash ready indicator (p. 109)
   This indicator appears when you use the video flash light (optional).
- 25 Video flash mode indicator (p. 109)
- 26 Tape counter indicator (p. 31)/Time code indicator (p. 31)/Self-diagnosis display indicator (p. 174)
- 27 FULL charge indicator (p. 16)

## Обозначение частей и регуляторов

- 14 Индикатор STBY/REC (стр. 26)/режим видеоконтроля (стр. 42)
- ☐З Индикатор счетчика ленты (стр. 31)/ индикатор кода времени (стр. 31)/ индикатор функции самодиагностики (стр. 182)/индикатор фотосъемки на ленту (стр. 48)
- 16 Индикатор оставшейся ленты (стр. 31)
- 17 Индикатор ZERO SET MEMORY (стр. 71, 77,
- [18] Индикатор режима поиска (стр. 37, 78, 80)
- 19 Индикатор NIGHTSHOT (стр. 33)
- 20 Индикатор А/V → DV (стр. 98)/индикатор DV IN (стр. 103)
- 21 Индикатор аудиорежима (стр. 121)
- 22 Предупреждающие индикаторы (стр. 183)
- 23 Лампочка записи (стр. 26) Этот индикатор появляется в видоискателе.
- 24 Индикатор готовности видеов (стр. 117) Этот индикатор появляется при использовании видеовспышки (не прилагается).
- 25 Индикатор режима видеовспышки (стр. 117)
- 26 Индикатор счетчика ленты (стр. 31)/ индикатор кода времени (стр. 31)/ индикатор функции самодиагностик (стр. 182)
- 27 Индикатор зарядки FULL (стр. 16)

## **SECTION 2 DISASSEMBLY**

The following flow chart shows the disassembly procedure.




2.5 inch LCD model : DCR-TRV230E/TRV335E/TRV330E 3 inch LCD model : DCR-TRV430E


3.5 inch LCD model : DCR-TRV530E

Memory stick model : DCR-TRV325E/TRV330E/TRV430E/TRV530E


# 2-1. LCD UNIT, PD-139 BOARD (2.5 INCH LCD MODEL) (TRV230E/TRV235E/TRV325E/TRV330E)




## [PD-139 BOARD SERVICE POSITION]




# 2-2. LCD UNIT, PD-138/139 BOARD (3/3.5 INCH LCD MODEL) (TRV430E/TRV530E)




## [PD-138/139 BOARD SERVICE POSITION]




## 2-3. FRONT PANEL SECTION, SI-028/029 BOARD




## [SI-028/029 BOARD SERVICE POSITION]




## 2-4. CABINET (R) SECTION



# 2-5. CF-079 BOARD (2.5 INCH LCD MODEL) (TRV230E/TRV235E/TRV325E/TRV330E)




# 2-6. CF-080 BOARD (3/3.5 INCH LCD MODEL) (TRV430E/TRV530E)




## [CF-079/080, SI-028/029 BOARDS SERVICE POSITION]


retainer




## 2-7. EVF SECTION, LB-068/070 BOARD




## [LB-068/070, CF-079/080, SI-028/029 BOARDS SERVICE POSITION]




## 2-8. LENS SECTION, CD-294/317 BOARD




## [CD-294/317, CF-079/080, SI-028/029 BOARDS SERVICE POSITION]




# 2-9. PC-082 BOARD (MEMORY STICK MODEL) (TRV325E/TRV330E/TRV430E/TRV530E)




## [PC-082, CF-079/080, SI-028/029 BOARDS SERVICE POSITION]




## 2-10. BATTERY PANEL SECTION, BATTERY TERMINAL BOARD



## 2-11. CONTROL SWITCH BLOCK (SS-1380), FU-150/154 BOARD



## 2-12. CABINET (L) SECTION, MECHANISM DECK-1




## [MECHANISM DECK SERVICE POSITION-1]

**Note:** Use the parts only which can be removed easily from outside of the mechanism deck.


Operate the VTR using the adjustment remote commander. (with the HOLD switch set in the OFF position)

## How to raise the cassette compartment manually


⟨ Remove the hook in the direction of the arrow (a) to raise the cassette compartment
\( \) in the direction of the arrow (b).
\( \)



## 2-13.VC-254 BOARD




## 2-14. MECHANISM DECK-2, MD FRAME




# [CONNECTION DIAGRAM FOR SERVICE POSITION (Mainly for voltage measurement and check)] (VC-254, FU-150/154, CD-294/317, SI-028/029, PC-082, CF-079/080 BOARDS, MECHANISM DECK-2)

Note: Operate the VTR using the adjustment remote commander (with the HOLD switch set in the OFF position)




## 2-15. HINGE SECTION



#### 2-16. CIRCUIT BOARDS LOCATION







CF-079 (2.5 INCH LCD MODEL) CF-080 (3/3.5 INCH LCD MODEL) (USER FUNCTION, EVF DRIVE)

PD-138 (3 INCH LCD MODEL) PD-139 (2.5/3.5 INCH LCD MODEL)  $^\prime$ RGB DRIVE, TIMING GENERATOR, $^{ackslash}$ LCD DRIVE, BACK LIGHT DRIVE

> FU-150 (2.5 INCH LCD MODEL) FU-154 (3/3.5 INCH LCD MODEL)



SI-028 (2.5 INCH LCD MODEL) SI-029 (3/3.5 INCH LCD MODEL) STEADY SHOT, REMOTE COMMANDER RECEIVER, LASER LINK





CAMERA/Hi8/STD8/PB PROCESS, DV SIGNAL. PB RF AMP, VIDEO IN/OUT, AD CONVERTER, MODE/CAMERA/MECHA CONTROL, LASER LINK, DRUM CAPSTAN DRIVE, AUDIO PROCESS, MIC,

DC/DC CONVERTER

#### 2-17. FLEXIBLE BOARDS LOCATION


The flexible boards contained in the mechanism deck are not shown.






# SECTION 3 BLOCK DIAGRAMS


## 3-1. OVERALL BLOCK DIAGRAM (1/5) (): Page No. shown in () indicates the page to refer on the schematic diagram.



## 3-2. OVERALL BLOCK DIAGRAM (2/5) (): Page No. shown in () indicates the page to refer on the schematic diagram.



## **3-3. OVERALL BLOCK DIAGRAM (3/5)** (): Page No. shown in () indicates the page to refer on the schematic diagram.





ZOOM VR AD

3-7


#### 3-4. OVERALL BLOCK DIAGRAM (4/5) (): Page No. shown in () indicates the page to refer on the schematic diagram. M2000 MECHA DECK VC-254 BOARD(3/4) (SEE PAGE 4-41,52) (4-39)(4-42)IC4401 IC1301 CN4402 I 01306 DRUM PWM DRUM PWM IC4501 DRUM ERROR DRUM VS IC4401 SWITCHING DRP SO,DRP SI,XDRP SCK (3/3) (1/2)U, V, W -(<u>M</u>) DIGITAL8 MECHA CONTROL SIGNAL PROCESS CONTROL CAP PWM CAP PWM LPF CAP ERROR PWM DRIVE SWITCHING VSP SO,VSP SI,XVSP SCK (4-49)DRUM FG FG AMP DRUM FG MC BUS DRUM PG PG AMP DRUM PG (4-42)FRRV,TRRT,TRRV DRUM PG M902 CAPSTAN MOTOR IC4402 CN4403 ATF ERR CAP FG U,V,W CAP VS $\left(\underline{\mathsf{M}}\right)$ DEW AD TO OVERALL BLOCK(3/5) (SEE PAGE MODE SW A-C HU,HV,HW XCS TAKO (IC3701) 2 · 3 · 4 CAP FG FG1,2 IC4502 CAPSTAN FG FG AMP EEPROM XCS AU (IC5701) -DEW AD DEW SENSOR XCS TRF (IC3101) -(4-40) VREF (IC3301) S901 MODE SWITCH DV RF SWP MODE SW A-C TAPE END XFE ON DRUM 8 PB TAPE TOP (4-42)T REEL FG XCS MECHA (IC4803) IC4401 M903 LOADING MOTOR CN4401 S REEL FG (2/3)LM(+).LM(-) $-(\underline{M})$ HI SO,HI SI,XHI SCX VC SO,VC SI,XVC SCX TAPE LED ON REC PROOF VC RF SWP Q002 TAPE END SENSOR TAPE END TAPE END DETECT (4-35)Q001 TAPE TOP SENSOR VSP SO,VSP SI,XVSP SCK TAPE TOP TAPE TOP(C) DRUM PWM IC4902 T REEL FG T REEL AFG CAMERA CONTROL HI8/STD8 MECHA CONTROL CAP PWM T REEL FG AMP T REEL(+),(-) T REEL SENSOR VC SO,VC SI,XVC SCX LINE OUT V (IC3301) -S REEL FG S REEL(+),(-) DRUM PG S REEL SENSOR H002 S REEL AFG $(2 \cdot 3 \cdot 4)$ 115 CAP FG TAPE LED ON LED DRIVE IC4901 EEPROM MODE SW A-0 REC PROOF ME SW HI8 MP SW XCS KINUTA (IC2201) -DA STRB (IC2291) ME/MP LOAD UNLOAD HI8 MP XCS EEPROM S002 TO OVERALL BLOCK(1/5) (SEE PAGE CAP FG 15 TAPE END CN1108(4/4) DV RF SWP (IC4501 (62)) — FOR ADJUSTMENTS TAPE TOP VC RF SWP (IC4902 47) XCS CH,CH SO,XCH SCK T REEL AFG S REEL AFG IRIS PWM STB ON CK CONT 1,2 (IC2201) -TAPE LED ON ME SW HI SO,HI SI,XHI SCX HI8 MP SW HALL AD FC RST ZM RST LENS FILTER SW ON MF A,B PITCH AD YAW AD XCS VC (IC4803) 23) - ZM RST FC RST LENS FILTER SW ON 88 MF B STB ON MF A (84) HALL AD 97 PITCH AD HI SO,HI SI,XHI SO YAW AD (SEE PAGE

## **3-5. OVERALL BLOCK DIAGRAM (5/5)** (): Page No. shown in () indicates the page to refer on the schematic diagram.







#### 3-7. POWER BLOCK DIAGRAM (2/3) (): Page No. shown in () indicates the page to refer on the schematic diagram.



## 3-8. POWER BLOCK DIAGRAM (3/3) (): Page No. sh

(): Page No. shown in () indicates the page to refer on the schematic diagram.







3-15 3-16E

# SECTION 4 PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS


## 4-1. FRAME SCHEMATIC DIAGRAM (1/3)



## FRAME SCHEMATIC DIAGRAM (2/3)



#### FRAME SCHEMATIC DIAGRAM (3/3)






#### 4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

## THIS NOTE IS COMMON FOR WIRING BOARDS AND SCHEMATIC DIAGRAMS (In addition to this, the necessary note is printed in each block)

#### (For printed wiring boards)

- Pattern from the side which enables seeing.


  (The other layers' patterns are not indicated.)
- Through hole is omitted.
- Circled numbers refer to waveforms.
- There are few cases that the part printed on diagram isn't mounted in this model.
- Chip parts.



#### (For schematic diagrams)

- All capacitors are in  $\mu F$  unless otherwise noted. pF:  $\mu \mu F$ . 50V or less are not indicated except for electrolytics and tantalums.
- Chip resistors are 1/10W unless otherwise noted.  $k\Omega$ =1000 $\Omega$ . MW=1000 $k\Omega$ .
- Caution when replacing chip parts.
- New parts must be attached after removal of chip.

  Be careful not to heat the minus side of tantalum capacitor, Because it is damaged by the heat.
- Some chip part will be indicated as follows.



- Constants of resistors, capacitors, ICs and etc with XX indicate that they are not used.
- In such cases, the unused circuits may be indicated.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Signal name

 $X = DIT \rightarrow DIT PB/XREC \rightarrow PB/REC$ 


- inon flammable resistor
- two: if usible resistor
   panel designation
- === : B+ Line \*
   === : B- Line \*
- EN/OUT direction of (+,−) B LINE. \*
   : adjustment for repair. \*
- Circled numbers refer to waveforms. \*
- \* Indicated by the color red.

Note: The components identified by mark △ or dotted line with mark △ are critical for safety.

Replace only with part number specified.

#### (Measuring conditions voltage and waveform)

- Voltages and waveforms are measured between the measurement points and ground when camera shoots color bar chart of pattern box. They are reference values and reference waveforms.\*
- (VOM of DC 10 M $\Omega$  input impedance is used.).
- Voltage values change depending upon input impedance of VOM used.) \*
- 1. Connection



2. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.




Fig. a (Video output terminal output waveform)






Fig.b (Picture on monitor TV)

When indicating parts by reference number, pleas include the board name.

## CD-294 (CCD IMAGER) PRINTED WIRING BOARD (DCR-TRV230E/TRV235E/TRV325E/TRV330E) CD-317 (CCD IMAGER) PRINTED WIRING BOARD (DCR-TRV430E/TRV530E)






#### For printed wiring boards

- Refer to page 4-107 for parts location.
- CD-294, CD-317 boards consists of multiple layers. However, only the sides (layers) A and B are shown.
- Chip parts


#### Transistor



There are a few cases that the part printed on this diagram isn't mounted in this model.




#### For Schematic Diagram





- The CD-294/317 board mounted as a repair part is not equipped with a CCD imager.
   When replacing this board, remove the CCD imager from the old one and mount it onto the new one.
- If the CCD imager has been replaced, carry out all the adjustments for the camera section.

Н

 As the CCD imager may be damaged by static electricity from its structure, handle it carefully like for the MOS IC.
 In addition, ensure that the receiver is not covered with dusts nor exposed to strong light. VC-254 (CAMERA/STD8/Hi8/PB PROCESS, DV SIGNAL, PB RF AMP, VIDEO IN/OUT, AD CONVERTER, MODE/CAMERA/MECHA CONTROL, LASER LINK, DRUM CAPSTAN DRIVE, AUDIO PROCESS, MIC, DC/DC CONVERTER) PRINTED WIRING BOARD









#### For Schematic Diagram


- Refer to page 4-11 for printed wiring board.
- Refer to page 4-103 for waveforms.






#### For Schematic Diagram

- Refer to page 4-11 for printed wiring board.
- Refer to page 4-103 for waveforms.





DV SIGNAL PROCESS-2 / LANC, DV IN/OUT FP-272

#### • Refer to page 4-11 for printed wiring board. • Refer to page 4-103 for waveforms. 4 | 5 | 6 | 7 | 8 | 9 | 3 10 11 | 12 | 13 | 14 15 16 | 17 VC-254 BOARD(6/18) DIGITAL8 PB RF AMP(RF(D) BLOCK) Α -REF.NO.:10000 SERIES-XX MARK:NO MOUNT NO MARK:REC/PB MODE R :REC MODE P :PB MODE RP\_4.75V > L3103 10uH L3104 10uH R3123 22k R3126 ≸ В (67) TO(18/18) A 2.8V ∑> ₩ L3102 10uH C3111 + 10u + 6.3V T C3122 10u 6.3V R3144 560 С Q3111,3116, 27 TO(4/18) < RF\_1.9V ∑ FLYING ERASE OSC D sw ps ∑ ALL\_PS T C3114 C3119 T CH CH T RECA1 Q3102 2SA1774HT2 VRB DET RECA1 ∑∑ RECA2 RECA2 ∑ RECCK RECCK ∑ RECDT Ε PLLSW PLLMSK PLLMSK 🔊 M2000 MECHANISM DECK VIDEO HEAD R3107 ₹ ₹ R3111 46 TO(4/18 F 4.7 P1.0 CLK IC3103 IC3101 ADDT1 < (%) PB X OUT ADDT2 ≪₹ EQ.PLL A/D CONV. (TRF) IC3101 CXA2071R-T4 DATA2 AMP (TRW) I RECA2 ADDT4 ≪<del>X</del> RECA2 IC3103 CXA2072R-T4 2.8 vcc3 TESTIN ADDT5 < $\Rightarrow$ G 2.8 N AD D GND R1.9/P0 (3) PECA1 R1.9/P0 (3) PESW\_PS 1.4 (2) CONTO 2.8 (2) CONTO DC\_TC2 (P) XDRP\_SCK SW\_PS AGC GND (8) DRP SO ∑≫ XDRP\_SCK XDRP\_SCK (21)(22) XCS\_TRF XCS TRE ∑≫ REC\_CRRTO XCS S IO GND S IO GND AFF3 AFF1 I/O VCC JSWP AFF OUT BUF VCC BUF OUT AGC VCC AGCTC1 REC\_CRRTO ∑> REC\_CRRT1 REC\_CRRT1 ALL\_F TEST VDD CLK GND DATA VCC1 NC GND GND GND R3108 1M DV RF SWP DV\_RF\_SWP Н DRUM\_8PB DRUM\_8PB XFE\_ON XFE\_ON 🏻 Q3107,3109,3119,3120 8mmPB CONT (69) TO(11/18) < XME/MP ∑ XME/MP ALL\_PS RECCK RECDT C3131 0.01u B 70 TO(17/18 (CN1108)) ( RF\_MON ≪-RF\_IN ∑≫-IC3102 TO(9/18) \ DV\_PB\_RF \ SIGNAL PATH VIDEO SIGNAL K SIGNAL PATH Y/CHROMA CHROMA SIGNAL REC REC/PB PB REC 16 РВ **=>>>** Ref.signal

For Schematic Diagram

#### For Schematic Diagram


G

16

- Refer to page 4-11 for printed wiring board.
- Refer to page 4-104 for waveforms. • Refer to page 4-53 for printed wiring board of FP-270 flexible. 5 7 8 9 6 10 11 12 13 14 15 VC-254 BOARD(7/18) NO MARK:REC/PB MODE R :REC MODE P :PB MODE VIDEO IN/OUT A\_4.75V B1 T0(18/18) -REF.NO.:10000 SERIES-XX MARK:NO MOUNT REG\_GND (74) TO(8/18) TAKO\_C\_OUT ≪ FP-270 FLEXIBLE (12) TO(1/18, 8/18) TAKO\_Y\_OUT << I AV TERMINAL (14) TO(2/18) KINUTA\_C\_OUT >> В AV JACK IN 5>-XS JACK IN ∑≫ S VIDEO S\_C\_I/0 L3705 10uH C3734 10u 6.3V 36 35 34 33 32 31 30 29 28 27 26 25 S\_GND UDZS-TE17-8.2B S\_GND С S\_Y\_I/0 S\_Y\_I/0 SHASSIS GND 0.01u B XS\_JACK\_IN AUDIO\_L\_I/O IR\_VIDEO 1R\_V\_0UT & 74,7 AV\_JACK\_IN VIDEO I/O AUDIO/VIDEO DR\_V\_OUT VIDEO\_I/O Q3701 2SC4738F-Y/GR(TPL3) BUFFER 1.3 Y\_IN1 ≰ R3727 1k LND102 AV\_GND IC3701 C3709 0.033u R3702 4700 →(₹) MAIN\_GND2 SYNC\_SEP\_TC
  Y\_IN2 D (50) LINE IN/OUT, AGC.ACC (76) TO(15/18) Q3702-3705 SWITCH AUDIO\_L\_I/O ∑ CLAMP\_TC1 (77) TO(12/18) IR\_VIDEO < 4 Y\_IN3 4 Y\_IN3 4 CLAMP\_TC2 40 C3701 0.01u B XCS\_TAKO R3701 4700 Q3702 RN2104F(TPL3) SDC\_IN ≪ (78) TO(13/18) (#) Y\_GCA\_CONT XCS\_TAKO ∑ (49)(41)XVIDEO\_IN ∑ C\_IN1 R3726 10k Ε ACC\_CONT SIGNAL PATH ACC\_CONT ∑ C3731 0.01u B 79) TO(8/18) AGC\_CONT AGC\_CONT ∑ VIDEO SIGNAL AUDIO CHROMA Y/CHROMA SIGNAL REC  $\Rightarrow$ VSP\_S0 VSP\_S0 ∑ РВ (80) TO(13/18) C3715 0.33u XVSP\_SCK ∑≫ 03705 2SC4738F-Y/GR(TPL3) CAIN\_Y\_OUT >> (56) TO(5/18) CAIN\_C\_OUT >>

VIDEO IN/OUT / S VIDEO, AUDIO/VIDEO FP-270


For Schematic Diagram • Refer to page 4-11 for printed wiring board. 3 5 6 8 9 10 12 4 11 VC-254 BOARD(8/18) NO MARK:REC/PB MODE R :REC MODE P :PB MODE VIDEO A/D CONV. -REF.NO.:10000 SERIES-83 T0(10/18,11/18 13/18,17/18(CN1104)) Α →>>> HI\_SI XX MARK:NO MOUNT ≪ xcs\_align > 84) TO(10/18) L3602 10uH ≪ HI SO -≪ XHI\_SCK XSYS\_RST 58 T0(5/18,10/18,11/18 13/18.17/18(CN1117)) C3631 0.1u B 82) TO(18/18) C3604 10u 6.3V B 1608 L3601 10uH A 4.75V >> В D\_2.8V >>-TCK -≪ тск (42) TO(4/18,17/18(cn1104)) TMS -≪Z TMS R3607 10k TD\_2-3 -≪ TD\_2-3 (86) TO(17/18(CN1104)) R3608 TD 3-4 —<u></u> TD\_3-4 (43) TO(4/18) Q3601 2SA1774HT2L AMP (12) TO(7/18) < TAKO\_Y\_OUT∑≫ ADABOT ADAIN → IFI\_Y0 03602 C JP04601008S0 BUFFER R3617 ADATOP → IFI\_Y1 R1.1/P0 DYOUT2 → IFI\_Y2 ΔηΔΙ/ΠΠ B1.1/P0 DYOUT3 → IFI\_Y3 ADAVSS R1.6/P0 DYOUT4 (路) (74) TO(7/18) < TAKO\_C\_OUT∑> → IFI\_Y4 IC3603 C3603 0.01u R1.2/P0 DYOUT5 (3)-→ IFI\_Y5 ∆D8R∩T ∞ AD8VDD DYOUT6 (E) →∑≫ IFI Y6 VIDEO A/D CONVERTER BYOUT7 (%) AD8VSS → IFI\_Y7 (20) TO(2/18,17/18(CN1104)) AD8TOP DVSS2 5 IC3603 D DVDD2 (S) AD8TB MB87L1241PFV-G-BND-ER R3622 470 R1.0/P0 DCOUTO →∑≫IFI\_C0 DAVSS DAREF
APCVO
AGCVO
CLPVO R1.0/P0 DCOUT1 \$\pi\$ →∑NFI\_C1 R1.0/P0 DCOUT2 R1.0/P0 DCOUT3 P1.0/P0 C3618 →∑∑IFI\_C2 —∑≫IFI\_C3 AGC\_CONT≪ 79 TO(7/18) DCOUT4 (4) →∑SIFI\_C4 O.1 ACCVO
O DATOP
DABOT
2.8 © DAVDD ACC\_CONT≪ DCOUT5 (4)-→∑>IFI\_C5 (85) TO(17/18(CN1104)) →∑≫IFI\_C6 DCOUTE (2)-Ε →∑∑IFI C7 > (22) TO(2/18,13/18 17/18(CN1104)) →∑NFI VD →∑>ifi\_HD F 3 SPCK ∑≫— (21) TO(2/18,17/18(CN1104)) →∑>IFI\_0E SIGNAL PATH (33) TO(4/18,17/18(CN1104)) → ∑ AFCK VIDEO SIGNAL Y/CHROMA CHROMA REC G РΒ 16



Hi8/STD8 PB RF AMP VC-254 (9/18)

#### For Schematic Diagram

- Refer to page 4-11 for printed wiring board.
- Refer to page 4-104 for waveforms.



#### For Schematic Diagram • Refer to page 4-11 for printed wiring board. • Refer to page 4-104 for waveform. 5 6 8 9 10 11 12 13 14 15 16 17 | 18 | 19 26 TO(3/18) 120 T0(17/18 (CN1113)) (119) TO(12/18) 71 TO(6/18,15/18, 17/18(CN1108)) 69) TO(6/18) 90 TO(9/18) 57 TO(5/18) (18) TO(2/18) (121) TO(17/18 (CN1116)) VC-254 BOARD(11/18) CAMERA CONTROL,HI8/STD8 MECHA CONTROL, STEADY SHOT(VC,SE BLOCK) SIGNAL PATH -REENO : 10000 SERIES-REC REC/PB PB NO MARK:REC/PB MODE R :REC MODE P :PB MODE Drum speed servo Drum phase servo Drum servo (speed and phase) Capstan speed servo Capstan servo (speed and phase) **>>** 99 TO(10/18) sys v ≪ CK\_CONT 7) TO(1/18,2/18) CK\_CONT1 €€ (113) TO(13/18) XTAL20M < D R4936 100k 114) TO(17/18 (CN1104)) SSS\_FROM\_VC 《~ Ε (115) TO(17/18 (CN1101)) STB\_ON 63 T0(5/18,8/18,10/18, 13/18,17/18(CN1117)) STB\_ON << --€⊠HI\_SO HI\_SI > (83) TO(8/18,10/18,13/18, 17/18(CN1104)) > (94) TO(10/18) -≪Xcs\_vc XCS\_VC\_STAR R4923 47k VC\_F\_BUSY CAP\_FG ∑> MF\_B CAP ON CAP\_ON < TABLISH-POLY OF STANKING CAP\_FWD < R4925 W 470k DRUM\_ON DRUM\_FG DRUM FG ∑> DRUM\_PG DRUM\_PG >> TAPE\_LED\_ON XCH\_SCK UNLOAD VC SI Not Used IC4902 UNLOAD ≪ (TANUKI→VC) VC\_SI R0.2/P0.7 (VC→TANUKI) VC\_SO 116) T0(13/18, 14/18) Not Used TAPE\_TOP SCK\_VC TAPE\_TOP ∑ CAMERA CONTROL, HI8/STD8 MECHA CONTRO XME/MP HI\_SO HI\_SI Not Used/DOP CAP\_PWM < DRUM PWM 《 XCS\_VC\_STAR XRST\_KINUTA XRST\_KINUTA XCS\_KINUTA MM)YAW, PWM R1.4/PO IRIS\_PWM 1.2 DRUM\_PWM CAP\_PWM 80.5 Not Used DA\_STRB MODE\_SW\_B >> MODE\_SW\_B DRUM\_PWI MODE\_SW\_C ∑≫— △(႙) ZM\_RST\_LED IC2001 2.8 × Ø ZM\_RST\_SENS CAP\_PWM -W R4921 10k SREEL\_AFG FC RST YAW/PITCH SENSOR AMP TREEL\_AFG >>> ME\_SW\_ C4911 0.1u (117) TO(14/18) XCS\_EEPROM HI8\_MP\_SW 5>-VC\_F\_BUSY DRUM\_BRAKE < C2008 22u 6.3V IC4901 **∑**SE\_2.8V (122) TO(17/18(CN1116)) VST\_C\_RESET (118) TO(18/18) A 2.8V 53 TRV230E/ TRV235E TRV325E/ TRV330E/ TRV530E TRV430E R1128 R1132 100k R1132 M

# For Schematic Diagram • Refer to page 4-11 for printed wiring board. • Refer to page 4-104 for waveforms.

1 2 3 4 5 6 7 8 9 10 11 12 13 14

VC-254 BOARD(12/18) EVR, LASER LINK(ER, IR BLOCK) NO MARK:REC/PB MODE Α -REF.NO.:10000 SERIES-XX MARK:NO MOUNT NO MARK:IR ON/IR OFF MODE ():IR ON MODE []:IR OFF MODE AU\_2.8V L2291 (144) TO(18/18) <del>✓</del> ≪ A 4.75V C3914 10u 6.3V В -**≪** A\_2.8V REG\_GND R3908 12k -W-R3903 33k C3910 4.7u 6.3V R3912 330 → RP\_IR MT\_CONT → MT\_CONT C IC2291 MT\_F0 → MT\_F0 92) TO(9/18) DOC\_DET Q3903 2SA1774HT2L SWITCH →>>> DOC DET MT Q → MT\_Q XVC\_SCK RF\_ENV\_LEVEL -) A\_4.9V(VCC) → RF\_ENV\_LEVEL VC\_SO CFG\_DUTY DI (N) PO. → CFG\_DUTY ( N A\_4.9V(VDD2) (124) TO(14/18) IR\_V\_DEV (38)DI (N) 0.9

REC\_Y/MT\_CONT DOC\_DET (S) 0.9

REC\_L\_CONT RF\_AGC\_CONT (S) 0.9

MT\_F0 RP\_IR (S) 0.9 DOC\_DET VC\_SO MT CONT -≪Z vc\_so RF\_ENV\_LEVEL XVC SCK CLAMP C1

CLAMP C1

CONTROL


C —≪Z XVC\_SCK DRV CL OUT (119) TO(11/18) DA\_STB -≪Z DA\_STB D 2.9 REC\_BIAS AFC\_F0\_ADJ AFC\_F0\_ADJ VC\_RF\_SWP IR\_CARR (0.6)/[0] DRV EM OUT -≪ VC\_RF\_SWP IC3901 FRQ\_TUNE IR\_A\_DEV 0.9 ACC/RF\_CONT FRQ\_TUNE (S) 1.6 0 NC (1.3)/[0] (2.0)/[0.5] DRV SW (2.0) 1.6 © CFG\_DUTY

1.8 © 1.5M\_DEV

1.9 Q AU\_BPF IR\_V\_DEV CFG\_DUTY IR DRIVE (77) TO(7/18) ⟨ IR\_VIDEO ∑ (39)NC (1.3)/[0] (1. 1.5M\_DEV MT\_Q IC3901 AN2920FHQ-EB R3921 ≰ HALL\_REF HALL\_GAIN AU\_BPF HALL\_REF (5) 0.9 0.3 (2.3)/[3.6] REF A DEV ADJ → HALL\_GAIN 1.7M\_DEV 1.6 7 1.7M\_DEV 200M\_MIC\_CONT 2.8 2 A\_FADE F82291 0uH 2.8 2 D\_3.2V(VDD1) HALL\_GAIN HALL\_OFFSET HALL\_GAIN ( ) 1.2 R3919 560 → HALL\_OFFSET (24) TO(3/18) HALL\_OFFSET HALL OFFSET | HALL REF →>>> HALL REF -w-SWP(SEL) 2.8 VC RF SWP (2.3)/[2.6] ARF OUT (3.0)/[0] STBY **→**(♣) Lch IN Ε DA\_STB ALC C (2.3)/[3.6] STB(LD) (128) TO(15/18) (2.9)/[0] CHUP C IR\_R ∑ SIGNAL PATH C3927 0.01u FRQ\_TUNE > (4) TO(1/18) FRQ\_TUNE VIDEO SIGNAL ZOOM\_MIC\_CONT SOOM\_MIC\_CONT (125) TO(16/18) **AUDIO** CHROMA Y/CHROMA SIGNAL R3922 39k → 1.5M\_DEV 1.7M\_DEV (126) TO(15/18) →>> 1.7M DEV REC AU BPF → AU\_BPF  $\Rightarrow$ F ΡВ AFC\_F0\_ADJ → AFC\_F0\_ADJ > (15) TO(2/18) + C3903 C3919 C3916 C3920 0.47u 1u 0.47u B B B (32) TO(4/18) IR\_FSC >>> IR\_ON ∑> G (102) TO(10/18) SIRCS\_PWM >>>-

> EVR, LASER LINK VC-254 (12/18)

# For Schematic Diagram • Refer to page 4-11 for printed wiring board. • Refer to page 4-104 for waveforms.




**DIGITAL8 MECHA CONTROL** VC-254 (13/18)

4-39 4-40

#### For Schematic Diagram


- Refer to page 4-11 for printed wiring board.
- Refer to page 4-104 for waveforms.




#### For Schematic Diagram


• Refer to page 4-11 for printed wiring board.

• Refer to page 4-104 for waveform. 5 7 9 3 6 8 12 10 11 13 14 15 VC-254 BOARD(15/18) AUDIO PROCESS(AU BLOCK)



**AUDIO PROCESS** VC-254 (15/18)







CONNECTOR VC-254 (17/18)

#### For Schematic Diagram

- Refer to page 4-11 for printed wiring board.
- Refer to page 4-104 for waveforms.




LS-057 (S/T REEL SENSOR), FP-228 (DEW SENSOR), FP-299 (MODE SWITCH), FP-300 (TAPE TOP), FP-302 (TAPE END), FP-301 (TAPE LED) FLEXIBLE BOARDS




#### FP-270 (S VIDEO, AUDIO/VIDEO), FP-272 (LANC, DV IN/OUT) FLEXIBLE BOARDS


— Ref. No. FP-270, FP-272 Flexible Boards; 30,000 Series —

• Refer to page 4-27 for schematic diagram.





• Refer to page 4-24 for schematic diagram.




#### For printed wiring boards

Chip parts




There are a few cases that the part printed on this diagram isn't mounted in this model.



#### PC-082 (DIGITAL STILL CONTROL, DS STILL PROCESS) PRINTED WIRING BOARD

— Ref. No. PC-082 Board; 20,000 Series —




#### For printed wiring boards


- Refer to page 4-109 for parts location.
- PC-082 board consists of multiple layers. However, only the sides (layers) A and B are shown.
- Chip parts


#### Transistor



There are a few cases that the part printed on this diagram isn't mounted in this model.








DIGITAL STILL CONTROL 1 PC-082 (1/3)


4-59

16

#### For Schematic Diagram

- Refer to page 4-55 for PC-082 printed wiring board.
- Refer to page 4-65 for printed wiring board of FP-271 flexible.





DS STILL PROCESS PC-082 (3/3)

4-63

4-64

#### FP-271 (USB), FP-282 (FOCUS), FP-275 (SWITCH) FLEXIBLE BOARDS


— Ref. No. FP-271, FP-282, FP-275 Flexible Boards; 30,000 Series —

• Refer to page 4-62 for schematic diagram.

• Refer to page 4-76 for schematic diagram.

11-121-089-1

FP-282 FLEXIBLE(SIDE A)




282-97 A R 7-70I

• Refer to page 4-76 for schematic diagram.

1-680-131-

 $\bigcirc$ 


FOCUS
AUTO-MANUAL



#### For printed wiring boards


- FP-271 flexible board consists of multiple layers.
   However, only the sides (layers) A and B are shown.
- FP-282, FP-275 flexible boards consists of multiple layers. However, only the sides (layers) A is shown.

There are a few cases that the part printed on this diagram isn't mounted in this model.



USB FP-271 FOCUS SWITCH FP-275

SUPER NIGHT SHOT



**USER FUNCTION, EVF DRIVE** CF-079

For printed wiring board

CD-294 (2.5 INCH LCD MODEL) CD-317 (3/3.5 INCH LCD MODEL) (CCD IMAGER)

• Chip parts Transistor

• Refer to page 4-109 for parts location.

the sides (layers) A and B are shown.


Diode


2 1

this diagram isn't mounted in this model.

LB-068 (2.5 INCH LCD MODEL) LB-070 (3/3.5 INCH LCD MODEL) (EVF BACK LIGHT)

4-67 4-68







**USER FUNCTION, EVF DRIVE** CF-080

• Chip parts Transistor

CD-294 (2.5 INCH LCD MODEL) CD-317 (3/3.5 INCH LCD MODEL) (CCD IMAGER)

4-72 4-71






USER FUNCTION FOCUS SWITCH FP-275


#### For Schematic Diagram


• Refer to page 4-67 (CF-079), 4-71 (CF-080) for printed wiring board.

• Refer to page 4-105 for waveforms.



SI-028 (DCR-TRV230E/TRV235E/TRV325E/TRV330E), SI-029 (DCR-TRV430E/TRV530E) (STEADY SHOT, REMOTE COMMANDER RECEIVER, LASER LINK) PRINTED WIRING BOARDS





4-80

## STEADY SHOT, REMOTE COMMANDER RECEIVER, LASER LINK SI-028, SI-029

VC-224 (CAMERA/Hig/STD8/PB PROCESS, DV SIGNAL, PB RF AMR VIDEO IN/OUT, AD CONVERTER, MODE/CAMERA/MECHA CONTROL, LASER LINK, DRUM CAPSTAN DRIVE, AUDIO PROCESS, MIC,

For printed wiring boards

• Refer to page 4-110 for parts location.

SI-028 (2.5 INCH LCD MODEL) SI-029 (3/3.5 INCH LCD MODEL) (STEADY SHOT, REMOTE COMMANDER RECEIVER, (LASER LINK

• SI-028, SI-029 boards consists of multiple layers.


However, only the sides (layers) A and B are shown.

There are a few cases that the part printed on this diagram isn't mounted in this model.

FP-283 (PANEL REVERSE)

#### FP-273 (MIC, HEADPHONES) FLEXIBLE BOARD (DCR-TRV530)


- Ref. No. FP-273 Flexible Board; 30,000 Series -




#### For printed wiring board

• FP-273 flexible board consists of multiple layers. However, only the sides (layers) A and B are shown.

There are a few cases that the part printed on this diagram isn't mounted in this model.





LB-068 (EVF BACK LIGHT) PRINTED WIRING BOARD (DCR-TRV230E/TRV235E/TRV325E/TRV330E) LB-070 (EVF BACK LIGHT) PRINTED WIRING BOARD (DCR-TRV430E/TRV530E)


— Ref. No. LB-068, LB-070 Boards; 1,000 Series — \_B-068 BOARD SIDE\_A) LB-068 BOARD (SIDE B) K **□** ■ A D702 R706 R705 R703  $\bigcirc$  $\bigcirc$ R704 TH701 16 10 CN702 1-680-021-16 2


#### For printed wiring boards

- Refer to page 4-110 for parts location.
- LB-068, LB-070 boards consists of multiple layers. However, only the sides (layers) A and B are shown.
- Chip parts


Transistor

There are a few cases that the part printed on this diagram isn't mounted in this model.






4-83



#### FP-283 (PANEL REVERSE) FLEXIBLE BOARD

— Ref. No. FP-283 Flexible Board; 30,000 Series —

• Refer to page 4-89, 4-95 for schematic diagram.




S601 (PANEL REVERSE SW)

#### For printed wiring board


FP-283 flexible board consists of multiple layers. However, only the sides (layers) A is shown.

There are a few cases that the part printed on this diagram isn't mounted in this model.



## PD-138 (RGB DRIVE, TIMING GENERATOR, LCD DRIVE, BACK LIGHT DRIVE) PRINTED WIRING BOARD (DCR-TRV430E)

— Ref. No. PD-138 Board; 20,000 Series —




#### For printed wiring board

- Refer to page 4-110 for parts location.
- PD-138 board consists of multiple layers. However, only the sides (layers) A and B are shown.
- Chip parts

Transistor



There are a few cases that the part printed on this diagram isn't mounted in this model.




RGB DRIVE, TIMING GENERATOR **▮** PANEL REVERSE

PD-138 (1/2)


FP-283

#### For Schematic Diagram


- Refer to page 4-87 for PD-138 printed wiring board.
- Refer to page 4-86 for printed wiring board of FP-283 flexible.
- Refer to page 4-105 for waveforms.



## For Schematic Diagram • Refer to page 4-87 for printed wiring board. • Refer to page 4-106 for waveform.



## PD-139 (RGB DRIVE, TIMING GENERATOR, LCD DRIVE, BACK LIGHT DRIVE) PRINTED WIRING BOARD (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E)




#### For printed wiring board

- Refer to page 4-111 for parts location.
- PD-139 board consists of multiple layers. However, only the sides (layers) A and B are shown.
- Chip parts

#### Transistor




There are a few cases that the part printed on this diagram isn't mounted in this model.



#### For Schematic Diagram


- Refer to page 4-93 for PD-139 printed wiring board.
- Refer to page 4-86 for printed wiring board of FP-283 flexible.
- Refer to page 4-106 for waveforms.



#### For Schematic Diagram


• Refer to page 4-93 for printed wiring board.

• Refer to page 4-106 for waveform.



FU-150 (POWER SUPPLY) PRINTED WIRING BOARD (DCR-TRV230E/TRV235E/TRV325E/TRV330E) FU-154 (POWER SUPPLY) PRINTED WIRING BOARD (DCR-TRV430E/TRV530E)

— Ref. No. FU-150, FU-154 Boards; 1,000 Series —





#### For printed wiring boards


- Refer to page 4-111 for parts location.
- FU-150, FU-154 boards consists of multiple layers. However, only the sides (layers) A and B are shown.
- Chip parts

Transistor Diode

There are a few cases that the part printed on this diagram isn't mounted in this model.









#### 4-3. WAVEFORMS

#### **CD-294/317** BOARD **CAMERA REC**




#### VC-254 BOARD




4-103 4-104


#### PC-082 BOARD



**CF-079/080** BOARD




**PD-138** BOARD (1/2)





## **PD-139** BOARD (1/2) REC/PB


# ① IC5501 ⑩ ① IC5502 ⑩ ① IC5502 ⑩ ① IC5502 ⑩ ② IC5502 ⑩ ③ IC5502 ⑩ ⑥ IC5502 ⑪ ⑥ IC5502 ⑥


#### **PD-138/139** BOARD (2/2)























#### 4-4. MOUNTED PARTS LOCATION

4-4. MOUNTED PARTS	LOCATION	
CD-294/317 BOARD (SIDE A)	VC-254 BOARD (SIDE A)	
CD-294/317 BOARD (SIDE A)  C502	C1320 B-6   C3121 F-5   C442   C1328 B-8   C3122 F-5   C442   C1333 B-6   C3123 F-4   C442   C1336 A-6   C3124 F-4   C442   C1336 A-6   C3126 F-5   C442   C1337 A-8   C3127 F-5   C442   C1337 A-8   C3128 G-4   C442   C1340 B-6   C3129 G-4   C443   C1340 B-6   C3129 G-4   C443   C1342 B-8   C3131 F-5   C443   C1347 A-6   C3133 F-5   C443   C1347 A-6   C3133 F-5   C443   C1347 A-6   C3135 F-6   C443   C1356 A-6   C3135 F-6   C443   C1356 A-6   C3135 F-6   C443   C1358 A-9   C3138 F-5   C443   C1359 A-8   C3140 F-5   C443   C1508 F-4   C3601 B-4   C443   C1513 F-3   C3603 B-4   C490   C1516 E-3   C3604 B-3   C490   C1516 E-3   C3611 B-5   C490   C1516 E-3   C3611 B-5   C490   C1518 E-3   C3614 B-5   C491   C1520 E-3   C3615 B-5   C491   C1521 E-4   C3616 B-5   C571   C1522 E-4   C3617 B-5   C571   C1523 E-3   C3622 B-4   CN11   C1556 C-2   C3629 B-6   CN11   C1556 C-2   C3620 B-5   CN11   C1569 D-2   C3636 B-4   CN12   C2003 A-1   C3706 C-4   CN44   C2006 B-2   C3707 C-4   CN44   C2006 B-2   C3707 C-4   CN44   C2007 A-1   C3706 C-4   CN44   C3223 C-4   C4406 F-7   C1516   C2223 C-4   C4406 F-7   C1516	15   15   17   13   13   16   15   16   17   18   18   18   18   18   18   18
	C2242 D-7 C4416 E-7 L130 C2243 E-7 C4418 E-7 L130 C2244 F-5 C4419 F-7 L130 C2247 C-5 C4420 E-7 L130 C2250 F-5 C4421 F-7 L130	2 A-7 R1316 A-9 R3658 B-4 RB4903 D-8 3 B-7 R1319 A-8 R3659 B-4 4 B-7 R1320 A-8 R3660 B-4 T1301 B-8

#### VC-254 BOARD (SIDE B)

	- (/							
	C3117 G-14	C3918 B-18	C5740 C-16	IC1301 B-11	Q5718 A-16	R1574 D-16	R3371 C-11	R4820 B-15
	C3119 G-14	C3919 A-18	C5741 C-16	IC1304 B-13		R1575 D-16	R3372 C-11	R4821 B-15
	C3120 G-14	C3920 A-18	C5742 C-16	IC1501 F-15	R1144 D-10	R1576 D-16	R3375 C-13	R4822 B-15
	C3137 G-14	C3921 B-18	C5743 C-16	IC1552 D-17	R1149 A-16	R1577 D-16	R3376 C-14	R4823 B-15
	C3141 G-14	C3922 A-18	C5744 C-16	IC2291 D-16	R1150 A-16	R1596 D-16	R3385 E-13	R4824 A-15
	C3142 G-14	C3923 B-18	C5745 C-16	IC3101 F-14	R1151 E-16	R3103 F-13	R3386 C-14	R4829 B-15
	C3143 G-14	C3924 A-18	C5746 C-16	IC3102 F-15	R1152 E-16	R3104 F-13	R3387 F-15	R4830 B-15
	C3144 G-14	C3925 A-18	C5747 C-16	IC3201 F-13	R1153 E-16	R3107 G-14	R3388 F-15	R4832 C-15
	C3202 F-13	C3926 A-18	C5748 C-16	IC3202 F-12	R1154 E-16	R3108 G-14	R3389 F-14	R4833 A-14
	C3203 F-12 C3204 F-13	C3927 A-18	C5749 C-16	IC3301 D-14	R1155 E-16	R3109 G-14 R3110 G-14	R3390 F-14	R4834 A-14
	C3204 F-13 C3205 F-13	C3928 A-18 C3934 A-17	C5750 C-17 C5751 C-17	IC3302 C-12 IC3901 A-18	R1301 B-10 R1302 B-10	R3110 G-14 R3111 G-14	R3391 F-14 R3392 E-15	R4835 A-14 R4836 A-14
	C3206 F-13	C3935 B-18	C5752 C-17	IC4501 E-11	R1303 B-10	R3113 G-14	R3393 F-15	R4840 C-14
	C3207 F-13	C3936 B-18	C5753 C-17	IC4502 D-12	R1304 C-11	R3128 G-15	R3394 F-15	R4855 C-15
	C3208 F-13	C4440 G-13	C5754 C-17	IC4801 A-13	R1305 C-10	R3139 G-14	R3395 E-15	R4861 A-14
	C3210 F-13	C4441 G-13	C5755 C-17	IC4802 A-15	R1306 A-10	R3140 G-14	R3396 E-14	R4862 A-14
	C3211 F-13	C4442 G-13	C5756 C-17	IC4803 B-14	R1307 B-10	R3141 G-14	R3397 E-14	R4863 C-14
	C3212 F-13	C4501 F-11	C5757 C-17	IC4804 A-14	R1309 C-10	R3142 G-14	R3398 E-14	R4864 C-14
C1316 B-11 C	C3213 F-13	C4504 E-12	C5758 B-15	IC5701 B-16	R1310 A-10	R3205 F-13	R3903 B-17	R4867 A-14
C1317 B-11 C	C3214 F-13	C4505 E-12	C5759 B-16	IC5702 C-17	R1311 A-10	R3206 F-13	R3904 A-17	R4868 A-14
	C3215 F-13	C4506 E-12	C5806 C-18	IC5801 C-18	R1312 C-11	R3210 F-12	R3905 A-17	R4869 A-14
	C3216 F-12	C4507 E-12	C5807 C-18		R1313 A-11	R3212 F-13	R3908 B-17	R4872 C-14
	C3217 F-13	C4508 E-12	C5808 C-17	L1312 A-13	R1314 C-11	R3213 F-12	R3909 A-17	R4873 C-14
	C3218 F-12	C4509 F-11	C5809 C-17	L1313 B-13	R1317 A-12	R3214 F-13	R3911 A-18	R4876 C-13
	C3301 C-15	C4510 E-11	C5810 C-18	L1314 B-13	R1318 A-12	R3215 F-13	R3912 B-17	R4878 B-13
	C3302 C-12	C4801 C-15	C5812 C-18	L1315 A-13	R1321 A-12	R3307 D-13 R3309 E-13	R3913 B-18	R4882 B-13
	C3303 D-15	C4802 A-14	C5813 C-18	L1316 B-13	R1322 A-12		R3916 B-18	R4883 B-13
	C3305 E-13 C3306 C-14	C4803 B-15 C4804 A-15	C5814 C-17 C5815 C-17	L1553 D-17 L2291 D-15	R1323 A-11 R1326 C-11	R3310 E-12 R3311 E-12	R3917 A-18 R3918 A-18	R4884 B-13 R4885 B-13
	C3307 D-13	C4805 A-15	C5816 C-17	L3102 G-13	R1327 A-12	R3312 E-13	R3919 A-18	R4886 B-13
	C3308 D-13	C4806 A-14	C5817 C-18	L3102 G-14	R1330 A-11	R3313 E-13	R3920 A-18	R4887 B-13
	C3309 D-15	C4807 A-14	C5818 C-18	L3201 F-12	R1331 A-11	R3315 E-14	R3921 A-18	R4888 B-13
	C3310 D-13	C4808 A-15	C5819 C-17	L3303 E-13	R1332 A-11	R3316 E-14	R3922 A-18	R4896 B-15
C1339 A-13 C	C3311 E-15	C4810 A-15	C5820 C-18	L3304 E-15	R1333 A-11	R3317 E-15	R3923 B-18	R4897 B-13
C1341 B-13 C	C3312 E-13	C4811 A-15	C5821 C-18	L3305 E-13	R1334 A-11	R3318 E-15	R3924 A-18	R4898 B-13
	C3313 E-13	C4812 A-15	C5822 C-18	L3306 E-15	R1335 C-12	R3319 E-15	R3936 B-18	R4899 B-13
	C3314 E-12	C4813 A-14	C5823 C-17	L3307 C-10	R1336 A-11	R3320 E-13	R3939 B-18	R4902 F-12
	C3315 E-15	C4814 A-14	C5824 C-18	L3901 B-17	R1337 C-12	R3321 E-14	R3940 B-17	R4905 F-12
	C3316 E-15	C4815 A-14	C5825 C-17	L3902 B-18	R1338 A-11	R3322 E-13	R3941 B-17	R4920 D-11
	C3317 E-13	C4816 A-14	C5826 C-18	L3903 B-18	R1339 A-11	R3323 E-15	R3942 A-17	R4921 D-11
	C3318 E-13	C4817 A-14	C5827 C-17	L3904 B-18	R1340 A-11	R3324 E-15	R3943 A-17	R5707 A-16
	C3319 E-13	C4819 C-14 C4820 B-13	C5829 C-17 C5830 C-18	L5701 C-16 L5803 B-18	R1341 B-12	R3325 D-15	R3948 B-18 R3949 B-18	R5708 A-16
	C3320 F-13 C3321 E-13	C4820 B-13 C4821 B-13	C5830 C-18 C5832 B-18	L5803 B-18	R1342 B-12 R1343 C-12	R3326 E-15 R3327 E-15	R3949 B-18 R4408 G-12	R5709 A-17 R5710 A-17
	C3322 E-13	C4822 C-13	C5833 B-18	Q1302 B-12	R1345 A-11	R3328 F-14	R4409 G-12	R5714 A-17
	C3323 E-14	C4823 B-13	C5835 B-17	Q1303 A-12	R1346 A-11	R3329 F-15	R4410 G-12	R5715 A-17
	C3324 E-15	C4824 B-13	C5836 B-17	Q1304 A-11	R1347 A-12	R3330 D-11	R4428 G-12	R5717 B-15
	C3325 D-15	C4825 B-13	C5838 B-18	Q1305 B-12	R1348 A-12	R3331 E-14	R4429 G-12	R5718 B-15
	C3326 D-15	C4827 B-13	C5839 B-18	Q1306 B-12	R1349 A-13	R3332 F-15	R4450 G-13	R5719 B-15
	C3327 E-15	C4903 F-12	C5840 B-18	Q1307 A-12	R1355 B-12	R3333 D-10	R4451 G-13	R5720 B-17
	C3328 F-14	C4904 F-12	C5841 B-18	Q1308 A-12	R1356 B-12	R3334 F-14	R4452 G-13	R5721 B-17
	C3329 D-10	C5701 A-16	C5842 C-18	Q1309 B-12	R1357 C-11	R3335 C-10	R4502 E-12	R5724 C-16
	C3331 C-10	C5702 A-16	C5843 C-18	Q1311 A-12	R1358 C-11	R3335 F-15	R4503 E-12	R5725 C-16
	C3332 C-11	C5703 B-17	C5844 C-17	Q1312 A-12	R1359 C-10	R3336 F-14	R4507 F-12	R5728 C-16
	C3333 C-11 C3334 C-12	C5704 A-16 C5705 A-16	CN1101 E 16	Q1316 A-11 Q1321 A-11	R1360 A-10 R1361 B-13	R3337 C-11	R4508 E-10	R5730 C-16 R5731 C-17
	C3334 C-12 C3335 C-10	C5705 A-16 C5706 A-17	CN1101 E-16 CN1108 E-10	Q1321 A-11 Q1323 A-11	R1362 C-13	R3338 F-15 R3339 D-10	R4511 E-10 R4512 E-12	R5731 C-17 R5732 C-17
	C3336 C-10	C5707 A-16	ONTTOO L TO	Q1324 B-12	R1363 C-13	R3340 E-14	R4515 E-12	R5733 C-17
	C3337 C-11	C5708 A-16	D1101 E-16	Q1327 A-12	R1364 C-12	R3341 F-14	R4520 D-12	R5744 B-15
	C3338 C-11	C5709 B-17	D1102 E-16	Q1328 A-11	R1365 C-12	R3343 F-14	R4521 D-11	R5745 B-15
C1562 D-17 C	C3339 E-14	C5710 B-16	D1103 E-16	Q1329 A-12	R1366 B-12	R3345 D-10	R4522 D-11	R5746 B-15
C1564 D-17 C	C3340 E-14	C5713 B-17	D1105 F-16	Q1330 B-12	R1367 C-13	R3346 C-10	R4523 D-11	R5747 B-15
	C3341 E-15	C5714 A-16	D1106 E-16	Q1331 B-13	R1368 C-13	R3347 C-10	R4524 D-11	R5801 C-17
	C3342 E-15	C5715 B-17	D1501 G-16	Q1332 B-12	R1501 F-15	R3348 C-10	R4526 D-11	R5802 C-18
	C3343 E-15	C5716 A-16	D3301 E-12	Q1554 D-16	R1502 F-15	R3349 C-10	R4527 D-12	R5803 C-18
	C3345 E-15	C5717 B-17	D3302 E-12	Q3102 F-14	R1503 F-15	R3350 C-10	R4530 E-12	R5805 C-18
	C3346 E-13 C3348 E-13	C5718 B-16 C5719 A-17	D3303 E-15 D3304 E-15	Q3107 G-14 Q3109 G-14	R1504 G-15 R1505 G-15	R3351 E-15 R3352 C-12	R4801 C-15 R4802 C-15	R5806 C-17 R5807 C-18
	C3352 E-15	C5720 B-15	D4802 A-14	Q3119 G-14	R1506 G-15	R3353 C-10	R4803 C-14	R5809 C-18
	C3901 A-17	C5721 B-16	D4803 C-13	Q3120 G-14	R1508 G-15	R3354 C-10	R4804 A-14	R5814 C-17
	C3902 A-17	C5722 B-17	D4804 B-15	Q3201 F-13	R1509 F-15	R3356 E-15	R4805 A-14	R5815 C-18
	C3903 A-17	C5723 B-15	D4806 A-14	Q3305 F-14	R1512 G-16	R3357 C-10	R4806 C-15	R5816 C-17
C3102 F-14 C	C3904 A-17	C5724 B-17		Q3306 F-14	R1523 G-15	R3358 E-15	R4807 C-15	R5817 C-18
	C3905 A-17	C5725 B-16	FB1501 G-15	Q3309 E-15	R1561 D-16	R3359 C-12	R4808 A-14	R5818 C-17
	C3906 A-17	C5728 B-15	FB1502 G-15	Q3310 E-14	R1562 D-16	R3360 E-15	R4809 C-15	R5819 C-18
	C3908 A-17	C5730 B-16	FB1503 G-15	Q3311 F-15	R1563 D-16	R3361 C-11	R4810 C-15	R5820 C-18
	C3909 A-17	C5731 B-15	FB1505 G-15	Q3902 B-18	R1564 D-16	R3362 C-11	R4811 C-14	R5821 C-17
	C3910 B-17	C5732 B-17	FB2291 C-16	Q3903 B-18	R1565 D-17	R3363 C-11	R4812 A-15	R5822 C-17
	C3911 B-17 C3912 B-18	C5733 B-16 C5734 B-17	FB3303 C-12 FB3304 D-10	Q4801 C-15 Q4802 C-15	R1566 D-16 R1567 D-16	R3364 C-11 R3365 C-11	R4813 A-15 R4814 A-15	R5823 C-18 R5824 C-18
	C3912 B-16 C3913 B-17	C5735 B-16	FB3307 D-15	Q4804 C-14	R1568 D-17	R3366 C-11	R4815 A-15	R5825 C-17
	C3914 B-18	C5736 C-16	FB4501 D-11	Q4806 B-15	R1570 D-17	R3367 C-11	R4816 A-14	R5826 B-17
C3114 F-14 C	C3915 A-18	C5737 B-17	FB4801 A-14	Q4813 C-15	R1571 D-17	R3368 C-11	R4817 A-14	R5827 B-18
	C3916 A-18	C5738 C-16	FB4818 B-13	Q5708 A-16	R1572 D-17	R3369 C-11	R4818 A-15	R5828 C-17
C3116 G-14   C	C3917 B-18	C5739 C-17 I		Q5716 B-15	R1573 D-16	R3370 C-11	R4819 A-15	R5829 B-18

C-082 BOARD (SIDE A)	PC-082 BOARD (SIDE B)	CF-079 BOARD (SIDE A)
CC-082 BOARD (SIDE A)	C1164 A-7 R1180 C-12 C1167 A-8 R1182 D-12 C1168 A-8 R1183 B-7 C1169 C-9 R1184 B-8 C1180 A-9 R1185 C-12 C1181 A-9 R1180 D-8 C1188 B-7 R1200 D-8 C1181 B-7 R1201 D-8 C1189 B-7 R1203 D-10 C1191 B-7 R1203 D-10 C1191 B-7 R1207 D-9 C1192 B-7 R1209 A-11 C1195 C-12 R1911 E-7 C1200 B-7 C1902 D-10 C1903 D-12 C1907 C-10 R1914 D-11 C1967 B-8 C1969 A-11 C1972 B-12 C1914 D-11 C1969 A-11 C1972 B-12 C1973 B-10 C1974 B-11 CN1901 C-9 D1151 C-8 E1151 C-8 F1158 D-12 E1155 D-12 E1157 D-12 E1157 D-12 E1158 B-7 E1158 B-7 E1158 B-7 E1159 D-9 E1164 A-7 F1158 B-7 E1159 D-9 E1161 A-11 E1901 C-11 C1915 D-12 E1151 C-8 R1161 C-8 R1167 A-8 R1169 D-12 R1161 C-8 R1167 A-8 R1169 D-12 R1170 A-8 R1170 A-8 R1175 B-8 R1175 B-8 R1175 B-8 R1176 B-8	CF-079 BOARD (SIDE A)           BT101         E-2         IC201         F-7           IC202         F-6         IC203         B-4           C201         F-7         IC203         B-4           C201         F-7         L201         F-6           C205         F-7         L202         E-6           C206         F-6         C207         F-7         Q101         F-1           C208         F-7         Q102         F-1         C209         F-7         Q201         F-6           C210         F-6         C211         F-6         R101         F-2         C212         F-7         R103         F-1           C210         F-6         R103         F-1         C214         F-8         R106         F-1         C214         F-8         R106         F-1         C215         E-7         R103         F-1         C214         F-8         R106         F-1         C214         F-8         R106         F-1         C215         E-7         R108         F-1         C216         E-8         R113         D-1         C216         E-8         R112         B-4         C217         E-6         R131         E-3
11111111111111111111111111111111111111	151 B-6   Q1153 C-3   152 C-6   Q1156 B-6   Q1157 D-4   154 D-5   Q1158 D-4   Q1902 D-3   156 D-5   Q1901 D-3   157 C-3   Q1903 D-3   158 C-6   Q1157 C-3   Q1903 D-3   Q1903	152   C-6

1	25501 C-5 25502 A-3 25509 A-3 25510 B-3 25511 B-3 25601 B-3 25602 D-3 25603 B-2
1	05509 A-3 05510 B-3 05511 B-3 05601 B-3 05602 D-3
1	05510 B-3 05511 B-3 05601 B-3 05602 D-3
2 F-7	05511 B-3 05601 B-3 05602 D-3
5 F-8	05601 B-3 05602 D-3
C309   A-3   C309   A-3   C5508   C-5   C5508   C-5   C5508   C-5   C5509   A-4   C5510   A-5   C5500   A-5   C5	15602 D-3
7 F-7	
Signature   Sign	(JUUJ D Z
F-7	
F-5	R5501 A-5
F-6	R5502 A-5
2 E-7 R103 F-2 D302 B-2 R313 B-3 D701 A-4 C5514 A-4 R5 R315 B-5 R5 R5 R5 R106 F-2 D304 B-3 R314 A-3 D702 B-4 C5516 B-5 R5	R5503 B-5
3	R5504 C-6
4 F-8 R106 F-2 D304 B-3 R315 B-3 D702 B-4 C5516 B-5 R5 R5 R5 F-6 R108 F-1 D306 A-2 D307 B-1 D306 B-2 VDR302 B-2 VDR302 B-2 VDR302 B-2 R701 A-4 C5518 A-4 R5	R5505 A-5
5 F-6 R108 F-1 D306 A-2 D307 B-1 VDR301 B-2 VDR302 B-2 R701 A-4 C5518 A-4 R5 R702 A-4 C5522 A-3 R5 R209 F-7 S1-028/029 BOARD R702 A-4 C5528 A-5 R5 R502 F-7 R51-6 R51-7	R5506 B-4
7 E-6 R130 D-1 D308 B-2 VDR301 B-2 VDR302 B-2 O701 A-4 C5518 A-4 R5 R203 F-7 O701 A-4 C5520 B-5 R5 R5 R50 B-6 R207 F-6 R207 F-6 R207 F-6 R208 F-8 R209 F-7 R	R5507 B-4
7 E-6 H130 D-1 D308 B-2 VDR302 B-2 Q701 A-4 C5520 A-5 R5	R5508 B-4
1	R5509 B-4
C5522 A-3 R5	R5510 B-4
1 E-6 R207 F-6 R701 A-4 C5523 D-4 R5 3 A-3 R208 F-8 SI-028/029 BOARD R702 A-4 C5524 B-3 R5 4 B-3 R209 F-7 (SIDE B) R704 A-4 C5527 A-5 R5 6 B-5 R210 F-7 (SIDE B) R704 A-4 C5528 A-5 R5 7 B-3 R211 F-7 R705 B-4 C5529 D-6 R5 01 E-4 R213 F-6 C306 B-7 R706 B-4 C5530 D-5 R5 02 F-3 R214 E-7 CN301 B-6 TH701 A-4 C5532 A-3 R5	R5511 B-4
3 A-3 R208 F-8 SI-028/029 BOARD R702 A-4 C5524 B-3 R5 R5 R5 R209 F-7 (SIDE B) R703 A-4 C5527 A-5 R5 R5 R5 R210 F-7 (SIDE B) R704 A-4 C5528 A-5 R5 R5 R211 F-7 R212 F-6 C306 B-7 R706 B-4 C5520 D-5 R5	R5512 B-5
4 B-3 R209 F-7 (SIDE B) R703 A-4 C5527 A-5 R5 R5 R5 R5 R210 F-7 (SIDE B) R704 A-4 C5528 A-5 R5	R5513 B-5
R703   R44   C5528   R5   R5   R5   R5   R5   R5   R5   R	R5514 B-4
7 B-3 R211 F-7 R705 B-4 C5529 C-6 R5 R212 F-6 C306 B-7 R706 B-4 C5530 D-5 R5 01 E-4 R213 F-6 C5531 C-6 R5 02 F-3 R214 E-7 CN301 B-6 TH701 A-4 C5532 A-3 R5	R5515 B-4 R5516 B-5
R212 F-6 C306 B-7 R706 B-4 C5530 D-5 R5 01 E-4 R213 F-6 C5531 C-6 R5 02 F-3 R214 E-7 CN301 B-6 TH701 A-4 C5532 A-3 R5	R5517 D-5
01 E-4 R213 F-6 C5531 C-6 R5 02 F-3 R214 E-7 CN301 B-6 TH701 A-4 C5532 A-3 R5	R5517 D-3
02 F-3   R214 E-7 CN301 B-6 TH701 A-4 C5532 A-3   R5	R5521 D-5
111/01 // 4	R5522 B-4
03 D-1   R215 E-6	R5523 A-4
	R5524 A-4
	R5525 A-4
06 E-1   R218 E-7 C5605 B-2   R5	R5551 C-5
	R5553 B-5
	R5557 A-5
	R5559 B-6
	R5560 C-6
	R5561 A-3
	R5562 B-3
	R5563 B-3
05000 B 5	R5564 B-3
	R5565 B-3 R5566 B-3
	R5567 B-3
	R5568 A-3
	R5569 A-5
	R5570 A-3
	R5571 A-3
D5603 B-1 R5	R5572 C-6
	R5573 D-4
	R5574 D-4
3 E-10   R121 C-11 FB5502 B-6   R5	R5575 C-5
	R5609 A-2
	R5610 D-3
	R5611 B-2
	R5612 B-2
	A C 1 1 1 1 1
	R5613 D-4
	R5614 B-2
	R5614 B-2 R5616 B-2
4 C-13 R131 F-16 R5 5 R-11 R231 E-12 L5501 Δ-6 R5	R5614 B-2

R5619 B-1

R5620 B-1

R5712 B-2

T5601 D-3

L5501

L5504

L5505

L5601

A-6

A-4

C-5

D-4

D115 D116

D117

D118

D119

D120

D121

D122

Q103

R102

R109

R110

R111

R113

R114 R115

R116

R117 R118

B-11 B-11

B-12

C-10

D-11

D-14

D-11 F-17

F-16

E-10

E-11

C-11

D-13

D-17

E-11

C-11

D-13

E-11 C-11

R231 R232

S101

S102

S103

S104

S105

S106

S107

S109

S110

S111

S112

S113

S114

S115

S116

S117 S118 F-12 F-12

C-12

C-13

D-12 B-12

D-14 D-12

B-11

D-11

G-15

B-13

G-16

C-11

F-17

B-13

B-14 F-18

r D-1	)3 DOF	ט) שאוי	IDL
C5501 C5503 C5504 C5505 C5506 C5507	A-5 A-5 C-5 B-5 B-5 B-5	Q5505 Q5506 Q5508 Q5602 Q5603	A-3 B-3 B-3 D-3 B-2
C5508 C5508 C5509 C5510 C5511 C5515 C5515 C5516 C5517 C5518 C5519 C5527 C5529 C5533 C5534 C5536 C5537 C5538 C5537 C5539 C5530 C5602 C5602 C5602 C5604 C5605 C5606 C5607 C5704	B-5 A-4 A-4 B-4 B-5 B-5 B-5 A-3 B-4 A-5 C-6 A-5 B-3 B-3 B-3 D-4 C-5 B-3 B-3 B-3 B-3 B-3 B-3 B-3 B-3 B-3 B-3	R5501 R5502 R5503 R5504 R5505 R5506 R5507 R5508 R5509 R5510 R5511 R5512 R5523 R5524 R5525 R5551 R5553 R5557 R5557 R5572 R5572 R5573 R5574 R5575 R5576 R5577	A-5 A-6 A-5 B-4 B-4 B-4 B-4 A-4 C-5 B-5 A-6 B-3 A-3 A-3 B-6
CN5501 CN5502 CN5604 CN5701 CN5703 CN5704 CN5705	D-2 B-6	R5585 R5586 R5587 R5588 R5589 R5590 R5591 R5592	A-4 A-4 B-4 B-4 C-6 D-4
D5502 D5503 D5601 D5603 D5604	B-5 D-5 D-3 B-1 B-1	R5609 R5610 R5611 R5612 R5613 R5614	A-2 D-3 B-2 B-2 D-4 B-2
FB5502 FB5503 FB5504	B-6 A-4 A-4	R5616 R5617 R5618 R5619	B-2 B-2 B-2 D-3 B-1
IC5501 IC5502 IC5601 IC5602 IC5701	B-5 C-5 B-2 B-2 A-1	R5620 R5712 T5601	B-1 B-2 D-3
L5501 L5504 L5505 L5601	A-6 A-4 C-5 D-4		
Q5501 Q5503 Q5504	C-5 B-3 A-3		

#### PD-139 BOARD (SIDE A) FU-150/154 BOARD (SIDE A)

C401	A-2	L401	B-1
C402 C403 C404	A-1 A-1 B-1	LF401	A-2
C405	B-1	Q401	A-2
C406	B-1	Q402	A-4
C407	A-1	Q403	A-3
		Q404	B-2
CN401	A-1		
CN402	B-3	R401	B-1
		R406	A-1
D401	B-1	R407	A-1
D402	B-1	R408	A-2
D408	A-3	R409	B-2
		R410	B-2
F401	A-1	R429	A-1
F402	B-1	R430	A-1
F403	B-1		
F404	B-1		

#### **FU-150/154 BOARD (SIDE B)**

C409	A-5	R402	A-4
C410	B-5	R403	B-4
011400	пс	R420	B-5
CN403	B-6	R421 R422	B-5 A-5
D404	A-4	R423	A-5
D405	B-4	R424	B-5
D406	A-4	R425	B-5
D407	A-4	R426	B-5
		R427	B-5
F405	B-5	R428	B-5
F406	B-5		
Q405	B-5		
Q407	A-5		
Q408	A-5		
Q409	B-5		
Q410	B-5		
Q411	B-5		
Q412	B-5	l	

## SECTION 5 ADJUSTMENTS

#### Before starting adjustment 1.

## 1-1. Adjusting items when replacing main parts and boards. When replacing main parts, adjust the items indicated by in the following table.

		$\Box$	Rlo	ok r	anle	ocan	nent					Rep	olace	ed p		rte re	nla	cem	ent		_	_	_		_
			(Fluorescent tube)			(Drum assy.) *1		LS chassis assy	(CCD imager)	(LCD driver (EVF))	(Timing generator (EVF))	(RGB driver (LCD))	(Timing generator (LCD))	(Inverter)	SE301,302 (PITCH,YAW sensor)	IC1501, X1501 (Timing generator)	_	(Camera, Hi8/Std8 process)	(REC/PB AMP)	(EQ, A/D conv. PLL)	(LINE IN/OUT)	(DV signal process)	(3)	(IR transmitter)	(AUDIO IN/OUT, AFM)
Adjustment Section	Adjustment		ND901 (Fluc	LCD901 (LCI				TS o						Q5602, T5601	01,302 (F	501, X150	IC1502 (S/H	IC2201 (Can	IC3103 (REC	IC3101 (EQ,	IC3701 (LIN	IC3301 (DV	IC2291 (EVR)	IC3901 (IR t	IC5701 (AU)
			ND	ICI	ck *1	ck M901	ck M902	ck	oard IC6	oard IC2	oard IC202	oard IC5501	oard IC5502					IC2						IC3	
		Lens device	LCD block	LCD block	Mechanism deck	Mechanism deck	Mechanism deck	Mechanism deck	CD-294/317 board IC601	CF-079/080 board IC201	CF-079/080 board	PD-138/139 board	PD-138/139 board	PD-138/139 board	SI-028/029 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board	VC-254 board
Initialization of	Initialization of C, D, 8 page data	$\Box$																							
B,C,D,E,F,7,8	Initialization of B page data *2	$\perp$																				<u> </u>			$ldsymbol{f eta}$
page data	Initialization of E, F, 7 page data	Ļ							$\vdash$												<u> </u>	Щ	Ш		<u> </u>
	HALL adj.	•			-																<u> </u>	<u> </u>	Ш		$\vdash$
	Flange back adj.	1							•												<u> </u>	<u> </u>	Ш		_
	Optical axis adj.	•							•													_	Ш		<u> </u>
Camera	Color reproduction adj.	╄							•								•					_	Ш		<u> </u>
	AWB & LV standard data input	╄							•								•								L
	Auto white balance adj.	╄							•						_		•								<u> </u>
	Angular velocity sensor sens. adj.	丄													•								Ш		L
	VCO adj.	$\perp$								•													Ш		<u></u>
EVF	RGB AMP adj.	$\perp$																							<u> </u>
211	Contrast adj.	$\perp$																				•			
	COM DC adj. *5	$\perp$																							
	VCO adj.																								
	PSIG gray adj. *4																								
	RGB AMP adj.																								
	Black limit adj. *4																								
LCD	Contrast adj.	Т										•										•			
	Center level adj. *4											•													
	COM-AMP adj. *3	$\top$										•													
	V-COM adj.	$\top$		•								•											П		
	White balance adj.	$\top$	•	•								•		•									Н		
System control	Serial No. input	+		Ť					$\vdash$			_									Н		Н		$\vdash$
	REEL FG adj.	+							$\vdash$														Н		
	Switching position adj.	+			•	•			$\vdash$												Н	$\vdash$	$\forall$		$\vdash$
	AGC center level adj.	+			Ť	Ť			$\vdash$										•	•			H		$\vdash$
Servo & RF	APC & AEQ adj.	+					$\vdash$		$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$						•	•	Н		Н		$\vdash$
20110 C IG	PLL fo & LPF fo adj.	+		-					$\vdash$	-									•	•	Н	$\vdash$	$\vdash$		$\vdash$
	Hi8/Std8 switching position adj.	+			•				$\vdash$												H	$\vdash$	Н		$\vdash$
	CAP FG offset adj.	+		-	•		•		$\vdash$	$\vdash$		_									$\vdash$	$\vdash$			$\vdash$
	36MHz origin oscillation adj.	+			-		_		$\vdash$	$\vdash$						•					$\vdash$	$\vdash$			$\vdash$
	Chroma BPF fo adj.	+							$\vdash$	$\vdash$		$\vdash$									•	$\vdash$			$\vdash$
	S VIDEO OUT Y level adj.	+							$\vdash$												•	•	H		$\vdash$
Video	S VIDEO OUT chroma level adj.	+					$\vdash$		$\vdash$	$\vdash$			$\vdash$										$\vdash\vdash$		$\vdash$
	Hi8/Std8 Y/C level setting	+		-			$\vdash$		$\vdash$	$\vdash$		$\vdash$											$\vdash$		$\vdash$
	Hi8/Std8 AFC fo adj.	+							$\vdash$	-											Н	$\vdash$	•		$\vdash$
	IR video carrier frequency adj.	+					$\vdash$		$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$					_			$\vdash$	$\vdash$			$\vdash$
ID	IR video carrier frequency adj.  IR video deviation adj.	+							$\vdash$	_												$\vdash$			-
IR	IN VIUCO UCVIALIOII AUJ.	₩	_	-	_				$\vdash$	<u> </u>	_	_	$\vdash$		_				-			<u> </u>			
	3																								
	IR audio deviation adj.	╄							L		_	_	_								Ш	Ш			
	IR audio deviation adj. Hi8/Std8 AFM BPF fo adj.	$\pm$																					•		•
Audio	IR audio deviation adj. Hi8/Std8 AFM BPF fo adj. Hi8/Std8 AFM 1.5MHz deviation adj.																						•		•
Audio	IR audio deviation adj. Hi8/Std8 AFM BPF fo adj.						•																•		•

When replacing a board or EEPROM, adjust the items indicated by ● in the following table.

		Board EEPR						PRO	PROM							
			repl	aceı	nen	t_	repl	acen	nent							
Adjustment Section	Adjustment	CF-079/080 board (COMPLETE)	9 board (COMPLETE)	oard (COMPLETE) *2	PD-138/139 board (COMPLETE)	oard (COMPLETE)	oard IC1154 (FLASH MEMORY) *2	oard IC4502 (EEPROM)	oard IC4901 (EEPROM)							
	The second second	CF-079/08	SI-028/029 board	PC-082 board	PD-138/1	VC-254 board	PC-082 board	VC-254 board	VC-254 board							
Initialization of	Initialization of C, D, 8 page data	_				•		•								
B,C,D,E,F,7,8	Initialization of B page data *2 Initialization of E, F, 7 page data	⊢		•			•									
page data	HALL adj.	⊢				•	┝									
	Flange back adj.					•			•							
	Optical axis adj.	⊢				•			•							
Camera	Color reproduction adj.	⊢				•	$\vdash$									
Camera	AWB & LV standard data input															
	Auto white balance adj.	⊢														
	Angular velocity sensor sens. adj.															
	VCO adj.					•	$\vdash$		_							
EVF	RGB AMP adj.					•		•								
EVF	Contrast adj.	•				•		•								
	COM DC adj. *5	•				•		•								
	VCO adj.	Ť			•	•	$\vdash$	•								
	PSIG gray adj. *4	$\vdash$			•	•		•								
	RGB AMP adj.	Т			•	•		•								
	Black limit adj. *4	Г			•	•		•								
LCD	Contrast adj.				•	•		•								
	Center level adj. *4				•	•		•								
	COM-AMP adj. *3				•	•		•								
	V-COM adj.				•	•		•								
	White balance adj.				•	•		•								
System control	Serial No. input	Г				•		•								
	REEL FG adj.					•		•								
	Switching position adj.					•										
	AGC center level adj.															
Servo & RF	APC & AEQ adj.															
	PLL fo & LPF fo adj.															
	Hi8/Std8 switching position adj.															
	CAP FG offset adj.	L				•			•							
	36MHz origin oscillation adj.					•			•							
	Chroma BPF fo adj.							•								
Video	S VIDEO OUT Y level adj.					•		•								
Video	S VIDEO OUT chroma level adj.															
	Hi8/Std8 Y/C level setting					•			•							
	Hi8/Std8 AFC fo adj.	L				•	L		•							
	IR video carrier frequency adj.					•			•							
IR	IR video deviation adj.					•			•							
	IR audio deviation adj.	$ldsymbol{ldsymbol{ldsymbol{eta}}}$				•	<u> </u>		•							
	Hi8/Std8 AFM BPF fo adj.	_				•			•							
Audio	Hi8/Std8 AFM 1.5MHz deviation adj.					•			•							
	Hi8/Std8 AFM 1.7MHz deviation adj.	<u> </u>				•	_		•							
Mechanism	Tape path adj.															
	Table. 5-1-1(2).															

Table. 5-1-1(2).

- \*1: When replacing the drum assy or mechanism deck, reset the data of page: 2, address: A2 to A4 to "00". (Refer to "Record of Use check" of "5-4. SERVICE MODE")
- \*2: DCR-TRV325E/TRV330E/TRV430E/TRV530E
- \*3: DCR-TRV430E
- \*4: DCR-TRV230E/TRV235E/TRV325E/TRV330E/ TRV530E
- \*5: CF-079 board (Part No. suffix: 12 or later) CF-080 board (Part No. suffix: 13 or later)

Note: CD-294 board: DCR-TRV230E/TRV235E/

TRV325E/TRV330E

CD-317 board: DCR-TRV430E/TRV530E CF-079 board: DCR-TRV230E/TRV235E/

TRV325E/TRV330E

CF-080 board: DCR-TRV430E/TRV530E

PD-138 board: DCR-TRV430E

PD-139 board: DCR-TRV230E/TRV235E/

TRV325E/TRV330E/TRV530E SI-028 board: DCR-TRV230E/TRV235E/

TRV325E/TRV330E

SI-029 board: DCR-TRV430E/TRV530E

# 5-1. CAMERA SECTION ADJUSTMENT

# 1-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

## 1-1-1. List of Service Tools

• Oscilloscope • Color monitor

• Regulated power supply • Digital voltmeter

Ref. No.	Name	Parts Code	Usage
J-1	Filter for color temperature correction (C14)	J-6080-058-A	Auto white balance adjustment/check White balance adjustment/check
	ND filter 1.0	J-6080-808-A	White balance check
J-2	ND filter 0.4	J-6080-806-A	White balance check
	ND filter 0.1	J-6080-807-A	White balance check
J-3	Pattern box PTB-450	J-6082-200-A	
J-4	Color chart for pattern box	J-6020-250-A	
J-5	Adjustment remote commander (RM-95 upgraded) (Note1)	J-6082-053-B	
J-6	Siemens star chart	J-6080-875-A	For checking the flange back
J-7	Clear chart for pattern box	J-6080-621-A	
J-8	Multi CPC jig	J-6082-311-A	For adjusting the LCD block
J-9	CPC-13 jig	J-6082-443-A	For adjusting the video section For adjusting the color viewfinder
J-10	Power code (Note2)	J-6082-223-A	For connecting the battery terminal and DC power supply
J-11	Extension cable (100P 0.5mm)	J-6082-352-A	For extension between the PC-082 board (CN1901) and the VC-254 board (CN1104)
J-12	IR receiver jig	J-6082-383-A	For adjusting the IR transmitter
J-13	Minipattern box	J-6082-353-B	For adjusting the flange back
J-14	Camera base	J-6082-384-A	For adjusting the flange back

• Vectorscope

**Note1:** If the micro processor IC in the adjustment remote commander is not the new micro processor (UPD7503G-C56-12), the pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).

**Note2:** Connect the adjustment remote commander to the LANC jack, and set to HOLD switch to the "ADJ" side.




Fig. 5-1-1.

# 1-1-2. Preparations

**Note1:** For details of how remove the cabinet and boards, refer to "2. DISASSEMBLY".

**Note2:** When performing only the adjustments, the lens block and boards need not be disassembled.

- 1) Connect the equipment for adjustments according to Fig. 5-1-3.
- The front panel block (SI-028/029 board, focus ring, microphone unit) must be assembled because the focus ring is used for adjustments.

Note3: As removing the cabinet (R) (removing the VC-254 board CN1117) means removing the lithium 3V power supply (CF-079/080 board BT101), data such as date, time, user-set menus will be lost. After completing adjustments, reset these data. If the cabinet (R) has been removed, the self-diagnosis data, data on history of use (total drum rotation time etc.) will be lost. Before removing, note down the self-diagnosis data (data of page: 2, address: B0 to C6) and data on history use (data of page: 2, address: A2 to AA). (Refer to "5-4. Service Mode" for the self-diagnosis data and data on the history use.)

Note4: Setting the "Forced Camera Power ON" Mode

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 10, set data: 01, and press the PAUSE button.

The above procedure will enable the camera power to be turned on with the SS-1380 block removed. After completing adjustments, be sure to exit the "Forced Camera Power ON Mode".

Note5: Exiting the "Forced Camera Power ON" Mode

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: D, address: 10, set data: 00, and press the PAUSE button.
- 3) Select page: 0, address: 01, and set data: 00.




Fig. 5-1-2.




Fig. 5-1-3.

## 1-1-3. Precaution

## 1. Setting the Switch

Unless otherwise specified, set the switches as follows and perform adjustments without loading cassette.

1.	POWER switch (SS-1380 block) CAME	RA 8.	FOCUS switch (FP-282 flexible) MANUA
2.	NIGHT SHOT switch (Lens block)	FF 9.	BACK LIGHT (CF-079/080 board)OI
3.	DEMO MODE (Menu display)C	FF 10.	OI. PROGRAM AE (Menu display)OI
1.	DIGITAL ZOOM (Menu display)	FF 11.	. PICTURE EFFECT (Menu display)OI
5.	STEADY SHOT (Menu display)	FF 12.	2. DIGITAL EFFECT (Menu display)OI
5.	DISPLAY (Menu display)V-OUT/L	CD 13.	3. AUTO SHUTTER (Menu display)OI
7.	DISPLAY (CF-079/080 board)	ON 14.	4. 16:9 WIDE (MENU display)OI

# 2. Order of Adjustments

Basically carry out adjustments in the order given.




Fig.5-1-4.

# 3. Subjects

- Color bar chart (Color reproduction adjustment frame)
   When performing adjustments using the color bar chart, adjust the picture frame as shown in Fig. 5-1-4. (Color reproduction adjustment frame)
- Clear chart (Color reproduction adjustment frame)
   Remove the color bar chart from the pattern box and insert a clear chart in its place. (Do not perform zoom operations during this time.)
- 3) Flange back adjustment chart Make the chart shown in Fig. 5-1-5 using A0 size (1189mm × 841mm) black and white vellum paper.




Fig. 5-1-5.

**Note:** Use matte vellum paper bigger than A0, and make sure the edges of the black and white paper joined together are not rough.

# 1-2. INITIALIZATION OF B, C, D, E, F, 7, 8 PAGE DATA

## 1-2-1. INITIALIZATION OF C, D, 8 PAGE DATA

#### 1. Initializing the C, D, 8 Page Data

**Note1:** If "Initializing the C, D, 8 Page Data" is performed, all data of the C page, D page and 8 page will be initialized. (It is impossible to initialize a single page.)

**Note2:** If the C, D, 8 page data has been initialized, the following adjustments need to be performed again.

- 1) Modification of C, D, 8 page data
- 2) Serial No. input
- 3) Viewfinder system adjustments
- 4) LCD system adjustments
- 5) Servo and RF system adjustments
- 6) Video system adjustments

Adjusting page	С
Adjusting Address	10 to FF
Adjusting page	D
Adjusting Address	10 to FF
Adjusting page	8
Adjusting Address	00 to FF

#### **Initializing Method:**

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data
2	3	81	10	Set the data
3	3	80	0A	Set the data, and press the PAUSE button.
4	3	80		Check that the data changes to "1A"
5				Perform "Modification of C, D, 8 Page Data".

## 2. Modification of C, D, 8 Page Data

If the C, D, 8 page data has been initialized, change the data of the "Fixed data-2" address shown in the following tables by manual input.

#### **Modifying Method:**

- Before changing the data, select page: 0, address: 01, and set data: 01.
- New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

**Note:** If copy the data built in the different model, the camcorder may not operate.

- 3) When changing the data, press the PAUSE button of the adjustment remote commander each time when setting new data to write the data in the non-volatile memory.
- Check that the data of adjustment addresses is the initial value.
   If not, change the data to the initial value.

## Processing after Completing Modification of C, D, 8 Page data

Order	Page	Address	Data	Procedure
1	2	00	29	Set the data
2	2	01	29	Set the data, and press the PAUSE button.

**Note:** If the following symptoms occur after completing of the "Modification of C, D, 8 page data", check that the data of the "Fixed data-2" addresses of D page are same as those of the same model of the same destination.

- 1) The battery end mark on the LCD screen is flashing.
- 2) The power is shut off so that unit cannot operate.

## 3. C Page Table

Note: Fixed data-1: Initialized data. (Refer to "1. Initializing the C, D, 8 Page Data".)

Fixed data-2: Modified data. (Refer to "2. Modification of C, D, 8 Page Data".)

Remark	Page Data".)																																																																																										
00 to 0F         Switching position adj.           11         00           13         00           14 to 16         Fixed data-1           17         E0         REEL FG adj.           18         25         AEQ adj.           19         25         AEQ adj.           10         Fixed data-1           1B         25         AEQ adj.           1C         25         AEQ adj.           1C         25         AEQ adj.           1C         25         AEQ adj.           1E         25         AGC center level adj.           20         3E         PLL fo adj.           20         3E         PLL fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Cr level adj.           26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           20         To Steel data-1	Address	Initial value	Remark																																																																																								
Switching position adj.	00 to 0F	mitiai vaide	<u> </u>																																																																																								
11         00           12         00           13         00           14 to 16         Fixed data-1           17         E0         REEL FG adj.           18         25         AEQ adj.           19         25         AEQ adj.           10         Fixed data-1         AEQ adj.           10         Fixed data-1         AEQ adj.           11         BE         25         AGC center level adj.           15         3E         PLL fo adj.           20         3E         PLL fo adj.           20         3E         PLF fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out V level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           20 to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed dat		EE	Switching position adi.																																																																																								
12         00           13         00           14 to 16         Fixed data-1           17         E0         REEL FG adj.           18         25         AEQ adj.           19         25         AEQ adj.           10         Fixed data-1           1B         25         AEQ adj.           1C         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E         PLL fo adj.           20         3E         PLF fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           43         Fixed data-1           43			Switching position adj.																																																																																								
13																																																																																											
14 to 16         Fixed data-1           17         E0         REEL FG adj.           18         25         AEQ adj.           19         25         AEQ adj.           1A         Fixed data-1           1B         25         AEQ adj.           1C         25           1D         Fixed data-1           1E         25         AGC center level adj.           20         3E           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           43         Fixed data-1           43         Fixed data-1           44 to 48         Fixed data-2           44 to 48         Fixed data-2 <tr< td=""><td></td><td></td><td></td></tr<>																																																																																											
17			Fixed data-1																																																																																								
18         25         AEQ adj.           19         25         AEQ adj.           1A         Fixed data-1         Fixed data-1           1B         25         AEQ adj.           1C         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E         PLL fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           20         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-2           44 to 48         Fixed data-2           44 to 48         Fixed data-1           49         Fixed data-2           4A to 85         Fixed data-1		E0																																																																																									
19         25           1A         Fixed data-1           1B         25         AEQ adj.           1C         25           1D         Fixed data-1           1E         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E         PLL fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-2           44 to 48         Fixed data-2           44 to 48         Fixed data-2           4A to 85         Fixed data-1           86         Fixed data-2     <			_																																																																																								
1B         25         AEQ adj.           1C         25         Fixed data-1           1E         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           24 to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-2           44 to 48         Fixed data-1           49         Fixed data-2           4A to 85         Fixed data-1           86         Fixed data-2           87 to 88         Fixed data-1           89         Fixed data-1           89         Fixed data-2	19	25																																																																																									
1C         25           1D         Fixed data-1           1E         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E         PLL fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           44 to 48         Fixed data-2           44 to 85         Fixed data-1           86         Fixed data-2           87 to 88         Fixed data-1           89         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-2     <	1A		Fixed data-1																																																																																								
1C         25           1D         Fixed data-1           1E         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E         PLL fo adj.           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           44 to 48         Fixed data-2           44 to 85         Fixed data-1           86         Fixed data-2           87 to 88         Fixed data-1           89         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-2     <	1B	25	AEQ adj.																																																																																								
1E         25         AGC center level adj.           1F         3E         PLL fo adj.           20         3E           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-2           44 to 48         Fixed data-2           44 to 85         Fixed data-1           86         Fixed data-1           87 to 88         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-2           8A to 9A         Fixed data-2	1C	25																																																																																									
1F         3E         PLL fo adj.           20         3E           21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           43         Fixed data-2           44 to 48         Fixed data-1           49         Fixed data-1           40         Fixed data-1           86         Fixed data-1           87 to 88         Fixed data-1           89         Fixed data-1           89         Fixed data-1           89         Fixed data-1           9B         Fixed data-2	1D		Fixed data-1																																																																																								
20       3E         21       CA       APC adj.         22       99       LPF fo adj.         23 to 24       Fixed data-1         25       88       S VIDEO out Y level adj.         26       E3       S VIDEO out Cr level adj.         27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-1         40       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         80       Fixed data-1         89       Fixed data-1         9B       Fixed data-2	1E	25	AGC center level adj.																																																																																								
21         CA         APC adj.           22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cb level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           43         Fixed data-2           44 to 48         Fixed data-2           4A to 85         Fixed data-1           86         Fixed data-1           86         Fixed data-2           87 to 88         Fixed data-1           89         Fixed data-1           80         Fixed data-1           89         Fixed data-1           9B         Fixed data-2	1F	3E	PLL fo adj.																																																																																								
22         99         LPF fo adj.           23 to 24         Fixed data-1           25         88         S VIDEO out Y level adj.           26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           43         Fixed data-2           44 to 48         Fixed data-2           4A to 85         Fixed data-1           86         Fixed data-1           87 to 88         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-1           9B         Fixed data-2	20	3E																																																																																									
23 to 24       Fixed data-1         25       88       S VIDEO out Y level adj.         26       E3       S VIDEO out Cr level adj.         27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-1         40       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         80       Fixed data-2         81       Fixed data-1         82       Fixed data-2         83       Fixed data-1         84       Fixed data-1         85       Fixed data-1 <tr <="" td=""><td>21</td><td>CA</td><td>APC adj.</td></tr> <tr><td>25       88       S VIDEO out Y level adj.         26       E3       S VIDEO out Cr level adj.         27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         80       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>22</td><td>99</td><td>LPF fo adj.</td></tr> <tr><td>26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           43         Fixed data-2           44 to 48         Fixed data-1           49         Fixed data-1           40         Fixed data-1           86         Fixed data-1           87 to 88         Fixed data-1           89         Fixed data-1           80         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-2           Fixed data-2         Fixed data-2</td><td>23 to 24</td><td></td><td>Fixed data-1</td></tr> <tr><td>27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>25</td><td>88</td><td>S VIDEO out Y level adj.</td></tr> <tr><td>28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>26</td><td>E3</td><td>S VIDEO out Cr level adj.</td></tr> <tr><td>29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-1         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>27</td><td>A1</td><td>S VIDEO out Cb level adj.</td></tr> <tr><td>2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>28</td><td>04</td><td>Chroma BPF fo adj.</td></tr> <tr><td>2C     03     APC adj.       2D to 2F     Fixed data-1       30     E0     REEL FG adj.       31 to 42     Fixed data-1       43     Fixed data-2       44 to 48     Fixed data-1       49     Fixed data-2       4A to 85     Fixed data-1       86     Fixed data-2       87 to 88     Fixed data-1       89     Fixed data-1       8A to 9A     Fixed data-1       9B     Fixed data-2</td><td>29</td><td>20</td><td>PLL fo fine adj.</td></tr> <tr><td>2D to 2F Fixed data-1 30 E0 REEL FG adj. 31 to 42 Fixed data-1 43 Fixed data-2 44 to 48 Fixed data-1 49 Fixed data-2 4A to 85 Fixed data-1 86 Fixed data-1 87 to 88 Fixed data-1 89 Fixed data-1 89 Fixed data-1 99 Fixed data-1 Fixed data-1</td><td>2A to 2B</td><td></td><td>Fixed data-1</td></tr> <tr><td>30 E0 REEL FG adj.  31 to 42 Fixed data-1  43 Fixed data-2  44 to 48 Fixed data-1  49 Fixed data-2  4A to 85 Fixed data-1  86 Fixed data-1  87 to 88 Fixed data-1  89 Fixed data-1  89 Fixed data-1  99 Fixed data-2  Fixed data-2</td><td>2C</td><td>03</td><td>-</td></tr> <tr><td>31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>2D to 2F</td><td></td><td></td></tr> <tr><td>43 Fixed data-2 44 to 48 Fixed data-1 49 Fixed data-2 4A to 85 Fixed data-1 86 Fixed data-2 87 to 88 Fixed data-1 89 Fixed data-2 8A to 9A Fixed data-1 9B Fixed data-2</td><td></td><td>E0</td><td></td></tr> <tr><td>44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td></td><td></td><td></td></tr> <tr><td>49 Fixed data-2  4A to 85 Fixed data-1  86 Fixed data-2  87 to 88 Fixed data-1  89 Fixed data-2  8A to 9A Fixed data-1  9B Fixed data-2</td><td></td><td></td><td></td></tr> <tr><td>4A to 85 Fixed data-1  86 Fixed data-2  87 to 88 Fixed data-1  89 Fixed data-2  8A to 9A Fixed data-1  9B Fixed data-2</td><td></td><td></td><td></td></tr> <tr><td>86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td></td><td></td><td>Fixed data-2</td></tr> <tr><td>87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2</td><td>4A to 85</td><td></td><td>Fixed data-1</td></tr> <tr><td>89 Fixed data-2 8A to 9A Fixed data-1 9B Fixed data-2</td><td></td><td></td><td></td></tr> <tr><td>8A to 9A Fixed data-1 9B Fixed data-2</td><td></td><td></td><td></td></tr> <tr><td>9B Fixed data-2</td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td></tr> <tr><td>9C Fixed data-1</td><td></td><td></td><td></td></tr> <tr><td></td><td>9C</td><td></td><td>Fixed data-1</td></tr>	21	CA	APC adj.	25       88       S VIDEO out Y level adj.         26       E3       S VIDEO out Cr level adj.         27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         80       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	22	99	LPF fo adj.	26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           43         Fixed data-2           44 to 48         Fixed data-1           49         Fixed data-1           40         Fixed data-1           86         Fixed data-1           87 to 88         Fixed data-1           89         Fixed data-1           80         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-2           Fixed data-2         Fixed data-2	23 to 24		Fixed data-1	27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	25	88	S VIDEO out Y level adj.	28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         8A to 9A       Fixed data-1         9B       Fixed data-2	26	E3	S VIDEO out Cr level adj.	29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-1         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	27	A1	S VIDEO out Cb level adj.	2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	28	04	Chroma BPF fo adj.	2C     03     APC adj.       2D to 2F     Fixed data-1       30     E0     REEL FG adj.       31 to 42     Fixed data-1       43     Fixed data-2       44 to 48     Fixed data-1       49     Fixed data-2       4A to 85     Fixed data-1       86     Fixed data-2       87 to 88     Fixed data-1       89     Fixed data-1       8A to 9A     Fixed data-1       9B     Fixed data-2	29	20	PLL fo fine adj.	2D to 2F Fixed data-1 30 E0 REEL FG adj. 31 to 42 Fixed data-1 43 Fixed data-2 44 to 48 Fixed data-1 49 Fixed data-2 4A to 85 Fixed data-1 86 Fixed data-1 87 to 88 Fixed data-1 89 Fixed data-1 89 Fixed data-1 99 Fixed data-1	2A to 2B		Fixed data-1	30 E0 REEL FG adj.  31 to 42 Fixed data-1  43 Fixed data-2  44 to 48 Fixed data-1  49 Fixed data-2  4A to 85 Fixed data-1  86 Fixed data-1  87 to 88 Fixed data-1  89 Fixed data-1  89 Fixed data-1  99 Fixed data-2  Fixed data-2	2C	03	-	31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	2D to 2F			43 Fixed data-2 44 to 48 Fixed data-1 49 Fixed data-2 4A to 85 Fixed data-1 86 Fixed data-2 87 to 88 Fixed data-1 89 Fixed data-2 8A to 9A Fixed data-1 9B Fixed data-2		E0		44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2				49 Fixed data-2  4A to 85 Fixed data-1  86 Fixed data-2  87 to 88 Fixed data-1  89 Fixed data-2  8A to 9A Fixed data-1  9B Fixed data-2				4A to 85 Fixed data-1  86 Fixed data-2  87 to 88 Fixed data-1  89 Fixed data-2  8A to 9A Fixed data-1  9B Fixed data-2				86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2			Fixed data-2	87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	4A to 85		Fixed data-1	89 Fixed data-2 8A to 9A Fixed data-1 9B Fixed data-2				8A to 9A Fixed data-1 9B Fixed data-2				9B Fixed data-2								9C Fixed data-1					9C		Fixed data-1
21	CA	APC adj.																																																																																									
25       88       S VIDEO out Y level adj.         26       E3       S VIDEO out Cr level adj.         27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         80       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	22	99	LPF fo adj.																																																																																								
26         E3         S VIDEO out Cr level adj.           27         A1         S VIDEO out Cb level adj.           28         04         Chroma BPF fo adj.           29         20         PLL fo fine adj.           2A to 2B         Fixed data-1           2C         03         APC adj.           2D to 2F         Fixed data-1           30         E0         REEL FG adj.           31 to 42         Fixed data-1           43         Fixed data-2           44 to 48         Fixed data-1           49         Fixed data-1           40         Fixed data-1           86         Fixed data-1           87 to 88         Fixed data-1           89         Fixed data-1           80         Fixed data-1           89         Fixed data-2           8A to 9A         Fixed data-2           Fixed data-2         Fixed data-2	23 to 24		Fixed data-1																																																																																								
27       A1       S VIDEO out Cb level adj.         28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	25	88	S VIDEO out Y level adj.																																																																																								
28       04       Chroma BPF fo adj.         29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-1         8A to 9A       Fixed data-1         9B       Fixed data-2	26	E3	S VIDEO out Cr level adj.																																																																																								
29       20       PLL fo fine adj.         2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-1         4A to 85       Fixed data-1         86       Fixed data-1         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	27	A1	S VIDEO out Cb level adj.																																																																																								
2A to 2B       Fixed data-1         2C       03       APC adj.         2D to 2F       Fixed data-1         30       E0       REEL FG adj.         31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	28	04	Chroma BPF fo adj.																																																																																								
2C     03     APC adj.       2D to 2F     Fixed data-1       30     E0     REEL FG adj.       31 to 42     Fixed data-1       43     Fixed data-2       44 to 48     Fixed data-1       49     Fixed data-2       4A to 85     Fixed data-1       86     Fixed data-2       87 to 88     Fixed data-1       89     Fixed data-1       8A to 9A     Fixed data-1       9B     Fixed data-2	29	20	PLL fo fine adj.																																																																																								
2D to 2F Fixed data-1 30 E0 REEL FG adj. 31 to 42 Fixed data-1 43 Fixed data-2 44 to 48 Fixed data-1 49 Fixed data-2 4A to 85 Fixed data-1 86 Fixed data-1 87 to 88 Fixed data-1 89 Fixed data-1 89 Fixed data-1 99 Fixed data-1	2A to 2B		Fixed data-1																																																																																								
30 E0 REEL FG adj.  31 to 42 Fixed data-1  43 Fixed data-2  44 to 48 Fixed data-1  49 Fixed data-2  4A to 85 Fixed data-1  86 Fixed data-1  87 to 88 Fixed data-1  89 Fixed data-1  89 Fixed data-1  99 Fixed data-2  Fixed data-2	2C	03	-																																																																																								
31 to 42       Fixed data-1         43       Fixed data-2         44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	2D to 2F																																																																																										
43 Fixed data-2 44 to 48 Fixed data-1 49 Fixed data-2 4A to 85 Fixed data-1 86 Fixed data-2 87 to 88 Fixed data-1 89 Fixed data-2 8A to 9A Fixed data-1 9B Fixed data-2		E0																																																																																									
44 to 48       Fixed data-1         49       Fixed data-2         4A to 85       Fixed data-1         86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2																																																																																											
49 Fixed data-2  4A to 85 Fixed data-1  86 Fixed data-2  87 to 88 Fixed data-1  89 Fixed data-2  8A to 9A Fixed data-1  9B Fixed data-2																																																																																											
4A to 85 Fixed data-1  86 Fixed data-2  87 to 88 Fixed data-1  89 Fixed data-2  8A to 9A Fixed data-1  9B Fixed data-2																																																																																											
86       Fixed data-2         87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2			Fixed data-2																																																																																								
87 to 88       Fixed data-1         89       Fixed data-2         8A to 9A       Fixed data-1         9B       Fixed data-2	4A to 85		Fixed data-1																																																																																								
89 Fixed data-2 8A to 9A Fixed data-1 9B Fixed data-2																																																																																											
8A to 9A Fixed data-1 9B Fixed data-2																																																																																											
9B Fixed data-2																																																																																											
9C Fixed data-1																																																																																											
	9C		Fixed data-1																																																																																								

# C page

C page		
Address	Initial value	Remark
9D		Fixed data-2
9E		
9F to A4		Fixed data-1
A5		Fixed data-2
A6		Fixed data-1
A7		Fixed data-2
A8		
A9 to AE		Fixed data-1
AF		Fixed data-2
В0		
B1 to B6		Fixed data-1
В7		Fixed data-2
B8 to D5		Fixed data-1
D6		Fixed data-2
D7		(Modified data. Copy the data built in
D8		the same model.)
D9		
DA		
DB		
DC		
DD		
DE		
DF		
E0		
E1 to E5		Fixed data-1
E6		Fixed data-2
E7		Fixed data-1
E8	08	Serial No. input
E9	00	
EA	46	
EB	01	
EC	02	
ED	00	
EE	00	
EF	00	
F0 to F3		Fixed data-1
F4	00	Emergency memory address
F5	00	
F6	00	
F7	00	
F8	00	
F9	00	
FA	00	
FB	00	
FC	00	
FD	00	
FE	00	
FF	00	

Table. 5-1-2.

# 4. D Page Table

Note: Fixed data-1: Initialized data. (Refer to "1. Initializing the C, D, 8 Page Data".)
Fixed data-2: Modified data. (Refer to "2. Modification of C, D, 8

	_		
age i	Dat:	a".)	

Address	Initial value	Remark
00 to 0F		
10	00	Test mode
11 to 12		Fixed data-1
13		Fixed data-2
14		
15 to 1A		Fixed data-1
1B		Fixed data-2
1C to 1D		Fixed data-1
1E		Fixed data-2
1F		
20 to 22		Fixed data-1
23		Fixed data-2
24 to 26		Fixed data-1
27		Fixed data-2
28		(Modified data. Copy the data built in
29		the same model.)
2A to 2B		Fixed data-1
2C		Fixed data-2
2D		
2E to 2F		Fixed data-1
30		Fixed data-2
31		
32		Fixed data-1
33		Fixed data-2
34 to 43		Fixed data-1
44		Fixed data-2
45 to 47		Fixed data-1
48		Fixed data-2
49		
4A to 4D		Fixed data-1
4E		Fixed data-2
4F		Fixed data-1
50		Fixed data-2
51		(Modified data. Copy the data built in
52		the same model.)
53		
54		
55 to 57		Fixed data-1
58		Fixed data-2
59		(Modified data. Copy the data built in
5A		the same model.)
5B		
5C		
5D to 64		Fixed data-1
65		Fixed data-2
66		(Modified data. Copy the data built in
67		the same model.)
68		
69 to 6A		Fixed data-1
6B		Fixed data-2
6C to 83		Fixed data-1

# D page

D page		
Address	Initial value	Remark
84		Fixed data-2
85 to 86		Fixed data-1
87		Fixed data-2
88 to 8D		Fixed data-1
8E		Fixed data-2
8F		
90		
91		
92	87	VCO adj. (EVF)
93	6F	
94	27	Fixed data (*1)
		COM DC adj. (*2)
95	97	RGB AMP adj.(EVF)
96 to 98		Fixed data-1
99	37	Contrast adj. (EVF)
9A to 9F		Fixed data-1
A0		Fixed data-2
A1		
A2	80	VCO adj. (LCD)
A3	70	
A4	80/26	V-COM adj. (LCD)
A5	2B/B3	RGB AMP adj.(LCD)
A6	00/09	Fixed data (TRV430E)
		Black limit adj. (LCD) (TRV230E/
		TRV235E/TRV325E/TRV330E/TRV530E)
A7	B5/41	COM AMP adj. (LCD)
		(TRV430E)
		PSIG gray adj. (LCD) (TRV230E/
4.0	00	TRV235E/TRV325E/TRV330E/TRV530E)
A8	80	White balance adj. (LCD)
A9	80	G I' (I GD)
AA	3E/1A	Contrast adj. (LCD)
AB	00/4A	Fixed data (TRV430E)
		Center levei adj. (LCD) (TRV230E/
4.0		TRV235E/TRV325E/TRV330E/TRV530E)
AC		Fixed data-2
AD		Eined date 1
AE		Fixed data-1
AF		Fixed data-2
B0 to B7		Fixed data-1 Fixed data-2
B8		
B9 to BB		Fixed data-1
BC BD to D0		Fixed data-2
BD to D0		Fixed data-1 Fixed data-2
D1		
D2 to D6		Fixed data-1
D9 to FE		Fixed data-2 Fixed data-1
D8 to FF		FIXCU Udta-1

Note: XX/YY

XX: DCR-TRV430E

YY: DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E

\*1 : CF-079 board (Part No. suffix: 11) CF-080 board (Part No. suffix: 11 or 12) \*2 : CF-079 board (Part No. suffix: 12 or later) CF-080 board (Part No. suffix: 13 or later)

## Table. 5-1-3.

# 5. 8 Page Table

**Note:** Fixed data-1: Initialized data. (Refer to "1. Initializing the C, D, 8 Page Data".)

Fixed data-2: Modified data. (Refer to "2. Modification of C, D, 8 Page Data".)

Address	Remark
00 to 3F	Fixed data-1
40	Fixed data-2
41 to 78	Fixed data-1
79	Fixed data-2
7A to 8F	Fixed data-1
90	Fixed data-2
91 to FF	Fixed data-1

Table. 5-1-4.

# 1-2-2. INITIALIZATION OF B PAGE DATA (DCR-TRV325E/TRV330E/TRV430E/TRV530E)

**Note:** When reading the B page data, insert a "Memory Stick" into the "Memory Stick" slot.

## **Switch setting:**

POWER ...... MEMORY

# 1. Initializing the B Page Data

**Note:** If the B page data has been initialized, the following adjustments need to be performed again.

1) Modification of B page data

Adjusting page	В
Adjusting Address	00 to FF

## **Initializing Method:**

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	2	8F	03	Set the data, and press PAUSE button.
3	2	8F	00	Set the data, and press PAUSE button.
4	5	0E	00	Set the data, and press PAUSE button.
5	5	01	F3	Set the data, and press PAUSE button.
6	5	00	01	Set the data, and press PAUSE button.
7	5	0E		Check that the data changes to "01".
8				Perform "Modification of B Page Data".

## 2. Modification of B Page Data

If the B page data has been initialized, change the data of the "Fixed data-2" address shown in the following tables by manual input.

## **Preparations:**

Order	Page	Address	Data	Procedure
1	2	8F	03	Set the data, and press PAUSE button.
2	2	8F	00	Set the data, and press PAUSE button.

# **Modifying Method:**

- Before changing the data, select page: 0, address: 01, and set data: 01.
- 2) New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

**Note:** If copy the data built in the different model, the camcorder may not operate.

## When changing the data, don't press the PAUSE button.

# Processing after Completing Modification of B Page data:

Order	Page	Address	Data	Procedure
1	5	0E	00	Set the data, and press PAUSE button.
2	5	01	FB	Set the data, and press PAUSE button.
3	5	00	01	Set the data, and press PAUSE button.
4	5	0E		Check that the data changes to "01". (The change data are written in the flash memory.)
5	2	00	29	Set the data.
6	2	01	29	Set the data, and press PAUSE button.

# 3. B Page Table

Note: Fixed data-1: Initialized data. (Refer to "1. Initializing the B Page Data".)

Fixed data-2: Modified data. (Refer to "2. Modification of B Page Data".)

Address	Remark
00 to FF	Fixed data-1
	(Initialized data)

Table. 5-1-5.

# 1-2-3. INITIALIZATION OF E, F, 7 PAGE DATA

# 1. Initializing the E, F, 7 Page Data

**Note1:** If "Initializing the E, F, 7 Page Data" is performed, all data of the E page, F page and 7 page will be initialized. (It is impossible to

initialize a single page.)

**Note2:** If the E, F, 7 page data has been initialized, following adjustments need to be performed again.

- 1) Modification of E, F, 7 page data
- 2) Camera system adjustments
- 3) Servo and RF system adjustments
- 4) Video system adjustments
- 5) IR transmitter adjustments
- 6) Audio system adjustments

Adjusting page	F
Adjusting Address	10 to FF
Adjusting page	Е
Adjusting Address	00 to FF
Adjusting page	7
Adjusting Address	00 to FF

## **Initializing Method:**

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	6	00	51	Set the data.
3	6	01	51	Set the data, and press PAUSE button.
4	6	02		Check that the data changes to "01".
5				Perform "Modification of E, F, 7 Page Data".

# 2. Modification of E, F, 7 Page Data

If the E, F, 7 page data has been initialized, change the data of the "Fixed data-2" address shown in the following table by manual input.

## **Modifying Method:**

- Before changing the data, select page: 0, address: 01, and set data: 01.
- New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

**Note:** If copy the data built in the different model, the camcorder may not operate.

- 3) When changing the data, press the PAUSE button of the adjustment remote commander each time when setting new data to write the data in the non-volatile memory.
- Check that the data of adjustment addresses is the initial value.
   If not, change the data to the initial value.

# Processing after Completing Modification of E, F, 7 Page data

Order	Page	Address	Data	Procedure
1	2	00	29	Set the data
2	2	01	29	Set the data, and press the PAUSE
				button.

## 3. F Page Table

Note: Fixed data-1: Initialized data. (Refer to "1. Initializing the E, F, 7 Page Data".)

Fixed data-2: Modified data. (Refer to "2. Modification of E, F, 7 Page Data".)

Page	Data".)	
Address	Initial value	Remark
00 to 0F		
10	00	Emergency memory address
11	00	
12	00	
13	00	
14	00	
15	00	
16	00	
17	00	
18	00	
19	00	
1A	00	
1B	00	
1C to 22		Fixed data-1
23		Fixed data-2
24		(Modified data. Copy the data built in
25		the same model.)
26 to 2D		Fixed data-1
2E		Fixed data-2
2F to 37		Fixed data-1
38	4A	HALL adj.
39	70	
3A	8A	
3B		Fixed data-2
3C	80	Auto white balance & LV standard
3D	7A	data Input
3E	2B	
3F	80	
40	65	
41	80	
42	8D	Auto white balance adj.
43	87	P. 11. 1
44 to 46	22	Fixed data-1
47	33	Color reproduction adj.
48	34	Fixed data-1
49 4A to 4C	34	Color reproduction adj. Fixed data-1
4A to 4C	8C	36MHz origin osc. adj.
4E	2A	Flange back Adj.
4E 4F	18	Plange back Auj.
50	37	
51	0D	
52	13	
53	08	
54	6E	
55	00	
56	19	
57	00	
58	19	
59	00	
5A	00	
211		<u> </u>

# F page

F page		
Address	Initial value	Remark
5B	04	Flange back Adj.
5C	00	
5D	00	
5E	A7	Angular velocity sensor sensitivity
5F	A0	adj.
60	00	Optical axis adj.
61	00	Flange back Adj.
62	0A	Hi8/Std8 switching position adj.
63	00	
64	83	CAP FG offset adj.
65	50	Hi8/Std8 AFC fo adj.
66		Fixed data-1
67	65	Hi8/Std8 Y output level setting
68	72	Hi8/Std8 chroma output level setting
69 to 7A		Fixed data-1
7B	A6	Hi8/Std8 1.5MHz deviation adj.
7C	94	Hi8/Std8 1.7MHz deviation adj.
7D	80	Hi8/Std8 AFM BPF adj.
7E	41	IR video deviation adj.
7F	33	IR audio deviation adj.
80	C7	IR video carrier freq. adj.
81 to 8A	C/	Fixed data-1
		Fixed data-1
8B		
8C to 8D		Fixed data-1
8E		Fixed data-2
8F		
90 to 98		Fixed data-1
99		Fixed data-2
9A to AB		Fixed data-1
AC		Fixed data-2
AD		(Modified data. Copy the data built in
AE		the same model.)
AF		
B0		
B1		
B2		
B3 to B8		Fixed data-1
В9		Fixed data-2
BA		
BB to CC		Fixed data-1
CD		Fixed data-2
CE to D6		Fixed data-1
D7	FC	Color reproduction adj.
D8	F2	
D9 to DC		Fixed data-1
DD		Fixed data-2
DE to E0		Fixed data-1
E1		Fixed data-2
E2 to EA		Fixed data-1
EB		Fixed data-2
EC		
ED to FF		Fixed data-1
	1	Table 5.1.6

Table. 5-1-6.

# 4. E Page Table

**Note:** Fixed data-1: Initialized data. (Refer to "1. Initializing the E, F, 7 Page Data".)

Fixed data-2: Modified data. (Refer to "2. Modification of E, F, 7 Page Data".)

Page	Data".)
Address	Remark
00 to 04	Fixed data-1
05	Fixed data-2
06	
07 to 0E	Fixed data-1
0F	Fixed data-2
10	(Modified data. Copy the data built in
11	the same model.)
12	
13 to 17	Fixed data-1
18	Fixed data-2
19 to 1B	Fixed data-1
1C	Fixed data-2
1D	
1E to 33	Fixed data-1
34	Fixed data-2
35	Fixed data-1
36	Fixed data-2
37	Fixed data-1
38	Fixed data-2
39 to 3A	Fixed data-1
3B	Fixed data-2
3C to 50	Fixed data-1
51	Fixed data-2
52	Fixed data-1
53	Fixed data-2
54	Fixed data-1
55	Fixed data-2
56 to 58	Fixed data-1
59	Fixed data-2
5A to 5C	Fixed data-1
5D	Fixed data-2
5E	(Modified data. Copy the data built in
5F	the same model.)
60 to 6B	Fixed data-1
6C	Fixed data-2
6D to 71	Fixed data-1
72	Fixed data-2
73 to 7D	Fixed data-1
7E	Fixed data-2
7F to 8C	Fixed data-1
8D	Fixed data-2
8E to 9C	Fixed data-1
9D	Fixed data-2
9E to FF	Fixed data-1

Table. 5-1-7.

# 5. 7 Page Table

**Note:** Fixed data-1: Initialized data. (Refer to "1. Initializing the E, F, 7 Page Data".)

Fixed data-2: Modified data. (Refer to "2. Modification of E, F, 7 Page Data".)

	- Butti .)
Address	Remark
00 to A6	Fixed data-1
A7	Fixed data-2
A8	(Modified data. Copy the data built in
A9	the same model.)
AA	
AB	
AC to AE	Fixed data-1
AF	Fixed data-2
B0 to FF	Fixed data-1

Table. 5-1-8.

# 1-3. CAMERA SYSTEM ADJUSTMENTS

Before perform the camera system adjustments, check that the specified values of "VIDEO SYSTEM ADJUSTMENTS" are satisfied.

# 1. HALL Adjustment

For detecting the position of the lens iris, adjust AMP gain and offset.

Subject	Not required
Measurement Point	Display data of page 1 (Note1)
Measuring Instrument	Adjustment remote commander
Adjustment Page	F
Adjustment Address	38, 39, 3A
Specified Value 1	86 to 8A
Specified Value 2	14 to 18

**Note1:** Displayed data of page 1 of the adjustment remote commander.  $1:00: \underline{XX}$  IRIS display data

**Switch setting:** 

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	6	94	88	Set the data.
3	6	95	16	Set the data.
4	6	01	6D	Set the data, and press PAUSE button.
5	6	02		Check that the data changes to "01". (Note2)
6	6	01	00	Set the data, and press PAUSE button.

Note2: The adjustment data will be automatically input to page: F, address: 38, 39, 3A.

# **Checking method:**

Order	Page	Address	Data	Procedure
1	0	03	03	Set the data.
2	6	01	01	Set the data, and press PAUSE button.
3	1			Check that the IRIS display data (Note1) satisfies the specified value 1.
4	6	01	03	Set the data, and press PAUSE button.
5	1			Check that the IRIS display data (Note1) satisfies the specified value.2.

Order	Page	Address	Data	Procedure
1	6	94	00	Set the data.
2	6	95	00	Set the data.
3	6	01	00	Set the data, and press PAUSE
				button.
4	0	03	00	Set the data.
5	0	01	00	Set the data.

# 2. Flange Back Adjustment (Using Minipattern Box)

The inner focus lens flange back adjustment is carried out automatically. In whichever case, the focus will be deviated during auto focusing/manual focusing.

	-
Subject	Siemens star chart with ND filter for the minipattern box (Note1)
Measuring Instrument	Adjustment remote commander
Adjustment Page	F
Adjustment Address	4E to 5D, 61

Note1: Dark Siemens star chart.

**Note2:** Check that the data of page: 6, address: 02 is "00". If not, to page: 6, address: 01, set data: 00, and press the PAUSE button.

## Switch setting:

1)	POWER	CAMERA
2)	NIGHT SHOT	OFF

# **Preparations:**

- The minipattern box is installed as shown in the following figure.
  - Note: The attachment lenses are not used.
- Install the minipattern box so that the distance between it and the front of the lens of the camcorder is less than 3cm.
- Make the height of the minipattern box and the camcorder equal.
- Check that the output voltage of the regulated power supply is the specified voltage.
- Check that at both the zoom lens TELE end and WIDE end, the center of the Siemens star chart and center of the exposure screen coincide.

Specified voltage: The specified voltage varies according to the minipattern box, so adjust the power supply output voltage to the specified voltage written on the sheet which is supplied with the minipattern box.




Fig. 5-1-6.

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	6	82	01	Set the data.
3	6	01	13	Set the data, and press PAUSE button.
4	6	01	27	Set the data, and press PAUSE button.
5	6	02		Check that the data changes to "01". (Note3)

**Note3:** The adjustment data will be automatically input to page: F, address: 4E to 5D, 61.

Order	Page	Address	Data	Procedure
1	6	82	00	Set the data.
2	0	01	00	Set the data.
3				Turn off the power and turn on again.
4				Perform "Flange Back Check".

# 3. Flange Back Adjustment (Using Flange Back Adjustment Chart and Subject More Than 500m Away)

The inner focus lens flange back adjustment is carried out automatically. In whichever case, the focus will be deviated during auto focusing/manual focusing.

## 3-1. Flange Back Adjustment (1)

	· /
Subject	Flange back adjustment chart
	(2.0 m from the front of the protection
	glass)(Luminance: $350 \pm 50 \text{ lux}$ )
Measuring Instrument	Adjustment remote commander
Adjustment Page	F
Adjustment Address	4E to 5D, 61

**Note1:** Check that the data of page: 6, address: 02 is "00". If not, to page: 6, address: 01, set data: 00, and press the PAUSE button.

## Switch setting:

1)	POWER	. CAMERA
2)	NIGHT SHOT	OFF

## Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	6	82	01	Set the data.
3	6	01	13	Set the data, and press PAUSE button.
4	6	01	15	Set the data, and press PAUSE button.
5	6	02		Check that the data changes to "01". (Note2)

**Note2:** The adjustment data will be automatically input to page: F, address: 4E to 5D, 61.

# **Processing after Completing Adjustments:**

Order	Page	Address	Data	Procedure
1				Turn off the power and turn on again.
2				Perform "Flange Back Adjustment (2)"

## 3-2. Flange Back Adjustment (2)

Perform this adjustment after performing "Flange Back Adjustment (1)".

Subject	Subject more than 500m away (Subjects with clear contrast such as buildings, etc.)
Measurement Point	Check operation on TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	4E to 5D, 61

**Note1:** Check that the data of page: 6, address: 02 is "00". If not, to page: 6, address: 01, set data: 00, and press the PAUSE button.

## **Switch setting:**

- 1) POWER ......CAMERA
- 2) NIGHT SHOT ......OFF

#### **Preparations:**

 Set the zoom lens to the TELE end and expose a subject that is more than 500m away (subject with clear contrast such as building, etc.). (Nearby subjects less than 500m away should not be in the screen.)

## Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	6	82	01	Set the data.
3	6	01	13	Set the data, and press PAUSE button.
4				Place a ND filter on the lens so that the optimum image is obtain.
5	6	01	29	Set the data, and press PAUSE button.
6	6	02		Check that the data changes to "01".(Note2)

**Note2:** The adjustment data will be automatically input to page: F, address: 4E to 5D, 61.

1 rocessing arter Completing Aujustments.				
Order	Page	Address	Data	Procedure
1	6	82	00	Set the data.
2	0	01	00	Set the data.
3				Turn off the power and turn on again.
4				Perform "Flange Back Check".

# 4. Flange Back Check

Subject	Siemens star (2.0m from the front of the lens) (Luminance: approx. 200 lux)
Measurement Point	Check operation on TV monitor
Measuring Instrument	
Specified Value	Focused at the TELE end and WIDE end.

# Switch setting:

1)	POWER	CAMERA
2)	NIGHT SHOT	OFF

**Note:** When the auto focus is ON, the lens can be checked if it is focused or not by observing the data on the page 1 of the adjustment remote commander.

1) Select page: 0, address: 03, and set data: 0F.

2) Page 1 shows the state of the focus.

1:00: XX Odd: Focused Even: Unfocused

## **Checking method:**

- 1) Select page: 6, address: 40, and set data: 02.
- 2) Select page: 6, address: 41, and set data: 01.
- 3) Place the Siemens star 2.0m from the front of the lens.
- 4) To open the IRIS, decrease the luminous intensity to the Siemens star up to a point before noise appear on the image.
- 5) Shoot the Siemens star with the zoom TELE end.
- 6) Turn on the auto focus.
- 7) Check that the lens is focused (Note).
- 8) Select page: 6, address: 21, and set data: 10.
- 9) Shoot the Siemens star with the zoom WIDE end.
- 10) Observe the TV monitor and check that the lens is focused.

- 1) Select page: 6, address: 21, and set data: 00.
- 2) Select page: 6, address: 40, and set data: 00.
- 3) Select page: 6, address: 41, and set data: 00.
- 4) Select page: 0, address: 03, and set data: 00.

## 5. Optical Axis Adjustment

Align the lens Optical Axis with that of the CCD imager. If deviated, center of picture can lose focus when zoom is operated from the WIDE end to the TELE end.

Subject	Siemens star
Measurement Point	Check on the monitor TV
Measuring Instrument	
Adjustment Page	F
Adjustment Address	60

**Note:** This adjustment should be carried out upon completion of "Flange back adjustment".

## **Switch setting:**

1)	POWER	CAMERA
2)	DIGITAL ZOOM (Menu display)	OFF
3)	STEADY SHOT (Menu display)	OFF

#### Preparations before adjustments:

- Playback the monoscope segment of the system check tape (WR5-5CD).
- Attach the optical axis frame chart (transparent) on the monitor TV screen. Center of monoscope image and that that of optical axis frame must be agree.
- 3) Set to the camera mode.

#### Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: F, address: 60, set data: 00, and press the PAUSE button.
- 3) Place the Siemens star 2.0 m away from the front of the lens.
- 4) Shoot the Siemens star with the zoom TELE end.
- Point the lens toward the Siemens star chart until center of the Siemens star is located in the center of the optical axis frame.
- 6) Shoot the Siemens star with the zoom WIDE end.
- 7) Measure on the monitor TV screen in which area of the optical axis frame the center of the Siemens star is located. Measure the amount of displacement (distance between the center of the Siemens star and the center of the optical axis frame.) The measurement value is named L1.
- Read the correction data corresponding to the area from Table 5-1-9.
- Input the correction data to page: F, address: 60, and press the PAUSE button
- 10) Shoot the Siemens star with the zoom TELE end.
- 11) Point the lens toward the Siemens star chart until center of the Siemens star is located in the center of the optical axis frame.
- 12) Shoot the Siemens star with the zoom WIDE end.
- 13) Measure the amount of displacement (distance between the center of the Siemens star and the center of the optical axis frame.) The measurement value is named L2.
- 14) Compare the values L1 and L2, and confirm that L2 is smaller than L1. If L2 is lager than L1, select page: F, address: 60, set data: 00, and press the PAUSE button.

Area	Display phase	Correction data (Page: F, address: 60)
1	22.6° to 67.5°	01
2	67.6° to 112.5°	02
3	112.6° to 157.5°	03
4	157.6° to 202.5°	04
5	202.6° to 247.5°	05
6	247.6° to 292.5°	06
7	292.6° to 337.5°	07
8	337.6° to 22.5°	08

Table 5-1-9.

## **Processing after Completing Adjustments:**

1) Select page: 0, address: 01, and set data: 00.




Fig. 5-1-7.

# 6. Picture Frame Setting

Subject	Color bar chart
	(Color reproduction adjustment frame)
	(1.5m from the front of the lens)
Measurement Point	Video output terminal
Measuring Instrument	Oscilloscope and TV monitor
Specified Value	A=B, C=D, E=F

# **Switch setting:**

1)	POWER	. CAMERA
2)	NIGHT SHOT	OFF
3)	DIGITAL ZOOM (Menu display)	OFF
4)	STEADY SHOT (Menu display)	OFF

# **Setting method:**

- 1) Select page: 6, address: 82, and set data: 01.
- Adjust the zoom and the camera direction, and set to the specified position.
- Mark the position of the picture frame on the monitor display, and adjust the picture frame to this position in following adjustments using "Color reproduction adjustment frame".


# **Processing after Completing Camera System Adjustments:**

After completing the camera system adjustments, release the data settings.


1) Select page: 6, address: 82, and set data: 00.

# Check on the oscilloscope

# 1. Horizontal period



## 2. Vertical period



# Check on the monitor TV (Underscanned mode)




Fig. 5-1-10.

## 7. Color Reproduction Adjustment

Adjust the color Separation matrix coefficient so that proper color reproduction is produced.

Subject	Color bar chart (Color reproduction adjustment frame)
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	F
Adjustment Address	47, 49, D7, D8
Specified Value	All color luminance points should settle within each color reproduction frame.

# Switch setting:

1)	POWER	CAMERA
	NIGHT SHOT	
3)	DIGITAL ZOOM (Menu display)	OFF
4)	STEADY SHOT (Menu display)	OFF

## Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 6, address: 82, and set data: 01.
- 3) Select page: F, address: 8B, and write down the data.
- 4) Select page: F, address: 8B, set data: 29, and press the PAUSE button.
- 5) Select page: F, address: 2B, set data: 97, and press the PAUSE button.
- 6) Select page: 6, address: 01, set data: 3D, and press the PAUSE button.
- Adjust the GAIN and PHASE of the vectorscope, and adjust the burst luminance point to the burst position of the color reproduction frame.
- 8) Change the data of page: F, address: 47, 49, D7 and D8, settle each color luminance point in each color reproduction frame.
  Note: Be sure to press the PAUSE button of the adjustment remote commander before changing the addresses. If not, the new data will not be written to the memory.

- Select page: F, address: 8B, set the data written down at step
   and press the PAUSE button.
- 2) Select page: 6, address: 01, set data: 00, and press the PAUSE button
- 3) Select page: 6, address: 82, and set data: 00.
- 4) Select page: 0, address: 01, and set data: 00.




Fig. 5-1-11.

# 8. Auto White Balance & LV Standard Data Input

Adjust the white balance reference at 3200K, and adjust the normal coefficient of the light value.

Subject	Clear chart (Color reproduction adjustment frame)
Measuring Instrument	Adjustment remote commander
Adjustment Page	F
Adjustment Address	3C to 41

**Note1:** This adjustment should be carried out upon completion of "Color reproduction adjustments".

**Note2:** After the power is turned on, this adjustment can be done only once.

**Note3:** Check that the data of page: 6, address: 02 is "00". If not, to page: 6, address: 01, set data: 00, and press the PAUSE button.

# **Switch setting:**

1)	POWER	CAMERA
2)	NIGHT SHOT	OFF
3)	DIGITAL ZOOM (Menu display)	OFF
4)	STEADY SHOT (Menu display)	OFF

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	6	82	01	Set the data.
3	6	16	02	Set the data.
4				Wait for 2 sec.
5	6	01	11	Set the data, and press PAUSE button.
6	6	01	0D	Set the data, and press PAUSE button.
7	6	02		Check that the data changes to "01". (Note4)

**Note4:** The adjustment data will be automatically input to page: F, address: 3C to 41.

Order	Page	Address	Data	Procedure
1	6	01	00	Set the data, and press PAUSE button.
2	6	16	00	Set the data, and press PAUSE button.
3	6	82	00	Set the data.
4	0	01	00	Set the data.
5				Perform "Auto White Balance Adjustment".

# 9. Auto White Balance Adjustment

Adjust to the proper auto white balance output data.

If it is not correct, auto white balance and color reproducibility will be poor.

Subject	Clear chart
	(Color reproduction adjustment frame)
Filter	Filter C14 for color temperature
	correction
Measurement Point	Display data of page 1 (Note3)
Measuring Instrument	Adjustment remote commander
Adjustment Page	F
Adjustment Address	42, 43
Specified Value	R ratio: 2B20 to 2BA0
	B ratio: 5F20 to 5FE0

**Note1:** After the power is turned on, this adjustment can be done only once.

**Note2:** Perform "Auto White Balance & LV Standard Data Input" before this adjustment.

**Note3:** Displayed data of page 1 of the adjustment remote commander.

1 : XX : XX Display data

# **Switch setting:**

1)	POWER	CAMERA
2)	NIGHT SHOT	OFF
3)	DIGITAL ZOOM (Menu display)	OFF
4)	STEADY SHOT (Menu display)	OFF

# Adjusting method:

Order	Page	Address	Data	Procedure
1				Place the C14 filter for color temperature correction on the lens.
2	0	01	01	Set the data.
3	6	82	01	Set the data.
4	F	В8		Write down the data.
5	F	В8	2B	Set the data, and press PAUSE button.
6	F	В9		Write down the data.
7	F	В9	60	Set the data, and press PAUSE button.
8	F	BA		Write down the data.
9	F	BA	5F	Set the data, and press PAUSE button.
10	F	BB		Write down the data.
11	F	BB	80	Set the data, and press PAUSE button.
12	6	01	A7	Set the data, and press PAUSE button.
13				Wait for 2 sec.
14	6	01	A5	Set the data, and press PAUSE button.
15	6	02		Check that the data changes to "01". (Note4)
16	6	01	3F	Set the data, and press PAUSE button.
17	0	03	04	Set the data.
18	1			Check that the display data (Note3) satisfies the R ratio specified value.
19	0	03	05	Set the data.
20	1			Check that the display data (Note3) satisfies the B ratio specified value.

**Note4:** The adjustment data will be automatically input to page: F, address: 42, 43.

Onder	D	Addess	Dete	Dun an duna
Order	Page	Address	Data	Procedure
1	6	01	00	Set the data, and press PAUSE button.
2	6	82	00	Set the data.
3	F	В8		Set the data that is written down at step 4, and press PAUSE button.
4	F	В9		Set the data that is written down at step 6, and press PAUSE button.
5	F	BA		Set the data that is written down at step 8, and press PAUSE button.
6	F	BB		Set the data that is written down at step 10, and press PAUSE button.
7	0	03	00	Set the data.
8	0	01	00	Set the data.

# 10. White Balance Check

Subject	Clear chart (Color reproduction adjustment frame)
Filter	Filter C14 for color temperature correction  ND filter 1.0 and 0.4 and 0.1
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Specified Value	Fig. 5-1-12. A to B

# **Switch setting:**

1)	POWER	CAMERA
2)	NIGHT SHOT	OFF
3)	DIGITAL ZOOM (Menu display)	OFF
4)	STEADY SHOT (Menu display)	OFF

# Checking method:

Order	Page	Address	Data	Procedure
				Indoor white balance check
1				Check that the lens is not covered with either filter.
2	6	82	01	Set the data.
3	6	01	0F	Set the data, and press PAUSE button.
4				Check that the center of the white luminance point is within the circle shown Fig. 5-1-12. A.
5	6	01	00	Set the data, and press PAUSE button.
				Outdoor white balance check
6				Place the C14 filter on the lens.
7	6	01	3F	Set the data, and press PAUSE button.
8				Check that the center of the white luminance point is within the circle shown Fig. 5-1-12. B.
9				Remove the C14 filter.
				LV data check
10				Place the ND filter 1.5 (1.0+0.1+0.4) on the lens.
11	6	01	0F	Set the data, and press PAUSE button.
12				Wait for 2 sec.
13	0	03	06	Set the data.
14	1			Check that the display data (Note) satisfies the specified value.  Specified value: 0000 to 0BC0

**Note:** Displayed data of the adjustment remote commander.  $1: \underbrace{XX : XX}_{\text{Display data}}$ 

— Display data

Order	Page	Address	Data	Procedure
1	6	01	00	Set the data, and press PAUSE
				button.
2	6	82	00	Set the data.
3	0	03	00	Set the data.




Fig. 5-1-12. (A)




Fig. 5-1-12. (B)

# 11. Angular Velocity Sensor Sensitivity Adjustment

# **Precautions on the Parts Replacement**

There are two types of repair parts.

Type A: ENC03JA Type B: ENC03JB

Replace the broken sensor with a same type sensor. If replace with other type parts, the image will vibrate up and down or left and right during hand-shake correction operations. After replacing, readjust according to the adjusting method after replacement.

## **Precautions on Angular Velocity Sensor**

The sensor incorporates a precision oscillator. Handle it with care as if it dropped, the balance of the oscillator will be disrupted and operations will not be performed properly.

Subject	Arbitrary
Measurement Point	Display data of page 1 (Note1)
Measuring Instrument	Adjustment remote commander
Adjustment Page	F
Adjustment Address	5E, 5F
Specified Value	2900 to 4D00

Note1: Displayed data of the adjustment remote commander.

1 : XX : XX Display data

Note2: SI-028 board: DCR-TRV230E/TRV235E/TRV325E/TRV330E

SI-029 board: DCR-TRV430E/TRV530E

## **Switch setting:**

1)	STEADY SHOT (Menu display)	) ON
2)	700M	Contor

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	F	5E	A7	Set the data, and press PAUSE button.
3	F	5F	A0	Set the data, and press PAUSE button.
				Pitch sensor check (SI-028/029 board SE301)
4	0	03	11	Set the data.
5	1			Check that the display data (Note1) satisfies the specified value.
				Yaw sensor check (SI-028/029 board SE302)
6	0	03	12	Set the data.
7	1			Check that the display data (Note1) satisfies the specified value.

Order	Page	Address	Data	Procedure
1	0	01	00	Set the data.
2	0	03	00	Set the data.
3				Move the camcorder, and check that the steady shot operations have been performed normally

# 1-4. ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENT

Note1: When replacing the LCD unit, be careful to prevent damages

caused by static electricity.

Note2: Switch setting:

Note3: CF-079 board: DCR-TRV230E/TRV235E/TRV325E/TRV330E

CF-080 board: DCR-TRV430E/TRV530E

# [Adjusting connector]

Most of the measuring points for adjusting the viewfinder system are concentrated in CN1108 of VC-254 board.

Connect the Measuring Instruments via the CPC-13 jig (J-6082-443-A).

The following table shows the Pin No. and signal name of CN1108.

Pin No.	Signal Name	Pin No.	Signal Name
1	SWP	11	VCO
2	AFC F0	12	EVF VG
3	BPF MONI	13	DV RF SWP
4	FO ADJ RF IN	14	RF IN
5	PB RF	15	CAP FG
6	REG GND	16	RF MON
7	RF AGC OUT	17	TMS
8	VC RF SWP	18	TCK
9	EVF VR (*1), COM DC (*2)	19	TDO
10	EVF VB (*1), N.C. (*2)	20	TDI

\*1: CF-079 board (Part No. suffix: 11)

CF-080 board (Part No. suffix: 11 or 12)

\*2 : CF-079 board (Part No. suffix: 12 or later) CF-080 board (Part No. suffix: 13 or later)

Table 5-1-10.




Fig. 5-1-13.

# 1. VCO Adjustment (CF-079/080 board)

Set the VCO free-run frequency. If deviated, the EVF screen will be blurred.

Mode	Camera
Subject	Arbitrary
Measurement Point	Pin ① of CN1108 of VC-254 board (VCO)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	92, 93
Specified Value	$f = 15625 \pm 30$ Hz

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	92		Change the data and set the VCO frequency (f) to the specified value.
3	D	92		Press PAUSE button.
4	D	92		Read the data, and this data is named D <sub>92</sub> .
5				Convert D <sub>92</sub> to decimal notation, and obtain D <sub>92</sub> '. (Note)
6				Calculate D <sub>93</sub> ' using following equations (Decimal calculation) When D <sub>92</sub> '≥ 24 D <sub>93</sub> '= D <sub>92</sub> '-24 When D <sub>92</sub> '< 24 D <sub>93</sub> '= 0
7				Convert D93' to a hexadecimal number, and obtain D93. (Note)
8	D	93	D93	Set the data, and press PAUSE button.
9	0	01	00	Set the data.

**Note:** Refer to "Table 5-4-1. Hexadecimal-decimal Conversion Table".

# 2. RGB AMP Adjustment (CF-079/080 board)

Set the D range of the RGB driver used to drive the LCD to the specified value. If deviated, the LCD screen will become blackish or saturated (whitish).

Mode	Camera
Subject	Arbitrary
Measurement Point	Pin ② of CN1108 OF VC-254 board (EVF VG)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	95
Specified Value	$A = 7.44 \pm 0.10V$

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	95		Change the data and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value.
3	D	95		Press PAUSE button.
4	0	01	00	Set the data.

# 3. Contrast Adjustment (CF-079/080 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	Camera
Subject	Arbitrary
Measurement Point	Pin ② of CN1108 of VC-254 board (EVF VG)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	99
Specified Value	$A = 2.20 \pm 0.10V$

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	99		Change the data and set the voltage (A) between the 100 IRE and 0 IRE (pedestal) to the specified value. (The data should be "00" to "7F".)
3	D	99		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-14.




Fig. 5-1-15.

# 4. COM DC Adjustment

(CF-079 board (Part No. suffix: 12 or later)) (CF-080 board (Part No. suffix: 13 or later))

Set the reference level of the video signal for driving the LCD to an appropriate level. If deviated, the screen image will be whitish.

Mode	Camera
Subject	Arbitrary
Measurement Point	+ probe: Pin 1 of CN1108 of VC-254 board (EVF VG) – probe: Pin 9 of CN1108 of VC-254 board (COM DC)
Measuring Instrument	Digital volt meter
Adjustment Page	D
Adjustment Address	94
Specified Value	$A = +0.3 \pm 0.1 \text{Vdc}$

Order	Page	Address	Data	Procedure		
1	0	01	01	Set the data.		
2	D	94		Change the data and set the DC voltage (A) to the specified value. (The data should be "00" to "3F".)		
3	D	94		Press PAUSE button.		
4	0	01	00	Set the data.		

# 1-5. LCD SYSTEM ADJUSTMENT

**Note 1:** The back light (fluorescent tube) is driven by a high voltage AC power supply. Therefore, do not touch the back light holder to avoid electrical shock.

**Note 2:** When replacing the LCD unit, be careful to prevent damages caused by static electricity.

**Note 3:** Set the LCD BRIGHT to the center.

Set the LCD COLOR (Menu display) to the center.

Note 4: PD-138 board: DCR-TRV430E

PD-139 board: DCR-TRV230E/TRV235E/TRV325E/TRV330E/ TRV530E

#### [Adjusting connector]

Most of the measuring points for adjusting the LCD system are concentrated in CN5502 of the PD-138/139 board. Connect the measuring instruments via the multi CPC jig (J-6082-311-A). The following table shows the Pin No. and signal name of CN5502.

Pin No.	Signal Name	Pin No.	Signal Name
1	VB	2	XVD OUT
3	VG	4	PANEL COM/PSIG
5	VR	6	MAKER CHECK
7	XHD	8	XHD OUT
9	GND	10	GND

Table 5-1-11.




Fig. 5-1-16.

## [ LCD Type Check ]

By measuring the resistor value between Pin **(6)** of CN5502 and GND, the type of LCD can be discriminated.

Resistor value	4.7kΩ	22kΩ	33kΩ	47kΩ
LCD type	3.0 LCD TYPE SH (123k)	2.5 LCD TYPE SO (61k)	2.5 LCD TYPE SO (123k)	3.5 LCD TYPE SO (123k)
PD board	PD-138	PD-139	PD-139	PD-139
DCR-	TRV430E	TRV230E(*1) TRV330E(*1)	TRV235E TRV230E(*2) TRV325E TRV330E(*2)	TRV530E

\*1: Except AEP/UK model

\*2: AEP/UK model

Table 5-1-12.

## [ Adjusting Procedure]

PD-138 board:

- 1. VCO adjustment
- 2. RGB AMP adjustment
- 3. Contrast adjustment
- 4. COM AMP adjustment
- 5. V-COM adjustment
- 6. White balance adjustment

#### PD-139 board:

- 1. VCO adjustment
- 2. PSIG gray adjustment
- 3. RGB AMP adjustment
- 4. Black limit adjustment
- 5. Contrast adjustment
- 6. Center level adjustment
- 7. V-COM adjustment
- 8. White balance adjustment

# 1. VCO Adjustment (PD-138/139 board)

Set the VCO free-run frequency. If deviated, the LCD screen will be blurred.

Mode	VTR stop
Signal	No signal
Measurement Point	Pin (8) of CN5502 (HSY)
Measuring Instrument	Frequency counter
Adjustment Page	D
Adjustment Address	A2, A3
Specified Value	$f = 15625 \pm 30$ Hz

Note1: Refer to "LCD Type Check" for the discrimination of the LCD type.

## Adjusting method:

Order	ng met	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A2		Change the data and set the VCO frequency (f) to the specified value.
3	D	A2		Press PAUSE button.
4	D	A2		Read the data, and this data is named DA2.
5				Convert DA2 to decimal notation, and obtain DA2'. (Note2)
6				Calculate Da3' using following equations (Decimal calculation) [2.5 LCD TYPE SO (61k)] When Da2' $\geq$ 20 Da3' = Da2' - 20 When Da2' $<$ 20 Da3' = 0 [2.5 LCD TYPE SO (123k)] When Da2' $\geq$ 26 Da3' = Da2' - 26 When Da2' $\geq$ 26 Da3' = 0 [3.0 LCD TYPE SH (123k)] When Da2' $\geq$ 28 Da3' = Da2' - 28 When Da2' $\leq$ 28 Da3' = 0 [3.5 LCD TYPE SO (123k)] When Da2' $\leq$ 28 Da3' = 0 [3.5 LCD TYPE SO (123k)] When Da2' $\leq$ 9 Da3' = Da2' - 9 When Da2' $\leq$ 9 Da3' = Da2' - 9
7				Convert DA3' to a hexadecimal number, and obtain DA3. (Note2)
8	D	A3	D <sub>A</sub> 3	Set the data, and press PAUSE button.
9	0	01	00	Set the data.

Note2: Refer to "Table 5-4-1. Hexadecimal-decimal Conversion Table".

# 2. PSIG Gray Adjustment (PD-139 board) (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E)

Set the uniformity improvement signal to an appropriate level.

VTR stop
No signal
Pin 4 of CN5502 (PSIG)
Oscilloscope
D
A7
$A = 5.00 \pm 0.1V$

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A7		Change the data and set the PSIG signal level (A) to the specified value. (The data should be "00" to "7F")
3	D	A7		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-17.

# 3. RGB AMP Adjustment (PD-138 board) (DCR-TRV430E)

Set the D range of the RGB decoder used to drive the LCD to the specified value. If deviated, the LCD screen will become blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ③ of CN5502 (VG) External trigger: Pin ④ of CN5502 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	A5
Specified Value	3.0 LCD TYPE SH A = $3.72 \pm 0.05$ V

Note: Refer to "LCD Type Check" for the discrimination of the LCD type.

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A5		Change the data and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value. (The data should be "00" to "3F")
3	D	A5		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-18.

# 4. RGB AMP Adjustment (PD-139 board) (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E)

Set the D range of the RGB decoder used to drive the LCD to the specified value. If deviated, the LCD screen will become blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ③ of CN5502 (VG) External trigger: Pin ④ of CN5502 (PSIG)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	A5
Specified Value	2.5 LCD TYPE SO $A = 7.58 \pm 0.05V$ 3.5 LCD TYPE SO $A = 7.52 \pm 0.05V$

**Note:** Refer to "LCD Type Check" for the discrimination of the LCD type.

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A5		Change the data and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value. (The data should be "00" to "FF")
3	D	A5		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-19.


# 5. Black Limit Adjustment (PD-139 board) (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E)

Set the dynamic range of the LCD driver to an appropriate level. If deviated, the LCD screen will become blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement Point	Pin 4 of CN5502 (PSIG)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	A6
Specified Value	$A = 8.10 \pm 0.08V$

## Adjusting method:

Aujusu	Aujusting methou.					
Order	Page	Address	Data	Procedure		
1	0	01	01	Set the data.		
2	2	0E	61	Set the data.		
3	2	0F	53	Set the the data.		
4	D	A6		Change the data and set the PSIG signal amplitude (A) to the specified value. (The data should be "00" to "0F".)		
5	D	A6		Press PAUSE button.		
6	2	0E	00	Set the data.		
7	2	0F	00	Set the data.		
8	0	01	00	Set the data.		
9				Check that the specified value of "RGB AMP Adjustment" is satisfied.		



# 6. Contrast Adjustment (PD-138 board) (DCR-TRV430E)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ③ of CN5502 (VG) External trigger: Pin ④ of CN5502 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	AA
Specified Value	3.0  LCD TYPE SH A = $3.34 \pm 0.07 \text{V}$

Note: Refer to "LCD Type Check" for the discrimination of the LCD type.

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	AA		Change the data and set the voltage (A) between the 100 IRE and 0 IRE (pedestal) to the specified value. (The data should be "00" to "7F".)
3	D	AA		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-21.

# 7. Contrast Adjustment (PD-139 board) (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ③ of CN5502 (VG) External trigger: Pin ④ of CN5502 (PSIG)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	AA
Specified Value	2.5 LCD TYPE SO (61k) $A = 2.80 \pm 0.07V$ 2.5 LCD TYPE SO (123k) $A = 2.54 \pm 0.07V$ 3.5 LCD TYPE SO (123k) $A = 2.76 \pm 0.07V$

Note: Refer to "LCD Type Check" for the discrimination of the LCD type.

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	AA		Change the data and set the voltage (A) between the 100 IRE and 0 IRE (pedestal) to the specified value. (The data should be "00" to "7F".)
3	D	AA	·	Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-22.

# 8. Center Level Adjustment (PD-139 board) (DCR-TRV230E/TRV235E/TRV325E/TRV330E/TRV530E)

Set the video signal center level of LCD panel to an appropriate level.

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ③ of CN5502 (VG)
Measuring Instrument	Digital voltmeter
Adjustment Page	D
Adjustment Address	AB
Specified Value	$A = 7.00 \pm 0.03 Vdc$

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	AB		Change the data and set the DC voltage (A) to the specified value. (The data should be "00" to "7F".)
3	D	AB		Press PAUSE button.
4	0	01	00	Set the data.

# 9. COM AMP Adjustment (PD-138 board) (DCR-TRV430E)

Set the common electrode drive signal level of LCD to the specified value.

Mode	VTR stop
Signal	No signal
Measurement Point	Pin 4 of CN5502 (PANEL COM)
Measuring Instrument	Oscilloscope
Adjustment Page	D
Adjustment Address	A7
Specified Value	$A = 6.33 \pm 0.05V$

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A7		Change the data and set the PANEL COM signal level (A) to the specified value.
3	D	A7		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-1-23.

# 10. V-COM Adjustment (PD-138/139 board)

Set the DC bias of the common electrode drive signal of LCD to the specified value.

If deviated, the LCD display will move, producing flicker and conspicuous vertical lines.

Mode	VTR stop
Signal	No signal
Measurement Point	Check on LCD display
Measuring Instrument	
Adjustment Page	D
Adjustment Address	A4
Specified Value	The brightness difference between the section A and section B is minimum.

**Note:** This adjustment should be carried out upon completion of the following adjustments.

[PD-138 board]

RGB AMP Adjustment

Contrast Adjustment

COM AMP Adjustment

[PD-139 board]

RGB AMP Adjustment

Black Limit Adjustment

Contrast Adjustment

Center Level Adjustment

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A4		Change the data so that the brightness of the section A and that of the section B is equal. [PD-138 board] The data should be "00" to "FF". [PD-139 board] The data should be "00" to "3F".
3	D	A4		[PD-138 board] Subtract 8 from the data. [PD-139 board] Subtract 2 from the data.
4	D	A4		Press PAUSE button.
5	0	01	00	Set the data.




Fig. 5-1-24.

# 11. White Balance Adjustment (PD-138/139 board)

Correct the white balance.

If deviated, the reproduction of the LCD screen may degenerate.

Mode	VTR stop
Signal	No signal
Measurement Point	Check on LCD screen
Measuring Instrument	
Adjustment Page	D
Adjustment Address	A8, A9
Specified Value	The LCD screen should not be colored.

 $\textbf{Note1:} \quad \text{Check the white balance only when replacing the following parts.}$ If necessary, adjust them.

- 1. LCD panel
  2. Light induction plate
  3. IC5501

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	A8	80	Set the data, and press PAUSE button.
3	D	A9	80	Set the data, and press PAUSE button.
4	D	A9		Check that the LCD screen is not colored. If not colored, proceed to step 10.
5	D	A8		Change the data so that the LCD screen is not colored.
6	D	A8		Press PAUSE button.
7	D	A9		Change the data so that the LCD screen is not colored.
8	D	A9		Press PAUSE button.
9	D	A9		If the LCD screen is colored, repeat steps 5 to 9.
10	0	01	00	Set the data.

# 5-2. MECHANISM SECTION ADJUSTMENT

Mechanism Section adjustments, checks, and replacement of mechanism parts, refer to the separate volume "8mm Video Mechanism Adjustment Manual IX M2000 Mechanism".

# 2-1. Hi8/STANDARD8 MODE

# 2-1-1. OPERATING WITHOUT CASSETTE

- 1) Refer to "Section 2. DISASSEMBLY" and supply the power with the cabinet assembly removed. (So that the mechanical deck can be operated.)
- 2) Connect the adjustment remote commander to the LANC jack.
- 3) Turn on the HOLD switch of the adjustment remote commander.
- Close the cassette compartment without loading a cassette and complete loading.
- 5) Select page: 0, address: 01, and set data: 01.
- 6) Select page: F, address: 22, set data: 81, and press the PAUSE button of the adjustment remote commander.
- Select page: D, address: 10, set data: 10, and press the PAUSE button of the adjustment remote commander.
- 8) Disconnect the power supply of the unit, and connect it again.
- Select page: 2, address: 2E, and set data: 02.
   By carrying out the above procedure, the unit can be operated without loading a cassette. (Note2)

Be sure to carry out "Processing after Operations" after checking the operations.

Set the data of page: D, address: 10 to "12", if the sensor ineffective mode, forced VTR power supply ON mode is to be used together.

Note 2: Except for the camera recording mode.

#### [Procedure after checking operations]

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: F, address: 22, set data: 80, and press the PAUSE button of the adjustment remote commander.
- Select page: D, address: 10, set data: 00, and press the PAUSE button of the adjustment remote commander.
- 4) Select page: 2, address: 2E, and set data: 00.
- 5) Select page: 0, address: 01, and set data: 00.
- 6) Disconnect the power supply of the unit.

#### 2-1-2. TAPE PATH ADJUSTMENT

#### 1. Preparations for Adjustment

- 1) Clean the tape path face (tape guide, capstan shaft, pinch roller).
- 2) Connect the adjustment remote commander to the LANC jack.
- Turn on the HOLD switch of the adjustment remote commander.
- 4) Select page: 0, address: 01, and set data: 01.
- 5) Select page: 2, address: 2E, and set data: 02.
- Select page: F, address: 22, set data: 88, and press the PAUSE button of the adjustment remote commander. (Be sure to perform "Processing after operation" after completing adjustments.)
- Connect the oscilloscope to VC-254 board CN1108 via CPC-13 jig (J-6082-443-A).

Channel 1: VC-254 board, CN1108 Pin (5) External trigger: VC-254 board, CN1108 Pin (8)

- Playback Hi8/standard8 alignment tape for tracking. (WR5-1CP)
- 9) Check that the oscilloscope RF waveform is normal at the entrance and exit.

If not normal, adjust according to the separate volume "8mm Video Mechanical Adjustment Manual IX M2000 Mechanism".

10) Perform "Processing after operations", after completing adjustment.

## CN1108 of VC-254 board

Pin No.	Signal Name	Pin No.	Signal Name
1	SWP	11	VCO
2	AFC F0	12	EVF VG
3	BPF MONI	13	DV RF SWP
4	F0 ADJ RF IN	14	RF IN
5	PB RF	15	CAP FG
6	REG GND	16	RF MON
7	RF AGC OUT	17	TMS
8	VC RF SWP	18	TCK
9	EVF VR/COM DC	19	TDO
10	EVF VB/N.C.	20	TDI

Table 5-2-1.

#### [Procedure after operations]

- Connect the adjustment remote commander, and turn on the HOLD switch.
- 2) Select page: 0, address: 01, and set data: 01.
- 3) Select page: 2, address: 2E, and set data: 00.
- Select page: F, address: 22, set data: 80, and press the PAUSE button of the adjustment remote commander.
- 5) Select page: 0, address: 01, and set data: 00.
- 6) Remove the power supply from the unit.




Fig. 5-2-1.

#### 2-2. DIGITAL8 MODE

# 2-2-1. HOW TO ENTER RECORD MODE WITHOUT CASSETTE

- 1) Connect the adjustment remote commander to the LANC jack.
- Turn the HOLD switch of the adjustment remote commander to the ON position.
- 3) Close the cassette compartment without the cassette.
- Select page: 3, address: 01, and set data: 0C, and press the PAUSE button of the adjustment remote commander. (The mechanism enters the record mode automatically.)
   Note: The function buttons becomes inoperable.
- 5) To quit the record mode, select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander. (Whenever you want to quit the record mode, be sure to quit following this procedure.)

# 2-2-2. HOW TO ENTER PLAYBACK MODE WITHOUT CASSETTE

- 1) Connect the adjustment remote commander to the LANC jack.
- Turn the HOLD switch of the adjustment remote commander to the ON position.
- 3) Close the cassette compartment without the cassette.
- Select page: 3, address: 01, and set data: 0B, and press the PAUSE button of the adjustment remote commander. (The mechanism enters the playback mode automatically.)
   Note: The function buttons becomes inoperable.
- 5) To quit the playback mode, select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjustment remote commander. (Whenever you want to quit the playback mode, be sure to quit following this procedure.)

#### 2-2-3. OVERALL TAPE PATH CHECK

# 1. Recording of the tape path check signal

- Clean the tape running side (tape guide, capstan shaft, pinch roller).
- 2) Connect the adjustment remote commander to the LANC jack.
- Turn the HOLD switch of the adjustment remote commander to the ON position.
- 4) Set to the camera recording mode.
- 5) Select page: 3, address: 1C, set data: 5D, and press the PAUSE button of the adjustment remote commander.
- 6) Record for several minutes.
- 7) Release the recording mode.
- 8) Select page: 3, address: 1C, set data: 00, and press the PAUSE button.

## 2. Tape path check

- Clean the tape running side (tape guide, capstan shaft, pinch roller).
- 2) Connect the adjustment remote commander to the LANC jack.
- 3) Turn the HOLD switch of the adjustment remote commander to the ON position.
- Connect an oscilloscope to VC-254 board CN1108 via the CPC-13 jig (J-6082-443-A).

Channel 1: VC-254 board, CN1108 Pin (19) (Note)

External trigger: VC-254 board, CN1108 Pin (3)

**Note:** Connect a 75 $\Omega$  resistor between Pins (6) of CN1108 and (6) (GND).

- 5) Select page: 2, address: 2E, and set data: 01.
- 6) Playback the tape path check signal.
- 7) Select page: 3, address: 33, and set data: 08.
- 8) Select page: 3, address: 26, and set data: 31.
- Check that the oscilloscope RF waveform is flat at the entrance and exit.

If not flat, perform "2-1-2. TAPE PATH ADJUSTMENT " of "2-1. Hi8/STANDARD 8 MODE".

- 10) Select page: 3, address: 26, and set data: 00.
- 11) Select page: 3, address: 33, and set data: 00.
- 12) Select page: 2, address: 2E, and set data: 00.




Fig. 5-2-2.

## 5-3. VIDEO SECTION ADJUSTMENT

## 3-1. PREPARATIONS BEFORE ADJUSTMENTS

Use the following measuring instruments for video section adjustments.

# 3-1-1. Equipment to Required

- 1) TV monitor
- Oscilloscope (dual-phenomenon, band width above 30 MHz with delay mode) (Unless specified otherwise, use a 10:1 probe.)
- 3) Frequency counter
- 4) Pattern generator with video output terminal
- 5) Digital voltmeter
- 6) Audio generator
- 7) Audio level meter
- 8) Audio distortion meter
- 9) Audio attenuator
- 10) Regulated power supply
- 11) Digital8 alignment tapes
  - SW/OL standard (WR5-2D)

Parts code: 8-967-993-22

• Audio operation check for PAL (WR5-3CD)

Parts code: 8-967-993-37

• System operation check for PAL (WR5-5CD)

Parts code: 8-967-993-47

12) Hi8/standard8 alignment tapes

• For tracking adjustment (WR5-1CP)

Parts code: 8-967-995-07

• For video frequency characteristics adjustment (WR5-7CE)

Parts code: 8-967-995-18

• For checking Standard 8 mode operations

For LP (WR5-4CL)

Parts code: 8-967-995-56

For SP (WR5-5CSP)

Parts code: 8-967-995-47

Note: The following alignment tapes can also be used.

1) WR5-3CL (8-967-995-36)

2) WR5-4CSP (8-967-995-46)

• For checking Hi8 mode operations

For LP (WR5-8CLE)

Parts code: 8-967-995-57

For SP (WR5-8CSE)

Parts code: 8-967-995-48

• For Checking AFM stereo operations (WR5-9CS)

Parts code: 8-967-995-28

• For BPF adjustment (WR5-11CS)

Parts code: 8-967-995-76

- 13) Adjustment remote commander (J-6082-053-B)
- 14) CPC-13 jig (J-6082-443-A)
- 15) Power code (J-6082-223-A)

**Note:** Connect the adjustment remote commander to the LANC jack, and set the HOLD switch to the "ADJ" side.

- 16) IR receiver jig (J-6082-383-A)
- 17) Extension cable (100P, 0.5mm)(J-6082-352-A)

For extension between the PC-082 board (CN1901) and the VC-254 board (CN1104).

#### 3-1-2. Precautions on Adjusting

Note1: SI-028 board: DCR-TRV230E/TRV235E/TRV325E/TRV330E

SI-029 board: DCR-TRV430E/TRV530E

Note2: CF-079 board: DCR-TRV230E/TRV235E/TRV325E/TRV330E

CF-080 board: DCR-TRV430E/TRV530E

Note3: CD-294 board: DCR-TRV230E/TRV235E/TRV325E/TRV330E

CD-317 board: DCR-TRV430E/TRV530E

 The adjustments of this unit are performed in the VTR mode or camera mode.

To set to the VTR mode, set the power switch to "VCR or PLAYER" or set the "Forced VTR Power ON mode" using the adjustment remote commander (Note4).

To set to the Camera mode, set the power switch to "CAMERA" or set the "Forced Camera Power ON mode" using the adjustment remote commander (Note5).

After completing adjustments, be sure to exit the "Forced VTR Power ON Mode" or "Forced Camera Power ON Mode". (Note6)

2) The front panel block (SI-028/029 board, focus ring, microphone unit) need not be connected except during "IR transmitter adjustment" and "Audio adjustment". To remove, disconnect the following connector.

VC-254 board CN1116 (26P 0.5mm)

- 3) As removing the cabinet (R) assembly (removing CN1117 of the VC-254 board) means removing the lithium 3V power supply (BT101 on the CF-079/080 board), data such as date, time, user-set menus will be lost. After completing adjustments, reset these data. If the cabinet (R) assembly has been removed, the self-diagnosis data, data on history of use (total drum rotation time etc.) will be lost. Before removing, note down the self-diagnosis data (data of page: 2, address: B0 to C6) and the data on history use (data of page: 2, address: A2 to AA). (Refer to "5-4.Service Mode".)
- 4) The cabinet (R) assembly (CF-079/080 board, LCD block, viewfinder block) need not be connected to operate the VTR block. (Use the adjustment remote commander, to operate the VTR block.) When removing the cabinet (R) assembly, disconnect the following connector.
  - 1. VC-254 board CN1117 (45P 0.5mm)
  - 2. VC-254 board CN1120 (20P 0.8mm)
- The Memory stick connector need not be connected. To remove, disconnect the following connector.

(DCR-TRV325E/TRV330E/TRV430E/TRV530E)

PC-082 board CN1153 (12P 0.5mm)

- To open the PC-082 board, disconnect the following connectors. (DCR-TRV325E/TRV330E/TRV430E/TRV530E)
  - 1. PC-082 board CN1152 (6P 0.5mm)
  - 2. PC-082 board CN1901 (100P 0.5mm)

And use the following extension cable between the PC-082 board CN1901 and VC-254 board CN1104.

J-6082-352-A (100P, 0.5mm)

- 7) The lens block (CD-294/317 board) need not be connected. To remove, disconnect the following connectors.
  - 1. VC-254 board CN1501 (16P 0.5mm)
  - 2. VC-254 board CN1551 (24P 0.5mm)
- 8) By setting the "Forced VTR Power ON mode" or "Forced Camera Power ON mode", the video section can be operate even if the cabinet (L) assembly (SS-1380 block) has been removed. When removing the cabinet (L) assembly, disconnect the following connector.

FU-150/154 board CN402 (12P 0.8mm)

**Note4:** Setting the "Forced VTR Power ON" mode (VTR mode)

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 10, set data: 02, and press the PAUSE button

The above procedure will enable the VTR power to be turned on with the cabinet (L) assembly (SS-1380 block) removed.

After completing adjustments, be sure to exit the "Forced VTR Power ON mode".

**Note5:** Setting the "Forced Camera Power ON" mode (Camera mode)

1) Select page: 0, address: 01, and set data: 01.

Select page: D, address: 10, set data: 01, and press the PAUSE button.

The above procedure will enable the camera power to be turned on with the cabinet (L) assembly (SS-1380 block) removed. After completing adjustments, be sure to exit the "Forced Camera Power ON mode".


Note6: Exiting the "Forced Power ON" mode

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: D, address: 10, set data: 00, and press the PAUSE button
- 3) Select page: 0, address: 01, and set data: 00.

### 3-1-3. Adjusting Connectors

Some of the adjusting points of the video section are concentrated at VC-254 board CN1108. Connect the measuring instruments via the CPC-13 jig (J-6082-443-A). The following table lists the pin numbers and signal names of CN1108.

Pin No.	Signal Name	Pin No.	Signal Name
1	SWP	11	VCO
2	AFC F0	12	EVF VG
3	BPF MONI	13	DV RF SWP
4	FO ADJ RF IN	14	RF IN
5	PB RF	15	CAP FG
6	REG GND	16	RF MON
7	RF AGC OUT	17	TMS
8	VC RF SWP	18	TCK
9	EVF VR (*1), COM DC (*2)	19	TDO
10	EVF VB (*1), N.C. (*2)	20	TDI



CF-080 board (Part No. suffix: 11 or 12)

\*2 : CF-079 board (Part No. suffix: 12 or later) CF-080 board (Part No. suffix: 13 or later)

Table 5-3-1.




Fig. 5-3-1.

### 3-1-4. Connecting the Equipment

Connect the measuring instruments as shown in Fig. 5-3-2 and perform the adjustments.




Fig. 5-3-2.

### 3-1-5. Alignment Tape

The following table lists alignment tapes which are available. Use the tape specified in the signal column for each adjustment. If the type of tape to be used for checking operations is not specified, use whichever type.

### Digital8 alignment tape

Name	Usage
SW/OL standard (WR5-2D)	Switching position adjustment
Audio operation check (WR5-3CD),	Audio system adjustment
System operation check (WR5-5CD)	Operation check

## Hi8/standard 8 alignment tape

Name	Record -ing mode	Tape type	Tape speed	Usage
Tracking WR5-1CP	Standard 8	MP	SP	Tape path adjustment Switching position adjustment
Video frequency characteristics WR5-7CE	Hi8	ME	LP	Frequency characteristics adjustment
Operation check (SP mode) WR5-5CSP	Standard 8	MP	SP	
Operation check (SP mode) WR5-8CSE	Hi8	ME	SP	
Operation check (LP mode) WR5-4CL	Standard 8	MP	LP	Checking operations
Operation check (LP mode) WR5-8CLE	Hi8	ME	LP	
AFM stereo Operation check WR5-9CS	Standard 8	MP	SP	AFM stereo Checking operations
BPF adjustment WR5-11CS Standard		MP	SP	BPF adjustment

Tape type

ME ...... Particle type metal tape MP ...... Evaporated type metal tape

Fig.5-3-3. shows the 75% color bar signals recorded on the alignment tape.

**Note:** Measure using the VIDEO terminal (Terminated at  $75\Omega$ ).




Fig. 5-3-3. Color Bar Signal of the Alignment Tape

# 3-1-6. Input/output Level and Impedance

Video input/output

Special stereo minijack,  $1\mbox{Vp-p},75\Omega,$  unbalanced, sync negative S video input/output

4-pin mini DIN

Luminance signal: 1Vp-p,  $75\Omega$ , unbalanced, sync negative Chrominance signal: 0.300Vp-p,  $75\Omega$ , unbalanced

Audio input/output

Special stereo minijack:

Input: -7.5dBs, input impedance more than 47k $\Omega$ 

Output:–7.5dBs, (at load impedance 47k $\Omega$ ), impedance less than 2.2k $\Omega$ 

### 3-2. SYSTEM CONTROL SYSTEM ADJUSTMENT

### 1. Initialization of B, C, D, E, F, 7, 8 Page Data

If the B, C, D, E, F, 7, 8 page data is erased due to some reason, perform "1-2. INITIALIZATION OF B, C, D, E, F, 7, 8 PAGE DATA", of "5-1. CAMERA SECTION ADJUSTMENT".

### 2. Serial No. Input

### 2-1. Company ID Input

Write the company ID in the EEPROM (nonvolatile memory).

Page	С
Address	E8, E9, EA, EB, EC

#### Input method:

- 1) Select page: 0, address: 01, and set data: 01.
- Input the following data to page: C, addresses: E8 to EC.
   Note: Press the PAUSE button of the adjustment remote commander each time to set the data.

Address	Data
E8	08
E9	00
EA	46
EB	01
EC	02

3) Select page: 0, address: 01, and set data: 00.

### 2-2. Serial No. Input

Write the serial No. and model code in the EEPROM (nonvolatile memory). Convert the serial No. on the name plate from decimal to hexadecimal, and write in the EEPROM.

Page	С
Address	ED, EE, EF

#### Input method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Read the serial No. on the name plate, and take it as D<sub>1</sub>.

Example: If the serial No. is 77881.

 $D_1 = 77881$ 

**Note:** Use six digits of the low rank when a serial No. is more than seven digits.

B) Obtain D<sub>2</sub> and H<sub>1</sub> corresponding to D<sub>1</sub> from Table 5-3-2.

Example: If D<sub>1</sub> is "77881".

D<sub>2</sub>=D<sub>1</sub>-65536=12345

H<sub>1</sub>=FE

D₁ (Decimal)	D <sub>2</sub> (Decimal)	H <sub>1</sub> (Hexadecimal) (Service model code)
000001 to 065535	$\mathbf{D}_1$	FE
065536 to 131071	D <sub>1</sub> -65536	FE
131072 to 196607	Dı-131072	FE

Table 5-3-2.

4) Input H<sub>1</sub> to page: C, address: ED. (Model code input)

Example: If H<sub>1</sub> is "FE".

Select page: C, address: ED, set data: FE, and press the PAUSE button.

5) Obtain the maximum decimal not exceeding D<sub>2</sub> from Table 5-3-3, and take this as D<sub>3</sub>.

Example: If D<sub>2</sub> is "12345".

D<sub>3</sub>=12288

 Obtain the hexadecimal corresponding to D<sub>3</sub> from Table 5-3-3, and take this as H<sub>3</sub>.

Example: If D<sub>3</sub> is "12288".

H<sub>3</sub>=3000

7) Obtain the difference  $D_4$  between  $D_2$  and  $D_3$ . (Decimal calculation,  $0 \le D_4 \le 255$ )

 $D_4 = D_2 - D_3$ 

Example: If D<sub>2</sub> is "12345" and D<sub>3</sub> is "12288".

D<sub>4</sub>=12345-12288=57

8) Convert D<sub>4</sub> to hexadecimal, and take this as H<sub>4</sub>.

(Refer to "Hexadecimal-decimal conversion table" in "5-4. Service Mode".)

Example: If D<sub>4</sub> is "57".

H<sub>4</sub>=39

9) Input the upper 2 digits of H<sub>3</sub> to page: C, address: EE.

Example: If H<sub>3</sub> is "3000".

Select page: C, address: EE, set data: 30, and press the PAUSE button.

10) Input H<sub>4</sub> to page: C, address: EF.

Example: If H<sub>4</sub> is "39".

Select page: C, address: EF, set data: 39, and press the PAUSE button.

11) Select page: 0, address: 01, and set data: 00.

Decimal (D <sub>3</sub> )	Hexa- decimal (H <sub>3</sub> )														
0	0000	8192	2000	16384	4000	24576	6000	32768	8000	40960	A000	49152	C000	57344	E000
256	0100	8448	2100	16640	4100	24832	6100	33024	8100	41216	A100	49408	C100	57600	E100
512	0200	8704	2200	16896	4200	25088	6200	33280	8200	41472	A200	49664	C200	57856	E200
768	0300	8960	2300	17152	4300	25344	6300	33536	8300	41728	A300	49920	C300	58112	E300
1024	0400	9216	2400	17408	4400	25600	6400	33792	8400	41984	A400	50176	C400	58368	E400
1280	0500	9472	2500	17664	4500	25856	6500	34048	8500	42240	A500	50432	C500	58624	E500
1536	0600	9728	2600	17920	4600	26112	6600	34304	8600	42496	A600	50688	C600	58880	E600
1792	0700	9984	2700	18176	4700	26368	6700	34560	8700	42752	A700	50944	C700	59136	E700
2048	0800	10240	2800	18432	4800	26624	6800	34816	8800	43008	A800	51200	C800	59392	E800
2304	0900	10496	2900	18688	4900	26880	6900	35072	8900	43264	A900	51456	C900	59648	E900
2560	0A00	10752	2A00	18944	4A00	27136	6A00	35328	8A00	43520	AA00	51712	CA00	59904	EA00
2816	0B00	11008	2B00	19200	4B00	27392	6B00	35584	8B00	43776	AB00	51968	CB00	60160	EB00
3072	0C00	11264	2C00	19456	4C00	27648	6C00	35840	8C00	44032	AC00	52224	CC00	60416	EC00
3328	0D00	11520	2D00	19712	4D00	27904	6D00	36096	8D00	44288	AD00	52480	CD00	60672	ED00
3584	0E00	11776	2E00	19968	4E00	28160	6E00	36352	8E00	44544	AE00	52736	CE00	60928	EE00
3840	0F00	12032	2F00	20224	4F00	28416	6F00	36608	8F00	44800	AF00	52992	CF00	61184	EF00
4096	1000	12288	3000	20480	5000	28672	7000	36864	9000	45056	B000	53248	D000	61440	F000
4352	1100	12544	3100	20736	5100	28928	7100	37120	9100	45312	B100	53504	D100	61696	F100
4608	1200	12800	3200	20992	5200	29184	7200	37376	9200	45568	B200	53760	D200	61952	F200
4864	1300	13056	3300	21248	5300	29440	7300	37632	9300	45824	B300	54016	D300	62208	F300
5120	1400	13312	3400	21504	5400	29696	7400	37888	9400	46080	B400	54272	D400	62464	F400
5376	1500	13568	3500	21760	5500	29952	7500	38144	9500	46336	B500	54528	D500	62720	F500
5632	1600	13824	3600	22016	5600	30208	7600	38400	9600	46592	B600	54784	D600	62976	F600
5888	1700	14080	3700	22272	5700	30464	7700	38656	9700	46848	B700	55040	D700	63232	F700
6144	1800	14336	3800	22528	5800	30720	7800	38912	9800	47104	B800	55296	D800	63488	F800
6400	1900	14592	3900	22784	5900	30976	7900	39168	9900	47360	B900	55552	D900	63744	F900
6656	1A00	14848	3A00	23040	5A00	31232	7A00	39424	9A00	47616	BA00	55808	DA00	64000	FA00
6912	1B00	15104	3B00	23296	5B00	31488	7B00	39680	9B00	47872	BB00	56064	DB00	64256	FB00
7168	1C00	15360	3C00	23552	5C00	31744	7C00	39936	9C00	48128	BC00	56320	DC00	64512	FC00
7424	1D00	15616	3D00	23808	5D00	32000	7D00	40192	9D00	48384	BD00	56576	DD00	64768	FD00
7680	1E00	15872	3E00	24064	5E00	32256	7E00	40448	9E00	48640	BE00	56832	DE00	65024	FE00
7936	1F00	16128	3F00	24320	5F00	32512	7F00	40704	9F00	48896	BF00	57088	DF00	65280	FF00

Table 5-3-3.

### 3-3. SERVO AND RF SYSTEM ADJUSTMENT

Before perform the servo and RF system adjustments, check that the specified value of "36MHz Origin Oscillation Adjustment" of "VIDEO SYSTEM ADJUSTMENT" is satisfied.

### **Adjusting Procedure:**

- 1. REEL FG adjustment
- 2. PLL fo & LPF fo pre-adjustment
- 3. Switching position adjustment
- 4. AGC center level and APC & AEQ adjustment
- 5. PLL fo & LPF fo fine adjustment
- 6. Hi8/Standrd8 switching position adjustment
- 7. CAP FG offset adjustment

### 1. REEL FG Adjustment (VC-254 board)

Compensates the dispersion of the hall elements.

Measurement Point	Display data of page: 3, address: 03
Measuring Instrument	Adjustment remote commander
Adjustment Page	С
Adjustment Address	17, 30
Specified Value	00 or 01 or 04 or 05

### Adjusting method:

Order	Page	Address	Data	Procedure
1				Close the cassette compartment without inserting a cassette.
2	0	01	01	Set the data.
3	3	01	1C	Set the data, and press PAUSE button.
4	3	02		Check that the data changes to "00",
5	3	03		Check that the data is "00" or "01" or "04" or "05". (Note)
6	0	01	00	Set the data.

**Note:** If the data is other value, adjustment has errors. (Take an appropriate remedial measures according to the errors referring to the following table.)

Data	Contents of defect
02, 03, 06, 07	T reel is defective
08, 09, 0C, 0D	S reel is defective
0A, 0B, 0E, 0F	S reel and T reel are defective

### 2. PLL fo & LPF fo Pre-Adjustment (VC-254 board)

Mode	VTR stop
Measurement Point	Display data of page: 3, address: 03
Measuring Instrument	Adjustment remote commander
Adjustment Page	С
Adjustment Address	1F, 20, 22, 29
Specified Value	The data of page: 3, address: 02 is "00". The data of page: 3, address: 03 is "00".

#### Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	3	01	00	Set the data, and press PAUSE button.
3	3	01	30	Set the data, and press PAUSE button.
4	3	02		Check that the data changes to "00" within 10 sec. (Note)
5	3	03		Check that the data is "00". (Note)
6	0	01	00	Set the data.

**Note:** If it isn't satisfied, select page: C, address: 21, set the following data, and press the PAUSE button, and repeat steps 2 to 4.

	Setting data
When the data of page: C, address: 21 is "CA".	CE
When the data of page: C, address: 21 is "CE".	C6
When the data of page: C, address: 21 is "C6".	D2
When the data of page: C, address: 21 is "D2"	C2

If bit2, bit3, bit4, bit5 or bit6 of page: 3, address: 03 data is "1", there are errors.

For the error contents, see the following table. (For the bit values, refer to "5-4. SERVICE MODE", "4-3. 3. Bit value discrimination".)

Bit value of page: 3,	Error contents
address: 03 data	
bit $2 = 1$ or bit $3 = 1$	PLL fo fine adjustment is defective
bit $4 = 1$ or bit $5 = 1$	PLL fo adjustment is defective
bit 6 = 1	LPF fo is defective

### 3. Switching Position Adjustment (VC-254 board)

To obtain normal playback waveform output during the Digital8 playback mode, adjust the switching position.

1 / 3	81
Mode	VTR playback
Signal	SW/OL reference tape (WR5-2D)
Measurement Point	Display data of page: 3, address: 03
Measuring Instrument	Adjustment remote commander
Adjustment Page	С
Adjustment Address	10, 11, 12, 13
Specified Value	00

### Adjusting method:

Order	Page	Address	Data	Procedure
1				Insert the SW/OL reference tape and enter the VTR STOP mode.
2	0	01	01	Set the data.
3	3	21		Check that the data is "02". (Note1)
4	3	01	0D	Set the data, and press PAUSE button.
5	3	02		Check that the data changes to "00".
6	3	03		Check that the data is "00". (Note2)
7	С	10		Check that the data is other than "EE". (Note3)
8	0	01	00	Set the data.

**Note 1:** If the data of page: 3, address: 21 is "72", the tape top being played. After playing the tape for 1 to 2 seconds, stop it, perform step 4 and higher.

Note 2: If bit 0 of the data is "1", the A channel is defective. If bit 1 is "1", the B channel is defective. Contents of the defect is written into page: C, addresses: 10 and 12. See the following table. (For the bit values, refer to "5-4. SERVICE MODE", "4-3. 3. Bit value discrimination". ) If bit3 of the data is "1", the tape end being played, and adjustment has errors.

**Note 3:** If the data is "EE" rewind the tape and repeat steps 1 to 7.

### When the A channel is defective

Data of page:C,	Contents of defect
address:10	
EE	Writing into EEPROM (IC4502) is defective
E8	Adjustment data is out of range
E7	No data is returned from IC3301 (CAIN)

# When the B channel is defective

Data of page:C,	Contents of defect
address:12	
E8	Adjustment data is out of range
E7	No data is returned from IC3301 (CAIN)

### 4. AGC Center Level and APC & AEQ Adjustment

### 4-1. Preparations before adjustments

Mode	Camera recording
Subject	Arbitrary

Note: Use a Hi8 MP tape.

### Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	8	2A	C8	Set the data.
3				Record the camera signal for three minutes.


### 4-2. AGC Center Level Adjustment (VC-254 board)


Playback
Recorded signal at "Preparations before adjustments"
Pin ® of CN1108 (RF MON) (Note 1) Ext. trigger: Pin ® of CN1108 (DV RFSWP)
Oscilloscope
С
1E
The data of page: 3, address: 03 is "00"

**Note 1:** Connect a 75 $\Omega$  resistor between Pin (and Pin (GND) of CN1108. 75 $\Omega$  resistor (Parts code: 1-247-804-11)

Order	Page	Address	Data	Procedure
1				Playback the recorded signal at "Preparations before adjustments"
2	0	01	01	Set the data.
3	2	2E	01	Set the data.
4	3	33	08	Set the data.
5				Confirm that the playback RF signal is stable. (Fig. 5-3-4.)
6	3	01	23	Set the data, and press PAUSE button.
7	3	02		Check that the data is "00".
8	3	03		Check that the data is "00". (Note2)
9				Perform "APC & AEQ Adjustment".

**Note 2:** If the data of page: 3, address: 03 is other than "00", adjustment has errors.





# 4-3. APC & AEQ Adjustment (VC-254 board)

Mode	Playback
Signal	Recorded signal at "Preparations before adjustments"
	before adjustifients
Measurement Point	Pin (6) of CN1108 (RF MON) (Note 1) Ext. trigger: Pin (6) of CN1108 (DV RF SWP)
Measuring Instrument	Oscilloscope
Adjustment Page	С
Adjustment Address	18, 19, 1B, 1C, 21, 2C
Specified Value	The data of page: 3, address: 03 is "00"


**Note 1:** Connect a  $75\Omega$  resistor between Pin (6) and Pin (6) (GND) of CN1108

 $75\Omega$  resistor (Parts code: 1-247-804-11)

**Note 2:** The "AGC Center Level Adjustment" must have already been completed before starting this adjustment.

Aujusu			_	
Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	С	18	25	Set the data, and press PAUSE button.
3	С	19	25	Set the data, and press PAUSE button.
4	С	1B	25	Set the data, and press PAUSE button.
5	С	1C	25	Set the data, and press PAUSE button.
6	C	21	CA	Set the data, and press PAUSE button.
7	C	2C	03	Set the data, and press PAUSE button.
8				Playback the recorded signal at "Preparations before adjustments"
9	2	2E	01	
10	3	33	08	Set the data.
11				Confirm that the playback RF signal is stable. (Fig. 5-3-5.)
12	3	01	07	Set the data, and press PAUSE button.
13	3	02		Check that the data changes from "07" to "00" in about 20 seconds after pressing PAUSE button.
14	3	03		Check that the data is "00". (Note3)
15				Perform "Processing after Completing Adjustments".

**Note 3:** If the data is other than "00", adjustment has errors.



4-4. Processing after Completing Adjustments

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	2	2E	00	Set the data.
3	3	33	00	Set the data.
4	8	2A	00	Set the data, and press PAUSE button.
5	0	01	00	Set the data.

# 5. PLL fo & LPF fo Fine Adjustment (VC-254 board)

Mode	VTR stop
Signal	Arbitrary
Measurement Point	Display data of page: 3
Measuring Instrument	Adjustment remote commander
Adjustment Page	С
Adjustment Address	1F, 20, 22, 29
Specified Value	The data of page: 3, address: 02 is "00". The data of page: 3, address: 03 is "00".

### Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	3	01	30	Set the data, and press PAUSE button.
3	3	02		Check that the data changes to "00" within 10 sec.
4	3	03		Check that the data is "00". (Note)
5	0	01	00	Set the data.

**Note:** If bit2, bit3, bit4, bit5 or bit 6 of the data is "1", there are errors. For the error contents, see the following table. (For the bit values, refer to "5-4. SERVICE MODE", "4-3. 3. Bit value discrimination".)

Bit value of page: 3,	Error contents
address: 03	
bit $2 = 1$ or bit $3 = 1$	PLL fo fine adjustment is defective
bit $4 = 1$ or bit $5 = 1$	PLL fo adjustment is defective
bit 6 = 1	LPF fo is defective

# 6. Hi8/Standard8 Switching Position Adjustment (VC-254 board)

If deviated in this case causes switching noise or jitter on the Hi8/Standard8 mode played back screen.

Standardo mode prajed o	acii bereeiii
Mode	Playback
Signal	Hi8/Standard8 alignment tape:
	For tracking adjustment
	(WR5-1CP)
Measurement Point	CH1: Pin (8) of CN1108 (VC RF SWP)
	CH2: Pin ⑤ of CN1108 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	62, 63
Specified Value	$t1 = 0 \pm 10 \mu\text{sec}$

Order	Page	Address	Data	Procedure
1				Set to the stop mode.
2	0	01	01	Set the data.
3	F	22	C0	Set the data, and press PAUSE button.
4	2	2E	02	Set the data.
5				Set to the playback mode.
6	F	62		Change the data and minimize "t1". (Coarse adjustment)
7	F	62		Press PAUSE button
8	F	63		Change the data and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
9	F	63		Press PAUSE button
10	F	22	80	Set the data, and press PAUSE button.
11	2	2E	00	Set the data.
12	0	01	00	Set the data.




Fig. 5-3-6.

# 7. CAP FG Offset Adjustment (VC-254 board)

Set the Cap FG signal duty cycle to 50% to establish an appropriate capstan servo. If deviated, the uneven rotation of capstan and noise can occur in the Hi8/Standard8 LP mode.

Mode	Playback
Signal	Hi8/standard 8 alignment tape : For checking operation (WR5-5CSP)
Measurement Point	Pin (5) of CN1108 (CAP FG)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	64
Specified value	Duty = 50 ± 1 %

Order	Page	Address	Data	Procedure
1				Set to the stop mode.
2	0	01	01	Set the data.
3	2	2E	02	Set the data.
4				Set to the playback mode.
5	6	01	81	Set the data, and press PAUSE button.
6	6	02		Check that the data changes to "01".
7	6	01	00	Set the data, and press PAUSE button.
8				Check that Duty of CAP FG signal satisfies the specified value. If not, repeat steps 5 to 8.
9	2	2E	00	Set the data.
10	0	01	00	Set the data.




Fig. 5-3-7.

## 3-4. VIDEO SYSTEM ADJUSTMENTS

# 1. 36MHz Origin Oscillation Adjustment (VC-254 board)

Set the frequency of the clock for synchronization.

If deviated, the synchronization will be disrupted and the color will become inconsistent.

Mode	Camera
Subject	Not required
Measurement Point	Pin 16 of IC1502
Measuring Instrument	Frequency counter
Adjustment Page	F
Adjustment Address	4D
Specified Value	$f = 18000000 \pm 90$ Hz

## Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	F	4D		Change the data and set the frequency (f) to the specified value.
3	F	4D		Press PAUSE button.
4	0	01	00	Set the data.




Fig. 5-3-8.

## 2. Chroma BPF fo Adjustment (VC-254 board)


Set the center frequency of IC3701 chroma band-pass filter.

service requires	or res for emonia sand pass inter:
Mode	VTR stop
Signal	No signal
Measurement Point	CH1: Chroma signal terminal of S VIDEO OUT jack (75 $\Omega$ terminated) CH2: Y signal terminal of S VIDEO OUT jack (75 $\Omega$ terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	С
Adjustment Address	28
Specified Value	A = 100mVp-p or less B = 200mVp-p or more

## Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	11	10	Set the data, and press PAUSE button.
3				Check that the burst signal (B) is output to the chroma signal terminal of S VIDEO OUT jack.
4	3	0C	04	Set the data, and press PAUSE button.
5	С	28		Change the data for minimum amplitude of the burst signal level (A). (The data should be "00" to "07".)
6	С	28		Press PAUSE button.
7	3	0C	00	Set the data, and press PAUSE button.
8				Check that the burst signal level (B) satisfies the specified value.
9	D	11	00	Set the data, and press PAUSE button.
10	0	01	00	Set the data.

### When the data of page: 3, address: 0C, is 04:



When the data of page: 3, address: 0C, is 00:




Fig. 5-3-9.

# 3. S VIDEO OUT Y Level Adjustment (VC-254 board)

Mode	VTR stop
Signal	No signal
Measurement Point	Y signal terminal of S VIDEO OUT jack (75 $\Omega$ terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	С
Adjustment Address	25
Specified Value	$A = 1000 \pm 20 \text{mV}$

### Adjusting method:

Aajusting methoa:						
Order	Page	Address	Data	Procedure		
1	0	01	01	Set the data.		
2	D	11	10	Set the data, and press PAUSE button.		
3	3	0C	02	Set the data, and press PAUSE button.		
4	С	25		Change the data and set the Y signal level (A) to the specified value.		
5	С	25		Press PAUSE button.		
6	3	0C	00	Set the data, and press PAUSE button.		
7	D	11	00	Set the data, and press PAUSE button.		
8	0	01	00	Set the data.		




Fig. 5-3-10.

# 4. S VIDEO OUT Chroma Level Adjustment (VC-254 board)

Mode	VTR stop		
Signal	No signal		
Measurement Point	Chroma signal terminal of S VIDEO OUT jack (75 $\Omega$ terminated) External trigger: Y signal terminal of S VIDEO OUT jack		
Measuring Instrument	Oscilloscope		
Adjustment Page	С		
Adjustment Address	26, 27		
Specified Value	Cr level: $A = 700 \pm 14 \text{mV}$ Cb level: $B = 700 \pm 14 \text{mV}$ Burst level: $C = 300 \pm 6 \text{mV}$		

Adjusting method:					
Order	Page	Address	Data	Procedure	
1	0	01	01	Set the data.	
2	D	11	10	Set the data, and press PAUSE button.	
3	3	0C	02	Set the data, and press PAUSE button.	
4	С	26		Change the data and set the Cr signal level (A) to the specified value.	
5	С	26		Press PAUSE button.	
6	С	27		Change the data and set the Cb signal level (B) to the specified value.	
7	С	27		Press PAUSE button.	
8				Check that the burst signal level (C) is satisfied the specified value.	
9	3	0C	00	Set the data, and press PAUSE button.	
10	D	11	00	Set the data, and press PAUSE button.	
11	0	01	00	Set the data.	




Fig. 5-3-11.

# 5. VIDEO OUT Y, Chroma Level Check (VC-254 board)

Mode	VTR stop
Signal	No signal
Measurement Point	Video terminal of AUDIO/VIDEO jack (75 $\Omega$ terminated)
Measuring Instrument	Oscilloscope
Specified Value	Sync level: $A = 307 \pm 18 \text{mV}$ Burst level: $B = 300 \pm 18 \text{mV}$

### Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	11	10	Set the data, and press PAUSE button.
3	3	0C	02	Set the data, and press PAUSE button.
4				Check that the sync signal level (A) satisfies the specified value.
5				Check that the burst signal level (B) satisfies the specified value.
6	3	0C	00	Set the data, and press PAUSE button.
7	D	11	00	Set the data, and press PAUSE button.
8	0	01	00	Set the data.




Fig. 5-3-12.

# 6. Hi8/Standard8 Y/C Output Level Setting (VC-254 board)

Set the Y/C signal output level during the Hi8/Standard8 playback mode.

Mode	VTR stop
Signal	No signal
Adjustment Page	F
Adjustment Address	67, 68

**Note:** Perform this adjustment when IC2201 or IC4901 is replaced.

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	10	02	Set the data, and press PAUSE button.
3	6	6F	01	Set the data.
4	6	7F		Check that the data. When the data is "00", proceed to step 8. When the data is "03", proceed to step 5.
5	F	67	65	Set the data, and press PAUSE button.
6	F	68	72	Set the data, and press PAUSE button.
7				Proceed to step 10.
8	F	67	A0	Set the data, and press PAUSE button.
9	F	68	В8	Set the data, and press PAUSE button.
10	6	6F	00	Set the data.
11	D	10	00	Set the data, and press PAUSE button.
12	0	01	00	Set the data.

# 7. Hi8/standard 8mm AFC fo Adjustment

(VC-254 board)
Adjust the pull-in range of the clock generator (IC2201) for A/D conversion during Hi8/standard 8mm playback.

	2 2
Mode	VTR stop
Signal	No signal
Measurement Point	Pin ② of CN1108 (AFC f0)
Measuring Instrument	Digital voltmeter
Adjustment Page	F
Adjustment Address	65
Specified Value	A=1.40 ± 0.05Vdc
	Or the data of page: 6, address: 6E is "7C" to "84"

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	D	10	02	Set the data, and press PAUSE button.
3	3	0D	04	Set the data, and press PAUSE button.
4	6	63	04	Set the data.
5	6	6F	01	Set the data.
6	F	65	50	Set the data, and press PAUSE button.
7	6	01	C5	Set the data, and press PAUSE button.
8	6	02		Check that the data is "01".
9	6	01	00	Set the data, and press PAUSE button.
10	6	6E		Check that the data satisfies the specifies value. Or check that the DC voltage (A) satisfies the specified value. If outside, repeat steps 6 to 10.
11	3	0D	00	Set the data, and press PAUSE button.
12	6	63	00	Set the data.
13	6	6F	00	Set the data.
14	D	10	00	Set the data, and press PAUSE button.
15	0	01	00	Set the data.

## 3-5. IR TRANSMITTER ADJUSTMENTS

Adjust using the IR receiver jig (J-6082-383-A).

Note: If the distance between the IR receiver jig and the camcorder is below 1m, cover the LASER LINK emitter with a ND filter. (For example, when the distance is 30cm to 50cm, cover the LASER LINK emitter with a ND filter 1.0.)

### **Switch setting:**

SUPER LASER LINK ...... ON (Red LED is lit)

### IR Video Carrier Frequency Adjustment (VC-254 board)

Mode	VTR stop
Signal	Arbitrary
Measurement Point	Pin (5) of CN003 of IR receiver jig (RF) (Or Pin (6) of IC3901 of VC-254 board)
Measuring Instrument	Frequency counter
Adjustment Page	F
Adjustment Address	80
Specified Value	$f = 11.55 \pm 0.05 \text{ MHz}$

### **Connection of Equipment:**

Connect the measuring device as shown in the following figure, and adjust.




Fig. 5-3-13.

# Adjusting method:

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	3	0C	08	Set the data, and press PAUSE button.
3	F	80		Change the data, and set the video carrier frequency (f) to the specified value.
4	F	80		Press PAUSE button.
5	3	0C	00	Set the data, and press PAUSE button.
6	0	01	00	Set the data.

# 2. IR Video Deviation Adjustment (VC-254 board)

Mode	VTR stop
Signal	Arbitrary
Measurement Point	VIDEO OUT terminal of IR receiver jig (Terminated at $75\Omega$ )
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	7E
Specified Value	$A = 0.82 \pm 0.05 \text{ V}$

### **Connection of Equipment:**

Connect the measuring device as shown in the following figure, and adjust.





Fig. 5-3-14.

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2	3	0C	01	Set the data, and press PAUSE button.
3	F	7E		Change the data, set the video signal amplitude (A) to the specified value.
4	F	7E		Press PAUSE button.
5	3	0C	00	Set the data, and press PAUSE button.
6	0	01	00	Set the data.



# 3. IR Audio Deviation Adjustment (VC-254 board)

Mode	VTR stop
Signal	Video: No signal Audio: 400Hz, -7.5dBs, Audio left and right terminal of AUDIO/VIDEO jack
Measurement Point	AUDIO L terminal and AUDIO R terminal of IR receiver jig (Terminated at $47k\Omega$ )
Measuring Instrument	Audio level meter
Adjustment Page	F
Adjustment Address	7F
Specified Value	Signal level: -7.5 ± 1.0 dBs Level difference of L and R: Below 2dB

### **Connection of Equipment:**

Connect the measuring device as shown in the following figure, and adjust.




Fig. 5-3-16.

Order	Page	Address	Data	Procedure
1	0	01	01	Set the data.
2				Connect the audio level meter to the AUDIO L terminal of the IR receiver jig.
3	F	7F		Change the data and set the 400Hz audio signal level to the specified value.
4	F	7F		Press PAUSE button.
5				Connect the audio level meter to the AUDIO R terminal of the IR receiver jig.
6	F	7F		Check that the 400Hz audio signal level is within the specified value. If outside, repeat from step 2.
7	0	01	00	Set the data.

### 3-6. AUDIO SYSTEM ADJUSTMENTS

#### [Connecting the measuring instruments for the audio]

Connect the audio system measuring instruments in addition to the video system measuring instruments as shown in Fig. 5-3-17.

### [Adjustment Procedure]

- 1) Hi8/Standard8 AFM BPF fo adjustment
- 2) Hi8/Standard8 AFM 1.5MHz deviation adjustment
- 3) Hi8/Standard8 AFM 1.7MHz deviation adjustment
- 4) Digital8 playback level check
- 5) Overall level characteristics check
- 6) Overall distortion check
- 7) Overall noise level check
- 8) Overall separation check




Fig. 5-3-17.

### Hi8/Standard8 AFM BPF fo Adjustment (VC-254 board)

Sets the BPF passing frequency of IC5701 so that the AFM signal can separate from the playback RF signal properly. If deviated, the mono/stereo mode will be differentiated incorrectly, and noises and distortions will increase during high volume playback.

	<u> </u>
Mode	Playback
Signal	Hi8/Standard8 alignment tape: For BPF adjustment (WR5-11CS)
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Distortion meter
Adjustment Page	F
Adjustment Address	7D
Specified Value	The Main and Sub channel distortion rate should be almost the same (within $\pm 1\%$ ) and minimum.

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Set the Hi-Fi SOUND switch (menu display) to "2".
- Select page: F, address: 7D, change the data and minimize the distortion rate.
- 4) Press the PAUSE button.
- 5) Set the Hi-Fi SOUND switch (menu display) to "1".
- 6) Select page: F, address: 7D, change the data and minimize the distortion rate.
- 7) Press the PAUSE button.
- 8) Repeat steps 2) to 7) and set the data of address: 7D so that the distortions rates when the Hi-Fi SOUND switch is set to "2" and set to "1" respectively are almost the same and minimum.
- 9) Press the PAUSE button.
- 10) Select page: 0, address: 01, and set data: 00.
- 11) Set the Hi-Fi SOUND switch to "STEREO".

# 2. Hi8/Standard8 AFM 1.5 MHz Deviation Adjustment (VC-254 board)

Adjust to the optimum 1.5MHz audio FM signal deviation. If the adjustment is not correct, its playback level will differ from that of other units.

Mode	Playback
Signal	Hi8/Standard8 alignment tape: For checking AFM stereo operation Monoscope section (WR5-9CS)
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Audio level meter
Adjustment Page	F
Adjustment Address	7B
Specified Value	$-7.5 \pm 2.0$ dBs

### Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Set the Hi-Fi SOUND switch (menu display) to "1".
- Select page: F, address: 7B, change the data and set the 400Hz signal level to the specified value.
- 4) Press the PAUSE button.
- 5) Set the Hi-Fi SOUND switch (menu display) to "STEREO".
- 6) Select page: 0, address: 01, and set data: 00.

# 3. Hi8/Standard8 AFM 1.7 MHz Deviation Adjustment (VC-254 board)

Adjust to the optimum 1.7MHz audio FM signal deviation. If improper, this causes deteriorated separation (with stereo signal).

Mode	Playback
Signal	Hi8/Standard8 alignment tape:
	For checking AFM stereo operation
	Monoscope section (WR5-9CS)
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	7C
Specified Value	$-7.5 \pm 2.0$ dBs

### Adjusting method:

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Set the Hi-Fi SOUND switch (menu display) to "2".
- 3) Select page: F, address: 7C, change the data and set the 1kHz signal level to the specified value.
- 4) Press the PAUSE button.
- 5) Set the Hi-Fi SOUND switch (menu display) to "STEREO".
- 6) Select page: 0, address: 01, and set data: 00.

### 4. Digital8 Playback Level Check

Mode	Playback
Signal	Digital8 alignment tape: For audio operation check (WR5-3CD)
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Audio level meter and frequency counter
Specified Value	32 kHz mode: 1 kHz, $+3.0 \pm 2.0$ dBs 48 kHz mode: 1 kHz, $+3.0 \pm 2.0$ dBs 44.1 kHz mode: The 7.35kHz signal level during EMP OFF is $+2.0 \pm 2.0$ dBs. The 7.35kHz signal level during EMP ON is $-6 \pm 2$ dB from the signal level during EMP OFF.

#### **Checking Method:**

1) Check that the playback signal level is the specified value.

#### 5. Overall Level Characteristics Check

Mode	Recording and playback
Signal	400Hz, -66dBs signal: MIC jack left and right
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Audio level meter
Specified Value	$-7.5 \pm 3.0$ dBs

#### **Checking Method:**

- 1) Input the 400Hz, –66dBs signal in the MIC jack left and right.
- 2) Record the signal.
- 3) Playback the recorded section.
- 4) Check that the 400Hz signal level is the specified value.

### 6. Overall Distortion Check

Mode	Recording and playback
Signal	400Hz, -66dBs signal: MIC jack left and right
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Audio distortion meter
Specified Value	Below 0.4%(200Hz to 6kHz BPF ON)

### **Checking Method:**

- 1) Input the 400Hz, -66dBs signal in the MIC jack left and right.
- 2) Record the signal.
- 3) Playback the recorded section.
- 4) Check that the distortion is the specified value.

### 7. Overall Noise Level Check

Mode	Recording and playback
Signal	No signal: MIC jack left and right
Measurement Point	AUDIO/VIDEO jack left or right
Measuring Instrument	Audio level meter
Specified Value	Below –45dBs
	(IHF-A filter ON, 20kHz LPF ON)

### **Checking Method:**

- Connect the left terminal of MIC jack and its ground terminal with a jumper wire.
- Connect the right terminal of MIC jack and its ground terminal with a jumper wire.
- 3) Record the signal.
- 4) Playback the recorded section.
- 5) Check that the noise level is the specified value.
- 6) Remove the jumper wires.

## 8. Overall Separation Check

Mode	Recording and playback
Signal	No signal: MIC jack <left> [right] 400Hz, -66dBs signal: MIC jack <right> [left]</right></left>
Measurement Point	AUDIO/VIDEO jack <left> [right]</left>
Measuring Instrument	Audio level meter
Specified Value	Below –40dBs

<>: Left channel check

[]: Right channel check

### **Checking Method:**

- 1) Connect the <left> [right] terminal of MIC jack and its ground terminal with a jumper wire.
- 2) Input the 400Hz, -66dBs signal in the MIC jack <right> [left].
- 3) Record the signal.
- 4) Playback the recorded section.
- Check that the signal level of the AUDIO/VIDEO jack <left> [right] is the specified value.
- 6) Remove the jumper wire.

### 5-4. SERVICE MODE

### 4-1. ADJUSTMENT REMOTE COMMANDER

The adjustment remote commander is used for changing the calculation coefficient in signal processing, EVR data, etc. The adjustment remote commander performs bi-directional communication with the unit using the remote commander signal line (LANC). The resultant data of this bi-directional communication is written in the non-volatile memory.

#### 1. Using the Adjustment Remote Commander

- Connect the adjustment remote commander to the LANC terminal.
- Set the HOLD switch of the adjustment remote commander to "HOLD" (SERVICE position). If it has been properly connected, the LCD on the adjustment remote commander will display as shown in Fig. 5-4-1.



Fig. 5-4-1.

- 3) Operate the adjustment remote commander as follows.
  - · Changing the page

The page increases when the EDIT SEARCH+ button is pressed, and decreases when the EDIT SEARCH- button is pressed. There are altogether 16 pages, from 0 to F.

Hexadecimal notation	0	1	2	3	4	5	6	7	8	9	A	В	С	D	Е	F
LCD Display		1	2	3	Ч	5	5	7	8	9	Я	Ь	С	d	Ε	F
Decimal notation conversion value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

### · Changing the address

The address increases when the FF ( $\blacktriangleright \blacktriangleright$ ) button is pressed, and decreases when the REW ( $\blacktriangleleft \blacktriangleleft$ ) button is pressed. There are altogether 256 addresses, from 00 to FF.

- Changing the data (Data setting)
   The data increases when the PLAY (►) button is pressed, and decreases when the STOP (■) button is pressed. There are altogether 256 data, from 00 to FF.
- Writing the adjustment data
   The PAUSE button must be pressed to write the adjustment data (B, C, D, E, F, 7, 8 page) in the nonvolatile memory.
   (The new adjusting data will not be recorded in the nonvolatile memory if this step is not performed.)
- After completing all adjustments, turn off the main power supply (8.4 V) once.

# 2. Precautions Upon Using the Adjustment Remote Commander

Mishandling of the adjustment remote commander may erase the correct adjustment data at times. To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment.

### 4-2. DATA PROCESS

The calculation of the DDS display and the adjustment remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items. In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data. Indicates the hexadecimal-decimal conversion table.

xadecimal-de		OHIVE	31011 1	abic										2		
Lower digit hexadecim  Upper digit of hexadecimal		1	2	3	4	5	6	7	8	9	A (月)	B (b)	( <sup>C</sup> )	(년) D	E (E)	F (F
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	1:
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	3
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	4
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	6
4	64	65	66	67	68	69	70	71	72	73	74	77	76	77	78	7
5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	9
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	11
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	12
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	14
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	15
A (月)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	17
В (Ы)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	19
C (_)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	20
D (리)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	22
E ( <i>E</i> )	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	23
F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	25

**Note:** The characters shown in the parenthesis ( ) shown the display on the adjustment remote commander.

**(Example)** If the DDS display or the adjustment remote commander shows BD (ロロ);

Because the upper digit of the adjustment number is B (b), and the lower digit is D (d), the meeting point "189" of ① and ② in the above table is the corresponding decimal number.

Table, 5-4-1,

### 4-3. SERVICE MODE

### Additional note on adjustment

**Note:** After the completion of the all adjustments, cancel the service mode by either of the following ways.

- After data on page: D and F is restored, unplug the main power supply and remove the coin lithium battery. (In this case, date and time and menu setting have been set by users are canceled. Perform resetting.)
- 2) After data on page: D and F is restored, select page: 0, address: 01, and return the data to 00. And when data on page: 2 and 3 are changed, return data to the original condition.

### 1. Setting the Test Mode

Page F	Address 22
--------	------------

Data	Function
80	Normal
81	Test mode Various emergency prohibitions and releases Drum emergency, capstan emergency, loading motor emergency, reel emergency, tape top and end, DEW detection

Page D	Address 10
--------	------------

Data	Function
00	Normal
01	Forced camera power ON
02	Forced VTR power ON

- Before setting the data, select page: 0, address: 01, and set data:
- For page D and F, the data set will be recorded in the non-volatile memory by pressing the PAUSE button of the adjustment remote commander. In this case, take note that the test mode will not be exited even when the main power is turned off (8.4Vdc).
- After completing adjustments/repairs, be sure to return the data of page: D address: 10 to 00, and the data of page: F address: 22 to 80, and press the PAUSE button of the adjustment remote commander. And select page: 0, address: 01, and set data: 00.

### 2. Emergence Memory Address

### 2-1. C Page Emergence Memory Address

Page C	Address F4 to FF
--------	------------------

Address	Contents
F4	EMG code when first error occurs
F6	Upper: MSW code when shift starts when first error occurs
	Lower: MSW code when first error occurs
F7	Lower: MSW code to be moved when first error occurs
F8	EMG code when second error occurs
FA	Upper: MSW code when shift starts when second error occurs  Lower: MSW code when second error occurs
FB	Lower: MSW code to be moved when second error occurs
FC	EMG code when last error occurs
FE	Upper: MSW code when shift starts when last error occurs  Lower: MSW code when last error occurs
FF	Lower: MSW code to be moved when last error occurs

When no error occurs in this unit, data "00" is written in the above addresses (F4 to FF). when first error occurs in the unit, the data corresponding to the error is written in the first emergency address (F4 to F7). In the same way, when the second error occurs, the data corresponding to the error is written in the second emergency address (F8 to FB).

Finally, when the last error occurs, the data corresponding to the error is written in the last emergency address (FC to FF).

Note: After completing adjustments, be sure to initialize the data of addresses F4 to FF to "00".

### **Initializing method:**

- 1) Select page: 0, address: 01, and set data: 01.
- 2) Select page: 3, address: 01, set data: 37, and press the PAUSE button.
- 3) Select page: 0, address: 01, and set data: 00.

### 2-2. F Page Emergence Memory Address

**Note 1:** Emergence of PB mode only.

Page F	Address 10 to 1B
--------	------------------

Address	Contents
10	EMG code when first error occurs
12	Upper: MSW code when shift starts when first error
	occurs
	Lower: MSW code when first error occurs
13	Lower: MSW code to be moved when first error
	occurs
14	EMG code when second error occurs
16	Upper: MSW code when shift starts when second
	error occurs
	Lower: MSW code when second error occurs
17	Lower: MSW code to be moved when second error
	occurs
18	EMG code when last error occurs
1A	Upper: MSW code when shift starts when last error
	occurs
	Lower: MSW code when last error occurs
1B	Lower: MSW code to be moved when last error
	occurs

When no error occurs in this unit, data "00" is written in the above addresses (10 to 1B). when first error occurs in the unit, the data corresponding to the error is written in the first emergency address (10 to 13). In the same way, when the second error occurs, the data corresponding to the error is written in the second emergency address (14 to 17).

Finally, when the last error occurs, the data corresponding to the error is written in the last emergency address (18 to 1B).

**Note 2:** After completing adjustments, be sure to initialize the data of addresses 10 to 1B to "00".

### **Initializing method:**

- 1) Select page: 0, address: 01, and set data: 01.
- Select page: F, address: 10, set data: 00, and press the PAUSE button.
- 3) Select address: 11 to 1B and set data "00" into them in the same way as in address: 10.
- 4) Select page: 0, address: 01, and set data: 00.

### 2-3. EMG Code (Emergency Code)

Codes corresponding to the errors which occur are written in C page, addresses F4, F8 and FC (or F page, addresses 10, 14 and 18). The type of error indicated by the code are shown in the following table.

Code	Emergency Type
00	No error
10	Loading motor emergency during loading
11	Loading motor emergency during unloading
22	T reel emergency during normal rotation
23	S reel emergency during normal rotation
24	T reel emergency (Short circuit between S reel
	terminal and T reel terminal)
30	FG emergency at the start up of the capstan
40	FG emergency at the start up of the drum
42	FG emergency during normal rotation of the drum

### 2-4. MSW Code

- The lower parts of the data of C page, addresses F6, FA and FE (or F page, addresses 12, 16 and 1A) represent the MSW codes (mode switch mechanism position) when errors occurs.
- The upper parts of the data of C page, addresses F6, FA and FE (or F page, addresses 12, 16 and 1A) represent, when the mechanism position is to be moved, the MSW codes at the start movement (when moving the loading motor).
- The lower parts of the data of C page, addresses F7, FB and FF (or F page, addresses 13, 17 and 1B) represent the MSW codes of the desired movement when the mechanism position is to be moved. ← Unloading

movea.		\ OIIIO	aumi	•										-	_oaamig /
Mechanism po	sition	EJE	СТ	BL	USE	BL	LOAD	BL	STOP	BL	TURN	BL	REC/PB	BL	REW
MSB		<b></b>	0	0	0	0	0	0	0	0	0	0	0	0	0
MODE SW C		-	0	_	0		0		<u> </u>		<u> </u>	ز حــ ا	0	_ ;	_
MODE SW B		-	0	<u> </u>		_	_	<u> </u>	<u> </u>		0	إحا	0	_	0
MODE SW A		-	_	<del></del> -	<u> </u>	_	0	¦ <del></del>	0	¦ —	0	<del></del>	0	🗕	<b>→</b> ¦
	;	 	Ш	¦ II - ¦	l II	l II	II	¦ II	¦ II	¦ II	¦ II	II	II	11	II ¦
			_	7	ω	7	8	7	ြ	7	4	7	0	7	5
		 		 	 	 		 	 	 	 				!
	į			L	S chassis mo	veme	ent range	-	'	'		-			i
	;			<del>                                     </del>					Pinch	rolle	r is detached	1			1
	1		$\longrightarrow$	l Į								l l	<b>←</b>		
Releasing lock of									Pinch rolle	r is pı	essed				
cassette campartment															


Loading  $\rightarrow$ 

<b>Mechanism Position</b>	MSW Code	Contents
EJECT	1	Position at which the cassette compartment lock is released. The mechanism will not move any further in the unloading direction.
BL 7		BLANC code. Between two codes. The mechanism will not be stopped by this code while it is operating.
USE	3	EJECT completion position. When the cassette is ejected, the mechanism will stop at this position.
LOAD	2	Code during loading/unloading. Code that is used while the LS chassis is moving.
STOP	6	Normal stop position. The pinch roller separates, the tension regulator returns, and the brakes o both reels turn on.
TURN	4	Position at which is used when the pendulum gear swings from S to T or from T to S.
REC/PB	0	PB, REC, CUE, REV, PAUSE, FF positions. The pinch roller is pressed and tension regulator is on.
REW	5	REW position. REW are carried at this position.  The mechanism will not move any further in the loading direction.

### 3. Bit Value Discrimination

Bit values must be discriminated using the display data of the adjustment remote commander for the following items. Us the table below to discriminate if the bit value is "1" or "0".

Display on the adjustment remote commander



(Example) If the remote commander display is "8E", bit value from bit 7 to bit 4 can be discriminated from the column (a), and those from bit 3 to bit 0 from column (b).

	Display on the		Bit va	alues	
	adjustment	bit3	bit2	bit1	bit0
	remote	or	or	or	or
	commander	bit7	bit6	bit5	bit4
	0	0	0	0	0
	1	0	0	0	1
	2	0	0	1	0
	3	0	0	1	1
	4	0	1	0	0
	5	0	1	0	1
	6	0	1	1	0
	7	0	1	1	1
A	8	1	0	0	0
	9	1	0	0	1
	A (月)	1	0	1	0
	В (Ь)	1	0	1	1
	C ([)	1	1	0	0
	D (d)	1	1	0	1
$^{\odot}$	E ( <i>E</i> )	1	1	1	0
	F (F)	1	1	1	1

### 4. Switch check (1)

Page 2 Address 43
-------------------

Bit	Function	When bit value = 1	When bit value = 0
0	POWER SW (VTR MODE SW) (SS-1380 block)	OFF	ON (VCR/PLAYER)
1	POWER SW (CAM MODE SW) (SS-1380 block)	OFF	ON (CAMERA)
2	START/STOP SW (SS-1380 block)	OFF	ON
3	EJECT SW (SS-1380 block)	OFF	ON
4	CC DOWN SW (Mechanism chassis)	OFF (UP)	ON (DOWN)
5	PHOTO FREEZE SW (SS-1380 block)	OFF	ON
6	POWER SW (PHOTO STBY SW) (SS-1380 block) *1	OFF	ON (MEMORY)
7			

### \*1: DCR-TRV330/TRV530

### Using method:

- 1) Select page: 2, address: 43.
- 2) By discriminating the bit value of display data, the state of the switch can be discriminated.

### 5. Switch check (2)

Page 2	Address 49
--------	------------

Bit	Function	When bit value = 1	When bit value = 0
4	MIC jack (FP-273 flexible)	Used	Not used
5			
6	AUDIO/VIDEO jack (FP-270 flexible J102)	Used	Not used
7	S VIDEO jack (FP-270 flexible J101)	Not used	Used

### Using method:

- 1) Select page: 2, address: 49.
- 2) By discriminating the bit value of display data, the state of the switch can be discriminated.

### 6. Switch check (3)

Page 3	Address 5A

Bit	Function	When bit value = 1	When bit value = 0
6	HEADPHONES jack (FP-273 flexible)	Used	Not used

### Using method:

- 1) Select page: 3, address: 5A.
- 2) By discriminating the bit value of display data, the state of the switch can be discriminated.

# 7. Switch check (4)

Page 2	Address 60 to 65

### **Using method:**

- 1) Select page: 2, address: 60 to 65.
- 2) By discriminating the display data, the pressed key can be discriminated.

Address				Da	ıta			
Audress	00 to 0C	0D to 24	25 to 3F	40 to 5D	5E to 81	82 to AA	AB to D7	D8 to FF
	EDIT SEARCH + (CF-079/080) (S117)	EDIT SEARCH – (CF-079/080) (S116)	SUPER LASER LINK (FP-275)	STOP (FP-275)	FF (FP-275)	REC (FP-275) *2		No key input
61 (KEY AD1) (IC4803 <b>9</b> 4)		PHOTO (PHOTO START) (SS-1380)	PAUSE (FP-275)	REW (FP-275)	PLAY (FP-275)			No key input
62 (KEY AD2) (IC4803 <b>9</b> 5)	` /	EXPOSURE (SE-1380)	MENU EXECUTE (SE-1380)	TITLE (CF-079/080) (S108)	VOLUME + (CF-079/080) (S111)	VOLUME – (CF-079/080) (S113)	BACKLIGHT (CF-079/080) (S115)	No key input
63 (KEY AD3) (IC4803 <b>9</b> 6)	` /	MEMORY – (CF-079/080) (S104)*1	MEMORY INDEX (CF-079/080) (S106)*1	MEMORY DELETE (CF-079/080) (S109)*1	MEMORY PLAY (CF-079/080) (S112)*1	MEMORY MIX (CF-079/080) (S114)*1	PANEL CLOSE (S910)	PANEL OPEN (S910)
64 (KEY AD4) (IC4803 ⑨)		SUPER NIGHT SHOT (FP-275)	END SEARCH (CF-079/080) (S105)	DISPLAY (CF-079/080) (S107)	PB ZOOM (CF-079/080) (S110)	FADER (CF-079/080) (S118)	FOCUS AUTO (FP-282)	FOCUS MANUAL (FP-282)
65 (KEY AD5) (IC4803 <b>®</b> )		PANEL REVERSE (FP-283)						PANEL NORMAL (FP-283)

<sup>\*1:</sup> DCR-TRV325E/TRV330E/TRV430E/TRV530E

### 8. Record of Use check

**Note:** When replacing the drum assembly, initialize the data of address: A2 to A4.

D 1	Address A2 to AA
Page /	L Address A / 10 A A
1 450 2	11441655112 to 1111

Bit	Function		Remarks
A2	Drum rotation	Minute	
A3	counted time	Hour (L)	10th place digit and 1st place digit of counted time (decimal digit)
A4	(BCD code)	Hour (H)	1000th place digit and 100th place digit of counted time (decimal digit)
A5	User initial power	Year	
A6	on date	Month	After setting the clock, set the date of power on next
A7	(BCD code)	Day	
A8	Final condensation	Year	
A9	occurrence date	Month	
AA	(BCD code)	Day	

### Using method:

1) The record of use data is displayed at page: 2, addresses: A2 to AA.

Note: This data will be erased (reset) when the CF-079/080 board (VC-254 board CN1117 (45P)) is removed.

# Initializing method:

1) Using the adjustment remote commander, select the object address and set data: 00.

<sup>\*2:</sup> Except AEP/UK model of DCR-TRV325E/TRV330E/TRV430E/TRV530E

# 9. Record of Self-diagnosis check

Address	Self-diagnosis code
В0	"Repaired by" code (Occurred 1st time) *1
B1	"Block function" code (Occurred 1st time)
B2	"Detailed" code (Occurred 1st time)
B4	"Repaired by" code (Occurred 2nd time) *1
B5	"Block function" code (Occurred 2nd time)
В6	"Detailed" code (Occurred 2nd time)
B8	"Repaired by" code (Occurred 3rd time) *1
В9	"Block function" code (Occurred 3rd time)
BA	"Detailed" code (Occurred 3rd time)
BC	"Repaired by" code (Occurred 4th time) *1
BD	"Block function" code (Occurred 4th time)
BE	"Detailed" code (Occurred 4th time)
C0	"Repaired by" code (Occurred 5th time) *1
C1	"Block function" code (Occurred 5th time)
C2	"Detailed" code (Occurred 5th time)
C4	"Repaired by" code (Occurred the last time) *1
C5	"Block function" code (Occurred the last time)
C6	"Detailed" code (Occurred the last time)

<sup>\*1: &</sup>quot;01" → "C", "03" → "E"

# Using method:

1) The past self-diagnosis codes are displayed at page: 2, addresses: BC to C6. Refer to "SELF-DIAGNOSIS FUNCTION" for detail of the self-diagnosis code.

Note: This data will be erased (reset) when the CF-079/080 board (VC-254 board CN1117 (45P)) is removed.

# SECTION 6 REPAIR PARTS LIST

# 6-1. EXPLODED VIEWS


NOTE:

- -XX, -X mean standardized parts, so they may have some differences from the original one.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Abbreviation

HK : Hong Kong model
AUS : Australian model
JE : Tourist model
CN : Chinese model


The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety. Replace only with part number specified.

### 6-1-1. OVERALL SECTION




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
1	X-3951-161-1	GRILLE ASSY, MICROPHONE		9	A-7074-651-A	FP-273 BOARD, COMPLETE	
2	3-065-310-01	RING, RUBBER		10	3-065-327-01	CUSHION (MI)	
3	3-067-347-01	MI SCREW M2 (H)		11	3-742-854-01	LID, BATTERY CASE (FOR RMT-814)	
4	X-3949-376-1	CAP(N) ASSY, LENS		12	1-475-141-61	REMOTE COMMANDER (RMT-814)	
5	X-3951-207-1	PANEL ASSY (P), FRONT		13	3-065-326-01	CABINET (UPPER)	
6	3-066-722-01	CUSHION, SENSOR		14	3-065-325-01	LID(BT), CPC	
7	3-948-339-61	TAPPING		15	3-065-567-01	TAPPING (M1.7)	
8	A-7074-726-A	SI-028 (M) BOARD, COMPLETE		16	3-066-720-01	CUSHION (SI)	
		(TRV230E/TRV235E/TRV325E/	TRV330E)	MIC901	1-542-312-11	MICROPHONE (Lch)	
8	A-7074-812-A	SI-029 (M) BOARD, COMPLETE		MIC902	1-542-312-11	MICROPHONE (Rch)	
		(TRV430E/	TRV530E)				

# 6-1-2. CABINET (L) SECTION-1




Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
51	3-066-721-01	CUSHION, LENS		60	3-948-339-61	TAPPING	
52	1-680-119-11	FP-265 FLEXIBLE BOARD		61	A-7074-650-A	FP-272 BOARD, COMPLETE	
53	3-065-372-01	FRAME, MD		62	1-680-121-11	FP-266 FLEXIBLE BOARD	
54	1-815-124-11	CONNECTOR, EXTERNAL (HOT SHOE	)	63	A-7074-648-A	FP-270 BOARD, COMPLETE	
		(TRV325E/TRV330E/TRV430E	/TRV530E)	64	A-7074-649-A	FP-271 BOARD, COMPLETE	
54	1-815-124-21	CONNECTOR, EXTERNAL (HOT SHOE	)			(TRV325E/TRV330E/	TRV430E/TRV530E)
		(TRV230E	/TRV235E)				
				65	4-974-725-01	( - /)	
55		FP-264 FLEXIBLE BOARD		66	A-7074-647-A	PC-082 BOARD, COMPLETE	
56	A-7096-437-A	VC-254 (QBPS) BOARD, COMPLETE (	,			(TRV325E/TRV330E/	FRV430E/TRV530E)
		,	/TRV235E)	67	1-500-226-11	BEAD, FERRITE	
56	A-7096-440-A	VC-254 (QFPS) BOARD, COMPLETE (	,			(TRV325E/TRV330E/	TRV430E/TRV530E)
		(TRV325E/TRV330E	,	68	3-066-169-01	SHEET, MD	
56	A-7096-443-A	VC-254 (QFPA) BOARD, COMPLETE (	,	* 69	X-3951-170-1	SHIELD ASSY, DD	
			(TRV430E)				
57	A-7074-725-A	FU-150 (PF) BOARD, COMPLETE		70	3-941-343-21	TAPE (A)	
		(TRV325E	/TRV330E)	71	3-066-759-01	SHEET, VC	(======================================
				72	3-066-707-01	SHEET (T), ELECTROSTATIC	(TRV530E:AEP,CN)
57	A-7074-767-A	FU-150 (P) BOARD, COMPLETE		73	3-065-662-01	LABEL, LS CAUTION	
	. 7074 044 1	`	/TRV235E)	74	3-065-567-01	TAPPING (M1.7), P	
57	A-7074-811-A	FU-154 (PF) BOARD, COMPLETE	(TD) (E00E)	7-	0.007.047.04	141 00DE14/140 (II)	
	0.005.007.04		/TRV530E)	75	3-067-347-01	MI SCREW M2 (H)	N. (
58	3-065-397-01	HOLDER, MS		CN910	1-815-123-11	CONNECTOR, MEMORY STIC	
59	1-680-134-11	FP-274 FLEXIBLE BOARD	(TD) (E00E)			(TRV325E/TRV330E/	IKV430E/IKV530E)
		(TRV325E/TRV330E/TRV430E	/TRV530E)				

# 6-1-3. CABINET (L) SECTION-2




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	Description	<u>Remarks</u>
101	X-3951-159-1	CABINET (L) ASSY		107	1-476-415-31	SWITCH BLOCK, CONTROL (S	S-1380)
102	3-052-815-01	BELT (ES), GRIP				(TRV325E/TRV43	0E/TRV530E:AEP)
103	3-067-347-01	MI SCREW M2 (H)		107	1-476-415-41	SWITCH BLOCK, CONTROL (S	S-1380)
104	3-065-308-01	LABEL (L)				(	TRV230E:AEP,UK)
105	3-978-765-01	SLIDER, G LOCK		108	X-3951-158-1	FRAME ASSY, CS	
				* 109	3-065-324-01	SHEET METAL (LOWER), STRA	<b>ΑP</b>
106	3-713-791-01	SCREW (M1.7X4), TAPPING, P2		110	X-3951-157-1	PANEL ASSY, BATTERY	
107	1-476-415-11	SWITCH BLOCK, CONTROL (SS-1380)					
		(TRV330E/TRV530E:E,HK,AU	IS,JE,CN)	111	3-065-567-01	TAPPING (M1.7)	
107	1-476-415-21	SWITCH BLOCK, CONTROL (SS-1380)		112	4-974-725-01	SCREW (M1.7X2.5), P	
		(TRV230E:E,HK,AUS/T	RV235E)	BT901	1-694-772-11	TERMINAL BOARD, BATTERY	

# 6-1-4. CABINET (R) SECTION (2.5 INCH LCD MODEL)(TRV230E/TRV235E/TRV325E/TRV330E)



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
151	1-791-948-11	CABLE, FLEXIBLE FLAT (FFC-001)		163	3-969-387-01	FOOT, RUBBER	
152	A-7074-675-A	CF-079 (SBF) BOARD, COMPLETE		164	X-3951-234-1	CABINET R (139) ASSY	
		(TRV325E	/TRV330E)			(TRV230	E:AEP,UK/TRV235E)
152	A-7074-686-A	CF-079 (SB) BOARD, COMPLETE		164	X-3951-235-1	CABINET R (141) ASSY	(TRV325E)
		(TRV230E	/TRV235E)	164	X-3951-327-1	CABINET (R) (141R) ASSY	(TRV330E)
153	3-948-339-61	TAPPING		164	X-3951-329-1	CABINET R (139R) ASSY (TR	RV230E:E,HK,AUS)
154	1-476-416-11	SWITCH BLOCK, CONTROL (SE-1380	)				
				165	3-065-353-01	COVER (B), JACK (TRV325E	E/TRV330E)
* 155	3-065-398-01	RETAINER, SPEAKER		165	3-065-353-11	COVER (B), JACK (TRV230E	E/TRV235E)
* 156	3-058-658-01	SPACER (101), SPEAKER		166	3-065-352-01	COVER (F), JACK	
* 157	3-065-385-01	HOLDER, VTR		167	3-065-386-01	RETAINER, TRIPOD	
158	X-3951-173-1	BUTTON ASSY, VTR		168	3-065-373-01	SCREW (Y), TRIPOD	
		(TRV230E:E,HK,AUS	/TRV330E)				
158	X-3951-257-1	BUTTON ASSY, VTR		* 169	3-065-521-01	SHEET, MUFFLE	
		(TRV230E:AEP,UK/TRV235E	/TRV325E)	170	3-066-939-01	SHEET, CF ELECTROSTATIC	
				171	3-066-940-01	SHEET (2), CF ELECTROSTA	TIC
159		FP-275 BOARD, COMPLETE		172	3-066-943-01	SHEET (R), B	
160		FP-282 BOARD, COMPLETE		173	3-941-343-21	TAPE (A)	
161	X-3951-189-1	COVER (141) ASSY, HINGE					
		(TRV230E/TRV325E	,	S910	1-771-848-11	SWITCH, PUSH	
161		COVER (139) ASSY, HINGE (TRV235E	=)	SP901	1-529-590-11	SPEAKER (2.0CM)	
162	3-067-347-01	MI SCREW M2 (H)					


# 6-1-5. CABINET (R) SECTION (3/3.5 INCH LCD MODEL)(TRV430E/TRV530E)



: BT101 (Lithium battery) CF-080 board on the mount position. (See page 4-71)

Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
201	1-791-948-11	CABLE, FLEXIBLE FLAT (FFC-001)		214	X-3951-328-1	CABINET (R) (149R) A	ASSY
202	A-7074-677-A	CF-080 (SBF) BOARD, COMPLETE				(1)	RV530E:E,HK,AUS,JE,CN)
203	3-948-339-61	TAPPING		215	3-065-353-01	COVER (B), JACK	
204	1-476-416-11	SWITCH BLOCK, CONTROL (SE-1380	)	216	3-065-352-01	COVER (F), JACK	
* 205	3-065-398-01	RETAINER, SPEAKER		217	3-065-386-01	RETAINER, TRIPOD	
				218	3-065-373-01	SCREW (Y), TRIPOD	
* 206	3-058-658-01	SPACER (101), SPEAKER					
* 207	3-065-385-01	HOLDER, VTR		* 219	3-065-521-01	SHEET, MUFFLE	
208	X-3951-173-1	BUTTON ASSY, VTR(TRV530E:E,HK,A	US,JE,CN)	220	3-066-939-01	SHEET, CF ELECTROS	TATIC
208	X-3951-257-1	BUTTON ASSY, VTR(TRV430E/TRV53	0E:AEP)	221	3-066-941-01	SHEET (3), CF ELECTF	ROSTATIC
209	A-7074-652-A	FP-275 BOARD, COMPLETE		222	3-066-943-01	SHEET (R), B	
				223	3-067-601-01	CF ELECTROSTATIC S	HEET (4)
210	A-7074-653-A	FP-282 BOARD, COMPLETE					
211	X-3951-176-1	COVER (148) ASSY, HINGE		224	3-941-343-21	TAPE (A)	
212	3-067-347-01	MI SCREW M2 (H)		S910	1-771-848-11	SWITCH, PUSH	
213	3-969-387-01	FOOT, RUBBER		SP901	1-529-590-11	SPEAKER (2.0CM)	
214	X-3951-237-1	CABINET R (149) ASSY					
		(TRV430E/TRV	530E:AEP)				


# 6-1-6. LCD SECTION (2.5 INCH LCD MODEL)(TRV230E/TRV235E/TRV325E/TRV330E)



Ref. No.	Part No.	<u>Description</u> <u>Re</u>	<u>emarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
251 252 253 254 * 255	3-065-364-01 3-067-347-01 3-989-735-51 A-7096-434-A 3-065-368-01	CABINET C (2), P MI SCREW M2 (H) SCREW (M1.7), LOCK ACE, P2 INDICTION LCD BLOCK ASSY (SERVICE) HOLDER (2), LCD		264 265 266 267 267	3-318-203-11 3-065-367-01 X-3951-177-1 X-3951-259-1 X-3951-261-1	SCREW (B1.7X6), TAPPING FRAME (2), P CABINET M (2) ASSY, P COVER (139) ASSY, CPC COVER (141) ASSY, CPC	(TRV230E) (TRV325E)
256		PD-139 (X12) BOARD, COMPLETE 10E:AEP,UK/TRV235E/TRV325E/TRV330E:A	(FPIIK)	267 267	X-3951-320-1 X-3951-413-1	COVER (139C) ASSY, CPC COVER (141C) ASSY, CPC	(TRV235E) (TRV330E)
256	`	PD-139 (X6) BOARD, COMPLETE (TRV230E:E,HK,AUS/TRV330E:HK,AU	, ,	268 △ D902	3-065-366-01 1-518-721-11	WINDOW (2), LCD LIGHT. BACK	(11110002)
256	A-7074-791-A	PD-139 (SGX6) BOARD, COMPLETE	0E:CN)	LCD901	8-753-050-60	ACX307AKC-J (SERVICE) BOE:AEP,UK/TRV235E/TRV325E	F/TRV330F·AFPUK)
257	3-065-567-01	TAPPING (M1.7)	02:0:1)		(		-,
258	3-065-395-01	COVER C (2.5), HINGE		LCD901	8-753-050-65	ACX308AK-J (SERVICE) (TRV230E:E,HK,AUS/TRV330	E:HK,AUS,JE,CN,E)
259	4-974-725-01	SCREW (M1.7X2.5), P		<b>△</b> ND901	1-518-725-11	TUBE, FLUORESCENT, COLD	CATHODE
260	A-7074-654-A	FP-283 BOARD, COMPLETE				(TRV230E:E,HK,AUS/TRV330	E:HK,AUS,JE,CN,E)
261	X-3951-181-1	HINGE ASSY		△ ND901	1-518-725-21	TUBE, FLUORESCENT, COLD	CATHODE
262	3-065-394-01	COVER (M), HINGE			(TRV23	30E:AEP,UK/TRV235E/TRV325E	E/TRV330E:AEP,UK)
263	1-960-973-21	HARNESS (VP-076)					

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety. Replace only with part number specified.


# 6-1-7. LCD SECTION (3/3.5 INCH LCD MODEL)(TRV430E/TRV530E)



Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
301	X-3951-180-1	CABINET C (3) ASSY, P		314	3-066-106-01	P FRAME (3.0) (TRV430E)	
302	A-7096-435-A	INDICTION LCD BLOCK ASSY (SERVI	CE)	315	X-3951-179-1	CABINET M (3) ASSY, P (TI	RV530E)
303	3-067-347-01	MI SCREW M2 (H)		315	X-3951-326-1	CABINET (M) (3) ASSY, P (T	RV430E)
304	3-989-735-61	SCREW (M1.7), LOCK ACE, P2		316	X-3951-263-1	COVER (145) ASSY, CPC	(TRV430E)
* 305	3-065-392-01	HOLDER (3), LCD		316	X-3951-265-1	COVER (149) ASSY, CPC	(TRV530E)
306	4-974-725-01	SCREW (M1.7X2.5), P		317	3-065-366-01	WINDOW (2), LCD	
307	A-7074-674-A	PD-139 (Z12) BOARD, COMPLETE (TR	RV530E)	<b>△</b> D902	1-518-721-11	LIGHT, BACK	
307	A-7074-827-A	PD-138 (Y12) BOARD, COMPLETE (TI	RV430E)	LCD901	1-803-854-21	INDICATOR MODULE LIQUII	D CRYST (SERVICE)
308	3-065-396-01	COVER C (3), HINGE					(TRV430E)
309	3-065-567-01	TAPPING (M1.7)		LCD901	8-753-051-00	ACX310AK-J (SERVICE)(TR	V530E)
				⚠ ND901	1-517-855-31	TUBE, FLUORESCENT, COLD	) CATHODE
310	A-7074-654-A	FP-283 BOARD, COMPLETE					(TRV530E)
311	X-3951-181-1	HINGE ASSY					
312	3-065-394-01	COVER (M), HINGE		⚠ ND901	1-517-856-31	TUBE, FLUORESCENT, COLD	) CATHODE
313	1-960-973-21	HARNESS (VP-076)					(TRV430E)
314	3-065-391-01	FRAME (3), P (TRV530E)					

 The components identified by mark ∆ or dotted line with mark ∆ are critical for safety.
 Replace only with part number specified.


# 6-1-8. LENS, EVF SECTION



Be sure to read "Precautions upon replacing CCD imager" on page 4-10 when changing the CCD imager.


Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Re	ef. No.	Part No.	<u>Description</u>	<u>Remarks</u>
351	8-848-740-01	DEVICE, LENS LSV-700A			363	A-7074-678-A	LB-070 (SB) BOARD, COMPLETE	
352	X-3951-248-1	IRIS FLEXIBLE, ASSY					(TRV430	DE/TRV530E)
353	3-065-022-01	TAPPING (B1.7x3.5), HEAD			364	3-065-058-01	GUIDE, LAMP	
354	3-713-791-41	SCREW, TAPPING (M1.7x5), P2			365	3-065-059-01	ILLUMINATOR (1)	
355	1-758-553-11	FILTER BLOCK, OPTICAL			366	3-065-061-01		
					367	3-065-060-01	SHEET (1) (138), PRISM	
356	3-053-973-01	RUBBER (W), SEAL						
357	A-7074-724-A	CD-294 BOARD, COMPLETE			368	3-065-062-01	CUSHION (138), LCD	
		(TRV230E/TRV235E/TRV325E	/TRV330E)	*	369	3-058-232-01	CUSHION (1) (97), LCD	
357	A-7074-810-A	CD-317 BOARD, COMPLETE			370	X-3951-168-1	LENS (B) ASSY, VF	
		(TRV430E	/TRV530E)		371	X-3951-163-1	CABINET (UPPER) ASSY, EVF	
358	3-318-203-11	SCREW (B1.7X6), TAPPING			372	X-3951-167-1	CABINET (LOWER) ASSY, EVF	
359	3-065-057-01	GUIDE (2), FLEXIBLE						
				*	373	3-065-376-01	LABEL (138), B	
360	3-065-567-01	TAPPING (M1.7)			IC501	A-7031-228-A	CCD BLOCK ASSY (CCD IMAGER)	
361	X-3951-165-1	HINGE ASSY, VF			LCD903	8-753-028-49	LCX032AP-J	
362	1-680-123-11	FP-268 FLEXIBLE BOARD			M904	1-763-634-11	MOTOR STEPPING Z700 (Z00M)	
363	A-7074-676-A	LB-068 (SB) BOARD, COMPLETE			M905	1-763-635-11	MOTOR STEPPING F700 (FOCUS)	
		(TRV230E/TRV235E/TRV325E	/TRV330E)					

6-1-9. CASSETTE COMPARTMENT ASSY, DRUM ASSY




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
701	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		707	3-065-840-01	CUT (0.98X3X0.13), LUMILER (W)	
702	3-065-895-01	LEVER, REEL RELEASE		708	3-065-935-01	HLC CUT 1.8X4X0.5	
703	3-065-896-01	PLATE, BLIND		709	3-947-503-01	SCREW (M1.4)	
704	X-3951-298-1	CASSETTE COMPARTMENT ASSY		710	X-3951-299-1	SCREW ASSY, DRUM FITTING	
705	X-3951-302-1	DAMPER ASSY		M901	A-7048-951-A	DRUM (DKH-04A-R)(SERVICE)	
706	X-3951-297-1	GEAR ASSY, R DRIVE					

## 6-1-10. LS CHASSIS BLOCK ASSEMBLY




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
751	3-065-822-01	RAIL (S), GUIDE		771	3-065-830-01	SPRING, S RATCHET	
752	3-947-503-01	SCREW (M1.4)		772	X-3951-288-1	TABLE (T) ASSY, REEL	
753	A-7096-416-A	BASE (S) BLOCK ASSY, GUIDE		773	3-065-819-01	SPRING, TG1 ARM	
754	A-7096-415-A	BASE (T) BLOCK ASSY, GUIDE		774	3-065-821-01	RAIL (T), GUIDE	
755	A-7096-426-A	CHASSIS ASSY, LS		775	X-3951-289-1	TABLE (S) ASSY, REEL	
756	3-065-802-01	SPRING, TG7 ARM		776	3-065-833-01	GUIDE, LOCK	
757	A-7096-414-A	ARM BLOCK ASSY, TRG7		777	3-065-831-01	PLATE (SPR), RE RETURN	
758	3-065-801-01	RETAINER, TG7		778	X-3951-304-1	ARM ASSY, TG1	
759	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		779	3-065-835-01	GUIDE (S), CASSETTE	
760	X-3951-303-1	ARM ASSY, PINCH		780	3-065-820-01	SPRING, RVS ARM	
761	3-065-823-01	ARM, T RATCHET		781	X-3951-296-1	BAND ASSY, BT	
762	3-065-794-01	ROAD (SPR), PINCH ARM		782	3-065-836-01		
763	3-065-792-01	ROLLER, P LIM ARM		783	3-067-167-01		
764	3-065-834-01	GUIDE (T), CASSETTE		S001	1-692-614-11	SWITCH, PUSH (3KEY) (REC PROOF)	
765	3-065-824-01	SPRING, T RATCHET		H001	8-719-033-37	ELEMENT, HALL HW-105C (T REEL)	
766	A-7096-417-A	SOFT ASSY, T		H002	8-719-033-37	ELEMENT, HALL HW-105C (S REEL)	
767	7-627-852-38	SCREW, PRECISION +P1.7X1.8 TYPE3	3	D001	8-719-988-42	DIODE GL453 (TAPE LED)	
768	3-065-832-01	PLATE, LS CAM		Q001	8-729-907-25	PHOTO TRANSISTOR PT4850F (TAPE	TOP)
769	3-065-828-01	ARM, S RATCHET		Q002	8-729-907-25	PHOTO TRANSISTOR PT4850F (TAPE	END)
770	3-065-829-01	PLATE, S RATCHET (RE)					

#### 6-1-11. MECHANICAL CHASSIS BLOCK ASSEMBLY-1



Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	Description	<u>Remarks</u>
801	A-7096-422-A	BASE ASSY, DRUM		814	3-065-881-01	SPRING, P PRESSURE PLATE	
802	3-947-503-01	SCREW (M1.4)		815	3-065-934-01	HLW CUT 0.98X3X0.25	
803	3-065-928-01	SPACER, GROUND		816	1-786-096-11	SWITCH, ROTALY	
804	3-065-927-01	GROUND, DRUM		817	3-065-898-01	SPRING, EJECT ARM	
805	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		818	3-065-870-01	ROLLER, LS GUIDE	
806	3-067-154-01	SPRING, CAPSTAN		819	A-7096-421-A	ARM ASSY, HCL	
807	3-065-931-01	RAIL (T2), GUIDE		820	3-065-918-01	GEAR (2), CAM RELAY	
808	X-3947-398-1	SCREW ASSY, M1.7 PW		821	A-7096-419-A	GEAR ASSY, CHANGE	
809	3-065-933-01	PAN (2 MAIN 1.4X4.5), CAMERA		822	3-065-902-01	BELT, TIMING	
810	1-677-049-11	FP-228 FLEXIBLE BOARD (DEW SENS)	OR)	823	3-065-905-01	GEAR, RELAY	
811	1-680-434-11	FP-299 FLEXIBLE BOARD		824	3-065-882-01	ARM, EJECT	
812	3-065-877-01	PLATE (T), GUIDE LOCK		M902	8-835-701-01	MOTOR, DC SCE13A/C-NP (CAPSTAN	)
813	X-3951-301-1	PLATE ASSY, PINCH PRESSURE		M903	A-7096-420-A	MOTOR ASSY, LD (LOADING)	

#### 6-1-12. MECHANICAL CHASSIS BLOCK ASSEMBLY-2



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
851	3-065-920-01	ARM, HC DRIVE		860	7-624-101-04	STOP RING 1.2 (E TYPE)	
852	3-065-913-01	GEAR (4), LD		861	A-7096-412-A	GEAR (T) ASSY, GUIDE	
853	3-065-914-01	SHEET, COVER		862	X-3951-307-1	PLATE ASSY, M SLIDE	
854	3-065-917-01	GEAR (1), CAM RELAY		863	X-3951-305-1	ARM ASSY, LS	
855	3-065-934-01	HLW CUT 0.98X3X0.25		864	3-065-901-01	ROLLER, LS ARM	
856	3-065-915-01	GEAR (1), CAM		865	3-065-916-01	GEAR (2), CAM	
857	3-065-878-01	PLATE (S), GUIDE LOCK		866	3-065-919-01	ARM, T1 LIMITTER	
858	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		867	X-3951-308-1	ARM ASSY, GL	
859	A-7096-413-A	GEAR (S) ASSY, GUIDE		868	X-3951-300-1	CHASSIS ASSY, MECHANICAL	

| CD-294 | | CD-317 | | CF-079 | | CF-080

#### 6-2. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these
- CAPACITORS: uF: μF

RESISTORS
 All resistors are in ohms.
 METAL: metal-film resistor
 METAL OXIDE: Metal Oxide-film resistor

· COILS uH: μH

F: nonflammable

SEMICONDUCTORS
In each case, u: μ, for example:
uA...: μA..., uPA..., μPA...,
uPB..., μPB..., uPC..., μPC...,
uPD..., μPD...

When indicating parts by reference number, please include the board name.

The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety. Replace only with part number specified.

Abbreviation

HK : Hong Kong model
AUS : Australian model
JE : Tourist model
CN : Chinese model

Ref. No.   Part No.   Description   Remarks	uF: μF				uPD,	μPD	CN : Chinese model						
Continue	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	<u>R</u>	lef. No.	Part No.	<u>Description</u>			Remarks
## A-7074-810-A   CD-317 BOARD, COMPLETE   (TRV430E/TRV530E)   (IC601 is not included in this complete board.)		A-7074-724-A			TRV325E	/TRV330E)			A-7074-675-A	CF-079 (SBF) BOA			/TRV330E)
CREATING   TRANSPORTED   TRA			,			,				*******			
CRIAND-10000 Series		A-7074-810-A	CD-317 BOARD, 0	COMPLETE					A-7074-677-A	CF-080 (SBF) BOA	ARD, COM	PLETE	
CREATIVE				`		,					,		
CREATION			*********						A 7074 696 A		******		
CAPACITOR   CAPA			(IC601 is not in	,		,			A-7074-000-A	01-079 (3D) DOA			/TRV235F)
C601			(10001 10 1101 111			010 200.01,				******	,		,
C602   1-113-985-11   TANTAL CHIP   10uF   20%   20V   C603   1-162-964-11   CERAMIC CHIP   0.01uF   10%   50V   C606   1-13-682-11   TANTAL CHIP   33uF   20%   10V   C607   1-162-915-11   CERAMIC CHIP   10PF   0.5PF   50V   C707   1-162-915-11   CERAMIC CHIP   0.01uF   10%   25V   C610   1-163-360-11   CERAMIC CHIP   0.01uF   10%   50V   C201   1-135-201-11   TANTAL UM CHIP   0.01uF   10%   25V   C610   1-163-021-91   CERAMIC CHIP   0.01uF   10%   50V   C202   1-107-826-11   CERAMIC CHIP   0.01uF   10%   25V   C208   1-162-970-11   CERAMIC CHIP   0.01uF   10%   25V   C212   1-107-826-11   CERAMIC CHIP   0.01uF   10%   25V   C212   1-107-826-11   CERAMIC CHIP   0.01uF   10%   25V   C213   1-107-826-11   CERAMIC CHIP   0.01uF   10%   25V   C213   1-107-826-11   CERAMIC CHIP   0.01uF   10%   25V   C213   1-107-826-11   CERAMIC CHIP   0.01uF   10%   10V   C213   1-109-982-11   CERAMIC CHIP   0.01uF   10%   10V   C213   1-109-982-11			< CAPACITOR >							(Ref.No.;1000 Se			
C603										< BATTERY >			
C606								BT101	1-756-141-11	BATTERY, MANGA	ANESE LITH	HIUM	
C608   1-127-820-11   CERAMIC   CHIP   CHIP   CERAMIC CHIP   CER										,			
C610	C607	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V				< CAPACITOR >			
C611	C608	1-127-820-11	CERAMIC	4.7uF		16V		C101	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C207			CERAMIC CHIP	0.1uF							10uF		
CONNECTOR   CONNECTOR   CONNECTOR   CONNECTOR   CONNECTOR   FFC/FPC 16P   CONNECTOR   FFC/FPC 16P   CONNECTOR   FFC/FPC 16P   CONNECTOR	C611	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V							
CN601 1-766-346-21 CONNECTOR, FFC/FPC 16P  CD10E			COMMENTOD										
C210			< CUNNECTUR >					G208	1-162-9/0-11	CERAMIC CHIP	0.01uF	10%	25V
C212   1-164-739-11   CERAMIC CHIP   560PF   5%   50V   C213   1-107-687-11   TANTAL. CHIP   3.3uF   20%   20V   C214   1-107-687-11   TANTAL. CHIP   3.3uF   20%   20V   C216   1-107-826-11   CERAMIC CHIP   0.1uF   10%   16V   C216   1-107-826-11   CERAMIC CHIP   0.1uF   10%   10V   C216   1-109-982-11   CERAMIC CHIP   10F   10%   10V   C219   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C219   1-109-982-11   CERAMIC CHIP   2.2uF   10%   10V   C220   1-109-982-11   CERAMIC CHIP   2.2uF   10%   10V   C221   1-109-994-11   CERAMIC CHIP   2.2uF   10%   10V   C221   1-109-994-11   CERAMIC CHIP   1uF   10%   10V   C221   1-109-994-11   CERAMIC CHIP   1uF   10%   10V   C221   1-109-994-11   CERAMIC CHIP   2.2uF   10%   10V   C221   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C221   1-109-982-11   CERAMIC CHIP   2.2uF   2.2	CN601	1-766-346-21	CONNECTOR, FFC	C/FPC 16P				C209	1-162-970-11	CERAMIC CHIP	0.01uF	10%	
D601   8-719-073-01   D10DE   MA111-(K8).S0   C213   1-107-826-11   CERAMIC CHIP   0.1uF   10%   16V   C214   1-107-687-11   TANTAL. CHIP   3.3uF   20%   20V   C216   1-107-826-11   CERAMIC CHIP   0.1uF   10%   16V   C217   1-162-928-11   CERAMIC CHIP   0.1uF   10%   10V   C218   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C219   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C219   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C219   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C220   1-109-982-11   CERAMIC CHIP   2.2uF   10%   10V   C221   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C221   1-109-982-11   CERAMIC CHIP   1uF   10%   10V   C221   1-109-982-11   CERAMIC CHIP   2.2uF													
Name			< DIODE >										
C215	D601	0 710 072 01	DIODE MA111 /	NO) CO									
* FB601 1-500-282-11 FERRITE	וטטט	0-719-073-01	DIODE MATTI-(	NO).30				0214	1-107-007-11	TANTAL. UTIP	s.sur	20%	201
* FB601 1-500-282-11 FERRITE			< FERRITE BEAD	>									
Table   Tabl	* FDC04	1 500 000 11	FEDRITE	011									
C219													
C220	FD002	1-414-445-11	FERRITE	UUIT									
IC601			< IC >					0210	1 100 002 11	OLIVIANIO OTIII	Tui	1070	100
C602   8-759-561-46   IC   AD8014ART-RELT   CONNECTOR   CONNECTO									1-109-982-11				
CONNECTOR   CONN					GER)			C221	1-109-994-11	CERAMIC CHIP	2.2uF	10%	10V
CN101   1-794-057-21   PIN, CONNECTOR (PC BOARD) 2P	10602	8-759-561-46	IC AD8014AR1-I	REEL/						< CONNECTOR >			
L601 1-469-528-91 INDUCTOR 100uH L602 1-469-528-91 INDUCTOR 100uH			< COIL >					ON101	1 704 057 01		) /DC DOAE	ים, סם	
L602 1-469-528-91 INDUCTOR 100uH	1 601	1_460_528_01	INDLICTOR	100uH						,	`	,	
R601 1-216-808-11 METAL CHIP 82 5% 1/16W R602 1-216-829-11 METAL CHIP 1K 5% 1/16W R606 1-216-830-11 METAL CHIP 4.7K 5% 1/16W R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W R606 1-216-830-11 METAL CHIP											` ′		
* CN105 1-695-320-21 PIN, CONNECTOR (1.5MM)(SMD) 2P  R601 1-216-808-11 METAL CHIP 82 5% 1/16W R602 1-216-821-11 METAL CHIP 1K 5% 1/16W R604 1-216-864-91 SHORT 0 R605 1-216-829-11 METAL CHIP 4.7K 5% 1/16W R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W	LOOL	1 100 020 01	II DOOTON	Toodii								10) 01	
R602 1-216-821-11 METAL CHIP 1K 5% 1/16W CN107 1-784-320-11 CONNECTOR, FFC/FPC 6P CN201 1-779-334-11 CONNECTOR, FFC/FPC 20P CN201 1-216-829-11 METAL CHIP 4.7K 5% 1/16W R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W			< RESISTOR >				*					SMD) 2P	
R602 1-216-821-11 METAL CHIP 1K 5% 1/16W CN107 1-784-320-11 CONNECTOR, FFC/FPC 6P CN201 1-779-334-11 CONNECTOR, FFC/FPC 20P CN201 1-216-829-11 METAL CHIP 4.7K 5% 1/16W R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W	R601	1-216-808-11	METAL CHIP	82	5%	1/16W		CN106	1-779-327-11	CONNECTOR FFO	C/FPC 6P		
R604 1-216-864-91 SHORT 0 CN201 1-779-334-11 CONNECTOR, FFC/FPC 20P R605 1-216-829-11 METAL CHIP 4.7K 5% 1/16W R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W													
R605 1-216-829-11 METAL CHIP 4.7K 5% 1/16W R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W					0,3	.,				,			
R606 1-216-830-11 METAL CHIP 5.6K 5% 1/16W					5%	1/16W				,			
R609 1-216-845-11 METAL CHIP 100K 5% 1/16W		1-216-830-11	METAL CHIP	5.6K	5%	1/16W							
	R609	1-216-845-11	METAL CHIP	100K	5%	1/16W							

Be sure to read "Precautions upon replacing CCD imager" on page 4-10 when changing the CCD imager.

# CF-079 CF-080

Ref. No.	Part No.	<u>Description</u>		<u>R</u> (	emarks	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
		< DIODE >				R123 R124	1-216-832-11 1-216-832-11		8.2K 8.2K	5% 5%	1/16W 1/16W
D101		DIODE 01ZA8.2(						(TRV325E	E/TRV330E/	TRV430E	/TRV530E)
D102 D103		DIODE 01ZA8.2(1 DIODE CL-270HF				R125 R126	1-216-838-11 1-216-838-11		27K 27K	5% 5%	1/16W 1/16W
		(TRV325E/	TRV330E/TR	V430E/TR	V530E)			(TRV325E	E/TRV330E/	TRV430E	/TRV530E)
D104 D105		DIODE MA111-(F				R127	1-216-838-11	METAL CHIP	27K	5%	1/16W
D106	0 710 060 16	DIODE 01ZA8.2(	TDI 2)			R128	1-216-841-11	METAL CHIP	47K	5%	1/16W
D106 D107		DIODE 01ZA8.2(				R129	1-216-822-11	METAL CHIP	1.2K	5%	/TRV235E) 1/16W
D108		DIODE 01ZA8.2(				R130	1-216-821-11		1K	5%	1/16W
D109 D202		DIODE UDZSTE- DIODE 1T369-01				R131 R203	1-216-803-11 1-216-853-11		33 470K	5% 5%	1/16W 1/16W
		< FERRITE BEAD :	>			R205 R209	1-218-881-11 1-216-826-11		27K 2.7K	0.5% 5%	1/16W 1/16W
FB201	1-414-760-21	FERRITE	0uH			R210	1-216-841-11		47K	5%	1/16W
FB202	1-414-760-21	FERRITE	0uH			R211	1-216-843-11		68K	5%	1/16W
		< IC >				R212	1-216-837-11	METAL CHIP	22K	5%	1/16W
						R213	1-216-843-11		68K	5%	1/16W
IC201		IC CXA3579R-T4				R214	1-216-857-11		1M	5%	1/16W
IC202	8-732-403-37	IC CXD350TAK-1	4			R215 R216	1-216-845-11 1-216-816-11		100K 390	5% 5%	1/16W 1/16W
		< COIL >				R217	1-216-816-11		390	5%	1/16W
L201	1-469-525-91	INDUCTOR	10uH			R218	1-216-816-11	METAL CHIP	390	5%	1/16W
L202	1-412-949-21	INDUCTOR	6.8uH			R219	1-216-848-11		180K	5%	1/16W
		TDANOIOTOD				R220	1-216-839-11		33K	5%	1/16W
		< TRANSISTOR >				R221 R222	1-216-839-11 1-216-839-11		33K 33K	5% 5%	1/16W 1/16W
Q101	8-729-230-63		2SC4116YG-								
Q102 Q103	8-729-230-72 8-729-042-29		2SA1362-YG RN1104F(TP			R226 R227	1-216-864-91 1-216-864-91		0		
Q105	0-123-042-23		/TRV330E/TR		V530E)	R228	1-216-864-91		0		
		·			<i>'</i>	R229	1-216-864-91		0		
		< RESISTOR >				R230	1-216-864-91	SHORT	0		
R101	1-216-821-11				/16W	R231	1-216-864-91		0		
R102	1-216-810-11		120 5 TRV330E/TR		/16W	R232	1-216-864-91	SHORT	0		
R103	1-216-813-11				/16W			< SWITCH >			
R105	1-216-845-11	METAL CHIP			/16W	0101	1 771 100 00	CWITCH KEY DO	ADD/DECE	Τ\	
R106	1-216-807-11	METAL CHIP	68 5	5% 1/	/16W	S101 S102		SWITCH, KEY BO SWITCH, KEY BO	,	,	
R108	1-216-815-11	METAL CHIP	330 5	5% 1/	/16W	S103		SWITCH, KEY BO			
R109	1-216-822-11 1-216-822-11	METAL CHIP			/16W /16W	C104	1 771 120 00	,	E/TRV330E/	TRV430E	(TRV530E)
R110	1-210-022-11	METAL CHIP (TRV325E)	1.2K 5 TRV330E/TR		I	S104	1-11 1-130-02	SWITCH, KEY BC (TRV3258	E/TRV330E/	TRV430E/	/TRV530E)
R111	1-216-823-11	METAL CHIP	1.5K 5		/16W <sup>′</sup>	S105	1-771-138-82	SWITCH, KEY BO	ARD(END S	SEARCH)	,
R112	1-216-295-11	SHORT	0			S106	1-771-138-82	SWITCH, KEY BC	ARD(MS IN	IDEX)	
R113	1-216-814-11	METAL CHIP		5% 1/	/16W	0.00		(TRV325E	E/TRV330E/	TRV430E	/TRV530E)
R114	1-216-823-11	METAL CHIP			/16W	S107		SWITCH, KEY BO	`	,	
R115	1-216-823-11	METAL CHIP (TRV325E)	1.5K 5 TRV330E/TR		/16W V530E)	S108 S109		SWITCH, KEY BC SWITCH, KEY BC	,	,	
R116	1-216-825-11	METAL CHIP	2.2K 5	5% 1/	/16W ´			(TRV325E	E/TRV330E/	TRV430E	TRV530E)
R117	1-216-825-11	METAL CHIP	2.2K 5	5% 1/	/16W	S110	1-771-138-82	SWITCH, KEY BC	OARD(PB ZC	OOM)	
R118	1-216-825-11	METAL CHIP			/16W	S111		SWITCH, KEY BO			
D110	1 010 000 11		/TRV330E/TR\			S112	1-771-138-82	SWITCH, KEY BO	•	,	/TD\/E205\
R119 R120	1-216-828-11 1-216-828-11	METAL CHIP METAL CHIP			/16W /16W	S113	1-771-138-82	(TRV325) SWITCH, KEY BC	E/TRV330E/ DARD(VOLU		1KV53UE)
R121	1-216-828-11	METAL CHIP	3.9K 5	5% 1/	/16W	S114		SWITCH, KEY BO	)ARD(MEM	ORY MIX)	
D100	1_016 000 11	,	/TRV330E/TR		, ,	C11E	1_771 120 00	,	E/TRV330E/		TRV530E)
R122	1-216-832-11	IVICIAL UNIP	8.2K 5	5% 1/	/16W	S115	1-11 1-138-82	SWITCH, KEY BC	พาคต(ฉพกห	LIGHI)	

	C	F-079 CF-080	FP-270	FP-2	?71 FP	-272	FP-273	FP	P-275
Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
S116 S117 S118	1-771-138-82	SWITCH, KEY BOARD(EDIT SEA SWITCH, KEY BOARD(EDIT SEA SWITCH, KEY BOARD(FADER)	,		A-7074-650-A	FP-272 BOARI	******	of No :200	000 Series)
3110	1-771-130-02	SWITCH, KET BUAND(FADEN)				< CONNECTOR	,	e1.IVO.,30C	Juu Series)
	A-7074-648-A	FP-270 BOARD, COMPLETE		CN202	1-779-369-11			=(INDI)4P	)
		(Ref.N	lo.;30000 Series)	0.1202		0020.01.,		` '	OV IN/OUT)
		< DIODE >				< DIODE >			
D101 D102		DIODE UDZSTE-178.2B DIODE UDZSTE-178.2B		D202	8-719-064-61	DIODE 01BZ	A8.2(TE85L)		
		< JACK >				< JACK >			
J101	1-770-860-11	CONNECTOR, S TERMINAL(S V	(IDEO)	J201	1-793-995-11	JACK, SUPER	SMALL TYPE	(LANC)	
J102	1-778-040-11	JACK, SMALL TYPE(AUDIO/VID	DEO)			< RESISTOR >	•		
		< RESISTOR >		R204 R205	1-216-817-11 1-216-864-91		470 0	5%	1/16W
R101 R102	1-216-864-91 1-216-864-91			R207	1-216-864-91	SHORT	0		
R104 R105	1-216-864-91 1-216-864-91					< VARISTOR >	•		
R107	1-216-864-91	SHORT 0		VDR201	1-801-923-11	VARISTOR, CH	HIP		
R108 R109	1-216-864-91 1-216-864-91	SHORT 0			A-7074-651-A		,		
R110			0% 16V (Note)			******		ef.No.;300	000 Series)
R111	1-107-826-11	CERAMIC CHIP 0.1uF 1	0% 16V (Note)			< JACK >			
		< VARISTOR >		J301 J302	1-695-514-21 1-691-737-11				
		VARISTOR, CHIP VARISTOR, CHIP		0002	1-031-737-11	< PHOTO INTE	, , ,	LOGINI	OWLIT
VDR103	1-803-974-21	VARISTOR, CHIP VARISTOR, CHIP		PH301	8-759-014-54				
		VARISTOR, CHIP		PH302		HIC CNA1312			
	A-7074-649-A	FP-271 BOARD, COMPLETE			A-7074-652-A	FP-275 BOARI	D, COMPLETE		
		(TRV325E/TRV330E/TR	,			*****		ef.No.;300	000 Series)
		(Ref.N	lo.;30000 Series)			< DIODE >			
		< CAPACITOR >		D401	8-719-074-30	DIODE SML-	310LTT86		
C201	1-162-966-11	CERAMIC CHIP 0.0022uF 1	10% 50V	D402	8-719-064-61	DIODE 01BZ	A8.2(TE85L)		
		< CONNECTOR >				< RESISTOR >	•		
CN201	1-794-962-11	CONNECTOR, SQUARE TYPE(U	SB 5P)	R403 R404	1-216-825-11 1-216-828-11		2.2K 3.9K	5% 5%	1/16W 1/16W
		< DIODE >		R405 R406	1-216-823-11 1-216-832-11		1.5K 8.2K	5% 5%	1/16W 1/16W
D201	8-719-073-01	DIODE MA111-(K8).S0		R407	1-216-825-11		2.2K	5%	1/16W
		< LINE FILTER >		R408 R409	1-216-828-11 1-216-821-11		3.9K 1K	5% 5%	1/16W 1/16W
LF201 LF202		COIL, COMMON-MODE CHOKE COIL, COMMON-MODE CHOKE		R410	1-216-823-11	METAL CHIP	1.5K	5%	1/16W

Note: Capacitor is mounted to the location where R110,R111 are printed.

FP-2	75 FP-	-282 FP-283 FU-150	FU-15	54				
Ref. No.	Part No.	<u>Description</u> <u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
		< SWITCH >	D407 D408		DIODE 01ZA8.2			
S401 S402		SWITCH, KEY BOARD (STOP) SWITCH, KEY BOARD (SUPER NIGHT SHOT)	D-100	0 713 027 70	< FUSE >	11110		
S403 S404	1-771-138-82	SWITCH, KEY BOARD (FF)	A F404	1 570 400 01		201/4 441		
S404 S405		SWITCH, KEY BOARD (PAUSE) SWITCH, KEY BOARD (SUPER LASER LINK)	△ F401 △ F402	1-576-406-21	FUSE,MICRO(160 FUSE,MICRO(160	08)(1.4A)		
\$406		SWITCH, KEY BOARD (REC)	△ F403 △ F404	1-576-406-21	FUSE,MICRO(160 FUSE,MICRO(160	08)(1.4A)		
S407 S408	1-771-138-82	SWITCH, KEY BOARD (REW) SWITCH, KEY BOARD (REC)	<u></u> <b>▲ F405</b>	1-5/6-406-21	FUSE,MICRO(160 (TRV325E		/TRV430	E/TRV530E)
S409	1-771-138-82	SWITCH, KEY BOARD (PLAY)	<b>Æ</b> F406	1-576-406-21	FUSE,MICRO(160	08)(1.4A)		
	A-7074-653-A	FP-282 BOARD, COMPLETE ***********************************			< COIL >			
		(Ref.No.;30000 Series	L401	1-412-056-11	INDUCTOR	4.7uH		
		< SWITCH >			< LINE FILTER >			
S501	1-762-650-21	SWITCH, SLIDE(FOCUS AUTO/MANUAL)	LF401	1-411-957-11	FILTER, COMMO	N MODE		
	A 7074 654 A	ED 202 DOADD COMPLETE			< TRANSISTOR >			
	A-7074-004-A	FP-283 BOARD, COMPLETE ***********************************	Q401		TRANSISTOR	SSM3K0	,	3)
		(Ref.No.;30000 Series	Q403	8-729-804-41	TRANSISTOR TRANSISTOR	HAT1054 2SB1122	-ST-TD	
	. ==== =.	< SWITCH >	Q404 Q405		TRANSISTOR TRANSISTOR	RN1104F RN1104F	,	
S601	1-7/1-483-81	SWITCH, PUSH (1 KEY)(PANEL REV)	Q407	8-729-042-56	TRANSISTOR	MGSF34		E (TD) (00.5E)
	A-7074-725-A	FU-150 (PF) BOARD, COMPLETE	Q408	8-729-051-49	TRANSISTOR	TPC8305	(TE12L)	E/TRV235E)
	. 707.4 707.4	(TRV325E/TRV330E	Q409		TRANSISTOR	2SJ305(	ΓE85L)	E/TRV530E)
	A-7074-767-A	FU-150 (P) BOARD, COMPLETE (TRV230E/TRV235E	Q410 Q411		TRANSISTOR TRANSISTOR	RN2104F RN2104F	(TPL3)	
	A-7074-811-A	**************************************			,			E/TRV530E)
		(TRV430E/TRV530E	Q412	8-729-023-89	TRANSISTOR (TRV325E	2SJ305(7 TRV330E		E/TRV530E)
		(Ref.No.;1000 Series			< RESISTOR >			
		< CAPACITOR >	R401	1-216-821-11		1K	5%	1/16W
C401 C402	1-107-826-11 1-107-826-11	CERAMIC CHIP 0.1uF 10% 16V CERAMIC CHIP 0.1uF 10% 16V	R402 R403	1-216-295-11 1-216-821-11		0 1K	5%	1/16W
C403 C404		CERAMIC CHIP 0.022uF 10% 25V TANTAL. CHIP 22uF 20% 16V	R406	1-216-853-11		470K	5% 5%	1/16W 1/16W
C404		TANTAL. CHIP 22uF 20% 16V TANTAL. CHIP 22uF 20% 16V	R407	1-216-857-11		1M		
C406	1-119-751-11	TANTAL. CHIP 22uF 20% 16V	R408 R409	1-216-150-91 1-216-821-11		10 1K	5% 5%	1/8W 1/16W
C409	1-109-982-11	CERAMIC CHIP 1uF 10% 10V	R410	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
C410	1-109-982-11	CERAMIC CHIP 1uF 10% 10V (TRV325E/TRV330E/TRV430E/TRV530E	R420	1-216-821-11	METAL CHIP (TRV325E	1K E/TRV330E	5% /TRV430	1/16W E/TRV530E)
		< CONNECTOR >	R421	1-216-821-11		1K E/TRV330E	5% /TRV430	1/16W E/TRV530E)
* CN401	1_580_780_91	PIN, CONNECTOR (SMD) 6P	R422	1-216-857-11	METAL CHIP	1M	5%	1/16W
CN401		CONNECTOR, FFC/FPC 12P	R423	1-216-809-11		100	5%	1/16W
CN403		CONNECTOR, BOARD TO BOARD 48P	R424	1-216-841-11		47K	5%	1/16W
		< DIODE >	R425	1-216-809-11		100 TRV330F	5% /TR\/430	1/16W E/TRV530E)
		□IODE /     □	R426	1-216-857-11	,	1M	5%	1/16W
D401		DIODE 15S357-TPH3			(TRV325E	TRV330E	/TRV430	E/TRV530E)
D402 D404 D405	8-719-056-85	DIODE 01ZA8.2(TPL3) DIODE UDZSTE-178.2B DIODE 01ZA8.2(TPL3)	R427	1-216-841-11		47K	5% /TD\//30	1/16W
D405 D406		DIODE 01ZA8.2(TPL3) DIODE 01ZA8.2(TPL3)			(1710/020	./ 111V 33UE,	1111430	E/TRV530E)

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

LB-068	LB-070	PC-082

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
1101. 110.		LB-068 (SB) BOA	RD. COMP	I FTF	riomanio	C1174	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
		(TRV230E	TRV235E/	TRV325E	/TRV330E)	C1175	1-162-913-11	CERAMIC CHIP	8PF	0.50PF	50V
	. 7074 070 4	*********			******	C1176	1-162-913-11	CERAMIC CHIP	8PF		50V
	A-7074-678-A	LB-070 (SB) BOA			/TRV530E)	C1177 C1178	1-107-826-11 1-107-826-11	CERAMIC CHIP CERAMIC CHIP	0.1uF 0.1uF	10% 10%	16V 16V
		*****				61176	1-107-020-11	CENAIVIIC CHIP	U.TUF	10%	100
			(1	Ref.No.;10	000 Series)	C1179	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
						C1180	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		< CAPACITOR >				C1181 C1182	1-107-826-11 1-107-826-11	CERAMIC CHIP CERAMIC CHIP	0.1uF 0.1uF	10% 10%	16V 16V
C702	1-164-505-11	CERAMIC CHIP	2.2uF		16V	C1183	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		< CONNECTOR >				C1185 C1189	1-107-826-11 1-107-826-11	CERAMIC CHIP CERAMIC CHIP	0.1uF 0.1uF	10% 10%	16V 16V
CN701	1-779-334-11	CONNECTOR, FFO	C/FPC 20P			C1199	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
CN702	1-691-354-21	CONNECTOR, FFO		16P		C1191	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		DIODE				C1192	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		< DIODE >				C1194	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
<b>△</b> D701	8-719-082-33	DIODE NSCW10	0-T38			C1195	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
D702	8-719-074-30	DIODE SML-310				C1196	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
						C1197	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
		< IC >				C1902	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
IC701	8-759-581-11	IC NJM2125F(T	E2)			C1903	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
						C1904	1-135-201-11	TANTALUM CHIP		20%	4V
		< TRANSISTOR >				C1905	1-135-201-11	TANTALUM CHIP		20%	4V
0704	0.750.054.40	TDANCICTOR	11004004	00000		C1906	1-164-315-11	CERAMIC CHIP	470PF	2%	50V
Q701 Q702	8-759-054-48 8-729-054-45	TRANSISTOR TRANSISTOR	UP04601 UP04312			C1907	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
						C1908	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		< RESISTOR >				C1909 C1910	1-107-826-11 1-107-826-11	CERAMIC CHIP CERAMIC CHIP	0.1uF	10% 10%	16V 16V
R701	1-218-883-11	METAL CHIP	33K	0.5%	1/16W	C1910	1-107-826-11	CERAMIC CHIP	0.1uF 0.1uF	10%	16V
R702	1-218-901-11	METAL CHIP	180K	0.5%	1/16W	C1912	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R703	1-216-827-11	METAL CHIP	3.3K	5%	1/16W						
R704	1-211-985-11	METAL CHIP	47	0.5%	1/16W	C1914	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
R705	1-216-821-11	METAL CHIP	1K	5%	1/16W			< CONNECTOR >			
R706	1-216-839-11	METAL CHIP	33K	5%	1/16W						
		. THEDMICTOD .				I .	1-779-327-11	CONNECTOR, FFC			
		< THERMISTOR >	>				1-573-352-11	CONNECTOR, FFC		ARD 1001	0
TH701	1-810-811-11	THERMISTOR, N	TC (1608)								
								< DIODE >			
	A-7074-647-A	PC-082 BOARD,				D1151	8-719-073-01	- (			
		,			/TRV530E)	D1152	8-719-056-85	DIODE UDZSTE-	178.2B		
		**********			000 Series)			< FERRITE BEAD :	`		
			(		200 001.00)						
		< CAPACITOR >				I .	1-414-760-21		0uH		
C1151	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	I .	1-414-760-21 1-414-813-11	FERRITE FERRITE	OuH OuH		
C1154		CERAMIC CHIP	0.1uF	10%	16V		1-414-760-21		OuH		
C1156		CERAMIC CHIP	0.1uF	10%	16V		1-500-282-11		0uH		
C1158		CERAMIC CHIP	470PF	2%	50V						
C1160	1-164-315-11	CERAMIC CHIP	470PF	2%	50V		1-414-760-21	FERRITE	0uH		
04404	1 107 000 11	CEDAMIC CLUB	0.4	100/	161/		1-414-760-21	FERRITE	OuH		
C1161 C1163		CERAMIC CHIP CERAMIC CHIP	0.1uF 0.1uF	10% 10%	16V 16V	I .	1-414-760-21 1-414-760-21	FERRITE FERRITE	OuH OuH		
C1166		CERAMIC CHIP	0.1uF	10%	16V	101303	1 717 700-21	LITTLE	Juli		
C1167		CERAMIC CHIP	0.1uF	10%	16V			< IC >			
C1168		TANTALUM CHIP	10uF	20%	4V	101151	0.750.074.60		TEOES		
C1169	1-135-201-11	TANTALUM CHIP	10uF	20%	4V			IC TC7SHU04FU IC TC7S08F(TE8			
C1170		CERAMIC CHIP	0.1uF	10%	16V			IC MB81F16162			
C1171		CERAMIC CHIP	0.1uF	10%	16V	IC1154		IC MBM29LV400		N-S116-EI	R
C1172	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	IC1155	8-759-668-50	IC HD6417197FL	_77		
C1173	1-135-201-11	TANTALUM CHIP	10uF	20%	4V						

Note: The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety. Replace only with part number specified.

# PC-082 PD-138

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
IC1157		•	D\\\/ 110		1101111111110	R1203	1-216-853-11	•	470K	5%	1/16W
IC1157	8-759-657-69 8-759-525-53	IC PDIUSBP11A IC RN5RZ31BA-				R1203 R1205	1-216-809-11		470K 100	5% 5%	1/16W
IC1156	8-759-082-58	IC TC7W08FU(T				R1203	1-216-853-11		470K	5% 5%	1/16W 1/16W
IC1160	8-759-082-58	IC TC7W08FU(T				R1208	1-216-845-11		100K	5%	1/16W
IC1901	8-759-699-91	IC MB87J4421P				R1211	1-216-821-11		1K	5%	1/16W
101001	0 700 000 01	10 11107011211	II G DIVD			111211	1 210 021 11	WEINE OIII	110	0 70	1/1011
		< COIL >				R1903	1-216-864-91	SHORT	0		
						R1905	1-216-864-91		0		
L1151	1-469-528-91	INDUCTOR	100uH			R1906	1-216-841-11	METAL CHIP	47K	5%	1/16W
						R1907	1-216-864-91		0		
		< TRANSISTOR >				R1912	1-216-864-91	SHORT	0		
0=0						5.0					
Q1153	8-729-042-29		RN1104F			R1914	1-216-864-91	SHORT	0		
Q1154	8-729-042-72		RN1107F		עם וכ			. COMPOSITION	CIDCILIT DI	001/ >	
Q1155 Q1156	8-729-037-53 8-729-037-61		2SA1832I		<sup>2</sup> L3)			< COMPOSITION	CIRCUIT BI	_UUK >	
Q1902	8-729-037-61		RN2104F RN2104F	` '		DR1151	1_92/1_277_91	RES, NETWORK 4	1 7KY/I	(1005)	
Q1302	0-729-037-01	MANOIOTON	111121041	(TFL3)				RES, NETWORK 4		(1005)	
Q1903	8-729-042-29	TRANSISTOR	RN1104F	(TPL3)				RES, NETWORK		(1005)	
41000	0 720 0 12 20	110,000,0101		(11 20)				RES, NETWORK		(1005)	
		< RESISTOR >						RES, NETWORK		(1005)	
								,		,	
R1151	1-216-864-91	SHORT	0					< VARISTOR >			
R1152	1-216-857-11	METAL CHIP	1M	5%	1/16W						
R1153	1-216-864-91	SHORT	0			VDR111	1-801-862-11	VARISTOR, CHIP			
R1154	1-216-829-11	METAL CHIP	4.7K	5%	1/16W	VDR112	1-801-862-11	VARISTOR, CHIP			
R1155	1-216-841-11	METAL CHIP	47K	5%	1/16W						
D4450	4 040 057 44	METAL OLUB	48.0	<b>5</b> 0/	4.4.0044			< VIBRATOR >			
R1156	1-216-857-11	METAL CHIP	1M	5%	1/16W	V44E4	1 701 000 01	VIDDATOD OFDA	NAIO / AONALI	_\	
R1157	1-216-864-91	SHORT	0			X1151		VIBRATOR, CERA	,	,	
R1158 R1159	1-216-864-91 1-216-845-11		0 100K	5%	1/16W	X1152	1-781-762-21	VIBRATOR, CRYS	IAL(25.804	łownz)	
R1160	1-216-845-11	METAL CHIP	100K	5%	1/16W						
111100	1-210-045-11	WILIAL OITH	1001	J /0	1/1000		Δ-7074-827-Δ	PD-138 (Y12) BO	ARD COME	PLETE (TI	RV430F)
D4404	1-216-829-11	METAL CHIP	4.7K	5%	1/16W		7. 707 1 027 7.	********			
R1161					1/10//						
R1161 R1163	1-216-805-11		47	5%	1/16W						000 Series)
R1161 R1163 R1165		METAL CHIP METAL CHIP									
R1163	1-216-805-11	METAL CHIP	47	5%	1/16W			< CAPACITOR >			
R1163 R1165	1-216-805-11 1-216-845-11	METAL CHIP METAL CHIP	47 100K	5% 5%	1/16W 1/16W					f.No.;200	000 Series)
R1163 R1165 R1166 R1167	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11	METAL CHIP METAL CHIP METAL CHIP METAL CHIP	47 100K 100K 100K	5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W	C5501		< CAPACITOR >	(Re	f.No.;200 20%	000 Series) 4V
R1163 R1165 R1166 R1167	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11	METAL CHIP METAL CHIP METAL CHIP METAL CHIP	47 100K 100K 100K 100K	5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W	C5503	1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP	22uF 0.1uF	20% 10%	000 Series) 4V 16V
R1163 R1165 R1166 R1167 R1168 R1169	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11	METAL CHIP	47 100K 100K 100K 100K	5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504	1-107-826-11 1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF	20% 10% 10%	4V 16V 16V
R1163 R1165 R1166 R1167 R1168 R1169 R1170	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K	5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505	1-107-826-11 1-107-826-11 1-162-970-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF	20% 10% 10% 10%	4V 16V 16V 25V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100	5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504	1-107-826-11 1-107-826-11 1-162-970-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF	20% 10% 10%	4V 16V 16V
R1163 R1165 R1166 R1167 R1168 R1169 R1170	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K	5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF	20% 10% 10% 10% 10%	4V 16V 16V 25V 25V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11 1-216-809-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100	5% 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF	20% 10% 10% 10% 10%	4V 16V 16V 25V 25V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11 1-216-809-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100	5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF	20% 10% 10% 10% 10% 10%	4V 16V 16V 25V 25V 25V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100	5% 5% 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF	20% 10% 10% 10% 10%	4V 16V 16V 25V 25V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11 1-216-809-11	METAL CHIP SHORT	47 100K 100K 100K 100K 100K 3.3K 100 100	5% 5% 5% 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF	20% 10% 10% 10% 10% 10% 20%	4V 16V 16V 25V 25V 25V 16V 20V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11	METAL CHIP SHORT METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 0	5% 5% 5% 5% 5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 1uF 0.1uF	20% 10% 10% 10% 10% 10% 10% 10%	4V 16V 16V 25V 25V 25V 26V 16V 20V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-84-91 1-216-845-11 1-216-841-11 1-211-978-11	METAL CHIP SHORT METAL CHIP METAL CHIP METAL CHIP METAL CHIP METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 0 100K 47K 24	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 10% 10% 20% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-84-91 1-216-845-11 1-216-841-11 1-211-978-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 0 100K 47K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 10% 10% 50%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-216-841-11 1-211-978-11 1-211-978-11 1-216-821-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 47K 24 24 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-135-259-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP TANTAL. CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 10% 20% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1179 R1180 R1181	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-216-841-11 1-211-978-11 1-211-978-11 1-216-821-11 1-216-823-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 47K 24 24 1K 1.5K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-164-739-11 1-107-826-11 1-107-826-11 1-107-826-11 1-135-259-11 1-164-357-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.01uF	20% 10% 10% 10% 10% 10% 10% 5% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1179 R1180 R1181 R1182	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-216-841-11 1-211-978-11 1-216-821-11 1-216-823-11 1-216-829-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 47K 24 24 1K 1.5K 4.7K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-164-739-11 1-107-826-11 1-107-826-11 1-107-826-11 1-135-259-11 1-164-357-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP TANTAL. CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 10% 20% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1179 R1180 R1181	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-216-841-11 1-211-978-11 1-211-978-11 1-216-821-11 1-216-823-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 47K 24 24 1K 1.5K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 10% 20% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1178 R1180 R1181 R1182 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-216-841-11 1-211-978-11 1-216-821-11 1-216-823-11 1-216-829-11 1-216-821-11	METAL CHIP	47 100K 100K 100K 100K 100K 3.3K 100 100 100 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5% 0.5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516	1-107-826-11 1-107-826-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 20% 10% 5% 10% 5% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1179 R1180 R1181 R1182 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-84-91 1-216-841-11 1-211-978-11 1-216-821-11 1-216-823-11 1-216-829-11 1-216-829-11	METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5% 0.5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11 1-107-826-11 1-107-826-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CER	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.01uF 0.01uF	20% 10% 10% 10% 10% 10% 20% 10% 5% 10% 5% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 50V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1178 R1180 R1181 R1182 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-216-841-11 1-211-978-11 1-216-821-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-91	METAL CHIP SHORT	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5% 0.5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CER	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.01uF 0.01uF 0.001uF	20% 10% 10% 10% 10% 10% 20% 5% 10% 5% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1178 R1180 R1181 R1182 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-211-978-11 1-216-821-11 1-216-823-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-91 1-216-864-91	METAL CHIP SHORT SHORT	47 100K 100K 100K 100K 3.3K 100 100 100 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 0.5% 5% 5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP TANTAL. CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.001uF 0.001uF 82PF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 20% 5% 10% 5% 10% 20% 5% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1180 R1181 R1182 R1185 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11 1-216-841-11 1-216-841-11 1-216-823-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-11 1-216-849-11 1-216-845-11	METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 0.5% 0.5% 5% 5%	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-135-177-21 1-107-826-11 1-164-739-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP CER	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.01uF 0.01uF 0.001uF	20% 10% 10% 10% 10% 10% 20% 5% 10% 5% 10% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1178 R1180 R1181 R1182 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-841-11 1-211-978-11 1-216-821-11 1-216-823-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-91 1-216-864-91	METAL CHIP SHORT SHORT	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-164-357-11 1-162-926-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-113-994-11 1-127-573-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP TANTAL. CHIP	22uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.001uF 0.001uF 82PF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 20% 5% 10% 5% 10% 20% 5% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 50V
R1163 R1165 R1166 R1167 R1168 R1169 R1170 R1171 R1172 R1173 R1174 R1176 R1177 R1178 R1180 R1181 R1182 R1185 R1185	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-827-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11 1-216-841-11 1-216-841-11 1-216-823-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-11 1-216-849-11 1-216-845-11	METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520 C5521	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-164-357-11 1-162-926-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-113-994-11 1-127-573-11	< CAPACITOR >  TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	22uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.01uF 0.01uF 0.01uF 0.001uF	20% 10% 10% 10% 10% 10% 10% 20% 5% 10% 5% 10% 20% 5% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 50V 16V 16V 16V 16V 16V
R1163 R1165 R1166 R1167  R1168 R1169 R1170 R1171 R1172  R1173 R1174 R1176 R1177 R1178  R1179 R1180 R1181 R1182 R1185  R1186 R1187 R1188 R1189 R1190  R1191 R1192	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11 1-216-841-11 1-216-821-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-11 1-216-849-11 1-216-845-11 1-216-849-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11	METAL CHIP SHORT SHORT METAL CHIP METAL CHIP SHORT SHORT METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100 47K 24 24 1K 1.5K 4.7K 1K 4.7K 0 0 100K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520 C5521	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-135-259-11 1-164-357-11 1-162-926-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP TANTALUM CHIP TANTALUM CHIP	22uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.001uF 1.uF 0.001uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 20% 5% 5% 10% 20% 5% 5% 10% 10% 20% 5%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 16V 16V 16V 16V 16V 16V 16V 16V 25V
R1163 R1165 R1166 R1167  R1168 R1169 R1170 R1171 R1172  R1173 R1174 R1176 R1177 R1178  R1178  R1180 R1181 R1182 R1185  R1186 R1187 R1188 R1189 R1190  R1191 R1192 R1193	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11 1-216-841-11 1-216-821-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11	METAL CHIP SHORT SHORT METAL CHIP METAL CHIP METAL CHIP SHORT SHORT METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K 4.7K 0 0 100K 100K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520 C5521 C5524 C5527 C5528 C5530	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-162-926-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	22uF 0.1uF 0.01uF 0.01uF 0.01uF 0.01uF 0.1uF 1.uF 0.1uF 0.1uF 0.1uF 1.0uF 0.001uF 1.0uF 0.001uF 1.0uF 0.001uF 0.1uF 0.001uF 0.1uF 0.001uF 0.1uF 0.001uF	20% 10% 10% 10% 10% 10% 10% 5% 10% 5% 10% 5% 10% 10% 10% 10% 10% 10% 10%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 16V 16V 16V 16V 16V 16V 16V 25V 25V
R1163 R1165 R1166 R1167  R1168 R1169 R1170 R1171 R1172  R1173 R1174 R1176 R1177 R1178  R1178  R1180 R1181 R1182 R1185  R1186 R1187 R1188 R1189 R1190  R1191 R1192 R1193 R1194	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11 1-216-841-11 1-216-821-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-847-11 1-216-847-11 1-216-847-11	METAL CHIP SHORT SHORT METAL CHIP METAL CHIP SHORT METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K 4.7K 0 0 100K 100K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520 C5521	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-162-926-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP TANTALUM CHIP TANTALUM CHIP	22uF 0.1uF 0.01uF 0.01uF 0.01uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF 0.001uF 10uF 0.001uF 10uF 0.1uF 0.1uF 0.1uF 0.1uF 0.1uF	20% 10% 10% 10% 10% 10% 20% 5% 5% 10% 20% 5% 5% 10% 10% 20% 5% 10% 20% 10% 20% 10% 20%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 16V 16V 16V 16V 16V 16V 16V 16V 25V
R1163 R1165 R1166 R1167  R1168 R1169 R1170 R1171 R1172  R1173 R1174 R1176 R1177 R1178  R1178  R1180 R1181 R1182 R1185  R1186 R1187 R1188 R1189 R1190  R1191 R1192 R1193	1-216-805-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-845-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-809-11 1-216-845-11 1-216-841-11 1-216-821-11 1-216-829-11 1-216-829-11 1-216-829-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11 1-216-849-11	METAL CHIP SHORT SHORT METAL CHIP METAL CHIP SHORT METAL CHIP	47 100K 100K 100K 100K 3.3K 100 100 100 100K 47K 24 24 1K 1.5K 4.7K 1K 4.7K 0 0 100K 100K	5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5% 5	1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W 1/16W	C5503 C5504 C5505 C5506 C5507 C5508 C5509 C5510 C5511 C5512 C5513 C5514 C5515 C5516 C5517 C5518 C5519 C5520 C5521 C5524 C5527 C5528 C5530	1-107-826-11 1-162-970-11 1-162-970-11 1-162-970-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-107-826-11 1-162-926-11 1-107-826-11	CAPACITOR > TANTAL. CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTAL. CHIP CERAMIC CHIP TANTALUM CHIP CERAMIC CHIP	22uF 0.1uF 0.01uF 0.01uF 0.01uF 0.01uF 0.1uF 1.uF 0.1uF 0.1uF 0.1uF 1.0uF 0.001uF 1.0uF 0.001uF 1.0uF 0.001uF 0.1uF 0.001uF 0.1uF 0.001uF 0.1uF 0.001uF	20% 10% 10% 10% 10% 10% 10% 5% 10% 5% 10% 5% 10% 10% 10% 10% 10% 10% 10%	4V 16V 16V 25V 25V 25V 16V 20V 16V 50V 16V 6.3V 50V 16V 16V 16V 16V 16V 16V 16V 25V 25V

Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
C5602		CERAMIC CHIP	4.7uF	10%	10V	R5513	1-216-857-11	· · · · · · · · · · · · · · · · · · ·	1M	5%	1/16W
C5604		CERAMIC CHIP	0.015uF	10%	50V	R5515	1-216-864-91		0	J /0	1/1000
C5605		CERAMIC CHIP	0.1uF	10%	16V	R5516	1-216-833-11	METAL CHIP	10K	5%	1/16W
C5606		CERAMIC CHIP CERAMIC CHIP	0.1uF 12PF	10% 10%	16V 3KV	R5521 R5523	1-216-864-91 1-216-809-11		0 100	5%	1/16W
<b>△</b> C5607	1-131-939-91	GENAIVIIG GRIP	1277	10%	SNV	noozo	1-210-009-11	WETAL CHIP	100	370	1/1000
C5704	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R5524	1-216-809-11		100	5%	1/16W
		OONNEOTOD				R5525	1-216-809-11		100	5%	1/16W
		< CONNECTOR >				R5551 R5553	1-216-841-11 1-216-829-11		47K 4.7K	5% 5%	1/16W 1/16W
CN5501	1-691-362-11	CONNECTOR, FFO	C/FPC (ZIF)	24P		R5557	1-216-864-91		0	0 70	1/1000
		CONNECTOR, BO			)					==.	
		CONNECTOR, FFO		10P		R5562 R5563	1-216-833-11 1-216-841-11		10K 47K	5% 5%	1/16W 1/16W
	1-766-336-21					R5564	1-216-857-11		1M	5%	1/16W
		,				R5565	1-216-857-11		1M	5%	1/16W
		PIN, CONNECTOR		RD) 6P		R5569	1-216-848-11	METAL CHIP	180K	5%	1/16W
UN3703	1-779-333-21	CONNECTOR, FFO	J/FPU 22P			R5570	1-216-845-11	METAL CHIP	100K	5%	1/16W
		< DIODE >				R5571	1-216-857-11		1M	5%	1/16W
						R5572	1-216-821-11		1K	5%	1/16W
D5502 D5503		DIODE 1T369-0 DIODE MA111-(				R5573 R5573	1-216-864-11 1-216-864-91		0	5%	1/16W
D5503		DIODE MA111-(				n0073	1-210-004-91	SHUNI	U		
			,			R5574	1-216-864-91		0		
		< FERRITE BEAD	>			R5575	1-216-864-91 1-216-833-11		0	E0/	4 /4 C/M
FB5502	1-414-760-21	FERRITE	0uH			R5609 R5610	1-216-833-11		10K 1.8K	5% 5%	1/16W 1/10W
	1-414-760-21		0uH			R5611	1-216-848-11		180K	5%	1/16W
FB5504	1-414-760-21	FERRITE	0uH			D5040	4 040 007 44	METAL OLUB	001/	<b>5</b> 0/	4 /4 004 /
		< IC >				R5612 R5613	1-216-837-11 1-216-055-00		22K 1.8K	5% 5%	1/16W 1/10W
		(10)				R5614	1-216-835-11		1.5K	5%	1/16W
		IC RB5P003AM	1			R5616	1-216-809-11		100	5%	1/16W
105502			E40D)			R5617	1-216-837-11	METAL CHIP	22K	5%	1/16W
IC5601 IC5602		IC TC7W53FU(TIC TA75S393F-T				R5618	1-216-817-11	METAL CHIP	470	5%	1/16W
		IC BU9735K-E2				R5712	1-216-855-11		680K	5%	1/16W
		0011						TDANCEODAE	D		
		< COIL >						< TRANSFORME	K >		
L5501	1-469-525-91		10uH			<b></b> ∆ T5601	1-435-785-21	TRANSFORMER,	INVERTER		
L5505 L5601	1-412-956-21 1-419-387-21	INDUCTOR INDUCTOR	27uH 100uH								
L3001	1-419-307-21	INDUCTOR	тооип				A-7074-674-A	PD-139 (Z12) BC	ARD, COM	PLETE (TI	RV530E)
		< TRANSISTOR >	•					*********			*****
Q5502	8-729-041-23	TRANSISTOR	MGSF1P0	101 T1				PD-139 (X12) BC 30E:AEP,UK/TRV23			NE-VEDIIK)
Q5502	8-729-037-74	TRANSISTOR	UN9213J-				(111020	*********			, ,
Q5510	8-759-054-48	TRANSISTOR	UP04601	008Ś0			A-7074-786-A	PD-139 (X6) BOA			
Q5511 Q5601	8-759-054-48 8-729-037-74	TRANSISTOR TRANSISTOR	UP04601					(TRV230E:E,I			
Q300 I	0-129-031-14	THANSISTUR	UN9213J-	-(NO).3U			A-7074-791-A	PD-139 (SGX6) E			
Q5602	8-729-039-43	TRANSISTOR	FP216-TL					, ,	,	`	V330E:CN)
Q5603	8-729-054-45	TRANSISTOR	UP04312	008S0				**********			
		< RESISTOR >							(ni	;1.NO.,2U	000 Series)
								< CAPACITOR >			
R5501 R5503	1-216-853-11 1-218-895-11	METAL CHIP METAL CHIP	470K 100K	5% 0.5%	1/16W 1/16W	C5501	1 104 947 11	TANTAL. CHIP	22uF	20%	4V
R5505	1-216-835-11	METAL CHIP	15K	0.5% 5%	1/16W	C5503	1-104-647-11		22ur 0.1uF	10%	4 V 16 V
R5506	1-216-826-11	METAL CHIP	2.7K	5%	1/16W	C5504	1-107-826-11		0.1uF	10%	16V
R5507		METAL CHIP	47K	5%	1/16W	C5505		CERAMIC CHIP	0.01uF	10%	25V
110007	1-216-841-11	WEIAL OITH				C5506	1-162-970-11	CERAMIC CHIP	0.01uF	10%	: /m \ /
			68K	5%	1/16W/					1070	25V
R5508 R5509	1-216-841-11 1-216-843-11 1-216-837-11	METAL CHIP METAL CHIP	68K 22K	5% 5%	1/16W 1/16W	C5507	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
R5508 R5509 R5510	1-216-843-11 1-216-837-11 1-216-843-11	METAL CHIP METAL CHIP METAL CHIP	22K 68K	5% 5%	1/16W 1/16W	C5508	1-107-826-11	CERAMIC CHIP	0.1uF	10% 10%	25V 16V
R5508 R5509 R5510 R5511	1-216-843-11 1-216-837-11 1-216-843-11 1-216-857-11	METAL CHIP METAL CHIP METAL CHIP METAL CHIP	22K 68K 1M	5% 5% 5%	1/16W 1/16W 1/16W	C5508 C5509	1-107-826-11 1-107-687-11	CERAMIC CHIP TANTAL. CHIP	0.1uF 3.3uF	10% 10% 20%	25V 16V 20V
R5508 R5509 R5510	1-216-843-11 1-216-837-11 1-216-843-11	METAL CHIP METAL CHIP METAL CHIP	22K 68K	5% 5%	1/16W 1/16W	C5508	1-107-826-11 1-107-687-11 1-107-826-11	CERAMIC CHIP TANTAL. CHIP	0.1uF	10% 10%	25V 16V

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

# PD-139

<u>R</u>	ef. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	Description			<u>Remarks</u>
	C5512	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V			< TRANSISTOR >	•		
	C5515		CERAMIC CHIP	0.001uF	5%	50V			(110,000,010,1017)			
			CERAMIC CHIP	68PF	5%	50V	Q5503	8-759-054-48	TRANSISTOR	UP046010	08S0	
		(TRV23	0E:AEP,UK/TRV23	E/TRV325E	TRV330	E:AEP,UK)	Q5504	8-729-042-26	TRANSISTOR	2SB1462J	-QR(K8).	SO.
	C5516	1-162-926-11	CERAMIC CHIP	82PF	5%	50V	Q5505	8-729-041-23		NDS356A	P .	
			(TRV230E:E,HK,A				Q5506	8-729-037-74		UN9213J-		
	C5516	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	Q5508	8-759-054-48	TRANSISTOR	UP046010	08S0	
						(TRV530E)	05004	0 700 007 74	TD 411010T0D	118100401	(1(0), 00	
	05517	1 100 000 11	CEDAMIC CUID	4	100/	101/	Q5601	8-729-037-74 8-729-039-43		UN9213J-	(K8).SU	
	C5517 C5518		CERAMIC CHIP CERAMIC CHIP	1uF 1uF	10% 10%	10V 10V	Q5602 Q5603	8-729-039-43		FP216-TL UP043120	nocn	
			CERAMIC CHIP	1uF	10%	10V 10V	Q3003	0-729-054-45	THANSISTUR	07043120	10030	
			CERAMIC CHIP	1uF	10%	10V			< RESISTOR >			
	C5533		CERAMIC CHIP	4.7uF	10%	10V			(1120101011)			
							R5501	1-216-853-11	METAL CHIP	470K	5%	1/16W
	C5534	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	R5503	1-218-893-11	METAL CHIP	82K	0.5%	1/16W
	C5536		CERAMIC CHIP	0.1uF	10%	16V			(TRV23	0E:AEP,UK/		
			CERAMIC CHIP	0.01uF	10%	25V						/TRV530E)
			CERAMIC CHIP	0.1uF	10%	16V	R5503	1-218-895-11	METAL CHIP	100K	0.5%	1/16W
	C5602	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	DEFOC	1 010 000 11	(TRV230E:E,HK,A			
	C5604	1-164-657-11	CERAMIC CHIP	0.015uF	10%	50V	R5506 R5507	1-216-826-11 1-216-841-11	METAL CHIP METAL CHIP	2.7K 47K	5% 5%	1/16W 1/16W
	C5605		CERAMIC CHIP	0.015uF 0.1uF	10%	16V	h3307	1-210-041-11	WIETAL UTIF	4/ N	J /0	1/1000
			CERAMIC CHIP	0.1uF	10%	16V	R5508	1-216-843-11	METAL CHIP	68K	5%	1/16W
<u>^</u>			CERAMIC CHIP	12PF	10%	3KV	R5509	1-216-837-11		22K	5%	1/16W
	C5704		CERAMIC CHIP	0.1uF	10%	16V	R5510	1-216-843-11		68K	5%	1/16W
							R5511	1-216-857-11	METAL CHIP	1M	5%	1/16W
			< CONNECTOR $>$				R5512	1-216-845-11	METAL CHIP	100K	5%	1/16W
			CONNECTOR, FFC				R5523	1-216-809-11		100	5%	1/16W
*			CONNECTOR, BO				R5524	1-216-809-11		100	5%	1/16W
		1-764-709-11 1-794-998-21	CONNECTOR, FFC		IUP		R5525 R5551	1-216-809-11 1-216-841-11		100 47K	5% 5%	1/16W 1/16W
		1-766-336-21	CONNECTOR, FFC				R5553	1-216-839-11		33K	5%	1/16W
	01107 00	1 700 000 21	001111201011,110	,,,,,			110000		BOE:AEP,UK/TRV23			
	CN5704	1-778-508-21	PIN, CONNECTOR		D) 6P			(				,,
	CN5705	1-779-335-21	CONNECTOR, FFC	/FPC 22P			R5553	1-216-837-11	METAL CHIP	22K	5%	1/16W
									(TRV230E:E,HK,A			
			< DIODE >				R5553	1-216-841-11	METAL CHIP	47K	5%	1/16W
	DEFOO	0.710.100.00	DIODE 4TOCO OF	Τ0.4			DEFEZ	1 010 004 01	CHODT	0	•	(TRV530E)
			DIODE 1T369-01 DIODE RD3.3UM				R5557 R5571	1-216-864-91 1-216-809-11		0 100	5%	1/16W
			DIODE MA111-(				R5572	1-216-833-11		100 10K	5%	1/16W
	D3001	0 7 13 07 0 01	DIODE WIATTI	10).00			110072	1 210 000 11	WEIZE OIIII	TOIL	3 /0	1/1000
			< FERRITE BEAD	>			R5573	1-216-833-11	METAL CHIP	10K	5%	1/16W
							R5574	1-218-917-11	RES-CHIP	820K	5%	1/16W
		1-414-760-21		0uH			R5575	1-216-843-11		68K	5%	1/16W
	FB5504	1-414-760-21	FERRITE	0uH			R5576	1-216-857-11		1M	5%	1/16W
			10				R5577	1-216-853-11	METAL CHIP	470K	5%	1/16W
			< IC >				D5570	1 016 047 11	METAL CUID	150V	E0/	1/16\//
	IC5501	8-752-100-84	IC CXA3579R-T4	l			R5579 R5585	1-216-847-11 1-216-839-11		150K 33K	5% 5%	1/16W 1/16W
			IC CXD3512R-T4				R5586	1-216-839-11		33K	5%	1/16W
	100002	0 702 107 00		/TRV235E/T	RV325E	/TRV330F)	R5587	1-216-839-11		33K	5%	1/16W
	IC5502	8-752-409-15	IC CXD3516R-T4			,	R5588	1-216-848-11		180K	5%	1/16W
	IC5601	8-759-564-49	IC TC7W53FU(T	E12R)								
	IC5602	8-759-075-70	IC TA75S393F-T	E85R			R5590	1-216-821-11		1K	5%	1/16W
							R5591	1-216-864-91		0		
	IC5701	8-759-573-02	IC BU9735K-E2				R5592	1-216-864-91		0		
			2 COII 5				R5609	1-216-833-11		10K	5% 5%	1/16W
			< COIL >				R5610	1-216-055-00	WETAL UHIP	1.8K	5%	1/10W
	L5501	1-469-525-91	INDUCTOR	10uH			R5611	1-216-848-11	METAL CHIP	180K	5%	1/16W
			INDUCTOR	6.8uH			R5612	1-216-837-11		22K	5%	1/16W
		·		DE:AEP,UK/T	RV235E	/TRV325E/	R5613	1-216-055-00		1.8K	5%	1/10W
			,			/TRV530E)	R5614	1-216-833-11	METAL CHIP	10K	5%	1/16W
	L5505	1-412-956-21	INDUCTOR	27uH					•	E/TRV235E/		
	1.500	4.446.55= =:	(TRV230E:E,HK,A		E:E,HK,A	US,JE,CN)	R5614	1-216-835-11	METAL CHIP	15K	5%	1/16W
	L5601	1-419-387-21	INDUCTOR	100uH			I					(TRV530E)

Note: The components identified by mark  $\triangle$  or dotted line with mark  $\triangle$  are critical for safety. Replace only with part number specified.

						PD	-139	SI-028	SI-029	V	C-254
Ref. No.	Part No.	Description			Remarks	Ref. No.	Part No.	Description			Remarks
R5616	1-216-809-11	METAL CHIP	100	5%	1/16W			< RESISTOR	>		
R5617 R5618	1-216-837-11 1-216-817-11	METAL CHIP METAL CHIP	22K 470	5% 5%	1/16W 1/16W	R301	1-216-815-1	1 METAL CHIP	330	5%	1/16W
R5712	1-216-855-11		470 680K	5% 5%	1/16W	R307	1-216-864-9		0	370	1/1000
		< TRANSFORMER	۲>			R308 R309	1-216-001-0		18 10	5% 5%	1/16W 1/10W
<b>△</b> \T5601	1-435-227-11	TRANSFORMER,	INVERTER	3		R310	1-216-823-1	1 METAL CHIP	1.5K	5%	1/16W
		(TRV230E	TRV235E	TRV325E	/TRV330E)	R311	1-216-864-9		0		
<u> </u>	1-435-785-21	TRANSFORMER,	INVERTER	R (TRV530	E)	R312 R313	1-216-864-9 1-216-864-9		0 0		
						R314	1-216-864-9	1 SHORT	0		
	A-7074-726-A	SI-028 (M) BOAF (TRV230E	TRV235E	TRV325E	/TRV330E)	R315	1-216-864-9	1 SHORT < SENSOR >	0		
	A-7074-812-A	SI-029 (M) BOAF	RD, COMPI	LETE				COLINOON			
		*******		*******		SE301 SE302	1-803-042-3 1-803-042-4		GULAR VELOCI GULAR VELOCI		
		< CAPACITOR >		(nei.ivo., it	000 Series)			< VARISTOR	>		
0005	1 107 000 1:		0.4.5	4001	4017	I .		1 VARISTOR, C			
C305 C306	1-107-826-11 1-135-259-11	CERAMIC CHIP TANTAL. CHIP	0.1uF 10uF	10% 20%	16V 6.3V	VDR302	1-801-862-1	1 VARISTOR, C	НІР		
C307		CERAMIC CHIP	0.1uF	10%	16V		A 7000 407	A VO 054 (0DD	10) DOADD 001	ADI ETE	(OED) (IOE)
C308 C309	1-107-826-11 1-107-686-11	CERAMIC CHIP TANTAL. CHIP	0.1uF 4.7uF	10% 20%	16V 16V		A-7096-437-	·A VC-254 (QBP	,		(SERVICE) E/TRV235E)
0040	4 407 000 44	0504440 0140	0.4.5	100/	101		4 7000 440		******		
C310 C311	1-107-826-11 1-104-847-11	CERAMIC CHIP TANTAL. CHIP	0.1uF 22uF	10% 20%	16V 4V		A-7096-440-	·A VC-254 (QFP	S) BOARD, CON /TRV325E		
C312	1-104-847-11	TANTAL. CHIP	22uF	20%	4V		4 7000 440		******	*****	*****
		< CONNECTOR >					A-7096-443-	·A VC-254 (QFP	A) BOARD, CON ******		(TRV430É)
CN301	1-779-331-11	CONNECTOR, FFO	C/FPC 14P					ale			000 Series)
* CN302 * CN303 CN304	1-695-320-21 1-695-320-21 1-779-337-11	PIN, CONNECTOR PIN, CONNECTOR CONNECTOR, FFO	R (1.5MM)	(SMD) 2P				< CAPACITOR	۲>		,
011304	1-779-337-11	GOININEGTON, TT	J/1 F U ZUF			C1101	1-125-777-1	1 CERAMIC CH	IIP 0.1uF	10%	10V
		< DIODE >				C1102		1 CERAMIC CH 1 CERAMIC CH		10%	10V
D303	8-719-062-16	DIODE 01ZA8.2	(TPL3)			C1104 C1301		1 CERAMIC CH		10% 10%	10V 16V
D304 D305		DIODE UDZSTE- DIODE 1SS352-				C1302	1-107-826-1	1 CERAMIC CH	IIP 0.1uF	10%	16V
D305		DIODE 133332-				C1303	1-107-826-1	1 CERAMIC CH	IIP 0.1uF	10%	16V
D307	8-719-066-29	DIODE DCW281	0			C1304	1-107-826-1	1 CERAMIC CH		10%	16V
D308	8-719-067-44	DIODE CL-310IF	RS-X-TU			C1305 C1306	1-119-923-8			10% 10%	10V 16V
		. [1]0[.				C1307	1-164-941-1	1 CERAMIC CH	IP 0.0047uF	10%	16V
		< FUSE >				C1308	1-164-939-1	1 CERAMIC CH	IP 0.0022uF	10%	16V
<b> £</b> F301	1-533-874-11	FUSE, MICRO (20	00mA)			C1309	1-164-936-1			10%	16V
		< FERRITE BEAD	>			C1310 C1311		<ol> <li>CERAMIC CH</li> <li>CERAMIC CH</li> </ol>		10% 10%	16V 16V
ED004	1 414 700 01	FEDRITE	011			C1312	1-164-939-1	1 CERAMIC CH	IP 0.0022uF	10%	16V
FB001 FB002	1-414-760-21 1-414-760-21		OuH OuH			C1313	1-164-937-1	1 CERAMIC CH	IIP 0.001uF	10%	16V
		10				C1314		1 CERAMIC CH		10%	16V
		< IC >				C1315 C1316		<ol> <li>CERAMIC CH</li> <li>CERAMIC CH</li> </ol>		10% 10%	16V 16V
IC301	8-749-012-83					C1317		1 CERAMIC CH		10%	16V
		< COIL >				C1318 C1319		1 CERAMIC CH 1 CERAMIC CH		10%	16V 16V
L301	1-469-525-91	INDUCTOR	10uH			C1320		1 TANTALUM C		10% 20% FRV430I	4V
		< TRANSISTOR >				C1321		1 CERAMIC CH	IIP 4.7uF	10%	10V ´
Q301	8-729-140-75	TRANSISTOR	2SD999-	-T1-CLCK		C1322	1-135-201-1	1 TANTALUM C	HIR 100F	20%	4V

Note: The components identified by mark △ or dotted line with mark △ are critical for safety.

Replace only with part number specified.

Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
C1323	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C1524	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C1326	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C1525	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C1327	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C1552	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C1328	1-162-974-11	CERAMIC CHIP	0.01uF		50V	C1554	1-164-941-11	CERAMIC CHIP	0.0047uF	10%	16V
					(TRV430E)	C1556	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C1329	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V						
						C1558	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C1330	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C1559	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1331	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C1560	1-164-935-11	CERAMIC CHIP	470PF	10%	16V
C1332	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C1561	1-164-943-11		0.01uF	10%	16V
C1333		TANTAL UM OUUD	22uF	20%	6.3V	C1562	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C1334	1-135-201-11	TANTALUM CHIP	TOUF	20%	4V	C1563	1-125-839-91	TANTAL. CHIP	47uF	20%	6.3V
C1335	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1564	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C1336	1-133-239-11	TANTAL. CHIP	22uF	20%	6.3V	C1565	1-117-863-11		0.47uF	10%	6.3V
C1337	1-164-506-11	CERAMIC CHIP	4.7uF	2070	16V	C1566	1-164-943-11		0.47 ur	10%	16V
C1338	1-164-506-11	CERAMIC CHIP	4.7uF		16V	C1568	1-164-939-11		0.0022uF	10%	16V
C1339	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	0.000		02	0.00224.	. 0 / 0	
						C1569	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C1340	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1570	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C1341	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C1571	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C1342	1-165-319-11	CERAMIC CHIP	0.1uF		50V	C1572	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
					(TRV430E)	C2002	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1343	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V						
C1344	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V	C2003	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
04045	4 405 050 44	TANTAL OLUB	10 5	000/	0.017	C2005	1-164-343-11	CERAMIC CHIP	0.056uF	10%	25V
C1345	1-135-259-11	TANTAL CHIP	10uF	20%	6.3V	C2006	1-164-343-11		0.056uF	10%	25V
C1347	1-104-851-11	TANTAL CHIP	10uF	20%	10V	C2007		CERAMIC CHIP	0.056uF	10%	25V
C1348 C1350	1-135-259-11 1-104-913-11	TANTAL. CHIP TANTAL. CHIP	10uF 10uF	20% 20%	6.3V 16V	C2008	1-110-666-11	ELECT CHIP	22uF	20%	6.3V
C1352		CERAMIC CHIP	0.1uF	10%	10V 10V	C2009	1-164-343-11	CERAMIC CHIP	0.056uF	10%	25V
01002	1-125-777-11	OLITAWIO OTIII	U. Tui	10 /0	100	C2010	1-110-666-11		22uF	20%	6.3V
C1354	1-113-985-11	TANTAL. CHIP	10uF	20%	20V	C2012	1-110-501-11		0.33uF	10%	16V
C1355	1-164-505-11	CERAMIC CHIP	2.2uF		16V	C2014		TANTALUM CHIP	10uF	20%	4V
					(TRV430E)	C2015	1-164-943-11		0.01uF	10%	16V
C1356	1-164-505-11	CERAMIC CHIP	2.2uF		`16V ´						
C1357	1-104-851-11	TANTAL. CHIP	10uF	20%	10V	C2201	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C1359	1-164-506-11	CERAMIC CHIP	4.7uF		16V	C2202	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
						C2204	1-125-777-11		0.1uF	10%	10V
C1360	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C2208	1-164-392-11	CERAMIC CHIP	390PF	5%	50V
C1362	1-164-505-11	CERAMIC CHIP	2.2uF	400/	16V	C2210	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C1363	1-164-939-11	CERAMIC CHIP	0.0022uF 22PF	10% 5%	16V 16V	00011	1 105 010 11	TANTAL LIM CLUD	4 7F	20%	101/
C1501 C1502		CERAMIC CHIP CERAMIC CHIP	0.001uF	10%	16V 16V	C2211		TANTALUM CHIP CERAMIC CHIP	4.7ur 1uF	10%	10V 6.3V
01302	1-104-337-11	CENAIVIIC CITIF	0.00141	10 /0	100	C2212		CERAMIC CHIP	0.01uF	10%	16V
C1503	1-164-858-11	CERAMIC CHIP	22PF	5%	16V	C2214		CERAMIC CHIP	0.1uF	10%	16V
C1504		CERAMIC CHIP	1uF	0,0	10V	C2215		CERAMIC CHIP	1uF	10%	6.3V
C1505			1uF		10V						
C1506	1-131-861-91	TANTAL. CHIP	4.7uF	20%	20V	C2222	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1507	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C2223	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
						C2224	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1508		CERAMIC CHIP	1uF	10%	6.3V	C2226		CERAMIC CHIP	0.01uF	10%	16V
C1509		CERAMIC CHIP	0.001uF	10%	16V	C2227	1-117-863-11	CERAMIC CHIP	0.47uF	10%	6.3V
C1511	1-115-339-11	CERAMIC CHIP	0.1uF	10%	50V	00000	1 104 040 11	OEDAMIO OLUB	0.045	100/	101/
C1512		CERAMIC CHIP	0.001uF	10%	16V	C2229		CERAMIC CHIP CERAMIC CHIP	0.01uF 0.0015uF	10%	16V 16V
C1513	1-117-003-11	CERAMIC CHIP	0.47uF	10%	6.3V	C2230 C2232		TANTALUM CHIP	10uF	10% 20%	4V
C1514	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	C2233		CERAMIC CHIP	0.01uF	10%	16V
C1515		CERAMIC CHIP	0.22uF	10%	10V	C2234		CERAMIC CHIP	0.01uF	10%	16V
C1516	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	0220.		02	0.0.0.	. 0 / 0	
C1517		CERAMIC CHIP	120PF	5%	50V	C2236	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C1518		CERAMIC CHIP	1uF	10%	6.3V	C2238	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
						C2240		CERAMIC CHIP	1uF	10%	6.3V
C1519			0.22uF	10%	10V	C2242		CERAMIC CHIP	1uF		10V
C1520		CERAMIC CHIP	0.001uF	10%	16V	C2243	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C1521	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	000::	4 404 045 44	OED 4440 0:::5	0.04 5	4007	4017
C1522		CERAMIC CHIP	1uF	10%	6.3V	C2244		CERAMIC CHIP	0.01uF	10%	16V
C1523	1-10/-826-11	CERAMIC CHIP	0.1uF	10%	16V	C2247		CERAMIC CHIP	1uF	10%	6.3V
						C2250 C2291		TANTALUM CHIP CERAMIC CHIP	10uF 1uF	20% 10%	4V 6.3V
						C2291		CERAMIC CHIP	0.01uF	10%	16V
					'	J		22 30110 01111	3.0 Tul	. 5 /5	

D.C.N.	D. I.M.	B talk.			D I .	L D. C.N.	D. I.M.	B talk.			D I .
Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
C2293	1-119-750-11	TANTAL. CHIP	22uF	20%	6.3V	C3316	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3102	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3317	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3104	1-164-943-11	CERAMIC CHIP CERAMIC CHIP	0.01uF 0.01uF	10%	16V 16V	C3318	1-164-943-11	CERAMIC CHIP CERAMIC CHIP	0.01uF 0.001uF	10%	16V 16V
C3105 C3107	1-164-943-11 1-164-943-11	CERAMIC CHIP	0.01uF 0.01uF	10% 10%	16V 16V	C3319 C3320	1-164-937-11 1-135-201-11	TANTALUM CHIP		10% 20%	4V
03107	1-104-943-11	GENAIVIIG GHIF	0.01ur	10 /0	100	03320	1-133-201-11	TANTALUW GITE	TOUF	20 /0	<del>4</del> V
C3108	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C3321	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3109	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3322	1-117-863-11	CERAMIC CHIP	0.47uF	10%	6.3V
C3110	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3323	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3111	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C3324	1-119-923-81	CERAMIC CHIP	0.047uF	10%	10V
C3112	1-164-935-11	CERAMIC CHIP	470PF	10%	16V	C3325	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3113	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3326	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V
C3114	1-164-866-11	CERAMIC CHIP	47PF	5%	16V	C3327	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C3115	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3328	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3116	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V	C3329	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3117	1-164-935-11	CERAMIC CHIP	470PF	10%	16V	C3331	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C3119	1-164-866-11	CERAMIC CHIP	47PF	5%	16V	C3332	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3120	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3333	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3121	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3334	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3122	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C3335	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3123	1-164-942-11	CERAMIC CHIP	0.0068uF	10%	16V	C3337	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
00120	1 101 012 11	OLITAWIO OTIII	0.0000ui	1070	101	00007	1 120 007 01	OLIVIIVIIO OIIII	Tui	10 /0	0.0 v
C3124	1-164-942-11	CERAMIC CHIP	0.0068uF	10%	16V	C3338	1-164-882-11	CERAMIC CHIP	220PF	5%	16V
C3126	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3341	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C3127	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3342	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C3128	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3343	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3131	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3345	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
00400	4 405 777 44	OEDAMIO OLUD	0.4	100/	101/	00040	1 104 040 11	OEDAMIO OLUD	0.045	100/	101/
C3133	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3346	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3134 C3135	1-125-777-11 1-164-874-11	CERAMIC CHIP CERAMIC CHIP	0.1uF 100PF	10% 5%	10V 16V	C3348 C3601	1-164-943-11 1-135-201-11	CERAMIC CHIP TANTALUM CHIP	0.01uF	10% 20%	16V 4V
C3136	1-164-872-11	CERAMIC CHIP	82PF	5% 5%	16V 16V	C3603	1-164-943-11	CERAMIC CHIP	0.01uF	10%	4 v 16 V
C3137	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3604	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
03137	1-104-343-11	CLIMINIC CITIF	0.0141	10 /0	100	03004	1-100-209-11	TANTAL. OTHE	Toul	20 /0	0.57
C3138	1-164-874-11	CERAMIC CHIP	100PF	5%	16V	C3608	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3139	1-164-878-11	CERAMIC CHIP	150PF	5%	16V	C3610	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C3141	1-164-882-11	CERAMIC CHIP	220PF	5%	16V	C3611	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C3142	1-164-882-11	CERAMIC CHIP	220PF	5%	16V	C3612	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C3143	1-164-882-11	CERAMIC CHIP	220PF	5%	16V	C3614	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C3144	1-164-882-11	CERAMIC CHIP	220PF	5%	16V	C3615		CERAMIC CHIP	0.1uF	10%	10V
C3202	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3616	1-162-970-11		0.01uF	10%	25V
C3203	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C3617		CERAMIC CHIP	0.01uF	10%	25V
C3205	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3618		CERAMIC CHIP	0.01uF	10%	25V
C3206	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3619	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3210	1-164-941-11	CERAMIC CHIP	0.0047uF	10%	16V	C3620	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3212	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3622	1-162-970-11		0.01uF	10%	25V
C3213	1-119-923-81	CERAMIC CHIP	0.047uF	10%	10V	C3626		CERAMIC CHIP	0.1uF	10%	10V
C3215	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3629		CERAMIC CHIP	0.1uF	10%	10V
C3216	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3631	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3217	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3633	1-135-201-11	TANTALUM CHIP		20%	4V
C3301	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3634		CERAMIC CHIP	0.1uF	10%	10V
C3302	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3636	1-164-858-11	CERAMIC CHIP	22PF	5%	16V
C3303	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3701	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3305	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C3702	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3306	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3704	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C3307	1-164-850-11	CERAMIC CHIP	10PF	0.50PF		C3705	1-110-501-11		0.22ui 0.33uF	10%	16V
C3308	1-164-850-11	CERAMIC CHIP	10PF	0.50PF		C3706	1-164-943-11	CERAMIC CHIP	0.00ur	10%	16V
C3309	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3707	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C3310	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3708	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V
			-							•	
C3311	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3709	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C3312	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C3710	1-125-838-11		2.2uF	10%	6.3V
C3313	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V	C3711	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V
C3314	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V	C3712	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V
C3315	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V	C3714	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V

Pof No	Part No.	Description			Domarko	Ref. No.	Part No.	Description			Remarks
Ref. No.		•			Remarks			•			
C3715	1-110-501-11	CERAMIC CHIP	0.33uF	10%	16V	C4419	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3716	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4420	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C3717	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C4421	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3719	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4424	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3723	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4425	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V
C3724	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4426	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3728	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V	C4427	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3729	1-125-838-11	CERAMIC CHIP	2.2uF	10%	6.3V	C4428	1-119-923-81	CERAMIC CHIP	0.047uF	10%	10V
C3730	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4429	1-119-923-81	CERAMIC CHIP	0.047uF	10%	10V
C3731	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4430	1-164-505-11	CERAMIC CHIP	2.2uF	1070	16V
C3732	1-126-246-11	ELECT CHIP	220uF	20%	4V	C4431	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3733	1-126-246-11	ELECT CHIP	220uF	20%	4V	C4432	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3734	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C4433	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3735	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4434	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3901	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C4435	1-164-935-11	CERAMIC CHIP	470PF	10%	16V
C3904	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4436	1-164-935-11	CERAMIC CHIP	470PF	10%	16V
C3905	1-104-943-11	CERAMIC CHIP	0.01uF 0.47uF	10%	6.3V	C4430	1-104-933-11	CERAMIC CHIP	0.1uF	10%	10V 10V
C3905	1-117-863-11	CERAMIC CHIP	0.47uF 0.47uF	10%	6.3V	C4437	1-125-777-11	CERAMIC CHIP	0.1uF 0.1uF	10%	10V 10V
C3908	1-117-803-11	CERAMIC CHIP	1uF	10%	6.3V	C4439	1-123-777-11	CERAMIC CHIP	0.1uF 0.47uF	10 /0	10V 10V
								CERAMIC CHIP		100/	
C3909	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4440	1-107-826-11	CERAINIC CHIP	0.1uF	10%	16V
C3910	1-135-210-11	TANTALUM CHIP	4.7uF	20%	10V	C4441	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C3911	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4442	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C3912	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4501	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C3913	1-164-668-11	CERAMIC CHIP	510PF	5%	50V	C4504	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C3914	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C4505	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3915	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4506	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3916	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C4507	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3917	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C4508	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3918	1-164-848-11	CERAMIC CHIP	8PF	0.50PF		C4509	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3919	1-117-863-11	CERAMIC CHIP	0.47uF	10%	6.3V	C4510	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3920	1-117-863-11	CERAMIC CHIP	0.47uF	10%	6.3V	C4801	1-115-156-11	CERAMIC CHIP	1uF		10V
C3921	1-164-862-11	CERAMIC CHIP	33PF	5%	16V	C4802	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3922	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C4803	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3923	1-164-864-11	CERAMIC CHIP	39PF	5%	16V	C4804	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3924	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C4805	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
00324	1-125-057-51	OLITAWIO OTIII	Tui	10 /0	0.5 v	04000	1-104-031-11	IANTAL. OTTI	Toui	20 /0	100
C3925	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	C4806	1-119-749-11	TANTAL. CHIP	33uF	20%	4V
C3926	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4807	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C3927	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4808	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3928	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	C4810	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3934	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C4811	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
00005		0504440 01110	0.04 5	100/	4014	0.4040		0504440 01110	0.04 5	100/	101/
C3935	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4812	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C3936	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C4813	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C4401	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4814	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C4402	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4815	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C4403	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4816	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C4404	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4817	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C4405	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V	C4819	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V
C4406	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V	C4820	1-164-942-11	CERAMIC CHIP	0.0068uF	10%	16V
C4407	1-119-923-81	CERAMIC CHIP	0.047uF	10%	10V	C4821	1-164-858-11	CERAMIC CHIP	22PF	5%	16V
C4408	1-104-912-11	TANTAL. CHIP	3.3uF	10%	6.3V	C4822	1-164-854-11	CERAMIC CHIP	15PF	5%	16V
C4409	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4823	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C4410	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4824	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C4411	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4825	1-125-777-11		0.1uF	10%	10V
C4412	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4827	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C4413	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4902	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C4414	1-164-933-11	CERAMIC CHIP	220PF	10%	16V	C4903	1-164-850-11	CERAMIC CHIP	10PF	0.50PF	16V
C4415	1-164-935-11	CERAMIC CHIP	470PF	10%	16V	C4904	1-164-850-11	CERAMIC CHIP	10PF	0.50PF	
C4416	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C4905	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C4417	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V	C4906	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C4418	1-164-935-11	CERAMIC CHIP	470PF	10%	16V	C4907	1-125-777-11		0.1uF	10%	10V
					-						-

Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	Description			<u>Remarks</u>
C4908	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C5807	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V
C4909	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C5808	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V
C4910	1-125-777-11	CERAMIC CHIP	0.01uF	10%	10V	C5809	1-164-943-11	CERAMIC CHIP	0.022ui	10%	16V
C4911	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C5810	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V
C4912	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C5812	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
01012	1 101 010 11	OLI II III III OI III	0.0141	10 /0	101	00012	1 100 201 11	17 (IV 17 LEGIVI GITII	Tour	2070	1 0
C5701	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C5813	1-164-874-11	CERAMIC CHIP	100PF	5%	16V
C5702	1-135-201-11	TANTALUM CHIP		20%	4V	C5814	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C5703	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5815	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C5704	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C5816	1-164-874-11	CERAMIC CHIP	100PF	5%	16V
C5705	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	C5817	1-164-937-11	CERAMIC CHIP	0.001uF	10%	16V
C5706	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	C5818	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V
C5709	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5819	1-164-874-11	CERAMIC CHIP	100PF	5%	16V
C5710	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	C5820	1-164-874-11	CERAMIC CHIP	100PF	5%	16V
C5711	1-110-569-11	TANTAL. CHIP	47uF	20%	4V	C5821	1-107-819-11	CERAMIC CHIP	0.022uF	10%	16V
C5712	1-110-569-11	TANTAL. CHIP	47uF	20%	4V	C5822	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C5713	1-117-863-11	CERAMIC CHIP	0.47uF	10%	6.3V	C5823	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C5714	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C5824	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C5715	1-104-912-11	TANTAL. CHIP	3.3uF	20%	4V	C5825	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V
C5716	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	C5826	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C5717	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5827	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C5718	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5829	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C5719	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5830	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C5720	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5832	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C5721	1-164-939-11	CERAMIC CHIP	0.0022uF	10%	16V	C5833	1-164-938-11	CERAMIC CHIP	0.0015uF	10%	16V
C5722	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5835	1-164-938-11	CERAMIC CHIP	0.0015uF	10%	16V
C5723	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	C5836	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V
C5724	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5839	1-104-847-11	TANTAL. CHIP	22uF	20%	4V
C5725	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C5840	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C5728	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	C5841	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C5730	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	C5842	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C5731	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C5843	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C5732	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V	C5844	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V
C5733	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V						
C5734	1-125-837-91	CERAMIC CHIP	1uF	10%	6.3V			< CONNECTOR >			
C5735	1-125-777-11	CERAMIC CHIP	0.1uF	10%	10V	0014404	4 700 050 04	OONINGOTOD FE	\/EDO 00D		
05700	4 445 407 44	OED ANAIO OLUB	0.00 5	400/	401/			CONNECTOR, FFO		4 D D 4 0 0	Б
C5736		CERAMIC CHIP	0.22uF	10%	10V	CN1104	1-774-598-41	CONNECTOR, BO			
C5737		CERAMIC CHIP	1uF	10%	6.3V	CN1100	1 700 050 01	,	/TRV330E/	KV43UE	/TRV530E)
C5738		CERAMIC CHIP	1uF	10%	6.3V		1-766-350-21			ADD 400	,
C5739		CERAMIC CHIP	1uF	10%	6.3V		1-691-542-21			AKD 48F	,
C5740	1-110-40/-11	CERAMIC CHIP	0.22uF	10%	10V	CIVITI4	1-766-340-21	CONNECTOR, FFO	// TPU 1UP		
C5741	1_115_/67_11	CERAMIC CHIP	0.22uF	10%	10V	CN1115	1_766_3/0_21	CONNECTOR, FFO	YEDC 10D		
C5741	1-115-467-11	CERAMIC CHIP	0.22uF 0.001uF	10%	16V		1-766-340-21	,			
C5742		CERAMIC CHIP	0.001uF 0.001uF	10%	16V 16V			CONNECTOR, FFC		15D	
C5743		CERAMIC CHIP	0.001uF	10%	16V 16V		1-703-700-21			TUE	
C5744 C5745		CERAMIC CHIP	0.01uF	10%	16V 16V		1-794-996-21	,			
00140	1 104-540-11	OFTIVINO OTHE	J.OTUI	10/0	101	ONTOOL	1119-002-11	JOININEOTON, ITC	,,11 U 1UF		
C5746	1-117-863-11	CERAMIC CHIP	0.47uF	10%	6.3V	CN1551	1-750-360-21	CONNECTOR, FFO	:/FPC (7IF)	24P	
C5747		CERAMIC CHIP	0.47uF	10%	6.3V		1-774-636-21	,	\ /	- 11	
C5748		CERAMIC CHIP	0.47 uF 0.01 uF	10%	16V			PIN, CONNECTOR			
C5748		CERAMIC CHIP	68PF	10% 5%	16V 16V		1-766-340-21				
C5749 C5750		TANTALUM CHIP		20%	4V			CONNECTOR, FFO			
03730	1-10 <b>J-Z</b> UI <b>-</b> 11	IAINTALUIN UNIP	Toul	LU /0	τv	0114403	1-100-002-21	JOININE OTON, I'FL	// I I U ZZF		
C5751	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	CN4404	1-766-345-21	CONNECTOR, FFO	C/FPC 15P		
C5752	1-164-943-11	CERAMIC CHIP	0.01uF	10%	16V	0114404	1 700 040 21	OOMNEOTOTI, TT	//11 0 101		
C5752		CERAMIC CHIP	0.01uF	10%	16V 16V			< DIODE >			
C5753		CERAMIC CHIP	0.01uF 0.22uF	10%	10V 10V			< DIODE >			
C5754 C5755		CERAMIC CHIP	0.22ur 0.0068uF	10%	16V	D1101	8-710-062-16	DIODE 01ZA8.2(	TPI 3)		
00700	1-104-342-11	OLIMIVIIO ONIP	U.UUUUUL	I U /0	101	D1101		DIODE 01ZA8.2(			
C5756	1-115-/67-11	CERAMIC CHIP	0.22uF	10%	10V	שווע	0-118-002-10		(1PL3) [/TRV330E/1	B//43UE	/TR\/530E\
C5756	1-115-467-11	CERAMIC CHIP	0.22uF 0.0068uF	10%	16V	D1103	8_710_060 16	DIODE 01ZA8.2(		11V43UE	/ 111 ( ) ( ) ( )
		CERAMIC CHIP	0.0068uF 0.22uF		16V 10V						
C5758 C5759		CERAMIC CHIP	0.22uF 0.22uF	10% 10%	10V 10V	D1105	0-119-002-16	DIODE 01ZA8.2(	(1PL3) :/TRV330E/1	בס//אסטב	/TD\/E20E\
C5759		CERAMIC CHIP	0.22uF 0.01uF	10%	16V	D1106	8-710-056 0F	DIODE UDZSTE-		11V43UE	/ ITTV JJUE)
00000	1-10 <del>4-24</del> 3-11	OLIMIVIIO ONIP	บ.บานก	I U /0	101	סטווט	0-118-000-00			EV/430E	/TR\/£30E\
						I		(111/3/25)	/TRV330E/	n v430E	/INVOOUE)

Ref. No.	Part No.	<u>Description</u>		<u>Remarks</u>	Ref. No.	Part No.	Description		<u>Remarks</u>
D1301			T3SONY1)(TRV430E)	)		8-759-650-74			
D1302	8-719-081-19	DIODE 1SS383(	T5RSONY1)				IC MB90099PFV		
D1305	8-719-078-02	DIODE 188357(	T3SONY1)(TRV430E)				IC SN104266PN		
D1306 D1501	8-719-081-19	DIODE 155383(	13SONY1)(TRV430E) 15RSONY1) 1-T8A				IC MB87L1241P IC AN2225FHQ-I		
	0-710-100-04	DIODE 11375-0	I-TOA		103701	0-100-000-01	TO ANZZZJITIQ-I		
D1551	8-719-073-01	DIODE MA111-(	K8).S0				IC AN2920FHQ-I		
D2201	8-719-081-96	DIODE KV1870S	TL				IC CXA8096R-TI		
D2202 D3301	8-719-081-96	DIODE RV1870S	T1/16				IC LB1991V-TLN		
D3301	8-719-081-96	DIODE KV1870S	TL				IC BR9016RFV-E		
			K8).S0 TL TL T146 TL T146 TL 1001S0 K8).S0 K8).S0						
D3303	8-719-992-02	DIODE RB705D-	T146				IC S-84239FS-T		
D3304 D4401	8-719-081-96	DIODE MASSES	1L 1001S0				IC TL1596CPWF		
D4802	8-719-421-27	DIODE MA728-(	K8).S0				IC S-817A33AN		
D4803	8-719-073-01	DIODE MA111-(	K8).S0				IC BR9080RFV-E		
D. 400.4	0.740.070.04	DIODE MALLA			10.4000	0.750.000.00	10 14004400055	0.404.0ND.50	
D4804 D4806	8-/19-0/3-01	DIODE MA111-(	K8).S0				IC MB91192PFF		
D4000	0-719-421-07	DIODE WATSEN	K8).S0 'K-(K8).S0 R >				IC AK4550VT-E2		
		< PIN CONNECTO	R >				IC BH7870AKV-I		
ET101	1 015 000 01	DINI CONNECTOR	(CACE CHIELD)				< COIL >		
ET131 ET132		PIN, CONNECTOR PIN, CONNECTOR					< GUIL >		
ET133		PIN, CONNECTOR			L1301	1-416-670-11	INDUCTOR	33uH	
						1-416-669-11		22uH	
		< FERRITE BEAD	>		L1303	1-416-669-11		22uH	
ED1 E01	1-414-760-21	EEDDITE	0uH		L1304 L1305	1-416-669-11		22uH	
	1-414-760-21		OuH OuH		L1305	1-416-669-11	INDUCTOR	22uH	
	1-500-284-21		OuH		L1306	1-412-056-11	INDUCTOR	4.7uH	
	1-414-760-21		OuH		L1307	1-412-056-11		4.7uH	
FB1505	1-500-284-21	FERRITE	0uH		L1308	1-469-557-21	INDUCTOR	22uH	
					L1309	1-469-557-21		22uH	
	1-500-283-11		0uH		L1310	1-412-056-11	INDUCTOR	4.7uH	
	1-414-760-21 1-414-760-21		OuH OuH		1 1010	1-469-553-21	INDLICTOR	4.7uH	
	1-414-760-21		OuH			1-469-553-21		4.7uH	
	1-414-760-21		0uH		L1315	1-469-553-21		4.7uH	
					L1316	1-414-400-41		22uH	
	1-414-760-21		0uH		L1317	1-416-669-11	INDUCTOR	22uH	
	1-414-760-21		0uH		14040	4 440 050 44	INDUIGTOR	47.11	
	1-414-760-21 1-414-760-21		OuH OuH		L1318 L1319	1-412-056-11 1-412-056-11		4.7uH 4.7uH	
	1-414-760-21		OuH		LISIS	1-412-050-11		/TRV330E/TRV430E	(TRV530F)
100701	1 111 700 21	TERMITE	ouri		L1320	1-469-524-91	,	4.7uH	./ 11110001
FB4501	1-414-760-21	FERRITE	0uH		L1501	1-469-555-21	INDUCTOR	10uH	
	1-414-760-21		0uH		L1551	1-469-525-91	INDUCTOR	10uH	
FB4901	1-414-760-21	FERRIIE	0uH		L1552	1-469-555-21	INDLICTOR	10uH	
		< IC >			L1553	1-469-525-91		10uH	
		,			L2001	1-469-555-21		10uH	
		IC CXA3057R-T6			L2202	1-469-555-21	INDUCTOR	10uH	
		IC RN5RZ59BA-			L2204	1-469-525-91	INDUCTOR	10uH	
		IC TA75S01F(TE			1.0007	1 440 045 44	INDUOTOD	0.0	
		IC CXD2444R-T4 IC VSP2200Y-1/2			L2207 L2208	1-412-945-11 1-469-555-21		3.3uH 10uH	
101302	0-739-004-90	10 V3F22001-1/	ZIX		L2200	1-469-525-91		10uH	
IC1552	8-759-681-42	IC NJM12902V(	TE2)		L2291	1-469-555-21		10uH	
IC1553	8-759-637-96	IC MPC17A135E	TAÉL		L3102	1-469-525-91		10uH	
		IC NJM3230V(T			,				
		IC HG75C012SF			L3103	1-469-525-91		10uH	
102291	o-/59-/13-19	IC BH2222FV-E2			L3104 L3105	1-469-555-21 1-414-406-41		10uH 220uH	
JC3101	8-752-086-52	IC CXA2071R-T4	1			1-414-406-41		12uH	
		IC TC7S86FU(TE			L3201	1-469-526-91		22uH	
		IC CXA2072R-T4							
IC3201	8-752-093-69	IC CXA3265R-T4	1						
IC3202	8-759-075-70	IC TA75S393F-T	E85R						

Ref. No.	Part No.	Description	Remarks	Ref. No.	Part No.	Description	Remarks
		•				•	
L3303	1-412-936-11		0.56uH	Q3306	8-729-052-65	TRANSISTOR	2SA1774HT2L
L3304	1-414-246-11		1.8uH	Q3309	8-729-054-49	TRANSISTOR	UP04401008S0
L3305	1-469-525-91		10uH	Q3310	8-729-054-49		UP04401008S0
L3306	1-469-525-91		10uH	Q3601	8-729-052-65		2SA1774HT2L
L3307	1-469-525-91	INDUCTOR	10uH	Q3602	8-759-054-48	TRANSISTOR	UP04601008S0
L3601	1-469-525-91	INDUCTOR	10uH	Q3701	8-729-037-52	TDANCICTOD	2004720E V/CD/TDI 2)
L3602	1-469-525-91		10uH	Q3701	8-729-037-52		2SC4738F-Y/GR(TPL3) RN2104F(TPL3)
L3701	1-469-525-91	INDUCTOR	10uH	Q3702 Q3703	8-729-037-01		2SC4738F-Y/GR(TPL3)
L3701	1-469-525-91		10uH	Q3705	8-729-037-52		2SC4738F-Y/GR(TPL3)
L3901	1-469-555-21		10uH	Q3902	8-729-122-63		2SA1226-T1E4
L0301	1 400 000 21	INDOOTOT	10011	Q0302	0 723 122 00	THANOIOTON	ZONIZZO TILA
L3902	1-412-948-11	INDUCTOR	5.6uH	Q3903	8-729-052-65	TRANSISTOR	2SA1774HT2L
L3903	1-412-957-11		33uH	Q4401	8-729-037-52		2SC4738F-Y/GR(TPL3)
L3904	1-412-957-11		33uH	Q4401	8-729-052-66		2SC4617HT2L
L5701	1-469-525-91		10uH	Q4402	8-729-052-64		DTC144EHT2L
L5803	1-469-560-21	INDUCTOR	68uH	Q4801	8-729-037-52	TRANSISTOR	2SC4738F-Y/GR(TPL3)
							,
		< TRANSISTOR >		Q4802	8-729-037-52	TRANSISTOR	2SC4738F-Y/GR(TPL3)
				Q4804	8-729-041-43		HN1L02FU(TE85R)
Q1104	8-729-052-64	TRANSISTOR	DTC144EHT2L	Q4806	8-729-042-58		RN2102F(TPL3)
Q1301	8-729-043-60		CPH6102-TL	Q4813	8-729-054-47		UP04213008S0
Q1302	8-729-046-98		CPH6702-TL	Q4901	8-729-045-71	TRANSISTOR	RN1102F(TPL3)
Q1303	8-729-046-98		CPH6702-TL	_			
Q1304	8-729-046-98	TRANSISTOR	CPH6702-TL	Q5708	8-729-037-63		RN2111F(TPL3)
04005	0.700.040.00	TDANGIOTOD	0D110700 TI	Q5716	8-759-054-50		UP04501008S0
Q1305	8-729-046-98		CPH6702-TL	Q5717	8-729-054-52		UP04216008S0
Q1306	8-729-046-98		CPH6702-TL	Q5718	8-729-054-52	TRANSISTOR	UP04216008S0
Q1307 Q1308	8-729-044-58 8-729-044-58		SI2304DS-T1 SI2304DS-T1			< RESISTOR >	
Q1300	8-729-046-98		CPH6702-TL			< NEGIOTON >	
Q1005	0 720 040 00	THANOIOTON	01110702 12	R1105	1-218-990-11	SHORT	0 (TRV230E/TRV235E)
Q1311	8-729-101-07	TRANSISTOR	2SB798-T1-DLDK	R1106	1-218-990-11		0 (TRV230E/TRV235E)
Q1312	8-729-052-65		2SA1774HT2L	R1107	1-218-990-11		0 (TRV230E/TRV235E)
Q1314	8-729-052-64		DTC144EHT2L	R1108	1-218-990-11		0 (TRV230E/TRV235E)
Q1316	8-729-037-52		2SC4738F-Y/GR(TPL3)	R1109	1-218-990-11		0 (TRV230E/TRV235E)
Q1321	8-729-037-52		2SC4738F-Y/GR(TPL3)				,
			,	R1110	1-218-990-11	SHORT	0 (TRV230E/TRV235E)
Q1323	8-729-052-65	TRANSISTOR	2SA1774HT2L	R1111	1-218-990-11	SHORT	0 (TRV230E/TRV235E)
Q1324	8-729-037-52	TRANSISTOR	2SC4738F-Y/GR(TPL3)	R1112	1-218-990-11	SHORT	0 (TRV230E/TRV235E)
			(TRV430E)	R1113	1-218-990-11		0 (TRV230E/TRV235E)
Q1327	8-759-054-50		UP04501008S0	R1114	1-218-990-11	SHORT	0 (TRV230E/TRV235E)
Q1328	8-759-054-50		UP04501008S0				
Q1329	8-729-054-49	TRANSISTOR	UP04401008S0	R1115	1-218-990-11		0 (TRV230E/TRV235E)
04000	0.700.054.40	TDANCICTOD	LID0440400000 (TDV400E)	R1116	1-218-990-11		0 (TRV230E/TRV235E)
Q1330	8-729-054-49 8-729-039-86		UP04401008S0 (TRV430E)	R1117	1-218-990-11		0 (TRV230E/TRV235E)
Q1331 Q1332	8-729-039-66		FMMT717TA 2SC4738F-Y/GR(TPL3)	R1118 R1119	1-218-990-11 1-218-990-11		0 (TRV230E/TRV235E)
Q1333	8-729-037-52		2SC4738F-Y/GR(TPL3)	111113	1-210-990-11	3110111	0 (TRV230E/TRV235E)
Q1551	8-729-037-52		2SC4738F-Y/GR(TPL3)	R1120	1-218-990-11	SHORT	0 (TRV230E/TRV235E)
Q 1001	3 . 20 007 02			R1121	1-218-990-11		0 (TRV230E/TRV235E)
Q1554	8-729-037-52	TRANSISTOR	2SC4738F-Y/GR(TPL3)	R1122	1-218-990-11		0 (TRV230E/TRV235E)
Q1555	8-729-054-51		UP04116008S0	R1123	1-218-990-11		0 (TRV230E/TRV235E)
Q2207	8-759-054-48		UP04601008S0	R1124	1-218-953-11		1K 5% 1/16W
Q3102	8-729-052-65		2SA1774HT2L				
Q3103	8-729-052-64	TRANSISTOR	DTC144EHT2L	R1127	1-218-969-11	RES-CHIP	22K 5% 1/16W
							/TRV325E/TRV330E/TRV530E)
Q3104	8-729-052-64		DTC144EHT2L	R1127	1-218-965-11	RES-CHIP	10K 5% 1/16W
Q3107	8-729-037-52		2SC4738F-Y/GR(TPL3)				(TRV430E)
Q3109	8-729-054-44		UP04111008S0	R1128	1-218-977-11		100K 5% 1/16W
Q3111	8-729-052-65		2SA1774HT2L	R1131	1-218-974-11	RES-CHIP	56K 5% 1/16W
Q3116	8-729-047-19	TRANSISTOR	2SA1965-S-TL	D4404	1 010 077 11	DEC CUID	(TRV230E/TRV235E)
00117	0 750 054 40	TDANICICTOR	HD0460100000	R1131	1-218-977-11		100K 5% 1/16W
Q3117	8-759-054-48 8-729-054-47		UP04601008S0 UP04213008S0			(1KV325E	/TRV330E/TRV430E/TRV530E)
Q3118 Q3119	8-729-054-47 8-759-054-50		UP04501008S0	R1132	1-218-975-11	BEC-CHID	68K 5% 1/16W
Q3120	8-759-054-50		UP04501008S0	111102	1-210-9/0-11	HEO-OHIF	(TRV230E/TRV235E)
Q3201		TRANSISTOR	DTC144EHT2L	R1132	1-218-973-11	RES-CHIP	47K 5% 1/16W
Q0_01	30 002 04			11.702	0,0 11		/TRV330E/TRV430E/TRV530E)
				R1134	1-218-990-11		0 (TRV230E/TRV235E)
				R1144	1-218-961-11		4.7K 5% 1/16W
				R1145	1-218-990-11		0 (TRV230E/TRV235E)
							•

Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
R1146	1-218-990-11	SHORT	0 (TRV230	E/TRV2	(35E)	R1360	1-218-990-11	SHORT	0		
R1147	1-218-990-11	SHORT	0		,	R1361	1-218-990-11	SHORT	0		
R1148	1-218-990-11	SHORT	0			R1362	1-208-935-11		100K	0.5%	1/16W
R1151	1-218-941-11	RES-CHIP	100	5%	1/16W	R1363	1-208-697-11	METAL CHIP	3.9K	0.5%	1/16W
R1152	1-218-941-11	RES-CHIP	100	5%	1/16W	R1364	1-218-969-11	RES-CHIP	22K	5%	1/16W
R1153	1-218-941-11	RES-CHIP	100	5%	1/16W	R1365	1-218-953-11	RES-CHIP	1K	5%	1/16W
R1154	1-218-941-11	RES-CHIP	100	5%	1/16W	R1366	1-218-943-11	RES-CHIP	150	5%	1/16W
R1155	1-218-941-11		100	5%	1/16W	R1369	1-208-935-11	METAL CHIP	100K	0.5%	1/16W
R1301	1-218-969-11	RES-CHIP	22K	5%	1/16W	R1370	1-208-909-11	METAL CHIP	8.2K	0.5%	1/16W
R1302	1-218-971-11	RES-CHIP	33K	5%	1/16W	D4070		TRV230E/TRV235E			,
R1303	1 010 07/ 11	METAL CHIP	56K	0 50/	1/16W	R1370	1-208-709-11	WE TAL CHIP	12K	0.5%	1/16W
R1303	1-218-974-11 1-218-971-11	RES-CHIP	33K	0.5% 5%	1/16W						(TRV430E)
R1304	1-218-990-11	SHORT	0 0	370	1/1000	R1501	1-216-864-11	METAL CHIP	0	5%	1/16W
R1306	1-218-967-11	RES-CHIP	15K	5%	1/16W	R1502	1-216-864-91		0	J /0	1/1000
R1307	1-218-963-11	RES-CHIP	6.8K	5% 5%	1/16W	R1502	1-218-977-11		100K	5%	1/16W
111307	1-210-303-11	ILO-OIIIF	0.01	J /0	1/1000	R1504	1-218-941-11		1001	5%	1/16W
R1309	1-218-965-11	RES-CHIP	10K	5%	1/16W	R1505	1-218-941-11		100	5%	1/16W
R1310	1-218-970-11	METAL CHIP	27K	0.5%	1/16W	111303	1-210-341-11	ILO-OIII	100	J /0	1/1000
R1311	1-218-969-11		22K	5%	1/16W	R1506	1-218-941-11	RES-CHIP	100	5%	1/16W
R1312	1-218-961-11		4.7K	5%	1/16W	R1512	1-218-985-11		470K	5%	1/16W
R1313	1-218-964-11	RES-CHIP	8.2K	5%	1/16W	R1519	1-218-990-11	SHORT	0	0 70	1/1011
111010	1 210 001 11	TILO OTTI	O.LIX	0 70	171000	R1521	1-216-864-91		0		
R1314	1-218-969-11	RES-CHIP	22K	5%	1/16W	R1523	1-218-942-11		120	5%	1/16W
R1316	1-216-864-91	SHORT	0	0 70	1, 1011	111020	1 210 012 11	1120 01111	120	0 70	1, 1011
R1317	1-218-973-11		47K	5%	1/16W	R1551	1-218-973-11	RES-CHIP	47K	5%	1/16W
R1318	1-218-961-11		4.7K	5%	1/16W	R1552	1-218-953-11		1K	5%	1/16W
R1319	1-218-973-11		47K	5%	1/16W	R1555	1-218-975-11		68K	5%	1/16W
						R1556	1-218-953-11		1K	5%	1/16W
R1320	1-218-969-11	RES-CHIP	22K	5%	1/16W	R1557	1-218-975-11	RES-CHIP	68K	5%	1/16W
R1321	1-208-715-11	METAL CHIP	22K	0.5%	1/16W						
R1322	1-208-707-11	METAL CHIP	10K	0.5%	1/16W	R1560	1-218-929-11	RES-CHIP	10	5%	1/16W
R1323	1-218-977-11	RES-CHIP	100K	5%	1/16W	R1561	1-218-989-11	RES-CHIP	1M	5%	1/16W
R1326	1-218-965-11	RES-CHIP	10K	5%	1/16W	R1562	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
						R1563	1-218-965-11	RES-CHIP	10K	5%	1/16W
R1327	1-218-969-11	RES-CHIP	22K	5%	1/16W	R1564	1-218-981-11	RES-CHIP	220K	5%	1/16W
R1330	1-208-935-11	METAL CHIP	100K	0.5%	1/16W						
R1331	1-218-965-11	RES-CHIP	10K	5%	1/16W	R1565	1-218-985-11	RES-CHIP	470K	5%	1/16W
R1332	1-208-943-11	METAL CHIP	220K	0.5%	1/16W	R1566	1-218-985-11		470K	5%	1/16W
R1333	1-218-973-11	RES-CHIP	47K	5%	1/16W	R1567	1-218-957-11		2.2K	5%	1/16W
						R1568	1-218-967-11		15K	5%	1/16W
	1-218-977-11		100K	5%	1/16W	R1569	1-218-969-11	RES-CHIP	22K	5%	1/16W
R1335	1-218-977-11	RES-CHIP	100K	5%	1/16W						
		550 05			(TRV430E)	R1570	1-218-985-11		470K	5%	1/16W
R1336	1-218-969-11		22K	5%	1/16W	R1571	1-218-953-11		1K	5%	1/16W
R1337	1-218-977-11	RES-CHIP	100K	5%	1/16W	R1572	1-218-953-11	RES-CHIP	1K	5%	1/16W
D4000	1 000 005 11	METAL OLUD	1001/	0.50/	(TRV430E)	R1573	1-218-947-11		330	5%	1/16W
R1338	1-208-935-11	METAL CHIP	100K	0.5%	1/16W	R1574	1-218-969-11	KES-CHIP	22K	5%	1/16W
R1339	1-208-721-11	METAL CHIP	39K	0.5%	1/16W	R1575	1-218-953-11	RES-CHIP	1K	5%	1/16W
R1340	1-208-908-81	METAL CHIP	7.5K	0.5%	1/16W	R1576	1-218-965-11		10K	5%	1/16W
R1341	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R1577	1-218-973-11		47K	5%	1/16W
					(TRV430E)	R2001	1-218-969-11		22K	5%	1/16W
R1342	1-208-943-11	METAL CHIP	220K	0.5%	1/16W	R2002	1-218-969-11	RES-CHIP	22K	5%	1/16W
					(TRV430E)						
R1343	1-208-931-11	METAL CHIP	68K	0.5%	1/16W	R2003	1-218-969-11		22K	5%	1/16W
					(TRV430E)	R2004	1-218-969-11		22K	5%	1/16W
						R2005	1-218-989-11		1M	5%	1/16W
R1345	1-218-990-11	SHORT	0			R2006	1-218-965-11		10K	5%	1/16W
R1347	1-208-715-11	METAL CHIP	22K	0.5%	1/16W	R2007	1-218-965-11	RES-CHIP	10K	5%	1/16W
R1348	1-208-707-11	METAL CHIP	10K	0.5%	1/16W	Deces	1 010 000 1:	DEC OUTS	414	F0/	4/4014
R1349	1-218-990-11	SHORT	0			R2008	1-218-989-11		1M	5%	1/16W
R1350	1-216-864-91	SHORT	0			R2010	1-218-967-11		15K	5% 5%	1/16W
D4055	1 010 070 11	DEC CLUD	471/	E0/	4/4004	R2205	1-218-965-11		10K	5%	1/16W
R1355	1-218-973-11	RES-CHIP	47K	5% 5%	1/16W	R2206	1-218-977-11		100K	5% 5%	1/16W
R1356	1-218-937-11	RES-CHIP SHORT	47 0	5%	1/16W	R2209	1-218-965-11	NEO-UNIP	10K	5%	1/16W
R1357 R1358	1-218-990-11 1-218-990-11	SHORT	0								
R1358	1-218-990-11		0								
111000	7 210 330-11	3110111	J								

					_						
Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
R2210	1-218-954-11	RES-CHIP	1.2K	5%	1/16W	R3143	1-218-938-11	RES-CHIP	56	5%	1/16W
R2213	1-218-962-11	RES-CHIP	5.6K	5%	1/16W	R3144	1-218-950-11		560	5%	1/16W
R2215	1-218-953-11	RES-CHIP	1K	5%	1/16W	R3205	1-218-985-11		470K	5%	1/16W
R2216	1-218-963-11	RES-CHIP	6.8K	5%	1/16W	R3206	1-218-985-11		470K	5%	1/16W
R2218	1-218-949-11	RES-CHIP	470	5%	1/16W	R3210	1-218-965-11	RES-CHIP	10K	5%	1/16W
R2219	1-218-941-11	RES-CHIP	100	5%	1/16W	R3212	1-218-986-11	RES-CHIP	560K	5%	1/16W
R2220	1-218-972-11	RES-CHIP	39K	5%	1/16W	R3213	1-218-985-11		470K	5%	1/16W
R2221	1-218-952-11	RES-CHIP	820	5%	1/16W	R3214	1-218-981-11		220K	5%	1/16W
R2222	1-218-959-11	RES-CHIP	3.3K	5%	1/16W	R3215	1-208-939-11	METAL CHIP	150K	0.5%	1/16W
R2223	1-218-964-11	RES-CHIP	8.2K	5%	1/16W	R3309	1-218-990-11	SHORT	0		
R2224	1-218-966-11	RES-CHIP	12K	5%	1/16W	R3310	1-218-965-11	RES-CHIP	10K	5%	1/16W
R2225	1-218-949-11	RES-CHIP	470	5%	1/16W	R3311	1-218-965-11		10K	5%	1/16W
R2226 R2227	1-218-990-11 1-218-990-11	SHORT SHORT	0			R3312 R3313	1-218-946-11 1-218-990-11		270 0	5%	1/16W
R2228	1-218-990-11	SHORT	0			R3315	1-218-959-11	RES-CHIP	3.3K	5%	1/16W
112220	1 210 330 11	OHOTH	O			110010	1 210 333 11	TILO OTIII	0.010	3 70	1/1000
R2229	1-218-990-11	SHORT	0			R3316	1-218-959-11	RES-CHIP	3.3K	5%	1/16W
R2231	1-218-990-11	SHORT	0			R3317	1-218-961-11		4.7K	5%	1/16W
R2240	1-218-989-11	RES-CHIP	1M	5%	1/16W	R3318	1-218-965-11		10K	5%	1/16W
R2242	1-218-967-11	RES-CHIP	15K	5%	1/16W	R3319	1-218-965-11		10K	5%	1/16W
R2243	1-218-967-11	RES-CHIP	15K	5%	1/16W	R3320	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
D0044	1 010 066 11	RES-CHIP	12K	E0/	1/16W	R3321	1-218-959-11	RES-CHIP	3.3K	E0/	1/16W
R2244 R2245	1-218-966-11 1-218-949-11	RES-CHIP	470	5% 5%	1/16W	R3322	1-218-941-11		100	5% 5%	1/16W
R2245	1-218-953-11	RES-CHIP	470 1K	5%	1/16W 1/16W	R3323	1-218-947-11		330	5%	1/16W
R2248	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3324	1-218-961-11		4.7K	5%	1/16W
R2255	1-218-990-11	SHORT	0	<b>3</b> /0	1/ 10 00	R3325	1-218-937-11	RES-CHIP	47	5%	1/16W
TILLOO	1 210 000 11	0.10111	· ·			110020	. 210 007 11	1120 01111		0 70	171011
R2256	1-218-990-11	SHORT	0			R3326	1-218-990-11	SHORT	0		
R3103	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3328	1-218-849-11	METAL CHIP	1.2K	0.5%	1/16W
R3104	1-218-963-11	RES-CHIP	6.8K	5%	1/16W	R3331	1-218-961-11		4.7K	5%	1/16W
R3107	1-218-979-11	RES-CHIP	150K	5%	1/16W	R3333	1-218-990-11	SHORT	0		
R3108	1-218-989-11	RES-CHIP	1M	5%	1/16W	R3334	1-218-849-11	METAL CHIP	1.2K	0.5%	1/16W
R3109	1-218-966-11	RES-CHIP	12K	5%	1/16W	R3336	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R3110	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3337	1-218-990-11		0	J /0	1/1000
R3111	1-218-949-11	RES-CHIP	470	5%	1/16W	R3338	1-208-683-11		1K	0.5%	1/16W
R3113	1-218-966-11	RES-CHIP	12K	5%	1/16W	R3340	1-218-849-11	METAL CHIP	1.2K	0.5%	1/16W
R3114	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R3343	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R3115	1-218-965-11	RES-CHIP	10K	5%	1/16W	R3346	1-218-990-11	SHORT	0		
R3117	1-218-969-11	RES-CHIP	22K	5%	1/16W	R3349	1-218-990-11	SHORT	0		
R3118	1-220-196-11	METAL CHIP	13K	0.5%	1/16W	R3350	1-218-990-11		0	<b>5</b> 0/	4.44.00.44
R3119	1-218-970-11	METAL CHIP	27K	0.5%	1/16W	R3351	1-218-946-11		270	5%	1/16W
R3120	1-208-715-11	METAL CHIP	22K	0.5%	1/16W	R3352	1-218-990-11	SHUKI	0		
R3121	1-208-709-11	METAL CHIP	12K	0.5%	1/16W	R3356	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
R3122	1-208-931-11	METAL CHIP	68K	0.5%	1/16W	R3358	1-218-945-11		220	5%	1/16W
R3123	1-218-969-11	RES-CHIP	22K	5%	1/16W	R3360	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
R3124	1-218-969-11	RES-CHIP	22K	5%	1/16W	R3361	1-208-709-11	METAL CHIP	12K	0.5%	1/16W
R3125	1-218-945-11	METAL CHIP	220	0.5%	1/16W	R3362	1-218-990-11	SHORT	0		
D0400	1 010 000 11	DEC OUID	001/	F0/	4 /4 CM	D0004	1 000 700 11	METAL OLUB	101/	0.50/	4 /4 0///
R3126	1-218-969-11	RES-CHIP	22K	5%	1/16W	R3364	1-208-709-11	METAL CHIP	12K	0.5%	1/16W
R3127 R3128	1-218-971-11	RES-CHIP RES-CHIP	33K	5% 5%	1/16W 1/16W	R3365 R3367	1-218-990-11 1-218-938-11		0 56	E0/	1/16W
R3129	1-218-965-11 1-218-945-11	METAL CHIP	10K 220	0.5%	1/16W	R3368	1-218-938-11		56	5% 5%	1/16W
R3130	1-218-945-11	METAL CHIP	220	0.5%	1/16W	R3369	1-218-864-11		5.1K	0.5%	1/16W
	. 2.0 0.0			0.070	.,	1.0000	. 2.0 00		0	0.070	.,
R3131	1-218-945-11	METAL CHIP	220	0.5%	1/16W	R3370	1-218-938-11		56	5%	1/16W
R3132	1-218-946-11	RES-CHIP	270	5%	1/16W	R3372	1-218-938-11		56	5%	1/16W
R3133	1-218-945-11	RES-CHIP	220	5%	1/16W	R3375	1-218-965-11		10K	5%	1/16W
R3136	1-218-957-11	RES-CHIP	2.2K	5%	1/16W	R3376	1-218-953-11		1K	5%	1/16W
R3137	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R3385	1-216-864-91	SHORT	0		
R3138	1-218-941-11	RES-CHIP	100	5%	1/16W	R3386	1-216-864-91	SHORT	0		
R3139	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3394	1-218-990-11		0		
R3140	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3395	1-218-990-11		0		
R3141	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3396	1-218-990-11		0		
R3142	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R3397	1-218-990-11		0		

Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
R3398	1-218-990-11	SHORT	0			R4416	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R3607	1-218-965-11	RES-CHIP	10K	5%	1/16W	R4417	1-208-707-11	METAL CHIP	10K	0.5%	1/16W
R3611	1-218-965-11	RES-CHIP	10K	5%	1/16W	R4423	1-218-990-11	SHORT	0	F0/	4 (4 0) 14
R3617 R3622	1-218-951-11 1-218-949-11	RES-CHIP RES-CHIP	680 470	5% 5%	1/16W 1/16W	R4424 R4425	1-218-971-11	RES-CHIP RES-CHIP	33K	5%	1/16W 1/16W
H3022	1-218-949-11	KES-CHIP	470	5%	1/1000	K4425	1-218-959-11	KES-CHIP	3.3K	5%	1/1000
R3656	1-218-990-11	SHORT	0			R4426	1-218-977-11	RES-CHIP	100K	5%	1/16W
R3657	1-218-977-11	RES-CHIP	100K	5%	1/16W	R4427	1-218-965-11	RES-CHIP	10K	5%	1/16W
R3658	1-218-953-11		1K	5%	1/16W	R4428	1-217-671-11	METAL CHIP	1	5%	1/10W
R3659	1-218-960-11	RES-CHIP	3.9K	5%	1/16W	R4429	1-217-671-11	METAL CHIP	1	5%	1/10W
R3660	1-218-957-11	RES-CHIP	2.2K	5%	1/16W	R4430	1-218-985-11	RES-CHIP	470K	5%	1/16W
R3701	1-218-961-11		4.7K	5%	1/16W	R4431	1-218-967-11		15K	5%	1/16W
R3702	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R4432	1-218-973-11		47K	5%	1/16W
R3704	1-218-941-11		100	5%	1/16W	R4434	1-218-965-11		10K	5%	1/16W
R3705 R3706	1-218-981-11 1-218-954-11	RES-CHIP RES-CHIP	220K 1.2K	5% 5%	1/16W 1/16W	R4435 R4436	1-218-965-11 1-218-961-11		10K 4.7K	5% 5%	1/16W 1/16W
113700	1-210-954-11	INLO-CITIF	1.21	J /0	1/1000	114430	1-210-901-11	NL3-OHIF	4.71	J /0	1/1000
R3708	1-218-954-11	RES-CHIP	1.2K	5%	1/16W	R4447	1-218-971-11	RES-CHIP	33K	5%	1/16W
R3712	1-218-936-11	RES-CHIP	39	5%	1/16W	R4448	1-218-971-11		33K	5%	1/16W
R3713	1-218-935-11	RES-CHIP	33	5%	1/16W	R4449	1-218-972-11	RES-CHIP	39K	5%	1/16W
R3714	1-218-936-11	RES-CHIP	39	5%	1/16W	R4450	1-216-789-11	METAL CHIP	2.2	5%	1/16W
R3715	1-218-935-11	RES-CHIP	33	5%	1/16W	R4451	1-216-789-11	METAL CHIP	2.2	5%	1/16W
D0740	1 010 000 11	DEC OUID	00	F0/	4/4011	D4450	1 010 700 11	METAL OLUB	0.0	F0/	4 /4 () ()
R3716	1-218-936-11 1-218-935-11	RES-CHIP RES-CHIP	39 33	5%	1/16W 1/16W	R4452	1-216-789-11 1-218-989-11	METAL CHIP RES-CHIP	2.2 1M	5%	1/16W 1/16W
R3717 R3721	1-208-715-11	METAL CHIP	22K	5% 0.5%	1/16W	R4453 R4502	1-218-990-11	SHORT	0	5%	1/1000
R3722	1-218-953-11	RES-CHIP	1K	5%	1/16W	R4502	1-218-977-11		100K	5%	1/16W
R3724	1-218-953-11	RES-CHIP	1K 1K	5%	1/16W	R4507	1-218-953-11	RES-CHIP	166K	5%	1/16W
110724	1-210-955-11	INLO-CITIF	IIX	J /0	1/1000	114307	1-210-955-11	NL3-OHIF	IIX	J /0	1/1000
R3726	1-218-965-11	RES-CHIP	10K	5%	1/16W	R4508	1-218-985-11	RES-CHIP	470K	5%	1/16W
R3727	1-218-953-11	RES-CHIP	1K	5%	1/16W	R4511	1-218-953-11	RES-CHIP	1K	5%	1/16W
R3728	1-218-953-11	RES-CHIP	1K	5%	1/16W	R4512	1-218-961-11	RES-CHIP	4.7K	5%	1/16W
R3729	1-218-953-11	RES-CHIP	1K	5%	1/16W	R4514	1-218-977-11	RES-CHIP	100K	5%	1/16W
R3730	1-218-953-11	RES-CHIP	1K	5%	1/16W	R4520	1-218-953-11	RES-CHIP	1K	5%	1/16W
R3903	1-218-971-11	RES-CHIP	33K	5%	1/16W	R4521	1-218-965-11	RES-CHIP	10K	5%	1/16W
R3904	1-218-961-11	RES-CHIP	4.7K	5%	1/16W	R4522	1-218-965-11	RES-CHIP	10K	5%	1/16W
R3905	1-218-971-11	RES-CHIP	33K	5%	1/16W	R4523	1-218-985-11	RES-CHIP	470K	5%	1/16W
R3908	1-218-966-11	RES-CHIP	12K	5%	1/16W	R4524	1-218-977-11	RES-CHIP	100K	5%	1/16W
R3909	1-218-989-11	RES-CHIP	1M	5%	1/16W	R4526	1-218-985-11	RES-CHIP	470K	5%	1/16W
R3911	1-208-715-11		22K	0.5%	1/16W	R4527	1-218-977-11		100K	5%	1/16W
R3912	1-218-947-11		330	5%	1/16W	R4530	1-218-949-11		470	5%	1/16W
R3913	1-218-953-11		1K	5%	1/16W	R4801	1-218-973-11		47K	5%	1/16W
R3916	1-218-951-11		680	5%	1/16W	R4802	1-218-961-11		4.7K	5%	1/16W
R3917	1-218-979-11	RES-CHIP	150K	5%	1/16W	R4803	1-218-977-11	RES-CHIP	100K	5%	1/16W
R3918	1-218-979-11	RES-CHIP	150K	5%	1/16W	R4805	1-218-953-11	RES-CHIP	1K	5%	1/16W
R3919	1-218-950-11		560	5%	1/16W	R4806	1-218-953-11		1K	5%	1/16W
R3920	1-218-963-11		6.8K	5%	1/16W	R4807	1-218-957-11		2.2K	5%	1/16W
R3921	1-218-949-11		470	5%	1/16W	R4808	1-218-990-11		0	0 / 0	.,
R3922	1-218-972-11		39K	5%	1/16W	R4809	1-218-953-11		1K	5%	1/16W
R3923	1-218-949-11		470	5%	1/16W	R4810	1-218-953-11		1K	5%	1/16W
R3924	1-218-949-11		470	5%	1/16W	R4811	1-218-977-11		100K	5%	1/16W
R3936	1-218-955-11		1.5K	5%	1/16W	R4812	1-218-953-11		1K	5%	1/16W
R3939	1-218-990-11		0			R4813	1-218-953-11		1K	5%	1/16W
R3940	1-218-990-11	SHORT	0			R4814	1-218-965-11	RES-CHIP	10K	5%	1/16W
R3943	1-218-966-11	RES-CHIP	12K	5%	1/16W	R4815	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4401	1-218-973-11		47K	5%	1/16W	R4816	1-218-953-11		1K	5%	1/16W
R4402	1-218-983-11		330K	5%	1/16W	R4817	1-218-954-11		1.2K	5%	1/16W
R4405	1-218-977-11		100K	5%	1/16W	R4818	1-218-954-11		1.2K	5%	1/16W
R4407	1-218-949-11		470	5%	1/16W	R4819	1-218-954-11		1.2K	5%	1/16W
D4400	1 017 074 44	METAL CLUB	1	En/	1/10/4/	D4000	1 010 077 11	DEC CLUD	1001/	E0/	1/10//
R4408	1-217-671-11		1	5%	1/10W	R4820	1-218-977-11		100K	5% 5%	1/16W
R4409 R4410	1-217-671-11 1-217-671-11		1 1	5% 5%	1/10W	R4821 R4822	1-218-985-11 1-218-973-11		470K	5% 5%	1/16W 1/16W
R4410 R4411	1-217-671-11		1 82	5% 5%	1/10W 1/10W	R4823	1-218-973-11		47K 10K	5% 5%	1/16W
R4414	1-218-946-11		270	5% 5%	1/16W	R4824	1-218-958-11		2.7K	5%	1/16W
117717	1 210 0-10-11	TEO OTTO	2.0	<b>U</b> /U	1, 1011	117047	1 210 000-11	TEO OTTI	L., IX	<b>U</b> /0	17 10 8 8

Ref. No.	Part No.	<u>Description</u>			<b>Remarks</b>	Ref. No.	Part No.	<u>Description</u>			<u>Remarks</u>
R4829	1-218-953-11	RES-CHIP	1K	5%	1/16W	R4944	1-218-953-11	RES-CHIP	1K	5%	1/16W
R4830	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5707	1-218-953-11	RES-CHIP	1K	5%	1/16W
R4832	1-218-989-11	RES-CHIP	1M	5%	1/16W	R5708	1-218-953-11	RES-CHIP	1K	5%	1/16W
R4833	1-218-985-11	METAL CHIP	470K	0.5%	1/16W	R5709	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4834	1-218-985-11	METAL CHIP	470K 470K	0.5%	1/16W	R5710	1-218-965-11	RES-CHIP	10K	5%	1/16W
N4034	1-210-900-11	IVIETAL UNIP	47UK	0.5%	1/1000	h5/10	1-210-900-11	NES-CHIP	IUK	370	1/1000
R4835	1 010 000 11	METAL CHID	11/1	0.50/	1/16W	DE711	1 010 0/1 11	RES-CHIP	100	5%	1/16W
	1-218-989-11	METAL CHIP	1M	0.5%		R5711	1-218-941-11		100		
R4836	1-218-989-11	METAL CHIP	1M	0.5%	1/16W	R5712	1-218-941-11	RES-CHIP	100	5%	1/16W
R4840	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5714	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4855	1-218-977-11		100K	5%	1/16W	R5715	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4861	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5717	1-218-953-11	RES-CHIP	1K	5%	1/16W
D 4000	4 040 050 44	550 01115	414	<b>5</b> 0/	4 /4 00 44			(TRV325E	/TRV330E/	I KV430E/	TRV530E)
R4862	1-218-953-11		1K	5%	1/16W	D=740	4 040 007 44	DE0 0111D	4514	<b>5</b> 0/	4 /4 014/
R4863	1-218-973-11	RES-CHIP	47K	5%	1/16W	R5718	1-218-967-11	RES-CHIP	15K	5%	1/16W
R4864		RES-CHIP	560K	5%	1/16W						TRV235E)
R4867	1-218-985-11		470K	5%	1/16W	R5718	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4868	1-218-985-11	RES-CHIP	470K	5%	1/16W				/TRV330E/		
						R5719	1-218-976-11	RES-CHIP	82K	5%	1/16W
R4869	1-218-985-11		470K	5%	1/16W						TRV235E)
R4872	1-218-977-11	RES-CHIP	100K	5%	1/16W	R5719	1-218-975-11	RES-CHIP	68K	5%	1/16W
R4873	1-218-977-11		100K	5%	1/16W			,	/TRV330E/	TRV430E/	,
R4876	1-219-570-11		10M	5%	1/16W	R5720	1-218-979-11	RES-CHIP	150K	5%	1/16W
R4878	1-218-977-11	RES-CHIP	100K	5%	1/16W						
						R5721	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4882	1-218-949-11	RES-CHIP	470	5%	1/16W	R5724	1-218-985-11	RES-CHIP	470K	5%	1/16W
R4883	1-218-985-11	RES-CHIP	470K	5%	1/16W	R5725	1-218-985-11	RES-CHIP	470K	5%	1/16W
R4884	1-218-990-11	SHORT	0			R5730	1-218-952-11	RES-CHIP	820	5%	1/16W
R4885	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5731	1-218-949-11	RES-CHIP	470	5%	1/16W
R4886	1-218-953-11	RES-CHIP	1K	5%	1/16W						
						R5732	1-218-949-11	RES-CHIP	470	5%	1/16W
R4887	1-218-977-11	RES-CHIP	100K	5%	1/16W	R5733	1-218-985-11	RES-CHIP	470K	5%	1/16W
R4888	1-218-977-11	RES-CHIP	100K	5%	1/16W	R5742	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4897	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5743	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4898	1-218-989-11	RES-CHIP	1M	5%	1/16W	R5744	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4899	1-218-965-11	RES-CHIP	10K	5%	1/16W						
				- , -	.,	R5745	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4901	1-218-953-11	RES-CHIP	1K	5%	1/16W	R5746	1-218-965-11	RES-CHIP	10K	5%	1/16W
R4902	1-218-986-11	RES-CHIP	560K	5%	1/16W	R5747	1-218-973-11	RES-CHIP	47K	5%	1/16W
R4903	1-218-990-11	SHORT	0	0 70	17 1011	R5801	1-218-971-11	RES-CHIP	33K	5%	1/16W
R4904		RES-CHIP	100K	5%	1/16W	R5802	1-218-968-11	RES-CHIP	18K	5%	1/16W
R4906	1-218-990-11	SHORT	0	0 70	1/ 1000	110002	1 210 000 11	TILO OTTI	1010	0 70	1/1011
114300	1 210 330 11	OHOITI	O			R5803	1-218-957-11	RES-CHIP	2.2K	5%	1/16W
R4908	1-218-977-11	RES-CHIP	100K	5%	1/16W	R5805	1-218-961-11		4.7K	5%	1/16W
R4910	1-218-977-11		100K	5%	1/16W	R5806	1-218-965-11		10K	5%	1/16W
R4911	1-218-977-11		100K	5%	1/16W	R5807	1-218-963-11		6.8K	5%	1/16W
R4912	1-218-961-11		4.7K	5%	1/16W	R5809	1-218-957-11		2.2K	5%	1/16W
R4913	1-218-957-11		2.2K	5%	1/16W	113003	1-210-337-11	ILO-OIII	2.21\	J /0	1/1000
114313	1-210-337-11	TILO-OTTI	2.21	J /0	1/1000	R5814	1-218-963-11	RES-CHIP	6.8K	5%	1/16W
R4915	1-218-961-11	DEC-CHID	4.7K	5%	1/16W	R5815	1-218-953-11		1K	5%	1/16W
R4916	1-218-961-11		4.7K 4.7K	5%	1/16W	R5816	1-218-953-11		1K	5%	1/16W
R4917	1-218-953-11		1K	5%	1/16W	R5817	1-218-957-11		2.2K	5%	1/16W
R4918	1-218-957-11		2.2K	5%	1/16W	R5818	1-218-957-11		2.2K 2.2K	5%	1/16W
R4920	1-218-965-11		10K	5%	1/16W	113010	1-210-337-11	NLO-OHIF	2.21\	J /0	1/1000
N4920	1-210-900-11	NES-UNIP	IUN	370	1/1000	DE010	1-208-910-11	RES-CHIP	0.11/	5%	1/16W
D4004	1 010 005 11	DEC CIUD	101/	E0/	4 /4 CW/	R5819			9.1K		
R4921	1-218-965-11		10K	5%	1/16W	R5820	1-220-193-81		7.5K	5%	1/16W
R4922	1-218-973-11		47K	5%	1/16W	R5821	1-208-910-11		9.1K	5%	1/16W
R4923	1-218-973-11		47K	5%	1/16W	R5822	1-220-193-81		7.5K	5%	1/16W
R4924	1-218-973-11		47K	5%	1/16W	R5823	1-218-954-11	RES-CHIP	1.2K	5%	1/16W
R4925	1-218-985-11	RES-CHIP	470K	5%	1/16W						
B 10	1 010 05= :	DE0 0:::5	470.7	<b>5</b> 67		R5824	1-218-990-11	SHORT	0		
R4926	1-218-985-11		470K	5%	1/16W	R5825	1-218-990-11		0		
R4927	1-218-973-11		47K	5%	1/16W	R5826	1-218-954-11		1.2K	5%	1/16W
R4928	1-218-977-11		100K	5%	1/16W	R5827	1-218-963-11		6.8K	5%	1/16W
R4929	1-218-977-11		100K	5%	1/16W	R5828	1-218-963-11	RES-CHIP	6.8K	5%	1/16W
R4930	1-218-977-11	RES-CHIP	100K	5%	1/16W						
						R5829	1-218-971-11		33K	5%	1/16W
R4931	1-218-973-11		47K	5%	1/16W	R5830	1-218-977-11		100K	5%	1/16W
R4932	1-218-973-11		47K	5%	1/16W	R5831	1-218-968-11		18K	5%	1/16W
R4935	1-218-977-11		100K	5%	1/16W	R5834	1-218-957-11		2.2K	5%	1/16W
R4936	1-218-977-11		100K	5%	1/16W	R5846	1-218-990-11	SHORT	0		
R4943	1-218-953-11	RES-CHIP	1K	5%	1/16W						
						R5847	1-218-990-11	SHORT	0		

Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
		< COMPOSITION CIRCUIT BLOCK >			3-065-263-31	MANUAL, INSTRUCTION (E	NGLISH/DUTCH) (AEP)
	1-234-381-21	RES, NETWORK 100KX4 (1005)			3-065-263-41	MANUAL, INSTRUCTION	,
	1-234-381-21 1-234-381-21	RES, NETWORK 100KX4 (1005) RES, NETWORK 100KX4 (1005)			3-065-263-51	(SPANISH/ MANUAL, INSTRUCTION (IT	PORTUGUESE)(AEP) [ALIAN/GREEK)
RB4801	1-234-375-21	RES, NETWORK 1KX4 (1005)				•	(AEP)
RB4803	1-234-383-21	RES, NETWORK 470KX4 (1005)			3-065-263-61	MANUAL, INSTRUCTION (E	NGLISH/SWEDISH) (AEP)
RB4804	1-234-383-21	RES, NETWORK 470KX4 (1005)			3-065-263-71	MANUAL, INSTRUCTION (F	
	1-234-375-21	RES, NETWORK 1KX4 (1005)					(AEP)
	1-234-381-21 1-234-378-21	RES, NETWORK 100KX4 (1005) RES, NETWORK 10KX4 (1005)			3-065-263-81	MANUAL, INSTRUCTION (P	OLISH/CZECH)
RB4818	1-234-381-21	RES, NETWORK 100KX4 (1005)				,	(AEP)
RR4903	1-234-381-21	RES, NETWORK 100KX4 (1005)			3-065-263-91	MANUAL, INSTRUCTION (SLOVAKIAN	J/HUNGARIAN)(AEP)
1104300	1 204 001 21	TILO, INCTIVIOTIN TOURNA (1000)			3-065-264-11	MANUAL, INSTRUCTION (E	
		< TRANSFORMER >				(TRV230E:E,HK,AUS/TRV33	BOE:E,HK,AUS,JE,CN/ BOE:E,HK,AUS,JE,CN)
T1301	1-435-252-21	TRANSFORMER, DC-DC CONVERTER			3-065-264-21	MANUAL, INSTRUCTION (F	,
		VIDDATOD			\	230E:E/TRV325E:E/TRV330E	' '
		< VIBRATOR >			3-065-264-31	MANUAL, INSTRUCTION (A (TRV230E:E/TR)	KABIC/PERSIAN) V325E:E/TRV530E:E)
X1501	1-767-400-11	VIBRATOR, CRYSTAL (36MHz)				(	,
X3301 X4801	1-767-399-11 1-767-980-21	VIBRATOR, CRYSTAL (24.576MHz) VIBRATOR, CERAMIC (20MHz)			3-065-264-41	MANUAL, INSTRUCTION	DITIONAL CHINESE)
X4802	1-760-458-21	VIBRATOR, CRYSTAL (32.768KHz)				(TRV230E:HK/TRV33	
X4901	1-760-655-41	VIBRATOR, CRYSTAL (20MHz)			3-065-264-51	MANUAL, INSTRUCTION	MDI IEIED CHINECE)
						(S) TRV230E:E/TRV330E:E,JE,C)	MPLIFIED CHINESE) N/TRV530E:E,JE,CN)
		ACCESSORIES **********			3-066-676-01	SPVD-004 (USB DRIVER (C	
		****			3-987-015-01	BELT (S), SHOULDER	/TRV430E/TRV530E)
	1-475-141-61	REMOTE COMMANDER (RMT-814)				MEMORY STICK (MSA-4A)	
$\triangle$		ADAPTOR, AC (AC-L10A) RV235E/TRV325E/TRV330E:AEP.UK.E.H	IK VIIC IE/			(TRV325E/TRV330E	/TRV430E/TRV530E)
	(111VZ3UE/11	11V233L/111V323L/11NV33UE.AEF,UK,E,F	IN,AUS,JE/				

$\Lambda$	1-475-141-61 1-475-599-11	REMOTE COMMANDER (RMT-814)
<u> </u>		ADAPTOR, AC (AC-L10A)
	(INV23UE/II	RV235E/TRV325E/TRV330E:AEP,UK,E,HK,AUS,JE/ TRV430E/TRV530E:AEP,E,HK,AUS,JE)
$\Lambda$	1-475-599-81	ADAPTOR, AC (AC-L10B)
<u> </u>	1-475-599-61	(TRV330E:CN/TRV530E:CN)
$\Lambda$	1-569-007-11	ADAPTOR, CONVERSION 2P
<u> </u>	1-303-007-11	(TRV330E:JE/TRV530E:JE)
$\Lambda$	1_560_008_21	ADAPTOR, CONVERSION 2P
<u> </u>		DE:E,HK/TRV330E:E/TRV330E:HK/TRV530E:E,HK)
	(111720)	bele,filly fitty 350e.e/ fitty 350e.filly fitty 350e.e,filly
$\Lambda$	1-573-201-11	ADAPTOR, CONVERSION 21P
7:1		0E:AEP,UK/TRV235E/TRV325E/TRV330E:AEP,UK/
	(111720	TRV430E/TRV530E:AEP)
$\Lambda$	1-696-819-11	CORD, POWER
_		(TRV230E:AUS/TRV330E:AUS/TRV530E:AUS)
	1-757-293-11	CORD, CONNECTION(USB 5P)
		(TRV325E/TRV330E/TRV430E/TRV530E)
	1-765-080-11	CORD, CONNECTION(AV CABLE)(1.5m)
$\triangle$	1-769-608-11	CORD, POWER
		(TRV230E:AEP,E/TRV235E/TRV325E:AEP/
		TRV330E:AEP,E/TRV430E/TRV530E:AEP,E)
		,
$\triangle$	1-782-476-11	CORD, POWER (TRV330E:CN/TRV530E:CN)
$\triangle$	1-783-374-11	CORD, POWER
	(TRV230E:Uł	K,HK/TRV325E:UK/TRV330E:UK,HK/TRV530E:HK)
$\triangle$	1-790-732-11	CORD, POWER (TRV330E:JE/TRV530E:JE)
	3-065-263-11	MANUAL, INSTRUCTION (ENGLISH/RUSSIAN)

(TRV230E:AEP,UK/TRV235E/TRV325E/TRV330E:AEP,UK/


3-065-263-21 MANUAL, INSTRUCTION (FRENCH/GERMAN)

TRV430E/TRV530E:AEP)

X-3949-376-1 CAP(N) ASSY, LENS
NP-FM30 BATTERY PACK (Not supplied)
(EXCEPT TRV235E/TRV430E)
NP-FM50 BATTERY PACK (Not supplied)
(TRV235E/TRV430E)

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.


(AEP)



Take a copy of OPTICAL AXIS FRAME with a clear sheet for use.

## **(FOR CAMERA COLOR REPRODUCTION ADJUSTMENT)**

Take a copy of CAMERA COLOR REPRODUCTION FRAME with a clear sheet for use.



DCR-TRV230E/TRV235E/TRV325E/ TRV330E/TRV430E/TRV530E



## DCR-TRV230E/TRV235E/TRV325E/ TRV330E/TRV430E/TRV530E

# **Revision History**

Ver.	Ver. Date History		Contents	S.M. Rev. issued		
1.0	2001.02	Official Release	_			
1.1	2001.09	Correction-1 (PV01-016)	Correction of part No. for service part. S.M. correction: Page 6-8	Yes		


# 8mm Video MECHANICAL ADJUSTMENT MANUAL IX

Ver 1.0 2000. 12

# M2000 MECHANISM



Please use this manual with the service manual of the respective models.



Digital 8 MECHANISM DECK



#### **TABLE OF CONTENTS**

1.	Preparations for Check, Adjustment and
	Replacement of Mechanism Block
1-1. 1-2.	Service Jigs and Tools
2.	Periodic Inspection and Maintenance
2-1.	Rotary Drum Cleaning9
2-2.	Tape Path System Cleaning
2-3.	Periodic Inspection List
2-4.	Appling Oil and Grease
3.	Before Replacement, Check or Adjustment
3-1.	Phase Adjustment
3-2.	Cassette compartment assembly
4.	Check, Adjustment and Replacement
4-1.	Drum Assembly 14
4-2.	HCL Arm Assembly, Loading Motor Assembly 15
4-3.	Drum Base Assembly, Drum Earth 16
4-4.	Guide Rail T2, Capstan Motor 17
4-5.	Blind Plate, Lock Guide
4-6.	Reel Table (T) Assembly, T Soft Assembly 19
4-7.	S Ratchet RE Plate, Cassette Guide S20
4-8.	R Drive Gear Assembly, LS Cam Plate 21
4-9.	LS Cam Plate Position Adjustment 22
4-10.	LS Chassis Block Assembly 23
	TG7 Arm Block Assembly, Pinch Arm Assembly 24
	Guide Base (T) Block Assembly,
	Guide Base (S) Block Assembly25
4-13.	TG1 Arm, Reel Table (S) Assembly, Push Switch (3Key) · 26
	Hall Element (H001, H002 (T/S Reel)),
	Photo Transistor (Q001, Q002 (Tape Top/Tape End)),
	LED (D001 (Tape LED))
4-15.	LS Guide Roller, Guide Lock Plate (T),
	Pinch Pusher Assembly, Eject Arm 28
4-16.	Rotary Switch, Cam Relay Gear,
	Change Gear Assembly, Timing Belt29
4-17.	Guide Gear Assembly, Guide Gear T Assembly,
	Cam Relay Gear 1, Guide Lock Plate (S) 30
4-18.	LD Gear 4, Cam Gear 1, HC Drive Arm31
4-19.	M Slide Plate Assembly, LS Arm Assembly,
	Cam Gear 2, GL Arm Assembly
5.	Adjustment
5-1.	Check and Adjustment of TG1 Back-tension Position ····· 33
5-2.	Check and Adjustment of FWD/RVS Back-tension 34
5-3.	Capstan Motor Azimuth Position Adjustment 35
5-4.	Tape Path Adjustment 36
6.	<b>Exploded Views</b>
6-1.	Cassette Compartment Assy, Drum Assy 40
6-2.	LS Chassis Block Assembly 41
6-3.	Mechanical Chassis Block Assembly-1
6-4.	Mechanical Chassis Block Assembly-2
7.	Printed Wiring Boards and
	Schematic Diagrams44

#### 1. Preparations for Check, Adjustment and Replacement of Mechanism Block

#### Before Replacement, Check or Adjustment

- Refer to the "DISASSEMBLY" section of the SERVICE MANUAL of the respective models for details of removing cabinets and printed wiring boards.
- When checking a mechanism ir making any adjustment to the mechanism or replacing mechanical parts, be sure to use the Mode Selector II and select the appropriate status of the mechanical deck such that the mechanical status is suitable for the desired work. Refer to section "1-2. Mode Selector II Operating Procedure" for details on how to enter the mode shown in a rectangle \_\_\_\_\_ mode in the sequent sections of this manual.
- \* Assemble and adjust the parts in the USE mode if any mode is not specified in this manual.

#### 1-1. Service Jigs and Tools

Ref. No.		Name	Part code	Jig inscription	Used for		
J-1	Cleaning fluid		Y-2031-001-0				
J-2	Wiping cloth		7-741-900-53				
J-3	Super-fine applicator (made by Nippon Ap						
J-4	Head eraser		commercially available		Tape path		
J-5	Mirror (small oval ty	pe)	J-6080-840-A	GD-2038	Tape path		
J-6	Alignment tape	NTSC: WR5-1NP	8-967-995-02		For tracking adjustment		
J-0		PAL: WR5-1CP	8-967-995-07		Tor tracking adjustment		
J-7	FWD/RVS take-up to	orque cassette	J-6080-824-A	GD-2086			
J-8	Tape path screwdrive	r	J-6082-026-A		For tape guide adjustment		
J-9	Adjustment remote c	ommander (RM-95 upgrated)	J-6082-053-B		Tape path (for setting the path mode)(Note)		
J-10	MD process table	J-6082-166-A					
J-11	Floil grease	7-662-001-39					
J-12	Torque screwdriver		J-9049-330-A				
J-13	Mode Selector II		J-6082-282-B				
J-14	Mode Selector II con	version board	J-6082-516-A				
J-15	Mode Selector II RO	J-6082-314-E					
J-16	Thickness gauge		9-911-053-00		For capstan azimuth adjustment, LS cam plate position adjustment		

#### Other required equipment:

- Oscilloscope
- Analog tester (20  $k\Omega)$

**Note:** If the micro processor IC in the adjustment remote commander is not the new micro processor (UPD7503G-C56-12), the pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).




Fig. 1-1.

#### 1-2. Mode Selector II Operating Procedure

#### 1-2-1. Introduction

The Mode Selector II is a mechanism drive tool that assists maintenance work of the various mechanism decks. It has the following functions.

#### 1. Manual Test

In this mode, the motor of the mechanism deck is powered only during the period while the switch is turned on manually. Using the Manual Test, the operator can freely control the motor of the mechanism deck.

#### 2. Step Test

In this mode, the motor of the mechanism deck is kept turned on until the mechanical status is changed from the present mechanical status that is obtained from the sensor information. The Step Test is used to confirm a series of movements of the mechanism deck.

#### 3. Auto Test

The Mode Selector II stores the status transition table in its memory as data indicating the respective modes of the mechanism deck. The status transition table can be used to confirm whether a mechanism deck is operating normally or has abnormality from a series of movements of a mechanism deck. If an abnormal status transition is detected during operation, the "NG" indication appears and the mechanism stops moving.




Fig. 1-2.

#### Mode Selector II (J-6082-282-B) connection diagram





Fig. 1-3.


#### 1-2-2. Operation

#### 1. Operation Flow Chart




#### 2. Mode Selector II Power On

Turn on the main power of the Mode Selector II as follows. Press the SEL button.



#### 3. Mode Selector II Power Off

Turn off the main power of the Mode Selector II as follows. Press the RVS and FF buttons at the same time for 2 seconds or longer while the power is on.



#### 4. Mecha Select

When the main power is turned on, the MECHA SELECT display appears on the LCD screen. Select the desired mechanism name using the RVS and FF buttons. Selection is complete when the SEL button is pressed. (Fig. A shows the B mechanism.)




Fig. a

#### 5. Test Type Select

Using the <u>RVS</u> and <u>FF</u> buttons, select a desired test type from the three types of "MANUAL", "STEP" and "AUTO". Selection is complete when the SEL button is pressed.




Fig. b

#### 6. Manual Test

In this test, the motor of the mechanism deck is turned on only during the period while the RVS or FF button is pressed manually.




Fig. c

#### 7. Step Test

In this test, the direction of motor movement is determined by the RVS and FF buttons. The motor of the mechanism deck is kept turned on until the mechanical status is changed from the present mechanical status that is obtained from the sensor information.




Fig. d

# **8. Auto Test**In this test, the mechanism deck is tested as to whether it performs a series of movements correctly in accordance with the operation sequence that is memorized earlier for each type of deck, by checking the output signals from sensors with the stored memory. Turning

on the RVS or FF button performs the same operation.




Fig. e

#### 1-2-3. Mechanism Status (Position) Transition Table Using Mode Selector II

After selecting a mechanism deck, select either the MANUAL or STEP test (not AUTO) using the Mode Selector II. The desired mechanism status (position) can be specified by pressing the RVS or FF button. (The selected status appears on STATUS.)

	(	The second series		
EJ↔USE↔	LOAD↔	STOP ← → TU	JRN←→RI	P←→REW

MD name				M2000 Mechanism
A	В	C		
1	0	0	1	EJ
1	1	0	2	USE
0	1	0	3	LOAD
0	1	1	4	STOP
0	0	1	5	TURN
0	0	0	6	RP
1	0	1	7	REW

0 is common and short. 1 is common and open.

#### 1-2-4. Battery Alarm Indication

When the level of the battery used to supply power to this system decreases, this display appears asynchronously. When this happens, all operations are disabled and the battery must be replaced.




Fig. f

#### 2. Periodic Inspection and Maintenance

Be sure to perform the following maintenance and inspection so
that the machine delivers its full performance and functions, and
to protect the machine and tape. Also, perform the following
maintenance items after completing the repair work, regardless
of the number of hours the machine has been operated by the
user.

#### 2-1. Rotary Drum Cleaning

 Press a wiping cloth (Ref. No. J-2) moistened with cleaning fluid (Ref. No. J-1) lightly against the rotary drum. Rotate the upper drum with a super-fine applicator slowly in the counterclockwise direction to clean the rotary drum.

**Caution:** Never rotate the rotary drum by turning on the main power of the motor or rotate it in the clockwise direction. Never move the cloth vertically against the head tip, as this will surely damage the video head; the video head must not be cleaned by any other different methods.

# 2-2. Tape Path System Cleaning (Refer to Fig. 2-1.)

- 1) Set the EJECT state. Clean the tape running path (TG1, 2, 3, 4, 5, 6 and 7, pinch roller and capstan shaft) and lower drum with a super-fine applicator (Ref. No. J-3) moistened with cleaning fluid.
- **Note 1:** Be careful not to allow oil or grease of the various link mechanisms to get on the super-fine applicator (Ref. No. J-3).
- **Note 2:** Once the super-fine applicator has been moistened with alcohol, do not use it to clean other mechanical parts such as the tape guide. However, the pinch roller is cleaned with alcohol.
- **Note 3:** When cleaning the capstan shaft, be carefull not to move the oil seal. If the oil seal is moved, oil will leak.




Fig. 2-1

#### 2-3. Periodic Inspection List

Maintenance and inspection item		Operating hours (H)								Remarks		
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	Remarks
	Tape running surface cleaning	0	0	0	0	0	0	0	0	0	0	Be careful not to attach oil
	Rotary drum cleaning and degaussing	0	0	0	0	0	0	0	0	0	0	Be careful not to attach oil
	Timing belt	_	☆	_	☆	_	☆	_	☆	_	☆	
Drive mechanism	Capstan shaft	_	☆	_	☆	_	☆		☆	_	☆	Never attach oil to the tape running path during periodic inspection.
-	Loading motor	_	☆	_	☆	_	☆	_	☆	_	☆	
9	Abnormal sound	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	
nan eck	Back-tension measurement	_	☆	_	☆	_	☆	_	☆	_	☆	
Performance check	Brake system	_	☆	_	☆	_	☆	_	☆	_	☆	
Pe	FWD/RVS torque measurement	_	☆	_	☆	_	☆	_	☆	_	☆	

**Note:** When the machine is overhauled, replace the parts referring to the above list.

O: Cleaning, ☆: Check

#### 2-4. Appling Oil and Grease

When replacing or assembling the parts, use oil and grease while referring to the following.

#### On Oil

• Be sure to use the specified grease only. (If oil of different viscosity is used, it can cause various troubles.)

Oil: Part No. 7-661-018-18

(Mitsubishi diamond oil hydro fluid NT-68)

- The oil used for bearings must not contain any dust or other materials, otherwise excessive abrasion and seizure of the bearing could occur.
- A drop of oil means the amount of oil as shown in the illustration in the right, which is the amount that is attracted to the top of a rod of 2 mm diameter.

#### On Grease

• Be sure to use the specified grease only. (If oil of different viscosity is used, it can cause various troubles.)

Floil grease: Part No. 7-662-001-39

- Be sure to use grease into which dust is not mixed.
- The amount of grease is 1 to 1.5 mm diameter in length.




Fig. 2-2

# 3. Before Replacement, Check or Adjustment

#### 3-1. Phase Adjustment

The phase adjustment of this mechanism block has been adjusted by using the in-phase markings shown in the following figure. When replacing or assembling the parts, check the phase.




Fig. 3-1.

#### 3-2. Cassette compartment assembly

#### 1. Removal procedure

- 1) Set the EJ mode to move up the cassette compartment assembly ①.
- 2) Remove the capstan flexible board and flexible wiring board (FP-300) ① from the holders ②, ③ and ② in the directions of the arrows ③, ⑧ and ⑤.
- Push the damper assembly ③ in the directions of the arrows
   and ⑤ and remove it from the notch of the LS chassis block assembly.
- 4) Remove the two screws (camera pan2 main M1.4  $\times$  1.6) **4**.
- 5) With the cassette compartment assembly ① half opened, move the face plate in the direction of the arrow ⑤ and remove it from the grooves ⑥ and ⑦ on the LS chassis block assembly.
- 6) Remove the cassette holder (S) (a) and cassette holder (T) (a) of the cassette compartment assembly (b) from the groove on the LS chassis block assembly.

- 1) Set the USE mode.
- 2) Insert the cassette holder (S) (a) of the cassette compartment assembly (b) and cassette holder (T) (c) into the grooves on both sides of the LS chassis block assembly.
- 3) While moving down the cassette compartment assembly ①, lift up the face plate in the direction of the arrow ① and keep this status. Then, insert the face plate in the grooves ⑥ and ⑦ on the LS chassis block assembly.
- 4) Tighten the two screws (camera pan2 main M1.4×1.6) ④. Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 5) Move the damper arm of the damper assembly ③ to the 4 o'clock position and insert the damper assembly into the hole on the LS chassis block assembly and the dowel of the cassette holder (T) ⑨.
- 6) Align the damper assembly ③ with the notch of the LS chassis block assembly and rotate the damper assembly ③ in the opposite direction to the arrow ⑤ to fix it.




Fig. 3-2.

### 4. Check, Adjustment and Replacement

Note: For removal procedure of the cabinets, printed wiring boards and other parts, refer to "DISASSEMBLY" of the Service Manual of the respective

#### 4-1. Drum Assembly

#### 1. Removal procedure

1) Remove the three screws (drum fitting  $M1.4 \times 2.5$ ) ① fixing the drum and remove the drum.

#### 2. Attachment procedure

- Align the two reference holes A and B on the rear of the drum with the reference pins A and B of the drum base assembly.
- 2) Attach the drum with the three screws (drum fitting M1.4  $\times$  2.5) ① in the order of ②, ③ and ③. Tightening torque:  $0.078 \pm 0.01 \text{ N} \cdot \text{m} \ (0.8 \pm 0.1 \text{ kgf} \cdot \text{cm})$
- 3) Clean the drum while referring to 2-1.
- 4) Adjust the tape path. (Refer to "4. Tape Path Adjustment".)

**Note:** Do not touch the outside circumference.




Fig. 4-1.

#### 4-2. HCL Arm Assembly, Loading Motor Assembly

#### 1. Removal procedure

- 1) Hook the HC arm spring in the direction of the arrow **B**.
- Remove the HCL arm assembly ② from the loading motor assembly ④.
- 3) Remove the screw  $(M1.4 \times 2.5)$  ③.
- Remove the three claws of the loading motor assembly (4) from the mechanism chassis assembly in the direction of the arrow (a).

- Coat the worm shaft and gear of the loading motor assembly
   with grease.
- Insert the three claws of the loading motor assembly into the groove on the mechanism chassis assembly.
- Attach the screw (M1.4 × 2.5) ③.
   Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- Check the position of the HCL arm assembly ② and the HC drive arm. Then attach the HCL arm assembly ② to the loading motor assembly ④.
- Hook the HC arm spring ① on the notch of the loading motor assembly ④.
- 6) Clean the drum assembly. (Refer to section 2-1.)




Fig. 4-2.

#### 4-3. Drum Base Assembly, Drum Earth

#### 1. Removal procedure

- 2) Remove the drum assembly. (Refer to section 4-1.)
- 3) Remove the screw  $(M1.4 \times 2.5)$  ②.
- 4) Remove the claw ① of the guide rail T2 ③ from the hole ⑤ of the drum base assembly in the direction of the arrow ⑥.
- 5) Remove the three screws  $(M1.4 \times 2.5)$  **4**.
- 6) Remove the drum base assembly (5) in the direction of the arrow.
- 7) Remove the screw (screw assy PW  $M1.7 \times 2.6$ ) **6**.
- 8) Remove the drum earth ① and earth spacer ⑧.

- 1) Attach the ground spacer (a) and drum ground (7) with the screw (screw assy PW M1.7 × 2.6) (b).
  - Tightening torque:  $0.078 \pm 0.01 \text{ N} \cdot \text{m} (0.8 \pm 0.1 \text{ kgf} \cdot \text{cm})$
- 2) Align the drum base assembly (§) with the reference pin and tighten the three screws (M1.4 × 2.5) (4) in the order of (©), (H) and (1).
- 3) Insert the claw ① of the guide rail T2③ into the hole ② of the drum base assembly ③ and tighten the screw (M1.4×2.5) ②. Tightening torque: 0.078 ± 0.01 N•m (0.8 kgf•cm)
- 4) Remove the drum assembly. (Refer to 4-1.)
- 5) Attach the flexible wiring board (FP-300) ① and capstan flexible board to the drum base assembly.
- 6) Clean the tape running path. (Refer to 2-2.)




Fig. 4-3.

#### 4-4. Guide Rail T2, Capstan Motor

#### 1. Removal procedure

- 1) Remove the capstan flexible board and flexible wiring board (FP-300) ① from the holders ②, ③ and ② in the directions of the arrows ④, ⑧ and ⑥.
- 2) Remove the screw  $(M1.4 \times 2.5)$  ②
- 3) Remove the claw of the guide rail T2 ③ from the hole on the drum base assembly in the direction of the arrow ⑤.
- Remove the six solderings 4.
- 5) Remove the FP-228 flexible wiring board (2P) (DEW sensor) (5).
- 6) Remove the two screws (camera pan2 main M1.4 × 1.6) (and the screw (SANG camera pan2 main M1.4 × 4.5) (7).
- 7) Remove the capstan motor **8**.
- 8) Remove the capstan spring (a) (be careful not to drop the capstan spring) and timing belt (b).

#### 2. Attachment procedure

- Hook the timing belt ① on the gear of the capstan motor ②, attach the capstan motor while aligning it with the reference boss of the mechanism chassis assembly.
- 2) Attach the screw (SANG camera pan2 M1.4 × 4.5) ⑦ and capstan spring ⑨. (temporally attachment)
- 3) Attach the two screws (camera pan2 M1.4 × 1.6) **(6)**. Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 4) Attach the six solderings (4) to the FP-228 flexible wiring board
   (5) (2P) (DEW sensor) and the FP-299 flexible wiring board
   (4P).
- 5) Insert the guide rail T2 ③ into the hole on the drum base assembly and tighten the screw (M1.4 × 2.5) ②.

  Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 6) Attach the capstan flexible board and the flexible wiring board (FP-300) ① to the holders ②, ③ and ②.
- 7) Adjust the height of the capstan motor using the thickness gauge (Ref. No. J-16). (Refer to 5-3.)

**Note:** Be careful not to touch the center of the capstan motor <sup>(1)</sup> shaft and the FP-228 flexible wiring board (DEW sensor) with soldering iron or other tool.




Fig. 4-4.

#### 4-5. Blind Plate, Lock Guide

#### 1. Removal procedure

- 1) Remove the diode D001 (tape LED) ① from the notch of the plate ④.
- 2) Remove the flexible wiring board ② (FP-301) from T-shaped portion of the blind plate ④ in the direction of the arrow ④.
- 3) Remove the screw (camera pan2 main  $M1.4 \times 1.6$ ) ③.
- 4) Release the hook on the notches (©), (E) and (F) of the blind plate (4) in the direction of the arrow (B).
- 5) Remove the reel release lever (5) in the direction of the arrow (6)

- 1) Attach the reel release lever **(5)** to the blind plate **(4)**.
- 2) Hang the notches (a), (b), (c) and (c) of the blind plate (4) on the hook.
- 3) Attach the screw (camera pan2 main M1.4  $\times$  1.6) ③. Tightening torque:  $0.078 \pm 0.01 \text{ N} \cdot \text{m}$  ( $0.8 \pm 0.1 \text{ kgf} \cdot \text{cm}$ )
- 4) Attach the flexible wiring board (FP-301) ② to the T-shaped portion of the blind plate ④.
- 5) Attach the diode (tape LED) ① to the notch of the blind plate ④.




Fig. 4-5.

#### 4-6. Reel Table (T) Assembly, T Soft Assembly

#### 1. Removal procedure

- 1) Remove the blind plate. (Refer to 4-5.)
- Open the claw of the reel table T assembly ① in the directions
  of the arrows 

   and ② and remove the reel table T assembly.
- Remove the T soft assembly ② in the direction of the arrow
   A).
- 4) Remove the T ratchet spring ③.
- 5) Remove the T ratchet arm 4 in the direction of the arrow **①**.

- Insert the T ratchet arm 4 into the groove on the LS chassis block assembly to attach it.
- Attach the T ratchet spring 3 to the notch of the T ratchet arm
   and LS chassis block assembly.
- 3) Insert the T soft assembly into the groove on the LS chassis block assembly.
- Check the location of the reel table T assembly and attach the LS chassis block assembly to the shaft.
- 5) Attach the blind plate. (Refer to 4-5.)




Fig. 4-6.

#### 4-7. S Ratchet RE Plate, Cassette Guide S

#### 1. Removal procedure

- 1) Remove the blind plate. (Refer to 4-5.)
- Remove the RE return plate spring ①.
- Remove the S ratchet spring ②.
- Remove the S ratchet arm 3 in the direction of the arrow A.
   Note: Do not reuse the S ratchet arm.
- 5) Remove the S ratchet RE plate.
- 6) Remove the screw (camera tapping M1.4  $\times$  2) (5).
- 7) Remove the cassette guide S (6) in the direction of the arrow (8)

- 1) Attach the cassette guide S 6 to the notch of the LS chassis block assembly with the screw (camera tapping M1.4  $\times$  2).
- Attach the S ratchet RE plate 4 to the shaft of the LS chassis block assembly.
- Attach the S ratchet arm 3 to the shaft of the LS chassis block assembly. At this time, the dowel of the S ratchet RE plate 4 must be inserted into the U-shaped notch of the S ratchet arm
   3
- 4) Hook the S ratchet spring ② on the notch of the S ratchet arm and attach it to the notch of the LS chassis block assembly.
- Attach the RE return plate spring ① to the notch of the LS chassis block assembly.
- 6) Attach the blind plate. (Refer to 4-5.)




Fig. 4-7.

#### 4-8. R Drive Gear Assembly, LS Cam Plate

#### 1. Removal procedure

- 1) Remove the blind plate. (Refer to 4-5.)
- 2) Remove the lumiler cut washer  $(0.98 \times 3 \times 0.13)$  ①.
- 3) Remove the R drive gear assembly ②.
- 4) Remove the HLC cut  $(1.8 \times 4 \times 0.5)$  ③ and the two screws (precision type3 +P1.7 × 1.8) ④.
- 5) Remove the LS cam plate **⑤**.

- 1) Attach the R drive gear assembly ② with the lumiler cut washer  $(0.98 \times 3 \times 0.13)$  ①.
- 2) Align the LS cam plate 5 with the two dowels of the LS chassis block assembly, temporarily fix the LS cam plate 5 with the two screws (precision type3 +P1.7 × 1.8), then attach it with the HLC cut  $(1.8 \times 4 \times 0.5)$  3.
- 3) Adjust the position of the LS cam plate. (Refer to 4-9.)




Fig. 4-8.

#### 4-9. LS Cam Plate Position Adjustment

#### 1. Adjustment Procedure

- Perform loading of the LS chassis block assembly ① until the tip of the guide base (S) assembly reaches the drum base assembly.
- Loosen the two screws (precision type3 +P1.7 × 1.8) ② of the LS cam plate and slide the LS chassis block assembly to the drum side so as to remove play.
- 3) Insert the thickness gauge 0.6 mm (Ref. No. J-16) between the LS cam plate and the LS chassis block assembly. Push the LS cam plate in the direction opposite to the drum to remove play.
- 4) Fix the two screws (precision type3 +P1.7 × 1.8) ②. Tightening torque: 0.108 ± 0.01 N•m (1.1 kgf•cm)




Fig. 4-9.

#### 4-10.LS Chassis Block Assembly

#### 1. Removal procedure

- Move the LS chassis block assembly between USE and LOAD.
- 2) Remove the blind plate. (Refer to 4-5.)
- 3) Remove the R drive gear assembly. (Refer to 4-8.)
- 4) Remove the HCL cut  $(1.8 \times 4 \times 0.5)$  ①
- 5) Remove the three screws  $(M1.4 \times 2.5)$  ②
- Remove the LS chassis block assembly ③ in the direction of the arrow A.

#### 2. Attachment procedure

- Insert the LS guide roller and LS guide T2 pin of the mechanical chassis block assembly into the slot of the LS chassis block assembly .
- 2) Insert the pin of the LS arm assembly into the cam groove on the LS cam plate, face the TG7 drive pin ⑤ in the direction of the arrow ⑥, and insert it to the two slot of the mechanical chassis. Then, tighten the three screws (M1.4 × 2.5) ② in the order of ⑥, ⑥ and ⑥.
  - Tightening torque:  $0.078 \pm 0.01 \text{ N} \cdot \text{m} (0.8 \pm 0.1 \text{ kgf} \cdot \text{cm})$
- 3) Attach the HCL cut  $(1.8 \times 4 \times 0.5)$  ① to the pin of the LS arm assembly.
- 4) Attach the R drive gear assembly. (Refer to 4-8.)
- 5) Attach the blind plate. (Refer to 4-5.)
- 6) Clean the tape running path. (Refer to 2-2.)

Note: Each arm must move smoothly.




Fig. 4-10.

#### 4-11. TG7 Arm Block Assembly, Pinch Arm Assembly

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- 2) Remove the screw (camera pan2 M1.4  $\times$  1.6) ①.
- 3) Remove the TG7 retainer ② in the direction of the arrow.
- 4) Remove the TG7 arm block assembly **(6)** and TG7 arm spring **(7)**.
- 5) Remove the pinch roller arm assembly ③.
- 6) Remove the P lim arm roller **4** and pinch arm load spring **5**.

- Attach the P lim arm roller (4) to the pinch roller arm assembly
   (3).
- 2) Insert one end of the pinch arm load spring ⑤ into the hole on the rising metal sheet of the LS chassis block assembly, and hook the other end of the spring on the position setting protrusion of the LS-057 board.
- Attach the pinch roller arm assembly ③ to the shaft of the LS chassis block assembly, and hook the pinch arm load spring ⑤ on the rising metal sheet of the pinch roller assembly ③.
- 4) Hook the TG7 arm spring ① on the shaft of the LS chassis block assembly while the hook side of the spring is facing downward.
- 5) When attaching the TG7 arm block assembly **(®)** to the shaft of the LS chassis block assembly, hook the hook side of the TG7 arm spring **(ூ)** on the rising metal sheet of the LS chassis block assembly and hook the top side of the spring to the notch of the TG7 arm block assembly **(®)**.
- 6) Attach the TG7 retainer ② with the screw (camera pan2 M1.4 × 1.6) ①.
- Remove the LS chassis block assembly. (Refer to 4-10.)
   Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 8) Clean the tape running path. (Refer to 2-2.)




Fig. 4-11.

#### 4-12. Guide Base (T) Block Assembly, Guide Base (S) Block Assembly

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- Align the claw of the guide base (T) block assembly ① with the notch of the guide arm T and remove the guide base (T) block assembly.
- 3) Remove the screw  $(M1.4 \times 2.5)$  ② and remove the guide rail (T) ③.
- 4) Align the claw of the guide base (S) block assembly (4) with the notch of the guide arm S and remove the guide base (S) block assembly.
- 5) Remove the screw (M1.4 × 2.5) (§) and remove the guide rail (S) (§).

#### 2. Attachment procedure

- 1) Align the holes on the guide rail (S) (a) with the protrusions (at two locations) of the LS chassis block assembly and attach the guide rail (S) (a) with the screw (M1.4 × 2.5) (a).

  Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 2) Attach the guide base (S) block assembly **(4)** while aligning it with the groove on the guide arm S.
- 3) Align the holes on the guide rail (T) ③ with the protrusions (at two locations) of the LS chassis block assembly and attach the guide rail (T) ③ with the screw (M1.4 × 2.5) ②.

  Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 4) Attach the guide base (T) block assembly ① while aligning it with the groove on the guide arm T.

**Note:** Do not forget to hook the plate spring.

- 5) Withdraw the joint portion of the guide arm S and the guide arm T in the directions of the arrows (a) and (b).
- Attach the LS chassis block assembly to the mechanical chassis.
   (Refer to 4-10.)
- 7) Clean the tape running path. (Refer to 2-2.)

Note: Be careful of the shape of the guide base T/S block assembly.

Guide base (T) block assembly = Guide base (small)

Guide base (S) block assembly = Guide base (large)




Fig. 4-12.

#### 4-13. TG1 Arm, Reel Table (S) Assembly, Push Switch (3Key)

#### 1. Removal procedure

- Remove the TG1 arm spring ①.
   Note: Take note of the position where the spring has been hooked.
- Remove the TG1 arm ②.
- Open the claw of the reel table (S) assembly (4) in the directions of the arrows (B) and (C) and remove the reel table S assembly.
- 4) Remove the RVS arm spring **⑤**.
- 5) Rotate the S ratchet arm ③ in the direction of the arrow ⓐ and remove the BT band assembly ⑥.
- Remove the lock guide ⑦.
- 7) Remove the four solderings of the LS-057 board.
- 8) Remove the two claws (9) of the cassette guide T (12) from the notch of the LS chassis.
- 9) Remove the push switch (3key) ① by releasing the two claws of the cassette guide T ②.

#### 2. Attachment procedure

- 1) Attach the push switch (3key) ① to the cassette guide T ② with the two claws ①.
- Attach the cassette guide T <sup>(1)</sup> to the notch of the LS chassis block assembly with the two claws <sup>(3)</sup>.
- 3) Solder the cassette guide T ② to the LS-057 board at the four locations.
- 4) Attach the lock guide ⑦.
- 5) Attach the BT band assembly **6**.
- 6) Check the location of the reel table S ④. Then, rotate the S ratchet arm ③ in the direction of the arrow ④ and insert the band of the BT band assembly ⑥ into the groove on the side.
- 7) Attach the BT band assembly to the TG1 arm ② and attach it to the mechanism chassis block assembly.
- 8) Check the shape of the hook of the TG1 arm spring ①. Hook one end of the spring on the TG1 arm ②. Then, hook the other end of the spring on the same location of the LS chassis block assembly where you have taken note when the spring is removed.
- 9) Attach the RVS arm spring.
- 10) Check the TG1 back-tension. (Refer to 5-1.)

**Note:** The BT band assembly **(5)** must be completely inserted into the groove on the side of the reel table (S) **(4)**.




Fig. 4-13.

# 4-14. Hall Element (H001, H002 (T/S Reel)), Photo Transistor (Q001, Q002 (Tape Top/Tape End), D001 (Tape LED)), LED (D001 (Tape LED))

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- 2) Remove the LS grease cover.
- 3) Remove the two solderings and remove Q001 (tape top).
- 4) Remove the two solderings and remove Q002 (tape end).
- 5) Remove the two solderings and remove D001 (tape LED).
- Remove the four solderings respectively from H001 (T reel) and H002 (S reel) and remove the H001 and H002.

#### 2. Attachment procedure

- Solder H001 (T reel) and H002 (S reel) respectively at the four locations.
- 2) Solder Q002 (tape end) at the two locations.
- 3) Solder Q001 (tape top) at the two locations.
- 4) Solder D001 (tape LED) at the two locations.
- 5) Attach the LS grease cover.
- Attach the LS chassis block assembly to the mechanical chassis.
   (Refer to 4-10.)

**Note:** Be careful of the plarities of the Hall element (H001, H002), Phototransistor (Q001, Q002) and LED (D001).




Fig. 4-14.

### 4-15. LS Guide Roller, Guide Lock Plate (T), Pinch Pusher Assembly, Eject Arm

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- 2) Remove the LS guide roller ①.
- Remove the P pressure plate spring ②.
- 4) Remove the HLW cut  $(0.98 \times 3 \times 0.25)$  3
- 5) Remove the pitch pressure plate assembly **4** in the direction of the arrow **A**.
- 6) Remove the relay gear **5**.
- 7) Remove the screw (camera pan  $2M1.4 \times 1.6$ ) **6**.
- Remove the guide lock plate (T) (2) in the direction of the arrow
   (B).
- Remove the eject arm spring (3) and HLW cut (0.98 × 3 × 0.25) (9).

**Note:** Do not reuse the HLW cut.

10) Remove the eject arm ①.

- 1) Attach the eject arm spring (8) to the eject arm (10).
- Hook one end of the eject arm spring ® on the protrusion of the main chassis block assembly and attach the eject arm to the shaft.
- 3) Attach the HLW cut  $(0.98 \times 3 \times 0.25)$  **9**. Do not reuse the HLW cut.
- Attach the guide lock plate T ⑦ while aligning it with the notches ⑥ and ⑥.
- 5) Attach the screw (camera pan2 M1.4 × 1.6) **(6)**. Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- 6) Attach the relay gear **⑤**.
- 7) Attach the pinch pusher plate 4 with the HLW cut  $(0.98 \times 3 \times 0.25)$  3.
- 8) Attach the P pressure plate spring ②.

  Insert the concave side of the LS guide roller ① into the shaft to attach the LS guide roller.

  Note: Insert the roller completely.
- Attach the LS chassis block assembly to the mechanical chassis. (Refer to 4-10.)




Fig. 4-15.

#### 4-16. Rotary Switch, Cam Relay Gear, Change Gear Assembly, Timing Belt

Before replacing the timing belt, remove the guide rail T2 and capstan motor. (Refer to 4-4.)

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- Remove the guide lock plate (T), pinch pressure assembly and eject arm. (Refer to 4-15.)
- 3) Remove the cam relay gear ①.
- 4) Remove the timing belt ②.
- 5) Remove the HLW cut  $(0.98 \times 3 \times 0.25)$  ③ and change gear assembly ④.
- 6) Remove the four solderings (and remove the FP-299 flexible wiring board (b).
- 7) Push up the dowel of the rotary switch from the bottom of the mechanism chassis assembly and remove the rotary switch in the direction of the arrow.

- Insert the dowel of the rotary switch ① into the hole on the mechanism chassis assembly and attach the rotary switch clockwise.
- 2) Align the FP-299 flexible wiring board (a) with the reference hole on the mechanism chassis and solder the flexible wiring board to the rotary switch (a) (at four locations).
- 3) Attach the change gear assembly 4 with the HLC cut  $(0.98 \times 3 \times 0.25)\textcircled{3}$ .
- 4) Attach the timing belt ②.
  - **Note:** There must be a clearance between the rotary switch ⑦ and timing belt ②.
- 5) Attach the cam relay gear ①.
  - The in-phase markings of the rotary switch ⑦, cam relay gear (2) and cam relay gear (1) must be aligned.
- 6) Attach the guide lock plate (T), pinch pressure assembly and eject arm. (Refer to 4-15.)
- Attach the LS chassis block assembly to the mechanical chassis. (Refer to 4-10.)
- 8) Clean the shaft of the capstan motor. (Refer to 2-2.)




Fig. 4-16.

# 4-17. Guide Gear Assembly, Guide Gear T Assembly, Cam Relay Gear 1, Guide Lock Plate (S)

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- 2) Remove the screw (camera pan2 main M1.4  $\times$  1.6) ①.
- 3) Remove the guide lock plate (S) ② in the direction of the arrow (A).
- 4) Remove the two stop rings (E type 1.2) 3.
- 5) Remove the guide gear (S) assembly **(4)** and guide gear (T) assembly **(5)**.
- 6) Remove the HLW cut  $(0.98 \times 3 \times 0.25)$  **6**.
- 7) Remove the cam relay gear (1) ⑦.

#### 2. Attachment procedure

1) Attach the cam relay gear (1) 7 with the HLW cut (0.98 × 3 × 0.25) 6.

**Note:** The in-phase markings of the cam relay gear (1) ⑦, cam gear (2) and cam relay gear must be aligned.

2) Attach the guide gear (T) assembly (§) and guide gear (S) assembly (§) to the shaft in this order and adjust the positions. Then, attach them with the two stop rings (E type 1.2) (§).

**Note1:** The in-phase markings of the GL arm assembly, guide gear (S) (4) and guide gear (T) (5) must be aligned.

**Note2:** The guide gear assembly (S/T) has a different shape respectively. Pay attention to the shapes.

- 3) Fit the guide lock plate (S) ② in the groove on the shaft and insert the portion ③ into the notch. Then, attach the plate with the screw (camera pan2 main M1.4 × 1.6) ①.

  Tightening torque: 0.078 ± 0.01 N•m (0.8 ± 0.1 kgf•cm)
- Attach the LS chassis block assembly to the mechanical chassis. (Refer to 4-10.)




Fig. 4-17.

#### 4-18. LD Gear 4, Cam Gear 1, HC Drive Arm

Remove in advance the HCL arm assembly and loading motor assembly beforehand. (Refer to 4-2.)

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- 2) Remove the guide lock plate (S). (Refer to 4-17.)
- 3) Remove the cover sheet ① and LD gear (4) ②.
- 4) Remove the T1 limiter arm 3 and cam gear (1) 4.
- 5) Remove the HC drive arm (5) in the direction of the arrow.

#### 2. Attachment procedure

Attach the cam gear (1) 4.

- 1) Attach the HC drive arm **5** under the drive base assembly.
- The dowel of the HC drive arm (§) must be inserted into the groove on the lower side of the cam gear (1) (4).

  The in-phase markings of the cam gear (1) (4), cam gear (2)
  - and cam relay gear (1) must be aligned.
    Attach the LD gear (4) ② with the cover sheet ①.
- 4) Attach the guide plate (S).
- Attach the LS chassis block assembly to the mechanical chassis. (Refer to 4-10.)
- 6) Clean the tape running path. (Refer to 2-2.)




Fig. 4-18.

#### 4-19. M Slide Plate Assembly, LS Arm Assembly, Cam Gear 2, GL Arm Assembly

#### 1. Removal procedure

- 1) Remove the LS chassis block assembly. (Refer to 4-10.)
- 2) Remove the guide lock plate (S) (Refer to 4-17.)
- 3) Remove the relay gear ①.
- Remove the M slide plate assembly ② in the direction of the arrow ⑥.
- 5) Remove the LS arm assembly 3 and LS arm roller 4.
- 6) Remove the cam gear (2) **⑤**.
- 7) Remove the GL arm assembly **(6)** from the lower side of the cam relay gear (1) in the direction of the arrow **(B)**.

**Note:** After removing the GL arm assembly, fix the guide gear (S/T) assembly.

#### 2. Attachment procedure

1) Attach the GL arm assembly **(6)** to the shaft so that the GL arm assembly **(6)** is positioned under the cam relay gear (1).

**Note:** The in-phase markings of the guide gear (S/T) assembly and GL arm assembly 6 must be aligned.

2) While aligning the cam gear (2) (3) with the dowel of the GL arm assembly, attach the cam gear (2) (3).

**Note:** The in-phase markings of the cam relay gear (1), cam gear (1) and cam gear (2) ⑤ must be aligned.

- 3) Attach the LS arm roller (4) to the LS arm assembly (3). While aligning them with the cam groove on the cam gear (2) (5), attach them.
- 4) Attach the M slide plate assembly ②.
- 5) Attach the relay gear ①.
- 6) Attach the guide lock plate (S). (Refer to 4-17.)
- Attach the LS chassis block assembly to the mechaical chassis. (Refer to 4-10.)

Note: Check that the in-phase marking of each gear is aligned.




Fig. 4-19.

### 5. Adjustment

# 5-1. Check and Adjustment of TG1 Back-tension Position

#### 1. Check Procedure

- 1) Assemble the mechanism deck into the main unit.
- Thread a normal tape and let the machine enter the PB (or REC) mode.
- 3) Check that the distance between the upper flange of the TG1 guide and the side surface of the LS chassis block is  $12.0 \pm 0.4$  mm (range of fluctuation: 0.5 mm or less).




Fig. 5-1.

#### 2. Adjustment Procedure

- 1) Remove the cassette compartment and the blind plate.
- 2) Adjust the position of the TG1 guide by changing the tilt of the rising metal sheet of the LS chassis block assembly.

#### 5-2. Check and Adjustment of FWD/RVS Back-tension

#### 1. Check Procedure

 Install the mechanism deck in the main unit and set the take-up torque cassette (Ref. No. J-7).

2) Check the FWD/RVS take-up torque. Check the FWD torque in the PLAY state. Specified value: 7 to 12 gf•cm Check the RVS torque in the RVS state. Specified value: 19.5 to 29.5 gf•cm

#### 2. Adjustment Procedure

1) If the value of the FWD torque is larger than the specifications, change the position where the TG1 arm spring is hooked in the direction of the arrow **(A)**. If the value of the FWD torque is smaller than the specifications, change the position in the direction of the arrow **(B)**.




Fig. 5-2.

### 5-3. Capstan Motor Azimuth Position Adjustment

#### 1. Check Procedure

1) Insert the thickness gauge (Ref. No. J-16) of 0.75 mm between the protrusion of the mechanism chassis and the capstan motor, and check the azimuth position.

#### 2. Adjustment Procedure

- 1) Loosen the capstan azimuth adjustment screw (SANG camera pan 2 M1.4  $\times$  4.5), and insert the thickness gauge (0.75 mm)(Ref. No. J-16) between the protrusion of the mechanism chassis and the capstan motor.
- Slowly tighten the capstan azimuth adjustment screw until it slightly contacts the thickness gauge, and remove the thickness gauge.




Fig. 5-3.

#### 5-4. Tape Path Adjustment

**Purpose:** Adjust the linearity of the head.

#### If the adjustment is not correct:

Noise appears on the top and bottom of the screen when playing back the tape that is recorded by other recorders.

#### 5-4-1. Adjustment Preparation

- Clean the tape running surface (tape guides, drum, capstan shaft, pinch roller).
- Connect the adjustment remote commander to the remote terminal.
- Set the adjustment remote commander to the PATH mode (track shift mode)\* and release the auto tracking.
- 4) Connect an oscilloscope as follows:
  - CH1: Test connector' PB RF terminal
  - External trigger: Test connector' RF SWP terminal
- Playback the tracking alignment tape WR5-1NP (NTSC), WR5-1CP (PAL) (Ref. No. J-6).
- Confirm that the RF waveform on scope is flat both at entrance side and exit side.
  - If the RF waveform is not flat, perform the adjustment by referring to section 4-2.)
- After the adjustment is completed, release the PATH mode (track shift mode)\*.




Fig. 5-4.




Fig. 5-5.

#### \* Setting and releasing the track shift mode

In case of the DCR-TRV230

#### **Setting**

- 1. Select page: 0, address: 01 and set data: 01.
- 2. Select page: F, address: 22 and set data: 88, and press the PAUSE button
- 3. Select page: 2, address: 2E and set data: 02. (Note)

#### Releasing

- 1. Select page: 0, address: 01 and set data: 01.
- 2. Select page: F, address: 22 and set data: 80, and press the PAUSE button
- 3. Select page: 2, address: 2E and set data: 00.
- 4. Select page: 0, address: 01 and set data: 00. (Note)

Note: In case of the Digital8 only, set the data of page: 2, address: 2E.

#### 5-4-2. Tracking Adjustment (Refer to Fig. 5-6.)

- Playback the tracking alignment tape WR5-1NP (NTSC), WR5-1CP (PAL) (Ref. No. J-6).
- Adjust the No.3 guide until the envelope at the entrance side waveform becomes flat.
- Adjust the No.6 guide until the envelope at the exit side waveform becomes flat.
- $\rightleftharpoons$  The TG-3/6 zenith adjustment screws do not need to be adjusted.




Fig. 5-6.

# 5-4-3. No.7 Guide (TG7) Adjustment (Refer to Fig. 5-7.)

- 1) Playback the tape and set the REV mode.
- 2) Confirm that tape slack does not occur in between the No.6 guide (TG6) ① and capstan ②. If any tape slack occurs, rotate the TG7 nut ④ of the No.7 guide (TG7) ③ to remove the tape slack
- 3) Playback the tape again and confirm that tape slack does not occur between the capstan ② and No.7 guide (TG7) ③. If the tape slack occurs exceeding the specifications (specifications: 0.5 mm or less), rotate the TG7 nut ④ to make the tape slack below the specifications (0.5 mm). When the tape slack between the No.6 guide (TG6) ① and capstan ② is 0.3 mm or less in the REV mode, it means that the adjustment is completed.




Fig. 5-7.

# 5-4-4. CUE and REV Waveform Check (Refer to Fig. 5-8)

- Playback the tracking alignment tape WR5-1NP (NTSC), WR5-1CP (PAL)(Ref. No. J-6) and enter the REV mode.
   Confirm on an oscilloscope that the pitches between the peaks of the RF waveform are equally spaced for 5 seconds or more.
   If pitches between peaks of the RF waveform are not equal, perform sections "5-4-2 Tracking Adjustment" and "5-4-3 No. 7 Guide (TG7) Adjustment".
- 2) Enter the UCE mode. Confirm on an oscilloscope that the pitches between the peaks of the RF waveform are equally spaced for 5 seconds or more. If pitches between peaks of the RF waveform are not equal, perform section "5-4-2 Tracking Adjustment".




Fig. 5-8.

#### 5-4-5. Check upon Completion of Adjustment

#### 5-4-5-1. Tracking Check

- Playback the tracking alignment tape in the PATH mode. Compare the amplitude of the RF waveform in the AUTO tracking mode and with that in the PATH mode. Confirm that the amplitude of the RF waveform decreases to about 3/4 when the tracking alignment tape is switched from the AUTO tracking mode to the PATH mode. (Refer to Fig. 5-9)
- 2) During step 1, confirm that the minimum amplitude (E  $_{MN}$ ) is 65% or more of the maximum amplitude (E  $_{MAX}$ ) of the RF waveform. (Refer to Fig. 5-10)
- 3) Confirm that the RF waveform does not fluctuate too excessively.(Refer to Fig. 5-11)




Fig. 5-9.




Fig. 5-10.




Fig. 5-11.

#### 5-4-5-2. Rise-up Check (Refer to Fig. 5-12)

- 1) Playback the tracking alignment tape WR5-1NP (NTSC), WR5-1CP (PAL)(Ref. No. J-6).
- 2) Turn OFF the Track Shift mode.
- Eject the cassette tape once. Then insert the cassette tape for loading again.
- 4) Confirm that the RF waveform rises up to the flat envelope within 3 seconds after the machine enters the PLAY mode. Check also that the tape slack does not occur at around the pinch roller.
- 5) Run the tape in the CUE/REV and the FF/REW mode. Then playback the tracking alignment tape and confirm the RF waveform rises up to the flat envelope within 3 seconds after the machine enters the PLAY mode. Check also that the tape slack does not occur at around the pinch roller.
- 6) Repeat the above steps 3) to 5) once again for re-check.




Fig. 5-12.

#### 5-4-5-3. Tape Run Check (Refer to Fig. 5-13)

- 1) Playback the thin video tape such as P6-120MP (NTSC), P6-90MP (PAL). Confirm that tape does not float and the major tape curl of more than 0.3 mm does not occur at the top flange of the No. 3 guide (TG3), at the top flange of the No. 6 guide (TG6) and at both the top and bottom flanges of the No. 7 guide (TG7).
- 2) Confirm that tape does not float and the major tape curl of more than 0.3 mm does not occur at the flanges of the respective guide when the FF button is pressed during PLAY mode to enter the CUE mode and when the REW button is pressed during PLAY mode to enter the REV mode.





Fig. 5-13.


# 6. Exploded Views

# 6-1. Cassette Compartment Assy, Drum Assy




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
701 702 703 704 705	3-065-895-01 3-065-896-01 X-3951-298-1	PAN (2 MAIN M1.4X1.6), CAMERA LEVER, REEL RELEASE PLATE, BLIND CASSETTE COMPARTMENT ASSY DAMPER ASSY		707 708 709 710 M901	3-065-935-01 3-947-503-01	CUT (0.98X3X0.13), LUMILER (W) HLC CUT (1.8X4X0.5) SCREW (M1.4) SCREW ASSY, DRUM FITTING DRUM	
706	X-3951-297-1	GEAR ASSY, R DRIVE					

### 6-2. LS Chassis Block Assembly




Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>	Ref. No.	Part No.	<u>Description</u>	<u>Remarks</u>
751	3-065-822-01	RAIL (S), GUIDE		771	3-065-830-01	SPRING, S RATCHET	
752	3-947-503-01	SCREW (M1.4)		772	X-3951-288-1	TABLE (T) ASSY, REEL	
753	A-7096-416-A	BASE (S) BLOCK ASSY, GUIDE		773	3-065-819-01	SPRING, TG1 ARM	
754	A-7096-415-A	BASE (T) BLOCK ASSY, GUIDE		774	3-065-821-01	RAIL (T), GUIDE	
755	A-7096-426-A	CHASSIS ASSY, LS		775	X-3951-289-1	TABLE (S) ASSY, REEL	
756	3-065-802-01	SPRING, TG7 ARM		776	3-065-833-01	GUIDE, LOCK	
757	A-7096-414-A	ARM BLOCK ASSY, TG7		777	3-065-831-01	PLATE (SPR), RE RETURN	
758	3-065-801-01	RETAINER, TG7		778	X-3951-304-1		
759	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		779	3-065-835-01	GUIDE (S), CASSETTE	
760	X-3951-303-1	ARM ASSY, PINCH		780	3-065-820-01	SPRING, RVS ARM	
761	3-065-823-01	ARM, T RATCHET		781	X-3951-296-1	BAND (ASSY), BT	
762	3-065-794-01	ROAD (SPR), PINCH ARM		782	3-065-836-01	COVER, LS GREASE	
763		ROLLER, P LIM ARM		783	3-067-167-01	SCREW (M1.4X2), CAMERA TAPPING	
764	3-065-834-01	GUIDE (T), CASSETTE		D001	8-719-988-42	DIODE GL453 (TAPE LED)	
765	3-065-824-01	SPRING, T RATCHET		H001	8-719-033-37	ELEMENT, HALL HW-105C (T REEL)	
766	A-7096-417-A	SOFT ASSY, T		H002	8-719-033-37	ELEMENT, HALL HW-105C (S REEL)	
767	7-627-852-38	SCREW, PRECISION +P1.7X1.8 TYPE3	}	Q001	8-729-907-25	PHOTO TRANSISTOR PT4850F (TAPE	TOP)
768	3-065-832-01	PLATE, LS CAM		Q002	8-729-907-25	PHOTO TRANSISTOR PT4850F (TAPE	END)
769	3-065-828-01	ARM, S RATCHET		S001	1-692-614-11	SWITCH, PUSH (3 KEY) (REC PROOF	)
770	3-065-829-01	PLATE, S RATCHET (RE)					

# 6-3. Mechanical Chassis Block Assembly-1



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	Description	<u>Remarks</u>
801	A-7096-422-A	BASE ASSY, DRUM		814	3-065-881-01	SPRING, P PRESSURE PLATE	
802	3-947-503-01	SCREW (M1.4)		815	3-065-934-01	HLW CUT 0.98X3X0.25	
803	3-065-928-01	SPACER, GROUND		816	1-786-096-11	SWITCH, ROTARY	
804	3-065-927-01	GROUND, DRUM		817	3-065-898-01	SPRING, EJECT ARM	
805	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		818	3-065-870-01	ROLLER, LS GUIDE	
806	3-067-154-01	SPRING, CAPSTAN		819	A-7096-421-A	ARM ASSY, HCL	
807	3-065-931-01	RAIL (T2), GUIDE		820	3-065-918-01	GEAR (2), CAM RELAY	
808	X-3947-398-1	SCREW ASSY, M1.7 PW		821	A-7096-419-A	GEAR ASSY, CHANGE	
809	3-065-933-01	PAN (2 MAIN 1.4X4.5), CAMERA		822	3-065-902-01	BELT, TIMING	
810	1-677-049-11	FP-228 FLEXIBLE BOARD (DEW SENS	OR)	823	3-065-905-01	GEAR, RELAY	
811	1-680-434-11	FP-299 FLEXIBLE BOARD		824	3-065-882-01	ARM, EJECT	
812	3-065-877-01	PLATE (T), GUIDE LOCK		M902	8-835-701-01	MOTOR, DC SCE13A/C-NP (CAPSTAN	)
813	X-3951-301-1	PLATE ASSY, PINCH PRESSURE		M903	A-7096-420-A	MOTOR ASSY, LD (LOADING)	

# 6-4. Mechanical Chassis Block Assembly-2



Ref. No.	Part No.	Description	<u>Remarks</u>	Ref. No.	Part No.	Description	Remarks
851	3-065-920-01	ARM, HC DRIVE		860	7-624-101-04	STOP RING 1.2 (E TYPE)	
852	3-065-913-01	GEAR (4), LD		861	A-7096-412-A	GEAR (T) ASSY, GUIDE	
853	3-065-914-01	SHEET, COVER		862		PLATE ASSY, M SLIDE	
854	3-065-917-01	GEAR (1), CAM RELAY		863	X-3951-305-1	ARM ASSY, LS	
855	3-065-934-01	HLW CUT 0.98X3X0.25		864	3-065-901-01	ROLLER, LS ARM	
856	3-065-915-01	GEAR (1), CAM		865	3-065-916-01	GEAR (2), CAM	
857	3-065-878-01	PLATE (S), GUIDE LOCK		866	3-065-919-01	ARM, T1 LIMITTER	
858	3-065-932-01	PAN (2 MAIN M1.4X1.6), CAMERA		867	X-3951-308-1	ARM ASSY, GL	
859	A-7096-413-A	GEAR (S) ASSY, GUIDE		868	X-3951-300-1	CHASSIS ASSY, MECHANICAL	

# 7. Printed Wiring Boards and Schematic Diagrams

